





Large OTR Service Cranes Owner's Manual


Safety • Operation • Maintenance • Troubleshooting




Model 9000




Model 13500



Model 17000



Model 23000



Model 28000

**Notice: A copy of this manual must remain with the equipment at all times.
For a printable download copy, please visit: www.stellarindustries.com**

Stellar Industries, Inc.

190 State Street

PO Box 169

Garner, IA 50438

800-321-3741


Fax: 641-923-2811

www.stellarindustries.com

Serial Tag Location / P65 Warning

WARNING

Operating, maintaining, and servicing a Stellar product may expose you to chemicals including, but not limited to, engine exhaust, carbon monoxide, phthalates, and lead. These chemicals are known to the State of California to cause cancer and birth defects (or other reproductive harm). To keep your exposure to a minimum, be sure to avoid breathing exhaust and service your Stellar product in a well-ventilated area while wearing gloves or washing your hands frequently. For more information, go to www.P65Warnings.ca.gov/passenger-vehicle.



www.p65warnings.ca.gov

NOTICE

Cold Weather Performance

Although clear data on cold weather performance from every steel manufacturer is not available for all types and thicknesses of steel, Stellar Industries is confident that the weldments on our products will operate to 100% of their intended purpose to temperatures down to -40° F / C.

It is recommended if Stellar manufactured equipment needs to be used in temperatures below -40° F / C, the operator should pull the unit into a climate-controlled area and allow the weldments to warm up to and then maintain a temperature above this level.

Serial Tag Location





Table of Contents

Introduction	iv
Chapter 1 - Operations.....	1
Job Site Setup.....	2
Step 1: Disengage drive axle and set the parking brake.	2
Step 2: Engage the hydraulic power source.	2
Step 3: Turn on electrical power.....	3
Step 4: Position the stabilizers.....	3
Step 5: Operate the crane.....	4
Step 6: Stow the crane.....	6
Step 7: Stow the stabilizers.....	6
Step 8: Finalize Service	6
Step 9: Disengage the hydraulic power source.	6
Step 10: Leave the worksite.....	6
Radio Remote Control Functions.....	7
Safety Decals of Note	8
Chapter 2 - Maintenance.....	11
General Maintenance Guidelines.....	12
Basic Crane Maintenance Schedule*	12
Hydraulic Oil/Filter Maintenance	13
Washing the Crane	13
Paint Maintenance	13
PTO and Pump Maintenance.....	13
Rotation Gear Bearing Maintenance.....	13
Gear-Bearing Bolt Maintenance.....	14
Rotation Gear Bearing Thread Tightening Procedure.....	14
Rotation Gear Bearing Tilt Test	15
Rotation Gear Bearing Tilt Test (cont.).....	16
Torque Data Chart	17
Face Seal/O-Ring Size Chart.....	18
Lubrication Recommendations	19
TM4110 Lubrication Points	20
9000 Lubrication Points	21
TM6116 Lubrication Points.....	22
13500 Lubrication Points	23
TM7120 Lubrication Points	24
17000 Lubrication Points	25
TM12154 Lubrication Points	26
23000 Lubrication Points	27
TM16160 Lubrication Points	28
28000 Lubrication Points	29
TM20164 Lubrication Points	30
TM20164 Lubrication Points - Continued.....	31
Checking Gear Lube in Gear Box	32
Washing the Crane:	33
New Paint Care and Cleaning Procedures during Initial Ownership and Beyond	33
General Crane Washing Instructions	33
Chapter 3 - Troubleshooting.....	35
Troubleshooting	36
Troubleshooting - Continued.....	37
Manual Operation	42

Introduction

Stellar® Cranes are designed to provide safe and dependable service for a variety of operations. With proper use and maintenance, these cranes will operate at peak performance for many years.

To promote this longevity, carefully study the information contained in this manual before putting the equipment into service. Though it is not intended to be a training manual for beginners, this manual should provide solid guidelines for the safe and proper usage of the crane.

Once you feel comfortable with the material contained in this manual, strive to exercise your knowledge as you safely operate and maintain the crane. This process is vital to the proper use of the unit.

A copy of this manual is provided with every crane and can be found in the hard plastic manual case that is installed on the chassis. A copy of this manual shall remain with the crane at all times.

Throughout the manual, three signal words will be used to bring attention to important items:

NOTICE

A **NOTICE** signal word indicates a practice not related to physical injury.

⚠ WARNING

A **WARNING** signal word indicates a hazardous situation which, if not avoided, could result in death or serious injury.

⚠ DANGER

A **DANGER** signal word indicates a hazardous situation which, if not avoided, will result in death or serious injury.

Information contained within this manual does not cover all maintenance, operating, or repair instructions pertinent to all possible situations. Please be aware that some sections of this manual contain information pertaining to Stellar® manufactured cranes in general and may or may not apply to your specific model.

This manual is not binding. Stellar Industries, Inc. reserves the right to change, at any time, any or all of the items, components, and parts deemed necessary for product improvement or commercial/production purposes. This right is kept with no requirement or obligation for immediate mandatory updating of this manual.

If more information is required or technical assistance is needed, or if you feel that any part of this manual is unclear or incorrect, please contact the Stellar Customer Service Department by phone at 800-321-3741 or email at service@stellarindustries.com.

Chapter 1 - Operations

CHAPTER CONTENTS

- Job Site Setup..... 2
- Step 1: Disengage drive axle and set the parking brake. 2
- Step 2: Engage the hydraulic power source. 2
- Step 3: Turn on electrical power..... 3
- Step 4: Position the stabilizers. 3
- Step 5: Operate the crane..... 4
- Step 6: Stow the crane..... 6
- Step 7: Stow the stabilizers..... 6
- Step 8: Finalize Service 6
- Step 9: Disengage the hydraulic power source..... 6
- Step 10: Leave the worksite..... 6
- Radio Remote Control Functions..... 7
- Safety Decals of Note 8

Job Site Setup

Thoroughly plan the lift by understanding the work site area and your loads before positioning the vehicle. For a complete and detailed description of job site setup, please refer to the AEM Safety Manual (Form C-70-2). Consider the following:

- The vehicle should be positioned in an area free from bystanders and overhead obstructions. Use a signal person if necessary.
- **⚠ DANGER** Always maintain safe clearance from high voltage power lines in accordance with ANSI B30.5: 5-3.4.5 Operating Near Electric Power Lines. Death or serious injury will result from inadequate clearance if crane, load, or vehicle becomes electrically charged.
- Make certain that the vehicle is parked on stable, flat ground as close to the job as possible. The surface under the service truck must be able to support the weight of the machine and its load.
- Use wheel chocks if parking the vehicle on a slope.
- Always park the vehicle with the grade. If cross-grade parking is required, the load capacity must be decreased appropriately to mitigate tipping risk.
- Park the vehicle perpendicular and at the proper distance to the tire being serviced. The vehicle's proper distance will be determined by multiple variables and can be figured from the crane load chart, size of tire, type of service being performing, and various other factors.
- **⚠ WARNING** Never begin a lift without estimating the load weight and calculating the distance and position on the capacity chart.
- Once the vehicle is properly placed, secure the work area using safety cones.
- **⚠ WARNING** Do not operate the crane during electrical storms.
- In dusty work areas, every effort must be taken to keep dust and sand out of the moving parts of the machinery.
- In high humidity work areas, keep parts as dry as possible and well lubricated.

Step 1: Disengage drive axle and set the parking brake.

The drive axle must be disengaged and the parking brake must be set before operating any of the equipment.

Step 2: Engage the hydraulic power source.

1. Make certain that the transmission is in neutral/park.
2. Engage the hydraulic power source. If using a PTO, consult the PTO manual for specific instructions if needed. *Note: Allow the hydraulic system oil to warm before operating any of the hydraulic equipment, especially during cold weather.*

Step 3: Turn on electrical power.

Locate the desired function on the switch panel inside the cab and activate to power the equipment.

Step 4: Position the stabilizers.

Extend the stabilizers using the control levers or switches marked 'stabilizer' or 'outrigger'. These may be located at the crane operation center outside the cab of the vehicle.

1a. Models: 9000/13500 The Stabilizer/Crane switch needs to be toggled to 'Stabilizer' to operate the stabilizers.

1b. Models: 17000/23000/28000
The Remote/Manual switch needs to be toggled to 'Manual' to operate the stabilizers.

2. Locate the street side (SS) and curb side (CS) stabilizer control handles. Push the lever down to lower or extend the corresponding stabilizer leg. When the stabilizer makes solid contact with the ground, release the control lever. Note: On some models, level the crane base using the level provided.



Note: Some models may have and in/out extension levers or auxillary stabilizers.

⚠ WARNING Keep clear of stabilizer legs during operation. Moving stabilizers can cause serious crushing injuries. Make certain that all personnel are clear of the stabilizer and the ground contact point before operating.

⚠ WARNING Do not raise the rear tires of the truck off the ground with the stabilizers. Confirm that the stabilizers are positioned on stable, flat ground and that the truck is as level as possible both front to rear and side to side. Use stabilizer pads to ensure the proper distribution of weight.

Step 5: Operate the crane.

Using the Radio Remote:

To operate the crane using the radio remote control:

1. Make certain that the red e-stop button is in the up position (disengaged). On some models (17000/23000/28000), toggle the Remote/Manual switch to “Remote”. On other models (9000/13500), toggle the Crane/Stabilizer switch to “Crane” and the Crane Manual/Crane Remote switch to “Crane Remote”.
2. To start up the remote control, follow the instructions provided in the remote control manufacturer’s manual.
4. To operate the crane, activate and hold the desired paddle (See Radio Remote Control page for details). The remote control units for these models operate the crane functions proportionally by controlling the oil flow entering the control valve when a specific paddle is activated. The more you engage the paddle, the faster the crane function will operate.



Note: The Radio remote control is equipped with an emergency stop button. If you encounter a situation that you need to stop the crane functionality immediately, press down on the red Emergency Stop button.



Operating the Crane:

1. Slowly activate the main boom paddle up to unstow the crane from travel position.
2. Once the crane is unstowed, proceed with operating the proper paddles to perform the service.

Lifting the load:

Consider the following:

- When performing a lift, have the load as close to the ground as possible.
- **⚠ WARNING** Never exceed manufacturer’s capacity charts and ratings. These ratings are based on the machine’s hydraulic, mechanical, and structural design rather than stability. If there is a tire manipulator attached to your crane, use the manipulator load chart, as the weight of the unit must be taken into account.
- Center the crane directly over the load to avoid side loading.
- Make certain that the stabilizers are positioned on flat, stable ground. If the terrain is soft or

loose, stabilizer pads may be required. In icy conditions, bolts can be added to the holes in the stabilizer pads for additional traction.

- Never perform a lift that can induce a dynamic force greater than the capacity of the crane.
- It is the responsibility of the operator to know the weight of the handled load to avoid overloading the crane. Do not rely on the overload device to determine maximum rated loads. If the crane is picking more than the maximum rated load, the overload protection device may be malfunctioning. Discontinue use immediately and contact Stellar Customer Service for support.
- **⚠️ WARNING** Do not use a crane to lift personnel without factory approved lifting device.
- Do not attempt to lift fixed loads.

Moving the load:

Ensure that the load is secure and balanced before moving:

- Consult the Tire Industry Association (TIA) tire service training materials for proper tire handling.
- Be sure that the crane is level and stable before moving the load.
- Always look for any changes to the surroundings since the job site setup. Be aware of any new or missed overhead obstructions (branches, power lines, etc) and bystanders. Use a signal person if necessary.
- **⚠️ WARNING** Never operate the crane with personnel under any part the boom or load. Do not extend or rotate a load over anyone. Never allow personnel to place themselves under any part of the boom or load.
- **⚠️ WARNING** Never leave a crane load suspended or unattended.
- Do not use the boom to drag a load.
- Do not use the crane boom to push downward onto anything.
- Avoid sudden starts and stops when moving a load.

Step 6: Stow the crane.

When the job is complete, square up and center the tire manipulator over the bed. Lower the crane onto the bed with the lowest crane height possible.

Step 7: Stow the stabilizers.

Models: 9000/13500 Toggle the Stabilizer/Crane switch needs to 'Stabilizer' and stow the stabilizers.

Models: 17000/23000/28000 Toggle the Remote/Manual switch to 'Manual' and stow the stabilizers.

Step 8: Finalize Service

Finalize the service by storing the safety cones, shutting drawers and compartments, and securing the load.

Step 9: Disengage the hydraulic power source.

- Disengage the hydraulic power source.
- Turn off all switches on the control panel.
- Stow the radio remote in the cab. If your truck has a docking station, secure the remote prior to leaving the work site.

Step 10: Leave the worksite.

The parking brake must be released before moving the truck.

WARNING

Make certain that any air tanks are completely drained before moving the truck.

Radio Remote Control Functions



The tire crane is operated by a radio control system which operates an electronic valve bank. The controller (as shown above) operates the following functions:

- Main Boom Up and Down
- Outer Boom Up and Down
- Extension Boom In and Out
- Rotation Clockwise and Counter-Clockwise
- TireMan Clockwise and Counter-Clockwise
- TireMan Pad Clockwise and Counter-Clockwise
- TireMan Open and Close

- The Radio remote control is equipped with an emergency stop button. If you encounter a situation that you need to stop the crane functionality immediately, press down on the red Emergency Stop button. DO NOT use the e-stop as an on/off button, as it is intended solely for safety during emergencies.
- On units with continuous rotating pads:
If the teardrop pads become misaligned to each other, perform the following realignment procedure without any load. While holding Option 1 toggle (to disable one of the pads), operate the pad rotation function to rotate the other pad until the teardrops are aligned.
- The rechargeable battery included with this equipment is located on the underside of the remote.




Safety Decals of Note

Safety decals serve to inform the viewer of the hazard type, how to avoid the hazard, and the consequences of not avoiding the hazard.

Decals are considered safety equipment. They must be maintained, as would other safety devices. All safety instruction plates, notices, capacity charts and any other decal applied to the crane or service body must be kept legible and in good condition. Replace any decals that are missing, damaged, or illegible.

Detailed below are a number of key safety decals related to this equipment. Use the decal placement drawing in the Installation, Assembly Drawings, and Parts Manual to note the actual location of the safety decals on the equipment.

Body/Chassis



Decal Part Number: C4545

Decal Location: Four corners of the body/chassis

Hazard Type: Electrocutation Hazard

Consequences: Will result in death or serious injury.

Avoidance: Maintain safe clearance from high voltage power sources. Never approach vehicle or load if equipment is near a high voltage power source.

Stabilizers



Decal Part Number: C4795

Decal Location: Each stabilizer leg


Hazard Type: Crush Hazard

Consequences: Can result in death or serious injury.

Avoidance: Keep clear of stabilizer legs during operation.

Stabilizers


⚠ DANGER



Electrocution Hazard

Death or serious injury will result from inadequate clearance if crane, load, or vehicle becomes electrically charged.

- Maintain safe clearance from high voltage power sources.
- Never approach vehicle or load if equipment is near a high voltage power source.



Electrocution Hazard

Death or serious injury will result from touching tethered remote if crane, load, or vehicle becomes electrically charged.

- Maintain safe clearance from high voltage power sources.

⚠ WARNING




Crush Hazard

Keep clear of crane during operation. Failure to keep clear of moving crane can result in death or serious injury.



Untrained Operator Hazard

Read and understand all manuals and safety signs before operating or servicing this equipment.




Crush Hazard

Keep non-essential persons clear of crane during operation.




Misuse Hazard

Do not use one arm to sling a load.




Misuse Hazard

Do not use the unit for any jacking, pulling, or dragging involving an object or another vehicle.




Misuse Hazard

Do not drag the tire. The unit is designed to lift and position.




Misuse Hazard

Do not use one arm to break beads.




Misuse Hazard

Do not handle tires filled with ballast.



Misuse Hazard

Do not use the outer cylinder to push objects.



Misuse Hazard

Do not clamp an uninflated tire and then inflate.

54781 - Rev B

Decal Part Number: 54781
Decal Location: Each stabilizer leg
Hazard Type: Multiple
Consequences: Multiple
Avoidance: Multiple

This page intentionally left blank.

Chapter 2 - Maintenance

CHAPTER CONTENTS

General Maintenance Guidelines.....	12
Basic Crane Maintenance Schedule*.....	12
Hydraulic Oil/Filter Maintenance	13
Washing the Crane	13
Paint Maintenance	13
PTO and Pump Maintenance.....	13
Rotation Gear Bearing Maintenance.....	13
Gear-Bearing Bolt Maintenance.....	14
Rotation Gear Bearing Thread Tightening Procedure.....	14
Rotation Gear Bearing Tilt Test	15
Rotation Gear Bearing Tilt Test (cont.).....	16
Torque Data Chart.....	17
Face Seal/O-Ring Size Chart.....	18
Lubrication Recommendations.....	19
TM4110 Lubrication Points	20
9000 Lubrication Points.....	21
TM6116 Lubrication Points.....	22
13500 Lubrication Points.....	23
TM7120 Lubrication Points	24
17000 Lubrication Points	25
TM12154 Lubrication Points	26
23000 Lubrication Points	27
TM16160 Lubrication Points	28
28000 Lubrication Points	29
TM20164 Lubrication Points	30
TM20164 Lubrication Points - Continued.....	31
Checking Gear Lube in Gear Box	32
Washing the Crane:	33
New Paint Care and Cleaning Procedures during Initial Ownership and Beyond	33
General Crane Washing Instructions	33

General Maintenance Guidelines

Maintenance is an important part of extending the life of any Stellar® Crane. Performing key maintenance items on a scheduled program will prevent unnecessary downtime.

Before performing any maintenance to the crane, consider the following:

- **⚠️ WARNING** Only qualified service personnel are to perform maintenance on the crane. Never modify or alter any of the equipment, whether mechanical, electrical, or hydraulic, without explicit approval from Stellar Industries.
- Position the crane where it will be out of the way of other operations or vehicles in the area.
- Lower the boom fully to prevent uncontrolled movement.
- Place all controls in the off position and secure operating features from inadvertent motion. Follow all company directed lockout/tagout procedures.
- Before any service or repair is performed, disengage the hydraulic power source and shut off the engine.
- Allow systems to cool before performing any maintenance.
- Before performing any maintenance on electrical components, disconnect the power source.
- Before performing any maintenance on hydraulic components, relieve hydraulic oil pressure from all hydraulic circuits. Move pedals and control levers repeatedly through their operating positions to relieve all pressures.
- **⚠️ WARNING** Do not disconnect hydraulic hoses while there is still pressure in those components.
- **⚠️ WARNING** Do not touch or grab any hoses that could be under pressure.
- Replace parts with Stellar® approved parts only.
- Keep the crane and service body clean and free from grease build-up, oil and dirt to prevent slippery conditions.
- Label or tag parts when disassembling.
- Immediately repair or have repaired any components found to be inadequate.

Basic Crane Maintenance Schedule*

MAINTENANCE OPERATION	DAILY	WEEKLY	MONTHLY	HOURLY
CHECK HYDRAULIC RESERVOIR OIL LEVEL	X			
GREASE ROTATION GEAR INNER RACE BEARINGS		X		
GREASE ROTATION GEAR WORM DRIVE BEARINGS			3-MONTHS	
GREASE ROTATION GEAR OPEN GEAR TEETH.			X	
GREASE ALL CYLINDER PIVOT POINTS			X	
DRAIN AND REPLACE HYDRAULIC OIL				6500
TIGHTEN ALL HYDRAULIC LINES.			6-MONTHS	

* For a more detailed outline of scheduled inspection points, refer to the Stellar® Crane Inspection Log. The Stellar® Crane Inspection Log is an essential guide for the daily, monthly, quarterly and annual inspection tasks that will help maintain the quality of your Stellar product.

Hydraulic Oil/Filter Maintenance

Stellar Industries recommends the first filter change to occur after the first 250 hours of service. The second, and every subsequent change, should occur after every 1,000 hours of service. By following these guidelines, the hydraulic oil should last up to 6,500 hours.

Note: These recommendations are based on normal working parameters. If operating in less than favorable conditions (excessive dust, moisture, etc.), be sure to check the filter gauge often for filter change notice.

Washing the Crane

Important: Prior to washing the Stellar crane, all electrical components must be covered to prevent any water from being injected into the plastic housing. Avoid any direct water pressure to any of the electrical components.

Paint Maintenance

Touch up any chips or scratches to prevent further paint damage.

PTO and Pump Maintenance

Every six (6) months, remove the hydraulic pump from the PTO and lubricate the splines using Stellar PN 20885. Failure to lubricate shaft splines will cause damage to the PTO and Hydraulic pump.

Rotation Gear Bearing Maintenance

Rotation Worm Gear and Open Gear Teeth

Use a heavy Moly Lube grease (Stellar PN 4460) to lubricate the worm gear and open gear teeth of the rotation bearing. Slowly rotate the crane while pumping the grease between the worm and rotation gear. This should be greased every month or sooner depending on the usage of the crane. Another way of applying the grease would be to remove the gear guard and brush the Molube grease between the gear teeth of the rotation bearing.

NOTICE

Do not lubricate the worm and rotation gear teeth with EP2 grease. EP2 grease will wipe the Molube grease clean causing excessive wear.

Worm Gear Bearings and Races

Apply three (3) pumps of EP2 grease to the two grease zerks located on the side of the Rotation Gear bearing; every three months. After adding the EP2 grease, rotate the crane fully.

Inner Gear Bearing Race

The grease zerk for the inner race bearing is located on the compartment drip tray. The inner race will need to be lubricated with EP2 Grease weekly. The first week grease the inner race bearing at the one (1), three (3), five (5), seven (7), nine (9), and eleven (11) o'clock positions. The following week, grease the inner race bearing in the two (2), four (4), six (6), eight (8), ten (10) and twelve (12) o'clock positions. Rotate lubrication points every week.


Gear-Bearing Bolt Maintenance

Once a bolt has been torqued to 75% of its proof load and then removed, the torque coefficient may no longer be the same as when the bolt was new thus giving indeterminate clamp loads after torquing.

⚠ WARNING Anytime a torqued gear-bearing bolt is removed, it must be replaced with a new bolt of the identical grade and size.

NOTICE Always use Red Loctite Threadlocker sealant to secure the new bolt.

Rotation Gear Bearing Thread Tightening Procedure




Step 1: Refer to the Torque Data Chart on the previous page to determine the proper torque value based on the size of bolt used.

Step 2: Torque all bolts to approximately 40% of the specified torque value using the tightening sequence shown above. Note: The number of bolts may be different than shown in the diagram but the sequence will work using the same pattern in relation to Bolt #1.

Step 3: Torque all bolts to 75% of the specified torque value using the tightening sequence shown above.


Step 4: Torque all bolts to the listed torque value using the tightening sequence shown above.

Rotation Gear Bearing Tilt Test






1. Extend booms and tire manipulator above a suitable rest as shown.
2. Place a dial indicator to measure vertical movement at the back of the mast as shown.
3. Set the scale on the dial indicator to 0.

Rotation Gear Bearing Tilt Test (cont.)



4. Use the main cylinder to lower the booms and push down evenly on a suitable rest with the tire manipulator arms.
5. Check and record the dial indicator change. It should not exceed the following tilt measurements:
 - Stellar Model 9000/TM4110 = 0.060" (1.52 mm)
 - Stellar Model 13500/TM6116 - 28000/TM16160 = 0.090" (2.29 mm)
6. Return booms to a position above the rest. The dial indicator should return to calibration.

Torque Data Chart


		GRADE 5		GRADE 8		GRADE 9
						
SIZE (DIA-TPI)	BOLT DIA (INCHES)	PLAIN (FT-LB)	PLATED (FT-LB)	PLAIN (FT-LB)	PLATED (FT-LB)	PLATED (FT-LB)
5/16-18	0.3125	17	13	25	18	22
3/8-16	0.3750	31	23	44	33	39
7/16-14	0.4375	49	37	70	52	63
1/2-13	0.5000	75	57	105	80	96
9/16-12	0.5625	110	82	155	115	139
5/8-11	0.6250	150	115	220	160	192
3/4-10	0.7500	265	200	375	280	340
7/8-9	0.8750	395	295	605	455	549
1-8	1.000	590	445	910	680	823
1 1/8-7	1.1250	795	595	1290	965	1167
1 1/4-7	1.2500	1120	840	1815	1360	1646
1 3/8-6	1.3750	1470	1100	2380	1780	2158
1 1/2-6	1.500	1950	1460	3160	2370	2865

NOTE:

When using the torque data in the chart, the following rules should be observed:

- Bolt manufacturer’s particular specifications should be consulted when provided.
- Flat washers of equal strength must be used.
- All torque measurements are given in foot-pounds. To convert to inch-pounds, multiply by 12.
- Torque values specified are for bolts with residual oils or no special lubricants applied.
- Torque values for socket-head capscrews are the same as for grade 8 capscrews.
- Do not use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.
- Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.
- Fasteners should be replaced with the same or higher grade. If higher grade fasteners are used, these should only be tightened to the strength of the original.
- Tighten plastic insert or crimped steel-type lock nuts to approximately 110 percent of the dry torque values shown in the chart below, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value. **Note: “Lubricated” means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings. “Dry” means plain or zinc plated without lubrication. Tighten lubricated bolts to approximately 80% of dry bolts.**

Face Seal/O-Ring Size Chart




Hose Size	Fitting Size	Face Seal (A) Stellar® PN	O-ring Boss (B) Stellar® PN
1/4"	#4	C2027	D1245
3/8"	#6	C2028	D1246
1/2"	#8	C2029	D1247
5/8"	#10	32223	D1248
3/4"	#12	D1244	D1249
1"	#16		D1250

Lubrication Recommendations

CRANE LUBRICATION		
COMPONENT	LOCATION	RECOMMENDATION
HYDRAULIC SYSTEM	RESERVOIR	RBELOW -5°F HIGH VI, LOW POUR, ISO 22, AW HYDRAULIC OIL
		-5°F TO 90°F HIGH VI, LOW POUR, ISO 32, AW HYDRAULIC OIL
		ABOVE 90°F ISO 46, AW HYDRAULIC OIL
OPEN GEAR TEETH	CRANE ROTATION GEAR	MOLY GREASE 936SF HEAVY (STELLAR PN 4460)
WORM DRIVE BEARINGS (INCLUDING TURNTABLE BEARING INNER RACE)	CRANE ROTATION GEAR, INSIDE CRANE COMPARTMENT	EP2 LITHIUM COMPLEX GREASE (STELLAR PN 78090)
CYLINDERS	CRANE PIVOT AREAS	EP2 LITHIUM COMPLEX GREASE (STELLAR PN 78090)
CRANE PINS & BUSHINGS	CRANE PIVOT POINTS	EP2 LITHIUM COMPLEX GREASE (STELLAR PN 78090)
WEAR PAD LUBRICATION	N EXTENSION BOOMS	SYNTHETIC LUBRICANT CONTAINING TEFLON®
COMPRESSOR LUBRICATION		
COMPONENT	LOCATION	RECOMMENDATION
RECIPROCATING SINGLE STAGE	COMPRESSOR CRANKCASE	ISO 100 COMPRESSOR OIL
RECIPROCATING DOUBLE STAGE	COMPRESSOR CRANKCASE	ISO 100 COMPRESSOR OIL
SCREW COMPRESSOR	COMPRESSOR CRANKCASE	-15°F TO 86°F SYNTHETIC PERFORMING ISO 32 COMPRESSOR OIL
		-23°F TO 100°F SYNTHETIC PERFORMING ISO 46 COMPRESSOR OIL
		32°F TO 113°F SYNTHETIC PERFORMING ISO 68 COMPRESSOR OIL


TM4110 Lubrication Points



LUBRICATION POINTS

ITEM	DESCRIPTION
1	GREASE(EP2) PAD PIVOT PINS - BOTH SIDES
2	GREASE(EP2) PAD CYLINDER PINS - EACH END, BOTH SIDES
3	GREASE(EP2) LINK PIN POINTS - 8 PLACES TOTAL
4	GREASE(EP2) CLAMP CYLINDER PIN POINTS - EACH END, BOTH SIDES
5	GREASE(EP2) GEARBOX BEARING
6	GREASE(EP2) MAIN BEARING RACE
7	GREASE(EP2) BASE LINK PINS - EACH END OF LINK
8	GREASE(MOLY 936SF HEAVY) OPEN GEAR TEETH
9	MAIN ROTATION GEARBOX - CHECK OIL LEVEL (SAE 140)
REV. A REQ887 REF 134015	


9000 Lubrication Points



LUBRICATION POINTS

ITEM	DESCRIPTION
1	GREASE(EP2) ALL FITTINGS IN BANK
2	GREASE(EP2) STABILIZER PIVOT PINS - BOTH SIDES
3	GREASE(EP2) STABILIZER CYLINDER PINS - BOTH ENDS, BOTH SIDES
4	GREASE(EP2) WORM BEARINGS - FOUR PLACES TOTAL
5	GREASE(EP2) BOOM TIP PIN POINT
6	GREASE(MOLY 936SF HEAVY) WORM & GEAR TEETH (MAY BE DONE FROM ONE SIDE BY ALTERNATELY ADDING GREASE AND ROTATING)
7	GREASE (SEE LUBR. RECOMMENDATIONS) EXTENSION BOOM
REV. INITIAL RELEASE REQ887 REF134014	


TM6116 Lubrication Points



LUBRICATION POINTS

ITEM	DESCRIPTION
1	GREASE(EP2) PAD PIVOT PINS - BOTH SIDES
2	GREASE(EP2) PAD CYLINDER PINS - EACH END, BOTH SIDES
3	GREASE(EP2) LINK PIN POINTS - 8 PLACES TOTAL
4	GREASE(EP2) CLAMP CYLINDER PIN POINTS - EACH END, BOTH SIDES
5	GREASE(EP2) GEARBOX BEARING
6	GREASE(EP2) MAIN BEARING RACE
7	GREASE(EP2) BASE LINK PINS - EACH END OF LINK
8	GREASE(MOLY 936SF HEAVY) OPEN GEAR TEETH
9	MAIN ROTATION GEARBOX - CHECK OIL LEVEL (SAE 140)
REV. A REQ887 REF 99143	

13500 Lubrication Points




LUBRICATION POINTS

ITEMS	DESCRIPTION
1	GREASE(EP2) ALL FITTINGS IN BANK
2	GREASE(EP2) STABILIZER PIVOT PINS - BOTH SIDES
3	GREASE(EP2) STABILIZER CYLINDER PINS - BOTH ENDS, BOTH SIDES
4	GREASE(EP2) BOOM TIP PIN POINT
5	GREASE(MOLY 936SF HEAVY) WORM & GEAR TEETH
6	GREASE (SEE LUBR. RECOMMENDATIONS) EXTENSION BOOM

REV. D REQ887 REF 72143

TM7120 Lubrication Points

SHOWN WITH 90 DEG PAD




LUBRICATION POINTS

ITEM	DESCRIPTION
1	GREASE(EP2) WORM BEARINGS - 2 PLACES PER SIDE - BOTH SIDES
2	GREASE(EP2) PAD BEARING RACE - BOTH SIDES
3	GREASE(EP2) LINK PINS - 8 PLACES TOTAL
4	GREASE(EP2) CLAMP CYLINDER PINS - EACH END, BOTH SIDES
5	GREASE(EP2) GEARBOX BEARING
6	GREASE(EP2) MAIN BEARING RACE
7	GREASE(EP2) BASE PIN - 2 PLACES
8	GREASE(EP2) BASE LINK PINS - EACH END OF LINK
9	GREASE(MOLY 936SF HEAVY) OPEN GEAR TEETH
10	GREASE(MOLY 936SF HEAVY) WORM DRIVE TEETH - BOTH SIDES
11	MAIN ROTATION GEARBOX - CHECK OIL LEVEL (SAE 140)
12	GREASE(EP2) 90 DEG PAD PIVOT PIN - BOTH SIDES
13	GREASE(EP2) 90 DEG PAD CYLINDER PINS - EACH END, BOTH SIDES

REV. A REQ887 REF108919

17000 Lubrication Points




LUBRICATION POINTS

ITEM	DESCRIPTION
1	GREASE(EP2) ALL FITTINGS IN BANK
2	GREASE(EP2) STABILIZER PIVOT PINS - BOTH SIDES
3	GREASE(EP2) STABILIZER CYLINDER PINS - BOTH ENDS, BOTH SIDES
4	GREASE(EP2) BOOM TIP PIN POINT
5	GREASE(MOLY 936SF HEAVY) OPEN GEAR TEETH
6	GREASE (SEE LUBR. RECOMMENDATIONS) EXTENSION BOOM
7	CHECK GEARBOX OIL LEVEL(SAE80W90)
REV. D REQ887 REF 71260	

TM12154 Lubrication Points

SHOWN WITH 90 DEG PAD




LUBRICATION POINTS

ITEM	DESCRIPTION
1	GREASE(EP2) WORM BEARINGS - 2 PLACES PER SIDE - BOTH SIDES
2	GREASE(EP2) PAD BEARING RACE - BOTH SIDES
3	GREASE(EP2) LINK PIN POINTS - 8 PLACES TOTAL
4	GREASE(EP2) CLAMP CYLINDER PIN POINTS - EACH END, BOTH SIDES
5	GREASE(EP2) GEARBOX BEARING
6	GREASE(EP2) MAIN BEARING RACE
7	GREASE(EP2) BASE LINK PIN POINTS - EACH END OF LINK
8	GREASE(MOLY 936SF HEAVY) OPEN GEAR TEETH
9	GREASE(MOLY 936SF HEAVY) WORM DRIVE TEETH - BOTH SIDES
10	MAIN ROTATION GEARBOX - CHECK OIL LEVEL (SAE 140)
11	GREASE(EP2) 90 DEG PAD PIVOT PIN - BOTH SIDES
12	GREASE(EP2) 90 DEG PAD CYLINDER PINS - EACH END, BOTH SIDES

REV. INITIAL RELEASE REQ887 REF 128725

23000 Lubrication Points




LUBRICATION POINTS

ITEM	DESCRIPTION
1	GREASE(EP2) ALL FITTINGS IN BANK
2	GREASE(EP2) STABILIZER PIVOT PIN - BOTH SIDES
3	GREASE(EP2) STABILIZER CYLINDER PINS - BOTH ENDS, BOTH SIDES
4	GREASE(EP2) GEAR BEARING INNER RACE
5	GREASE(EP2) BOOM TIP PIN POINT
6	GREASE(MOLY 936SF HEAVY) OPEN GEAR TEETH
7	GREASE (SEE LUBR. RECOMMENDATIONS) EXTENSION BOOM
8	GREASE (SEE LUBR. RECOMMENDATIONS) STABILIZER EXTENSION
9	CHECK GEARBOX OIL LEVEL (SAE80W90)


REV. INITIAL RELEASE REQ887 REF 128721

TM16160 Lubrication Points



LUBRICATION POINTS	
ITEM	DESCRIPTION
1	GREASE(EP2) WORM BEARINGS - 2 PLACES PER SIDE - BOTH SIDES
2	GREASE(EP2) PAD BEARING RACE - BOTH SIDES
3	GREASE(EP2) CLAMP CYLINDER PIN POINTS - EACH END, BOTH SIDES
4	GREASE(EP2) GEARBOX BEARING
5	GREASE(EP2) MAIN BEARING RACE
6	GREASE(EP2) LINK PIN POINTS - EACH END OF LINK
7	GREASE(MOLY 936SF HEAVY) OPEN GEAR TEETH
8	GREASE(MOLY 936SF HEAVY) WORM DRIVE TEETH - BOTH SIDES
9	MAIN ROTATION GEARBOX - CHECK OIL LEVEL (SAE 140)
REV. A REQ887 REF109359	


28000 Lubrication Points



LUBRICATION POINTS

ITEM	DESCRIPTION
1	GREASE(EP2) ALL FITTINGS IN BANK
2	GREASE(EP2) STABILIZER PIVOT PIN - BOTH SIDES
3	GREASE(EP2) STABILIZER CYLINDER PINS - BOTH ENDS, BOTH SIDES
4	GREASE(EP2) GEAR BEARING INNER RACE
5	GREASE(EP2) BOOM TIP PIN POINT
6	GREASE(MOLY 936SF HEAVY) OPEN GEAR TEETH
7	GREASE (SEE LUBR. RECOMMENDATIONS) EXTENSION BOOM
8	GREASE (SEE LUBR. RECOMMENDATIONS) STABILIZER EXTENSION
9	CHECK GEARBOX OIL LEVEL (SAE80W90)
REV. INITIAL RELEASE REQ887 REF 128721	


TM20164 Lubrication Points



LUBRICATION POINTS

ITEM	DESCRIPTION
1	GREASE(EP2) ALL FITTINGS IN BANK
2	GREASE(EP2) STABILIZER PIVOT PINS - BOTH SIDES
3	GREASE(EP2) STABILIZER CYLINDER PINS - BOTH ENDS, BOTH SIDES
4	GREASE(EP2) BEARING INNER RACE - FOUR ZERKS
5	GREASE(EP2) BOOM TIP PIN POINT
6	GREASE(MOLY 936SF HEAVY) OPEN GEAR TEETH
7	GREASE (SEE LUBR. RECOMMENDATIONS) EXTENSION BOOM
8	CHECK OIL LEVEL IN BOTH GEARBOXES SAE80W90)
REV. INITIAL RELEASE REQ887 REF136850	

TM20164 Lubrication Points - Continued




LUBRICATION POINTS

ITEM	DESCRIPTION
1	GREASE(EP2) WORM BEARINGS - 2 PLACES PER SIDE - BOTH SIDES
2	GREASE(EP2) PAD BEARING RACE - BOTH SIDES
3	GREASE(EP2) LINK PINS - 16 PLACES TOTAL
4	GREASE(EP2) CLAMP CYLINDER PIN POINTS - EACH END, BOTH SIDES
5	GREASE(EP2) GEARBOX BEARING - BOTH SIDES
6	GREASE(EP2) MAIN BEARING RACE
7	GREASE(EP2) BASE PIN - BOTH SIDES
8	GREASE(EP2) BASE LINK PIN POINTS - EACH END OF LINK
9	GREASE(MOLY 936SF HEAVY) OPEN GEAR TEETH
10	GREASE(MOLY 936SF HEAVY) WORM DRIVE TEETH - BOTH SIDES
11	MAIN ROTATION GEARBOXES - CHECK OIL LEVEL (SAE 140)
REV. INITIAL RELEASE REQ887 REF 134351	

Checking Gear Lube in Gear Box

NOTE: The following instructions only apply to the 23000 and 28000 models.













1. Disengage the PTO, apply the parking brake, and turn off the ignition to the truck
2. Locate the gearbox underneath the crane base. This is done by looking up between the frame rails and through the hole in the body sub frame.



3. Find and remove the vent/fill plug. The plug is on the side of the gearbox and shown in the picture below.
4. See if any gear lube comes out of the hole.
 - a. If lube comes out, screw the plug back into the hole and tighten it to 35 ft-lbs.
 - b. If no lube comes out, fill the gearbox with 80/90-weight gear lube until you see it coming out the hole for the fill plug. Then screw the plug back into the hole and tighten it to 35 ft-lbs.
5. Clean up any excess or spilled gear lube.

Washing the Crane:

New Paint Care and Cleaning Procedures during Initial Ownership and Beyond

	0 to 30 days past manufacturing date	30 to 60 days past manufacturing date	After 60 days past manufacturing date	Any day paint surface is hot due to exposure to daylight
Water-only Rinse to Clean	<ul style="list-style-type: none"> low pressure no soap 			
Wax				
Handheld Pressure Washer			<ul style="list-style-type: none"> distance > 4 inches pressure < 1700 psi water temp < 120° F neutral pH detergent 	
Automated Wash System			<ul style="list-style-type: none"> pressure < 1700 psi water temp < 120° F neutral pH detergent non-abrassive brushes 	

General Crane Washing Instructions

Follow the parameters above while washing the crane at least once per week, especially when exposed to a dusty, acidic, or alkaline environment. This will maximize durability of the paint, wiring, and rubber material by removing corrosive substances collected from roads or job sites. When washing the crane, avoid direct water spray toward electrical components such as floodlights, radio remote receivers, the VEC center, and areas of the crane which may have rock chips. Avoid the use of stiff bristles. Use of a soft cloth or felt brush is recommended.

Although contact with anti-freeze, gasoline, hydraulic fluid, oil, or windshield washer fluid is expected with this type of equipment, washing these products from your paint surface in a timely manner will greatly enhance the life of your paint finish. Some compounds could be especially damaging to the paint finish and should be removed as soon as possible by rinsing with warm water at a minimum.

NOTICE Exposure time causing potential paint damage by hydraulic fluid and oil is reduced if the paint surface is hot.

This page left intentionally blank

Chapter 3 - Troubleshooting


CHAPTER CONTENTS

Troubleshooting.....	36
Troubleshooting - Continued	37
Manual Operation.....	42

Troubleshooting

This chapter will list a number of potential problems that may occur while operating the crane. Most problems are easily solved using the solutions portion of this chapter. If problems persist, please contact Customer Service at Stellar Industries 1-800-321-3741.

Serial Tag Location



Prior to troubleshooting:

Always make sure the parking brake is engaged and the PTO is engaged (if equipped).

To determine if there is an electrical or hydraulic problem, first try to operate the crane manually (See Manual Operation at end of this chapter). If the crane operates, there will be an electrical problem to trace. If the crane does not operate using the manual overrides, there is a problem within the hydraulic circuit.

Troubleshooting - Continued

PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
CRANE WILL NOT OPERATE	PTO IS NOT ENGAGED	ENGAGE PTO. IF PTO WON'T ENGAGE, REFER TO PTO MANUFACTURER'S MANUAL FOR DETAILS
	CRANE IS NOT RECEIVING PROPER HYDRAULIC FLOW	CHECK HYDRAULIC RESERVOIR FLUID LEVEL
		ENSURE PTO IS ENGAGED
		ENSURE PANIC BAR E-STOP IS NOT ENGAGED
		VERIFY SELECTOR SWITCH IS IN CRANE MODE AND NOT STABILIZER/OFF MODE
		ENSURE DUMP VALVE IS RECEIVING PROPER ELECTRICAL SIGNAL AND OPERATING PROPERLY
		VERIFY HYDRAULIC PUMP IS PRODUCING PROPER FLOW
		ENSURE HYDRAULIC OIL IS AT THE PROPER OPERATING TEMPERATURE
	CRANE IS NOT RECEIVING PROPER HYDRAULIC PRESSURE	CHECK HYDRAULIC RESERVOIR FLUID LEVEL
		ENSURE PTO IS ENGAGED
		ENSURE PANIC BAR E-STOP IS NOT ENGAGED
		VERIFY SELECTOR SWITCH IS IN CRANE MODE AND NOT STABILIZER/OFF MODE
		ENSURE DUMP VALVE IS RECEIVING PROPER ELECTRICAL SIGNAL AND OPERATING PROPERLY
		VERIFY HYDRAULIC PUMP IS PRODUCING PROPER PRESSURE
		CRANE DOES NOT HAVE PROPER ELECTRICAL POWER
	VERIFY GOOD GROUND	
	VERIFY GOOD POWER SUPPLY	
	VERIFY PROPER VOLTAGE	
	VERIFY ELECTRICAL WIRING/ CONNECTION INTEGRITY	

PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
CRANE WILL NOT OPERATE	CRANE DOES NOT HAVE PROPER ELECTRICAL POWER	VERIFY ENGINE SPEED CONTROL HAS BEEN ACTIVATED.
	RADIO CONTROL SYSTEM IS NOT FUNCTIONING	ENSURE MANUAL/REMOTE SWITCH IN THE 'REMOTE' POSITION
		ENSURE TRANSMITTER IS PROPERLY STARTED. REFER TO THE RADIO SYSTEM MANUFACTURER'S MANUAL FOR DETAILS
		VERIFY RECEIVER IS GETTING PROPER ELECTRICAL POWER
		ENSURE TRANSMITTER BATTERY IS CHARGED
		IF ERROR CODE IS DISPLAYED, REFER TO THE RADIO SYSTEM MANUFACTURER'S MANUAL FOR DETAILS
		ENSURE E-STOP SWITCH IS NOT ENGAGED
	MANUAL CONTROL SYSTEM IS NOT FUNCTIONING	ENSURE MANUAL/REMOTE SWITCH IN THE 'MANUAL' POSITION
		ENSURE E-STOP IS NOT ENGAGED
	CRANE OPERATES SLOWLY.	CRANE IS NOT RECEIVING PROPER HYDRAULIC FLOW
ENSURE PTO IS ENGAGED		
ENSURE PANIC BAR E-STOP IS NOT ENGAGED		
VERIFY SELECTOR SWITCH IS IN CRANE MODE AND NOT STABILIZER/OFF MODE		
ENSURE DUMP VALVE IS RECEIVING PROPER ELECTRICAL SIGNAL AND OPERATING PROPERLY		
VERIFY HYDRAULIC PUMP IS PRODUCING PROPER FLOW		
ENSURE HYDRAULIC OIL IS AT THE PROPER OPERATING TEMPERATURE		
VERIFY ENGINE SPEED CONTROL HAS BEEN ACTIVATED		
CRANE IS NOT RECEIVING PROPER HYDRAULIC PRESSURE		CHECK HYDRAULIC RESERVOIR FLUID LEVEL
		ENSURE PTO IS ENGAGED
		ENSURE PANIC BAR E-STOP IS NOT ENGAGED
		VERIFY SELECTOR SWITCH IS IN CRANE MODE AND NOT STABILIZER/OFF MODE
		ENSURE DUMP VALVE IS RECEIVING PROPER ELECTRICAL SIGNAL AND OPERATING PROPERLY
		VERIFY HYDRAULIC PUMP IS PRODUCING PROPER PRESSURE
CRANE OPERATES SLOWLY	CRANE DOES NOT HAVE PROPER ELECTRICAL POWER	CHECK FUSE AND HOLDER

PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
CRANE OPERATES SLOWLY	CRANE DOES NOT HAVE PROPER ELECTRICAL POWER	VERIFY GOOD GROUND
		VERIFY PROPER VOLTAGE
		VERIFY ELECTRICAL WIRING/ CONNECTION INTEGRITY
		ENSURE MANUAL/REMOTE SWITCH IS WORKING PROPERLY
		VERIFY ENGINE SPEED CONTROL HAS BEEN ACTIVATED
	REMOTE TRANSMITTER IS IN SNAIL MODE	SWITCH REMOTE FROM SNAIL MODE TO NORMAL MODE
CRANE WILL OPERATE MANUALLY BUT WILL NOT OPERATE ELECTRICALLY	REMOTE/MANUAL SWITCH IS IN THE 'MANUAL' POSITION	TOGGLE THE REMOTE/MANUAL SWITCH TO THE 'REMOTE' POSITION. ENSURE THE SWITCH IS WORKING PROPERLY
	RADIO RECEIVER DISPLAYING AN ERROR CODE.	REFER TO RADIO SYSTEM MANUFACTURER'S MANUAL
	TRANSMITTER IS NOT PROPERLY STARTED	START UP TRANSMITTER PROPERLY - REFER TO MFG MANUAL.
CRANE WILL OPERATE ELECTRICALLY BUT WILL NOT OPERATE MANUALLY	REMOTE/MANUAL SWITCH IS IN THE 'REMOTE' POSITION	TOGGLE THE REMOTE/MANUAL SWITCH TO THE 'MANUAL' POSITION. ENSURE THE SWITCH IS WORKING PROPERLY
NOT ALL CRANE FUNCTIONS OPERATE USING THE RADIO REMOTE TRANSMITTER OR CRANE PERATED INTERMITTENTLY	RADIO RECEIVER DISPLAYING AN ERROR CODE	REFER TO RADIO SYSTEM MANUFACTURER'S MANUAL
CYLINDER DRIFTS OUTWARD OR DOWNWARD	COUNTER BALANCE VALVES ARE NOT FUNCTIONING PROPERLY	CONTACT STELLAR CUSTOMER SERVICE FOR SUPPORT
CYLINDER DRIFTS OUTWARD OR DOWNWARD	COUNTER BALANCE VALVES ARE NOT FUNCTIONING PROPERLY	CONTACT STELLAR CUSTOMER SERVICE FOR SUPPORT
	AIR IN HYDRAULIC SYSTEM	FULLY CYCLE THE CYLINDER BOTH DIRECTIONS (BLOW PAST RELIEF) TO REMOVE AIR FROM SYSTEM
	LEAK IN HYDRAULIC SYSTEM	VISUALLY INSPECT. REPAIR/REPLACE IF NECESSARY
	DEFECTIVE CYLINDER PISTON SEALS	VISUALLY INSPECT. REPAIR/REPLACE IF NECESSARY
	EXCESSIVE LOAD INDUCED THROUGH CRANE	VERIFY CAPACITY CHART
	VALVE BANK NOT FUNCTIONING PROPERLY	VERIFY OIL QUALITY
	DAMAGED CYLINDER	VISUALLY INSPECT. REPLACE IF NECESSARY


PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
SINGLE CRANE FUNCTION ILL NOT OPERATE (WILL NOT PRESSURIZE)	VALVE SECTION SHUTTLE BALL IS NOT RELEASING	LOCATE A DIFFERENT VALVE SECTION FURTHER DOWN STREAM FROM THE VALVE SECTION THAT IS NOT FUNCTIONING. NOTE: USE A FUNCTION OTHER THAN ANY ROTATION SECTIONS SUCH AS CRANE ROTATION, TIREMAN ROTATION, OR PAD ROTATION. OPERATE THE VALVE SECTION OR CRANE FUNCTION FURTHER DOWN STREAM FROM THE FAULTY VALVE SECTION. EXTEND THE CYLINDER OR CYLINDERS UNTIL FULL EXTENSION IS ACHIEVED AND HOLD. WHILE HOLDING THAT FUNCTION, OPERATE THE FAULTY VALVE SECTION FUNCTION, THEN QUICKLY RELEASE THE HANDLE ASSEMBLY OF THE VALVE SECTION THAT WAS BEING HELD. BY PRESSURIZING THE THE FUNCTION FURTHER DOWN STREAM AND QUICKLY RELEASING THE HANDLE, THE BACK PRESSURE SHOULD RELEASE THE SHUTTLE BALL ON THE FAULTY VALVE SECTION. THIS MAY NOT WORK THE FIRST TIME SO REPEAT THE ABOVE PROCEDURE UNTIL THE FAULTY FUNCTION OPERATES PROPERLY
VIBRATIONS AND JERKING IN HYDRAULIC CYLINDERS	AIR IN CYLINDER	FULLY CYCLE THE CYLINDER BOTH DIRECTIONS (BLOW PAST RELIEF) TO REMOVE AIR FROM SYSTEM
	THE TEMPERATURE OF THE HYDRAULIC OIL IS TOO LOW	PERFORM MANEUVERS WITHOUT LOADS FOR SEVERAL MINUTES TO WARM UP THE OIL
	LACK OF OIL IN RESERVOIR	ADD HYDRAULIC OIL
	COUNTER BALANCE VALVES ARE NOT FUNCTIONING PROPERLY	CONTACT STELLAR CUSTOMER SERVICE FOR SUPPORT
CRANE ROTATION IS ABNORMAL DURING OPERATION	INADEQUATE BEARING LUBRICATION	LUBRICATE GEAR BEARING/GEAR BOX
	THE TRUCK IS NOT ON A LEVEL SURFACE	LEVEL THE TRUCK USING STABILIZERS
	ROTATION BEARING IS WORN	REPLACE WITH NEW BEARING KIT
	ROTATION MOTOR WORN	REPLACE ROTATION MOTOR
	GEAR BEARING WORN/ MISSING TEETH.	REPLACE WITH NEW BEARING KIT

PROBLEM	POSSIBLE CAUSE	POSSIBLE SOLUTION
THE CRANE DOES NOT LIFT THE LOADS ON THE LOAD CHART	INCORRECT SYSTEM PRESSURE	INCORRECT SYSTEM PRESSURE
	CRANE IS NOT RECEIVING PROPER HYDRAULIC PRESSURE	CHECK HYDRAULIC RESERVOIR FLUID LEVEL
		ENSURE DUMP VALVE IS OPERATING PROPERLY
		VERIFY HYDRAULIC PUMP IS PRODUCING PROPER PRESSURE
THE CRANE DOES NOT LIFT THE LOADS ON THE LOAD CHART	CRANE IS NOT RECEIVING PROPER YDRAULIC FLOW	CHECK HYDRAULIC RESERVOIR FLUID LEVEL
		ENSURE DUMP VALVE IS OPERATING PROPERLY
		VERIFY HYDRAULIC PUMP IS PRODUCING PROPER FLOW
		ENSURE HYDRAULIC OIL IS AT THE PROPER OPERATING TEMPERATURE
NOISE COMING FROM ARTICULATION POINTS	BUSHINGS ARE WORN	REPLACE BUSHINGS
	INADEQUATE LUBRICATION	LUBRICATE BUSHINGS
	DAMAGED STRUCTURE	INSPECT AND REPAIR/REPLACE AS NEEDED
	BROKEN/WORN PIN	REPLACE PIN
STABILIZERS FAIL TO OPERATE	REMOTE/MANUAL SWITCH IS IN THE REMOTE POSITION	TOGGLE SWITCH TO THE MANUAL POSITION
	REMOTE/MANUAL SWITCH IS MALFUNCTIONING.	INSPECT AND REPAIR/REPLACE AS NEEDED
	PANIC BAR/E-STOP IS ENGAGED (MODELS 9000/13500)	RELEASE PANIC BAR/E-STOP

Manual Operation

If the remote control malfunctions, follow these steps to operate the crane manually:

- 1. Switch to manual operation.**
Toggle the Remote/Manual switch to the 'Manual' position.
- 2. Operate Levers.** Using the levers on the crane control center at the crane base, return the crane to the stowed position. See the operation chapter for details on stowing the crane.
- 3. Shut off crane controls.**
- 5. Have the unit serviced immediately to restore remote control functionality.**





Subject to Change without Notification.
© 2025 Stellar Industries, Inc.