




Model 23000

Articulating Crane

Owner's Manual

Installation • Assembly Drawings • Parts



Notice: A copy of this manual must remain with the equipment at all times.
For a printable download copy, please visit: www.stellarindustries.com

Stellar Industries, Inc.

190 State Street

PO Box 169

Garner, IA 50438

800-321-3741

Fax: 641-923-2811

www.stellarindustries.com


Subject to Change without Notification.
© 2025 Stellar Industries, Inc.

Rev 6.6
PN 90307

Serial Tag Location / P65 Warning

WARNING

Operating, maintaining, and servicing a Stellar product may expose you to chemicals including, but not limited to, engine exhaust, carbon monoxide, phthalates, and lead. These chemicals are known to the State of California to cause cancer and birth defects (or other reproductive harm). To keep your exposure to a minimum, be sure to avoid breathing exhaust and service your Stellar product in a well-ventilated area while wearing gloves or washing your hands frequently. For more information, go to www.P65Warnings.ca.gov/passenger-vehicle.



www.p65warnings.ca.gov

NOTICE

Cold Weather Performance

Although clear data on cold weather performance from every steel manufacturer is not available for all types and thicknesses of steel, Stellar Industries is confident that the weldments on our products will operate to 100% of their intended purpose to temperatures down to -40° F / C.

It is recommended if Stellar manufactured equipment needs to be used in temperatures below -40° F / C, the operator should pull the unit into a climate-controlled area and allow the weldments to warm up to and then maintain a temperature above this level.

Serial Tag Location

STELLAR®		DATE
PATENT INFORMATION http://www.stellarindustries.com/ip		
MODEL NO.	SERIAL NO.	
MADE IN THE U.S.A. BY STELLAR INDUSTRIES, INC. PN C5942		




Table of Contents

Introduction	iv
Chapter 1 - Specifications	1
Model 23000 Specifications.....	2
Capacity Chart - Decal PN 128331	3
Chapter 2 - Installation.....	5
General Installation.....	6
Installer Notice	6
Torque Data Chart	7
Installation Overview	8
Mounting Kit Drawing	8
Hydraulic Installation	9
Hydraulic Pressure Settings	10
Face Seal/O-Ring Size Chart	10
Fittings	12
Flat Face O-Ring Seal - FFORX	12
SAE 37° JIC	12
Fittings - Continued	13
O-Ring Boss	13
Face Seal Female Swivel Fittings	13
Hydraulic Kit - PN 128728	14
Hydraulic Kit - PN 128728 Parts List	15
Hydraulic Kit - PN 128728 Parts List	16
Hydraulic Backup Valve (Opt.) PN - 103419	18
Hydraulic Backup Valve (Opt.) PN - 103419 Parts List	19
Hydraulic Backup Valve (Opt.) PN - 103419 (Continued).....	20
Hydraulic Backup Valve (Opt.) PN - 103419 (Continued).....	21
Hydraulic Backup Valve (Opt.) PN - 103419 (Continued).....	22
Valve Mobile Backup - 101759	23
Control Kit (900 MHz Version) - PN 127357	24
Control Kit (900 MHz Version) - PN 127357 Parts List.....	25
Grease Kit - PN 103070	26
Grease Kit - PN 103070 Parts List	27
Decal Placement 23000	28
Chapter 3 - Assembly Drawings.....	29
Base Assembly - PN 130736.....	30
Base Assembly - PN 130736 Parts List.....	31
Base Assembly - PN 127259.....	32
Base Assembly - PN 127259 Parts List.....	33
Bearing Assembly - PN 18471.....	34
Gear Box - PN 60505	35
Valve Bank - PN 42802	36
Valve Bank - PN 42802	37
Mast Assembly - PN 100730	38
Mast Assembly - PN 100730 Parts List	39
Main Cylinder Assembly - PN 101532.....	40
Main Cylinder Assembly - PN 101532 Parts List	41
Main Boom Assembly - PN 100724.....	42
Main Boom Assembly - PN 100724 Parts List.....	43
Outer Cylinder Assembly - PN 61245.....	44
Outer Cylinder Assembly - PN 61245 Parts List.....	45
Extension Boom Assembly - PN 128248.....	46

Table of Contents

Extension Boom Assembly - PN 128248 Parts List.....	47
Extension Cylinder Assembly- PN 128719	48
Extension Cylinder Assembly- PN 128719 Parts List	49
Stabilizer Assembly- PN 40453.....	50
Stabilizer Assembly- PN 40453 Parts List.....	51
Stabilizer Cylinder Assembly- PN 40456	52
Stabilizer Cylinder Assembly- PN 40456 Parts List	53
Reservoir Assembly - PN 86356	54
Reservoir Assembly - PN 86356 Parts List	55
Optional 15 Ton Hook Kit - PN 55139	56
Optional 15 Ton Hook Kit Parts List	57
Radio Transmitter - PN 89149/93084	58
Transmitter Docking Station Asm (Opt.) - PN 97334	60
Transmitter Docking Station (Opt.) - PN 97334 Parts List	61
Wiring Diagram Docking Station - PN 65989.....	62

Introduction

A copy of this manual is provided with every crane and can be found in the hard plastic manual case that is installed on the chassis. A copy of this manual shall remain with the crane at all times.

Throughout the manual, three signal words will be used to bring attention to important items:

NOTICE

A NOTICE signal word indicates a practice not related to physical injury.

⚠ WARNING

A WARNING signal word indicates a hazardous situation which, if not avoided, could result in death or serious injury.

⚠ DANGER

A DANGER signal word indicates a hazardous situation which, if not avoided, will result in death or serious injury.

Information contained within this manual does not cover operation, maintenance, or troubleshooting. Please refer to the Large OTR Crane Manual for details on these items.

This manual is not binding. Stellar Industries, Inc. reserves the right to change, at any time, any or all of the items, components, and parts deemed necessary for product improvement or commercial/production purposes. This right is kept with no requirement or obligation for immediate mandatory updating of this manual.

In closing:

If more information is required or technical assistance is needed, or if you feel that any part of this manual is unclear or incorrect, please contact the Stellar Customer Service Department by phone at 800-321-3741 or email at service@stellarindustries.com.

**For Technical Questions, Information, Parts, or Warranty, Call Toll-Free at
800-321-3741**

Hours: Monday - Friday, 8:00 a.m. - 5:00 p.m. CST

Or email at the following addresses:

Technical Questions, and Information

service@stellarindustries.com

Order Parts

parts@stellarindustries.com

Warranty Information

warranty@stellarindustries.com

Page left intentionally blank.

Chapter 1 - Specifications


CHAPTER CONTENTS

Model 23000 Specifications	2
Capacity Chart - Decal PN 128331	3

Model 23000 Specifications

Crane Rating:	230,000 ft-lbs (31.8 ton meters)
Standard Boom Length:	13' 4" (4.06m) from CL of Crane
Boom Extension:	Hydraulic 37" (0.94 m)
Maximum Horizontal Reach:	16' 5" (5.0 m) from CL of Crane
Maximum Vertical Lift: (From Base)	20' 8" (6.29m)
Cylinder Specifications:	Inner Lift Cylinder: 8" (20.3 cm) bore with integral pilot operated counterbalance valves
	Outer Lift Cylinder: 6.5" (16.5 cm) bore with integral pilot operated counterbalance valves
	Extension Cylinder: 5" (12.7 cm) bore with integral pilot operated counterbalance valves
Rotation: (planetary gear with pinion)	315 degree power
Lifting Capacities:	14,000 lbs @ 16'5" (6350 kg @ 5.m)
Power Supply Required:	PTO & Pump - 16 gpm @ 4,400 psi (60 lpm @ 304 bar)
Controls:	Fully Proportional Paddle Controls for all functions.
Stowed Height: (Above Truck Frame)	116" (295 cm)
Mounting Space Required:	48" (121.9 cm)
Chassis RBM (Recommended):	2,760,000 in-lb
Approximate Shipping Weight:	11,500 lbs (5,220 kg)

Capacity Chart - Decal PN 128331



This page left intentionally blank

Chapter 2 - Installation

CHAPTER CONTENTS

General Installation	6
Installer Notice.....	6
Torque Data Chart.....	7
Installation Overview	8
Mounting Kit Drawing	8
Hydraulic Installation.....	9
Hydraulic Pressure Settings.....	10
Face Seal/O-Ring Size Chart.....	10
Fittings	12
Flat Face O-Ring Seal - FFORX	12
SAE 37° JIC	12
Fittings - Continued.....	13
O-Ring Boss.....	13
Face Seal Female Swivel Fittings	13
Hydraulic Kit - PN 128728.....	14
Hydraulic Kit - PN 128728 Parts List.....	15
Hydraulic Kit - PN 128728 Parts List.....	16
Hydraulic Backup Valve (Opt.) PN - 103419.....	18
Hydraulic Backup Valve (Opt.) PN - 103419 Parts List.....	19
Hydraulic Backup Valve (Opt.) PN - 103419 (Continued)	20
Hydraulic Backup Valve (Opt.) PN - 103419 (Continued)	21
Hydraulic Backup Valve (Opt.) PN - 103419 (Continued)	22
Valve Mobile Backup - 101759.....	23
Control Kit (900 MHz Version) - PN 127357	24
Control Kit (900 MHz Version) - PN 127357 Parts List	25
Grease Kit - PN 103070	26
Grease Kit - PN 103070 Parts List.....	27
Decal Placement 23000	28

General Installation

This chapter is designed to serve as a general guide for the installation of a Stellar 23000 Crane on a Stellar Service Body. Each installation is considered unique so certain portions of this chapter may or may not apply to your direct application. If a question should arise during the installation process, please contact Stellar Customer Service at (800) 321 3741.

This crane is designed for use with a Stellar Service Body installed on a vehicle that meets the minimum chassis requirements of the crane. It is the installer's responsibility to assure that the crane is mounted on a platform that will support the maximum crane rating of this crane.

⚠ WARNING Do not install this crane on a body not capable of handling the loads imposed on it. Failure to do so may result in serious injury or death.

NOTICE When installing welder units to the service bodies, it is highly recommended that a surge protector is installed on the chassis batteries to protect the crane radio receiver, wiring and other electronic devices from an unexpected electrical spike or surge. Failure to do so could result in extensive damage to the service body and crane electrical circuit.

Installer Notice

According to Federal Law (49 cfr part 571), each final-stage manufacturer shall complete the vehicle in such a manner that it conforms to the standards in effect on the date of manufacture of the incomplete vehicle, the date of final completion, or a date between those two dates. This requirement shall, however, be superseded by any conflicting provisions of a standard that applies by its terms to vehicles manufactured in two or more stages.




Therefore, the installer of Stellar® products are considered one of the manufacturers of the vehicle. As such a manufacturer, the installer is responsible for compliance with all applicable federal and state regulations, as well as any OEM instructions such as chassis body builder guides. They are required to certify that the vehicle is in compliance with the Federal Motor Vehicle Safety Standards and other regulations issued under the National Traffic and Motor Vehicle Safety Act and also complies with recommended best practices from the chassis OEM.

Please reference the Code of Federal Regulations, title 49 - Transportation, Volume 5 (400-999), for further information, or visit <http://www.gpoaccess.gov/nara/index.html> for the full text of Code of Federal Regulations.

Torque Data Chart

When using the torque data in the chart, the following rules should be observed:

- Bolt manufacturer's particular specifications should be consulted when provided.
- Flat washers of equal strength must be used.
- All torque measurements are given in foot-pounds. To convert to inch-pounds, multiply by 12.
- Torque values specified are for bolts with residual oils or no special lubricants applied.
- Torque values for socket-head capscrews are the same as for Grade 8 capscrews.


		GRADE 5		GRADE 8		GRADE 9
						
Size (DIA-TPI)	Bolt DIA (Inches)	Plain (Ft-Lb)	Plated (Ft-Lb)	Plain (Ft-Lb)	Plated (Ft-Lb)	Plated (Ft-Lb)
5/16-18	0.3125	17	13	25	18	22
3/8-16	0.3750	31	23	44	33	39
7/16-14	0.4375	49	37	70	52	63
1/2-13	0.5000	75	57	105	80	96
9/16-12	0.5625	110	82	155	115	139
5/8-11	0.6250	150	115	220	160	192
3/4-10	0.7500	265	200	375	280	340
7/8-9	0.8750	395	295	605	455	549
1-8	1.000	590	445	910	680	823
1 1/8-7	1.1250	795	595	1290	965	1167
1 1/4-7	1.2500	1120	840	1815	1360	1646
1 3/8-6	1.3750	1470	1100	2380	1780	2158
1 1/2-6	1.500	1950	1460	3160	2370	2865

- **NOTICE** Do not use these values if a different torque value or tightening procedure is given for a specific application. Torque values listed are for general use only. Check tightness of fasteners periodically.
- Shear bolts are designed to fail under predetermined loads. Always replace shear bolts with identical grade.
- Fasteners should be replaced with the same or higher grade. If higher grade fasteners are used, these should only be tightened to the strength of the original.
- Tighten plastic insert or crimped steel-type lock nuts to approximately 110 percent of the dry torque values shown in the chart below, applied to the nut, not to the bolt head. Tighten toothed or serrated-type lock nuts to the full torque value. Note: "Lubricated" means coated with a lubricant such as engine oil, or fasteners with phosphate and oil coatings. "Dry" means plain or zinc plated without lubrication. Tighten lubricated bolts to approximately 80% of dry bolts.

Installation Overview

1. Relocate any obstructions on the frame that will be in the way of mounting the crane.
2. Measure the inside of the frame rails and cut the frame support to this length. Ensure that the frame supports have a tight fit between the frame rails.
3. Set the crane on the chassis and allow a minimum of 3" from the cab.
4. Make certain that the frame supports are installed square, cut to length in such a way as to support the frame flanges with the tie down rods are torqued.
5. Install the crane tie downs. Start at one corner and tighten both tie downs to 200 ft-lbs. Move to the diagonal set and tighten to 200 ft-lbs. Tighten the remaining 2 corners. Continue this pattern at 200 ft-lb increments until 650-700 ft-lbs is achieved. Be sure the mounting block stays perpendicular to the frame rail as they are tightened down.
6. Connect the pressure and return lines per the hydraulic kit.
7. Connect the electrical power and ground wires. Ground preferably connected to battery.
8. With the crane and outriggers in the stored position, check the reservoir for oil and fill if necessary.
9. Operate the crane for several cycles. Fully cycle the cylinder in both directions (blow past relief) to remove any air from the system.

Mounting Kit - PN 15659



PN 16659

ITEM	PART	DESCRIPTION	QTY
1	8054	MTG BLOCK 15000	4
2	11677	PLATE MOUNTING 23000	4
3	14498	TIE DOWN ROD	8
4	9180	WASHER 1.25 SAE FLAT YELLOW GR8	16
5	8834	NUT 1.25-7 HHGR8 TOP LOCKING	8
6	8978	NUT 1.25-7 HHGR8	16
7	8202	FRAME SUPPORT 15000 CRANE	4

Hydraulic Installation

Never modify or alter any of the equipment, whether mechanical, electrical, or hydraulic, without Stellar Industries' approval.

⚠ WARNING Do not touch or grab any hoses that could be under pressure. Release system pressure before attempting to make adjustments or repairs.

Do not attempt service or repair when PTO is engaged.

Disassemble and assemble hydraulic components on a clean surface.

Clean all metal parts in a nonflammable cleaning fluid. Then lubricate all components to aid in assembly.

⚠ WARNING Hydraulic fluid expands when heated. This raises the pressure in an unventilated tank. Release the tank pressure before removing the cap completely. Failure to do so may cause the oil to shoot out of the tank very rapidly and cause severe burns.

⚠ WARNING Do not rely on the hydraulic fluid to support the boom or crane. If hydraulic fluid escapes, the boom or crane can fall immediately. Make sure the ground or blocking is supporting the boom before performing any maintenance or repair.

NOTICE Contaminants in a hydraulic system affect operation and will result in serious damage to the system components. Dirty hydraulic systems are a major cause of component failures.

If evidence of foreign particles is found in the hydraulic system, flush the system.

When installing metal hydraulic tubes, tighten all fittings finger tight. Then, in order, tighten the fittings at the rigid end, the adjustable end, and the mounting brackets. After tubes are mounted, install the hoses. Connect both ends of the hose with all fittings finger tight. Position the hose so it does not rub the machine or another hose and has a minimum of bending and twisting. Tighten fittings in both couplings.


Due to manufacturing methods, there is a natural curvature to a hydraulic hose. The hose should be installed so any bend is with this curvature.

THIS PAGE LEFT INTENTIONALLY BLANK

Hydraulic Pressure Settings

Main Relief 4600 PSI			
		Pressure (PSI)	
Function	Flow	Extend	Retract
Inner	10.6	4400	2200
Outer	10.6	4400	2200
Extension	10.6	4400	4400
Rotation	3.9	2200	2200
TM Rot	6.6	2200	2200
TM Pad Rot	6.6	2500	2500
TM Clamp	6.6	4200	4200

Face Seal/O-Ring Size Chart



Hose Size	Fitting Size	Face Seal (A) Stellar® PN	O-ring Boss (B) Stellar® PN
1/4"	#4	C2027	D1245
3/8"	#6	C2028	D1246
1/2"	#8	C2029	D1247
5/8"	#10	32223	D1248
3/4"	#12	D1244	D1249
1"	#16		D1250

Fittings

Flat Face O-Ring Seal - FFORX

HOSE FITTING ONLY



FS




SIZE	THREAD SIZE	LB-FT TORQUE
-4	9/16-18 UNF	21
-5	5/8-18 UNF	25
-6	11/16-16 UN	40
-8	13/16-16 UN	46
-10	1-14 UNS	50
-12	1-3/16-12 UN	75
-16	1-7/16-12 UN	104
-20	1-11/16-12 UN	141
-24	2-12 UN	166
-32	2-1/2-12 UN	423

SAE 37° JIC

HOSE FITTING & FEMALE SWIVEL FITTINGS



JIC



SIZE	THREAD SIZE	LB-FT TORQUE
-2	5/16-24 UNF	7
-3	3/8-24UNF	9
-4	9/16-18 UNF	13
-5	5/8-18 UNF	16
-6	11/16-16 UN	20
-8	13/16-16 UN	41
-10	1-14 UNS	64
-12	1-3/16-12 UN	89
-16	1-7/16-12 UN	122
-20	1-11/16-12 UN	143
-24	2-12 UN	178
-32	2-1/2-12 UN	275

Fittings - Continued

O-Ring Boss

HYDRAULIC FITTING ONLY



-SIZE	THREAD SIZE	ORB	AORB
-4	7/16-20 UNF	15	23
-6	9/16-18 UNF	24	32
-8	3/4-16 UNF	40	55
-10	7/8-14 UNF	61	76
-12	1-1/16-12 UN	101	116
-16	1-5/16-12 UN	120	119
-20	1-5/8-12 UN	125	125
-24	1-7/8-12 UN	140	140
-32	2-1/2-12 UN	157	157


Face Seal Female Swivel Fittings

HYDRAULIC FITTING ONLY



-SIZE	THREAD SIZE	LB-FT TORQUE
-4	9/16-18 UNF	13
-6	11/16-16 UN	23
-8	13/16-16 UN	40
-10	1-14 UNS	61
-12	1-3/16-12 UN	86
-16	1-7/16-12 UN	119
-20	1-11/16-12 UN	125
-24	2-12 UN	140

Hydraulic Kit - PN 128728




Hydraulic Kit - PN 128728 Parts List

HOSES FROM VALVE
BANK TO BULKHEAD

TOP VIEW OF MAST
BULKHEAD PLATE

TOP VIEW OF MAIN
BOOM PORT TUBES

TO TM COUPLERS/EXT CYL



USE SPIRAL HOSE WRAP OVER HOSES
FROM BULKHEAD PLATE TO PORT TUBES,
AND FROM PORT TUBES TO FUNCTIONS.
(GROUPED AS SHOWN)


PN 128728

ITEM	PART	DESCRIPTION	QTY
1	128729	HOSE KIT 23000 V4 (INCL:2-21)	1
2	69750	HOSE-HYD 0.38 X 62	2REF
3	69751	HOSE-HYD 0.38 X 29	2REF
4	97596	HOSE-HYD 0.38 X 36	2REF
5	97598	HOSE-HYD 0.38 X 28	2REF
6	75928	HOSE-HYD 0.38 X 54	4REF
7	11674	HOSE-HYD 0.38 X 102	4REF
8	16493	HOSE-HYD 0.38 X 84	4REF
9	69752	HOSE-HYD 0.75 X 35	1REF
10	70772	HOSE-HYD 0.50 X 33	1REF
11	9104	HOSE-HYD 0.75 X 72	1REF
12	70774	HOSE-HYD 0.50 X 24	1REF
13	39895	HOSE-HYD 0.25 X 108	1REF
14	75927	HOSE-HYD 0.25 X 54	2REF
15	55677	HOSE-HYD 0.25 X 12	1REF
16	98234	HOSE-HYD 0.38 X 112	4REF
17	24405	HOSE-HYD 0.38 X 70	2REF
18	98235	HOSE-HYD 0.25 X 112	6REF
19	97597	HOSE-HYD 0.25 X 36	6REF
20	127263	HOSE-HYD 0.25 X 12	1REF
21	52614	HOSE-HYD 0.25 X 31	1REF
22	14354	FTG 12-10 MFS-MAORB 90	1
23	55394	SWTICH PRESS OVERLD CD=11C-5500R/WD	1
24	C1111	FTG 10-6 MORB-FORB STRAIGHT REDUCER	19
25	D0525	FTG 12-12-12 MFS-FFSS-MFS RUN TEE	1

Hydraulic Kit - PN 128728 Parts List

PN 128728			
ITEM	PART	DESCRIPTION	QTY
26	37179	FTG 8-10-8 MFS-MOAB-MFS TEE	1
27	D1435	FTG 12-10 MFS-MORB STRAIGHT	1
28	25361	FTG 6-6 MFS-MAORB 90 LONG	12
29	138728	GAUGE OIL LF 2.5 0-6000 CBM SAE SS TUBE	1
30	47405	FTG 6-6 MORB-MFS BULKHEAD STRAIGHT	4
31	13554	QUICK CPLR FFH04-38-SAE-F	2
32	13555	QUICK CPLR FFH04-38-SAE-M	2
33	13557	QUICK CPLR FFN06-12SAE-M	1
34	13556	QUICK CPLR FFN06-12SAE-F	1
35	44521	FTG 5-4 MORB-FORB STRAIGHT REDUCER	1
36	52820	FTG 4-5 MFS-MAORB 90	1
37	C0338	FTG 6-6 MFS-MAORB 90	5
38	3861	FTG 6-6 MAORB-FORB 90	1
39	0882	FTG 6 FFS CAP	2
40	D1302	FTG 6-10 MFS-MAORB 90	7
41	C4922	FTG 4-6 MFS-MORB STRAIGHT	1
42	C1854	FTG 6-8 MFS-MORB STRAIGHT	8
43	C1180	FTG 8-12 MFS-MORB STRAIGHT	4
44	C2376	FTG 8-8 MFS-FFSS 90	2
45	D1193	FTG 6-6 MFS-MAORB 45	2
46	C1198	FTG 4-4 MFS-MAORB 90	2
47	0279	FTG 6-6 MFS-MORB STRAIGHT	4
48	47406	FTG 8-8 MORB-MFS BULKHEAD STRAIGHT	2
49	23421	FTG 4-4-4 MFS-FFSS-MFS RUN TEE	1
50	D1190	FTG 4-6 MFS-MAORB 45	1
51	7343	FTG 6-8 MFS-MAORB 45	2


Hydraulic Backup Valve (Opt.) PN - 103419




Hydraulic Backup Valve (Opt.) PN - 103419 Parts List

PN 103419			
ITEM	PART	DESCRIPTION	QTY
1	C5968	FTG 12-12 MFS-MAORB 90	1
2	C3643	FTG 8-10 MFS-MAORB 90	1
3	C2142	FTG 12-12 MFS-MORB STRAIGHT	1
4	C2252	FTG 8-10 MFS-MORB STRAIGHT	1
5	26025	CAP SCR 0.50-13X2.25 HHGR5	2
6	C0956	CAP SCR 0.38-16X5.50 HHGR5	2
7	0352	WASHER 0.50 USS FLAT	4
8	0346	WASHER 0.38 USS FLAT	4
9	C6106	NUT 0.50-13 HHGR5 NYLOC	2
10	0347	NUT 0.38-16 HHGR5 NYLOC	2
11	101759	VALVE MOBILE CRANE BACKUP	1
12	103420	FORMED MNT BRKT CRANE EMER BLOCK 23/28	1
13	103418	PLATE COVER VALVE CRANE BACKUP 17/23/28	1
ITEMS NOT SHOWN			
PART	DESCRIPTION		QTY
102202	WIRE HARNESS VALVE CRANE EMER BLOCK		1
75110	TERML BUTT 16-14GA STP 22-18GA HS		2

Hydraulic Backup Valve (Opt.) PN - 103419 (Continued)



Hydraulic Backup Valve (Opt.) PN - 103419 (Continued)




NOTES:

*THIS WIRING METHOD IS FOR ALL AUTOMATIC AND ELECTRIC OVER AIR MANUAL TRANSMISSIONS.

*RELAY IS TO BE INSTALLED BEHIND THE DASH NEAR THE PTO SWITCH.

*IF INSTALLING ON A TRUCK WITH AN AIR OPERATED PTO, ADD AIR CONTROL VALVE PN: 57738, SEE PAGE 20.

Hydraulic Backup Valve (Opt.) PN - 103419 (Continued)




NOTES:

*THIS WIRING METHOD IS FOR AIR OPERATED TRANSMISSIONS

*AIR CONTROL VALVE IS TO BE LOCATED BEHIND THE DASH NEAR THE PTO.


*IF THE TRANSMISSION IS A TWO-WAY AIR OPERATION, PORT #4 SHOULD BE USED TO TURN THE PTO OFF.

Valve Mobile Backup - 101759



PN 101759			
ITEM	PART	DESCRIPTION	QTY
1	131389	VALVE CHECK MOBILE CRANE BACKUP	1
2	131390	FLOW DIVIDER MOBILE CRANE BACKUP	1
3	131391	VALVE RELIEF MOBILE CRANE BACKUP	1
4	131392	COIL 12VDC DEUTSCH MOBILE CRANE BACKUP	2
5	131393	VALVE CARTRIDGE MOBILE CRANE BACKUP	1
6	131394	VALVE CARTRIDGE MOBILE CRANE BACKUP	1
7	12153	FTG 10 MORB PLUG HOLLOW HEX	5


Control Kit (900 MHz Version) - PN 127357



Control Kit (900 MHz Version) - PN 127357 Parts List

PN 127357			
ITEM	PART	DESCRIPTION	QTY
1	89149	TRANSMITTER SCARECO 9 / 135 / 17 / 23 / 28	1
2	93082	RECEIVER ASM SCANRECO OTR 900 MHZ	1
3	89152	CABLE BACKUP 10M SCANRECO	1
4	89154	BATTERY SCANRECO	2
5	89155	CHARGER BATTERY SCANRECO	1
6	89639	STRAP CARRYING SCANRECO	1
7	93191	CABLE ASM M12 5P M-F RA 5FT	1REF
8	93192	DUST CAP M12 SKT BLACK PLASTIC	1REF
9	93695	WIRE HRNS CRANE 9K-28K	1
10	93204	WIRE HRNS CRANE MAST LRG OTR	1
11	68797	WIRE HARNESS MAIN BOOM 28000 TM LTS	2
12	125411	WIRE HRNS OTR COOLER FAN HTP	1
13	78246	BACKUP ALARM 87 DECIBEL	1
14	94004	E=STOP SWITCH ASM 17 / 23 / 28K CRANE	1
15	C4815	SWITCH, TOGGLE ON / OFF	3
16	8623	SWITCH TOGGLE ON-OFF-ON SGL P DBL T	1
17	125412	RELAY ASM COOLER FAN PWR INTRLK	1
18	125415	RELAY ASM HTP ALARM INDICATOR	1
19	6394	SWITCH TOGGLE MOM / ON / OFF / ON	2
20	127355	WIRE HRNS STBLZR CS CTRL 23 / 28K CRN	1
21	C0073	TERML BUTT 16-14GA HS BLUE	1


Grease Kit - PN 103070



Grease Kit - PN 103070 Parts List

PN 103070			
ITEM	PART	DESCRIPTION	QTY
1	104018	HOSE & FTG KIT GREASE LINE GEAR BRG. (INCL:2-3)	1
2	—	HOSE-HYD 0.13 X 30	1REF
3	104019	FTG 4-2 PTC-MP STRAIGHT GREASE LINE	1REF
4	103071	HOSE & FTG KIT GREASE LINE 23000 V3 (INCL:5-12)	1
5	105342	HOSE-HYD 0.13 X 68	1REF
6	105343	HOSE-HYD 0.13 X 138	1REF
7	105344	HOSE-HYD 0.13 X 156	2REF
8	105345	HOSE-HYD 0.13 X 245	2REF
9	105346	HOSE-HYD 0.13 X 259	1REF
10	104019	FTG 4-2 PTC-MP STRAIGHT GREASE LINE	2REF
11	104020	FTG 4-2 PTC-MP 90 GREASE LINE	5REF
12	104021	FTG 2-2 MP-FP 45 GREASE LINE	2REF
REV B REQ913-202506			

Decal Placement 23000



TIRE SERVICE DECAL KIT
FOR 23000 - PN 129056

DECALS IN BOLD ARE NOT SHOWN - PLACE ON BODY

General Tire Crane Decal Kit - PN 85362

Item No.	PN	Description	Location	QTY
01	15172	DECAL ASME/ANSI B30.22/B30.5	Crane Base	1
02	C4795	DECAL DANGER FOOT	Stabilizers - CS & SS	2
03	73929	DECAL RADIO PRESSURE WASHER NOTICE	Near Remote Receiver	1
04	16973	DECAL USE STELLAR APPROVED ATTACHMT	Main Boom - Both Sides	2
05	9188	DECAL WORM GEAR LUBRICATION	Crane Base	1
06	35234	MADE IN THE USA - STELLAR	Main Boom - Both Sides	2
07	4214	DECAL CONTACT STELLAR	Crane Base	1
08	C4545	DECAL DANGER ELECTROCUTION	Four Corners of the Body	4
09	C5910	DECAL STELLAR LOGO 4.00X9.50 PRE-MASKED	Body - Optional	3

23000 Decal Kit - PN 129055


Item No.	PN	Description	Location	QTY
10	54596	DECAL 23000 ID PRE-MASKED	Main Boom - Both Sides	2
11	128831	DECAL CAPACITY 23000	Stabilizers CS & SS	2
12	44526	DECAL SWITCH PANEL 23000 CRANE	Crane Base - CS	1
13	16620	DECAL SWITCH PLATE 28000	Crane Control Station	1
14	43469	DECAL V8 CONTROL 23000	Crane Control Station	1
15	43470	DECAL OUTRIGGERS 23000	Crane Control Station	1
16	22619	DECAL CHECK GEARBOX	Crane Base - CS	1
17	47404	DECAL COUPLERS 23000	Main Boom	1
18	54781	DECAL WARNING PLACARD	Stabilizers - CS & SS	2
19	54589	DECAL STELLAR LOGO 8X22.25 PRE-MASKED	Main Boom - Both Sides	2
20	125941	DECAL OIL TEMP	Crane Base	1

Chapter 3 - Assembly Drawings

CHAPTER CONTENTS

Base Assembly - PN 130736	30
Base Assembly - PN 130736 Parts List	31
Base Assembly - PN 127259	32
Base Assembly - PN 127259 Parts List	33
Bearing Assembly - PN 18471	34
Gear Box - PN 60505.....	35
Valve Bank - PN 42802	36
Valve Bank - PN 42802	37
Mast Assembly - PN 100730	38
Mast Assembly - PN 100730 Parts List.....	39
Main Cylinder Assembly - PN 101532.....	40
Main Cylinder Assembly - PN 101532 Parts List.....	41
Main Boom Assembly - PN 100724	42
Main Boom Assembly - PN 100724 Parts List	43
Outer Cylinder Assembly - PN 61245	44
Outer Cylinder Assembly - PN 61245 Parts List	45
Extension Boom Assembly - PN 128248	46
Extension Boom Assembly - PN 128248 Parts List	47
Extension Cylinder Assembly- PN 128719.....	48
Extension Cylinder Assembly- PN 128719 Parts List.....	49
Stabilizer Assembly- PN 40453.....	50
Stabilizer Assembly- PN 40453 Parts List.....	51
Stabilizer Cylinder Assembly- PN 40456.....	52
Stabilizer Cylinder Assembly- PN 40456 Parts List.....	53
Reservoir Assembly - PN 86356	54
Reservoir Assembly - PN 86356 Parts List	55
Optional 15 Ton Hook Kit - PN 55139	56
Optional 15 Ton Hook Kit Parts List	57
Radio Transmitter - PN 89149/93084.....	58
Transmitter Docking Station Asm (Opt.) - PN 97334	60
Transmitter Docking Station (Opt.) - PN 97334 Parts List	61
Wiring Diagram Docking Station - PN 65989	62

Base Assembly - PN 130736



NOTES:


FILTER ELEMENT: 47860.

BACK UP ALARM, E-STOP, & RADIO RECEIVER SHOWN FOR REFERENCE.

Base Assembly - PN 130736 Parts List

PN 130736			
ITEM	PART	DESCRIPTION	QTY
1	130737	BASE 23000 REAR MNT RH DRIVE	1
2	18471	TURNTABLE BEARING 23000	1
3	18041	WASHER 0.88 SAE FLAT YELLOW GR9	16
4	17962	CAP SCR 0.88-9X4.50 HHGR9 ZY	16
5	41337	PLATE COVER 23000	1
6	0479	CAP SCR 0.25-20X0.75 HHGR5	6
7	0340	WASHER 0.25 FLAT	40
8	42833	PLATE GREASE LINE MTG 23000	1
9	0342	NUT 0.31-18 HH NYLOC	5
10	0343	WASHER 0.31 USS FLAT ZINC	18
11	0485	CAP SCR 0.31-18X1.25 HHGR5	4
12	41082	BAR PANIC 23000 PC RED	1
13	22183	CAP SCR #8-32X0.75 BTNHD SS	2
14	0488	CAP SCR 0.31-18X2.00 HHGR5	2
15	C6219	WASHER 0.75 SAE FLAT YELLOW GR8	12
16	C1028	CAP SCR 0.75-10X3.00 HHGR8 ZY	12
17	22935	VALVE BLOCK CBCA-LAN-XTS	1
18	5591	WASHER 0.31 SAE FLAT YELLOW GR8	4
19	C0930	CAP SCR 0.31-18X3.00 HHGR5	4
20	127258	VB 5 SECT 23000/28000 OUTRIGGER	1
21	78432	FILTER HIGH PRESSURE 1.06-12SAE 5000PSI 10 MICRON	1
22	78433	CLAMP HIGH PRESSURE FILTER 3.00	1
23	0420	CAP SCR 0.31-18X0.75 HHGR5	4
24	41336	PLATE SWITCH MTG 23000	1
25	0339	CAP SCR 0.25-20X2.50 HHGR5	4
26	0333	NUT 0.25-20 HHGR5 NYLOC	18
27	0480	CAP SCR 0.25-20X1.00 HHGR5	10
28	44511	GUARD OUTRIG VB 23000	1
29	22185	WASHER 0.19 FLAT SS	2
30	22186	NUT #8-32 HH NYLOC SS	2
31	C0922	CAP SCR 0.31-18X1.00 HHGR5	3
32	0437	CAP SCR 0.25-20X1.25 HHGR5	2
33	41084	GUARD VB 23000 PC BLACK	1
34	124605	BRACKET VB MNT 23/28 2.56X5.50	2
35	124606	BRACKET VB MNT BASE 23/28 4.25	2
36	42802	VB 7 SECT DANFOSS PVG32	1
37	60505	GEAR BOX W/MOTOR 23/28000	1
38	21039	CAP SCR #10-24X1.50 BTNHD SS	4
39	D0178	WASHER #10 SAE FLAT	8
40	26034	NUT #10-24 HH NYLOC	4
41	78246	BACKUP ALARM 87 DECIBEL	1
43	131087	PLATE PRESSURE FILTER GUARD	1
44	131088	PLATE PRESSURE FILTER GUARD REMOVABLE	1
REV. A			

Base Assembly - PN 127259



NOTES:
 FILTER ELEMENT 47860
 BACK UP ALARM, E-STOP, &
 RADIO RECEIVER SHOWN
 FOR REFERENCE


Base Assembly - PN 127259 Parts List

PN 127259			
ITEM	PART	DESCRIPTION	QTY
1	39987	BASE 23000	1
2	18471	TURNTABLE BEARING 23000	1
3	18041	WASHER 0.88 SAE FLAT YELLOW GR9	16
4	17962	CAP SCR 0.88-9X4.50 HHGR9 ZY	16
5	41337	PLATE COVER 23000	1
6	0479	CAP SCR 0.25-20X0.75 HHGR5	6
7	340	WASHER 0.25 FLAT	38
8	42833	PLATE GREASE LINE MTG 23000	1
9	0342	NUT 0.31-18 HH NYLOC	5
10	0343	WASHER 0.31 USS FLAT ZINC	18
11	0485	CAP SCR 0.31-18X1.25 HHGR5	4
12	41082	BAR PANIC 23000 PC RED	1
13	22183	CAP SCR #8-32X0.75 BTNHD SS	2
14	0488	CAP SCR 0.31-18X2.00 HHGR5	2
15	C6219	WASHER 0.75 SAE FLAT YELLOW GR8	12
16	C1028	CAP SCR 0.75-10X3.00 HHGR8 ZY	12
17	22935	VALVE BLOCK CBCA-LAN-XTS	1
18	5591	WASHER 0.31 SAE FLAT YELLOW GR8	4
19	C0930	CAP SCR 0.31-18X3.00 HHGR5	4
20	127258	VB 5 SECT 23000/28000 OUTRIGGER	1
21	78432	FILTER HIGH PRESSURE 1.06-12SAE 5000PSI 10 MICRON	1
22	78433	CLAMP HIGH PRESSURE FILTER 3.00	1
23	0420	CAP SCR 0.31-18X0.75 HHGR5	4
24	41336	PLATE SWITCH MTG 23000	1
25	0339	CAP SCR 0.25-20X2.50 HHGR5	4
26	0333	NUT 0.25-20 HHGR5 NYLOC	17
27	0480	CAP SCR 0.25-20X1.00 HHGR5	9
28	44511	GUARD OUTRIG VB 23000	1
29	22185	WASHER 0.19 FLAT SS	2
30	22186	NUT #8-32 HH NYLOC SS	2
31	C0922	CAP SCR 0.31-18X1.00 HHGR5	3
32	0437	CAP SCR 0.25-20X1.25 HHGR5	2
33	41084	GUARD VB 23000 PC BLACK	1
34	124605	BRACKET VB MNT 23/28 2.56X5.50	2
35	124606	BRACKET VB MNT BASE 23/28 4.25	2
36	42802	VB 7 SECT DANFOSS PVG32	1
37	60505	GEAR BOX W/MOTOR 23/28000	1
38	21039	CAP SCR #10-24X1.50 BTNHD SS	4
39	D0178	WASHER #10 SAE FLAT	8
40	26034	NUT #10-24 HH NYLOC	4
41	78246	BACKUP ALARM 87 DECIBEL	1

Bearing Assembly - PN 18471


**USE EP2 LITHIUM COMPLEX GREASE, STELLAR PN 78090
ON BEARING RACE**

**GREASE MAIN BEARING RACE THROUGH
REMOTELY MOUNTED GREASE ZERK**




**USE MOLY GREASE 936SF HEAVY, STELLAR PN 4460
ON BEARING GEAR TEETH**

Gear Box - PN 60505




Valve Bank - PN 42802



Valve Bank - PN 42802

PN 42802			
ITEM	PART	DESCRIPTION	QTY
1	50234	DUMP VALVE	1
2	55126	DUMP VALVE COIL	1
3	50231	ACTUATOR COIL	7
4	50233	ACTUATOR ASSEMBLY	7
5	48696	BASE HANDLE	7
6	47866	HANDLE/LEVER	7
7	93087	SEAL KIT & TIE RODS DANFOSS PVG32	1
8	93088	SEAL KIT PVHC ACTUATOR PVG32	7
9	103392	SEAL KIT MANUAL OPERATOR PVG32	7


Mast Assembly - PN 100730



Mast Assembly - PN 100730 Parts List

PN 100730			
ITEM	PART	DESCRIPTION	QTY
1	100731	MAST 23000 V3	1
2	101532	CYLINDER ASM 23000 V3 MAST	1
3	0635	BUSHING 40DXR32 GARLOCK	2
4	2227	BUSHING BPC48DXR48 3.00X3.00	2
5	16344CR	PIN 2.50X16.25 D&T ZC	1
6	41053	PIN 3.00X17.50 D&T SS	1
7	13315	PIN CAP 0.56X4.00X0.19 YZ	4
8	11297	PLATE INSPECTION MAST 23000	1
9	D0790	WASHER 0.50 SAE FLAT YELLOW GR8	4
10	10172	CAP SCR 0.50-13X1.00 HHGR8	4
11	18041	WASHER 0.88 SAE FLAT YELLOW GR9	18
12	42308	CAP SCR 0.88-9X2.75 HHGR9	16
13	17962	CAP SCR 0.88-9X4.50 HHGR9	2
14	0343	WASHER 0.31 USS FLAT	2
15	0522	WASHER 0.31 LOCK	2
16	0484	CAP SCR 0.31-18X0.50 HHGR5	2

Main Cylinder Assembly - PN 101532



NOTES:


C-BALANCE VALVE C1090
CYLINDER SEAL KIT C6308
BUSHING PART NUMBER 5739
BUSHINGS INCLUDED IN 42827

GREASE FITTINGS SHOWN FOR REFERENCE

Main Cylinder Assembly - PN 101532 Parts List

PN 101532			
ITEM	PART	DESCRIPTION	QTY
1	100731	MAST 23000 V3	1
2	101532	CYLINDER ASM 23000 V3 MAST	1
3	0635	BUSHING 40DXR32 GARLOCK	2
4	2227	BUSHING BPC48DXR48 3.00X3.00	2
5	16344CR	PIN 2.50X16.25 D&T ZC	1
6	41053	PIN 3.00X17.50 D&T SS	1
7	13315	PIN CAP 0.56X4.00X0.19 YZ	4
8	11297	PLATE INSPECTION MAST 23000	1
9	D0790	WASHER 0.50 SAE FLAT YELLOW GR8	4
10	10172	CAP SCR 0.50-13X1.00 HHGR8	4
11	18041	WASHER 0.88 SAE FLAT YELLOW GR9	18
12	42308	CAP SCR 0.88-9X2.75 HHGR9	16
13	17962	CAP SCR 0.88-9X4.50 HHGR9	2
14	0343	WASHER 0.31 USS FLAT	2
15	0522	WASHER 0.31 LOCK	2
16	0484	CAP SCR 0.31-18X0.50 HHGR5	2

Main Boom Assembly - PN 100724




NOT SHOWN: 63038 - 1.3 FT
GREASE FITTINGS SHOWN
FOR REFERENCE

Main Boom Assembly - PN 100724 Parts List

PN 100724			
ITEM	PART	DESCRIPTION	QTY
1	100725	INNER BOOM 23000 V3	1
2	2227	BUSHING BPC48DXR48 3.00X3.00	4
3	13817	BUSHING 40DXR24 2.50X1.50 GARLOCK	4
4	61245	CYLINDER ASM 6.50X35.69	1
5	41056CR	PIN 2.50X11.13 D&T ZC	2
6	13315	PIN CAP 0.56X4.00X0.19 YZ	4
7	D0790	WASHER 0.50 SAE FLAT YELLOW GR8	4
8	10172	CAP SCR 0.50-13X1.00 HHGR8	4
9	0521	WASHER 0.25 LOCK	12
10	0340	WASHER 0.25 USS FLAT	12
11	96567	CLAMP 0.38 PORT TUBE TWIN - STAUFF LNGF	9
12	96566	CLAMP 0.50 PORT TUBE TWIN - STAUFF LNGF	3
13	0437	CAP SCR 0.25-20X1.25 HHGR5	9
14	0220	CAP SCR 0.25-20X1.50 HHGR5	3
15	96569	TUBE ASM 0.38X66.00 MAIN BOOM 13500 YZ	6
16	96568	TUBE ASM 0.50X66.00 MAIN BOOM 13500 YZ	2
17	104020	FTG 4-2 PTC-MP 90 GREASE LINE	2


Outer Cylinder Assembly - PN 61245



Outer Cylinder Assembly - PN 61245 Parts List

PN 61245			
ITEM	PART	DESCRIPTION	QTY
1	61244	CYLINDER 6.50X35.69	1
2	15995	MANIFOLD ASM DUAL T2A 5000PSI	1
3	1554	FTG 8-8 MFS-MORB STRAIGHT	2
4	C2252	FTG 8-10 MFS-MORB STRAIGHT	2
5	41496	TUBE ASM 0.50X14.16 23000 YZ	2
6	18701	CLAMP PORT TUBE ZR518	2
7	19370	HOSE CLAMP 5.63-8.50 5416K39	2
8	104021	FTG 2-2 MP-FP 45 GREASE LINE	1
9	104019	FTG 4-2 PTC-MP STRAIGHT GREASE LINE	1
10	104020	FTG 4-2 PTC-MP 90 GREASE LINE	1


Extension Boom Assembly - PN 128248



Extension Boom Assembly - PN 128248 Parts List

PN 128248			
ITEM	PART	DESCRIPTION	QTY
1	71546	OUTER BOOM 23000 V2	1
2	0865	BUSHING BPC48DXR32 3.00X2.00	2
3	17320	BUSHING 40DXR40 GARLOCK	2
4	38994	EXT BOOM 23000	1
5	41058	WEAR PAD 1.00X4.00X6.00	2
6	41059	WEAR PAD 3.00X4.00X1.75 NYLATRON	4
7	41060	WEAR PAD 3.00X4.00X1.38 NYLATRON	2
8	128719	CYLINDER ASM EXT 23000 V2 MANIFOLD	1
9	41061CR	PIN 2.50X7.25 D&T ZC	1
10	8377	PIN CAP 0.56X3.50X0.19 YZ	6
11	41062CR	PIN 2.50X12.88 D&T ZC	2
12	13315	PIN CAP 0.56X4.00X0.19 YZ	2
13	41064	PLATE WEAR PAD COVER 23000	6
14	5739	BUSHING 40DXR48 GARLOCK	2
15	70964	CLAMP 3 HOSE 0.38 HYD 28000	2
16	0343	WASHER 0.31 USS FLAT	4
17	0522	WASHER 0.31 LOCK	4
18	0488	CAP SCR 0.31-18X2.00 HHGR5	4
19	C6219	WASHER 0.75 SAE FLAT YELLOW GR8	24
20	4543	CAP SCR 0.75-10X2.00 HHGR8	24
21	D0790	WASHER 0.50 SAE FLAT YELLOW GR8	12
22	10172	CAP SCR 0.50-13X1.00 HHGR8	8
23	74115	PIN 3.00X13.75 D&T SS	1
24	10666	CAP SCR 0.50-13X1.25 HHGR8	4

Extension Cylinder Assembly- PN 128719




Extension Cylinder Assembly- PN 128719 Parts List

PN 128719			
ITEM	PART	DESCRIPTION	QTY
1	128718	CYLINDER 5.00X37.00	1
2	53516	MANIFOLD CBAL DOUBLE T2A SUN CBDD-LJN-XAJ	1
3	1556	FTG 8-8 MFS-MAORB 90	1
4	1554	FTG 8-8 MFS-MORB STRAIGHT	2
5	101386	TUBE ASM 0.50X4.39 YZ 23000 EXT EXTEND	1
6	128720	TUBE ASM 0.50X44.25 YZ 23000 EXT RETRACT	1
7	C0927	CAP SCR 0.31-18X2.25 HHGR5	2
8	101389	FTG 8-8 MFS-MAORB 90 LONG	1
9	104021	FTG 2-2 MP-FP 45 GREASE LINE	1
10	104019	FTG 4-2 PTC-MP STRAIGHT GREASE LINE	1

Stabilizer Assembly- PN 40453

BASE SHOWN AS REFERENCE


C-BALANCE VALVE C6184
CYLINDER SEAL KIT 35647
BASE END BUSHINGS 0635
ROD END BUSHINGS 4381
BUSHINGS INCLUDED IN 9994



Stabilizer Assembly- PN 40453 Parts List

PN 40453			
ITEM	PART	DESCRIPTION	QTY
1	40450	OUTRIGGER 23000	2
2	40455	WEAR PAD 2.00X8.00X1.50	2
3	15502	OUTRIGGER LEG 28000	2
4	40837	OUTRIGGER PAD 23000 96IN	2
5	16266CR	PIN 2.00X8.19 D&T ZC	2
6	2257	SNAP RING INSIDE 2.00	4
7	0635	BUSHING 40DXR32 GARLOCK	4
8	25574	BUSHING 40DXR20 2.50X1.25	4
9	10180	PLATE WEAR PAD COVER 28000	2
10	C5902	WASHER 0.63 SAE FLAT YELLOW GR8	12
11	C1025	CAP SCR 0.63-11X2.00 HHGR8 ZY	12
12	44517CR	PIN 2.50X13.63 D&T ZC	2
13	8377	PIN CAP 0.56X3.50X0.19 YZ	12
14	D0790	WASHER 0.50 FLAT GR8	12
15	10172	CAP SCR 0.50-13X1.00 HHGR8 ZY	12
16	40459CR	PIN 2.50X14.88 D&T ZC	2
17	9996CR	PIN 2.50X9.38 D&T ZC	2
18	13343	BUSHING 40DXR16 GARLOCK	4
19	8819	BUSHING QSI-3235-16	4
20	17320	BUSHING 40DXR40 GARLOCK	4
21	9994	CYLINDER 4.00X50.00	2
22	40456	CYLINDER ASM 5.00X19.25	1
23	40456	CYLINDER ASM 5.00X19.25	1
24	58052	SET SCREW 0.50-13X0.50	4

Stabilizer Cylinder Assembly- PN 40456




NOTES:

C-BALANCE VALVE C6184
CYLINDER SEAL KIT C6312
BUSHING PART NUMBER 0635
BUSHINGS INCLUDED IN 40457

Stabilizer Cylinder Assembly- PN 40456 Parts List

PN 40456			
ITEM	PART	DESCRIPTION	QTY
1	40457	CYLINDER 5.00X19.25	1
2	15822	MANIFOLD DOUBLE T11A 5000 PSI	1
3	279	FTG 6-6 MFS-MORB STRAIGHT	4
4	41343	TUBE ASM 0.38X7.06 YZ	2


Reservoir Assembly - PN 86356



Reservoir Assembly - PN 86356 Parts List

PN 86356			
ITEM	PART	DESCRIPTION	QTY
1	86357	RSRVR 45 GAL V2 23/28	1
2	11442	PLATE COVER TANK HEATER FLANGE	1
3	0479	CAP SCR 0.25-20X0.75 HHGR5	12
4	0340	WASHER 0.25 USS FLAT	12
5	11149	GASKET ARCTIC FOX HEATER #A-611	1
6	71411	FTG HOSE 6-6 PL-MP 90 BRASS	1
7	15463	THERMO SIGHT GAUGE ZINGA SG-O5-A-T-N	1
8	85928	FILTER TANK TOP 20 FORB	1
9	47858	HOSE 1.25(881-JC-JC-20-20-20-26)	1
10	123756	SWITCH TEMP NC TT-F5B-170R-PD	1
11	51275	FTG 20-16 MFS-MAORB 90	1
12	C2126	PLUG 0.75 NPT SQ HD MAGNETIC	1
13	C6327	FILTER STRAINER 35GAL TF-2030	1
14	C5552	FILTER STRAINER TFS-1220-0	1
15	C4907	BUSHING 2.00X1.25 BLK	1
16	C1057	FTG 20-20XCLOSE MP-MP NIPPLE STRAIGHT BLK	2
17	C5511	VALVE BALL 1.25	2
18	C4694	ST EL 1.25 90 DEG BLK	2
19	C2282	FTG 1.25 NPT TO 1.25 BARB	2
20	19799	FTG 20-16 MFS-MORB STRAIGHT	1
21	64517	FTG 20-20-20 MFS-FFSS-MFS RUN TEE	1
22	73633	FTG 20-12 FFSS-MFS STRAIGHT	1
23	0492	CAP SCR 0.38-16X0.75 HHGR5	4
24	C0922	CAP SCR 0.31-18X1.00 HHGR5	4
25	0343	WASHER 0.31 USS FLAT	8
26	0342	NUT 0.31-18 HHGR5 NYLOC	4
27	0501	CAP SCR 0.50-13X2.00 HHGR5	6
28	0519	WASHER 0.44 USS FLAT	12
29	C6106	NUT 0.50-13 HHGR5 NYLOC	6
30	81018	CAP FILL NO RELIEF ZINGA THREADED	1
31	58396	GASKET RG-11 TANK TOP FILTER	1
32	13002	DECAL HYD OIL SPECIFICATION MOBIL	1
33	42971	DECAL OIL FILTER CHANGE	1
34	85790	COOLER OIL MAR-32	1
35	64276	FTG 20-20 MFS-MAORB 90	1
36	C5946	HOSE CLAMP #8 RUBBER COATED	2
37	0335	CAP SCR 0.38-16X1.25 HHGR5	2
38	D1942	FTG 4-4 MFS-MP STRAIGHT	1
39	C4903	FTG 12-12 MFS-FFSS 90	1

Optional 15 Ton Hook Kit - PN 55139



Optional 15 Ton Hook Kit - PN 55139 Parts List

PN 55139			
ITEM	PART	DESCRIPTION	QTY
1	38994	EXT BOOM 23000	1
2	41499	HOOK 15 TON SWIVEL CROSBY 1028654	1
3	44069	COLLAR 1.78X3.00X1.19 PC BLACK	2
4	9142	PIN CAP 0.56X2.50X0.19 YZ	1
5	10172	CAP SCR 0.50-13X1.00 HHGR8 ZY	1
6	41066CR	PIN TEAR DROP 1.75X6.56 ZC	1
7	D0790	WASHER 0.50 FLAT GR8	1

Radio Transmitter - PN 89149/93084



PN 89149/93084


ITEM	PART	DESCRIPTION	QTY
1	95026	2-WAY MOMENTARY TOGGLE SWITCH	1
2	95027	TOGGLE SWITCH RUBBER BOOT	3
3	95025	SWITCH PADDLE SCANRECO (LABEL KIT INCLUDED)	6
4*	89474	3-WAY MOMENTARY TOGGLE SWITCH	2
5	95030	E-STOP SWITCH	1
6	95028	PUSH BUTTON START SWITCH	1
7	95029	PUSH BUTTON SWITCH BOOT	1

* "OPTION" switch may or may not be active depending on factory settings; additional functionality dependent on user.

This page intentionally left blank.

Transmitter Docking Station Asm (Opt.) - PN 97334

SCANRECO BELLY BOX G2B-MINI



Transmitter Docking Station (Opt.) - PN 97334 Parts List

PN 97334			
ITEM	PART	DESCRIPTION	QTY
1	97470	BRKT RADIO STOW SCANRECO 89149/89150	1
2	26288	LIGHT INDICATOR RED FORCE PTO	1
3	26031	BACKUP ALARM PIEZO JAMECO 123537	1
4	C6072	RELAY BOSCH 20-30 AMP	1
5	66413	SWITCH SPRING ROD OMRON Z-15GNJ55	1
6	66411	ANGLE AL SWITCH MOUNT DOCK STATION HET NOVA	1
7	D1711	CAP SCR #10-24X0.50 BTNHD SS	1
8	C4956	NUT #10-24 HH NYLOC SS	3
9	59075	CAP SCR #10-24X0.63 BTNHD ZC	2
10	66412	SCREW #8-32X1.25 BTNHD SS	2
11	22186	NUT #8-32 HH NYLOC SS	2
12	66416	DECAL DOCKING STATION HET NOVA 41922	1
13	17162	WEATHERSTRIP RIBBED 0.38X0.13	3.5


PARTS NOT SHOWN		
PART	DESCRIPTION	QTY
65989	WIRING DIAGRAM DOCKING STATION 65984	1
C0072	TERML RING #10 16-14GA	6
C0080	TERML QC F 0.19 16-14GA 0.20 TAB FULLY INS	4
C2607	TERML QC PIGGYBK 0.25 16-14GA	1
C4689	WIRE 14GA (RM) RED SAE J-1128	1.5
C4691	WIRE 14GA (RM) BLACK SAE J-1128	3
C4860	DECAL BALLAST MSTR OPERATION	1

Wiring Diagram Docking Station - PN 65989

NEGATIVE BRAKE SIGNAL

NOTE:


FOR AIR BRAKE SYSTEMS, THE RELAY WIRING IS NOT REQUIRED. INSTEAD, CONNECT A 16GA WIRE FROM THE "N/O" TERMINAL ON THE SAFETY GROUND HOBBS SWITCH TO THE "COM" TERMINAL ON THE DOCKING STATION SWITCH.



POSITIVE BRAKE SIGNAL

NOTE:

FOR AIR BRAKE SYSTEMS, THE RELAY WIRING IS NOT REQUIRED. INSTEAD, CONNECT A 16GA WIRE FROM THE "N/O" TERMINAL ON THE SAFETY GROUND HOBBS SWITCH TO THE "COM" TERMINAL ON THE DOCKING STATION SWITCH.





Subject to Change without Notification.
© 2025 Stellar Industries, Inc.