



- U.S.A. : **KUBOTA TRACTOR CORPORATION**
3401 Del Amo Blvd., Torrance, CA 90503, U.S.A.
Telephone : (310)370-3370
- Western Division : 1175 S. Guild Av., Lodi, CA 95240
Telephone : (209)334-9910
- Central Division : 14855 FAA Blvd., Fort Worth, TX 76155
Telephone : (817)571-0900
- Northern Division : 6300 at One Kubota Way, Groveport, OH 43125
Telephone : (614)835-1100
- Southeast Division : 1025 Northbrook Parkway, Suwanee, GA 30024
Telephone : (770)995-8855
- Canada : **KUBOTA CANADA LTD.**
5900 14th Avenue, Markham, Ontario, L3S 4K4, Canada
Telephone : (905)294-7477
- France : **KUBOTA EUROPE S.A.S**
19-25, Rue Jules Vercurysse, Z.I. BP88, 95101 Argenteuil Cedex, France
Telephone : (33)1-3426-3434
- Italy : **KUBOTA EUROPE S.A.S Italy Branch**
Via Grandi, 29 20068 Peschiera Borrome (MI) Italy
Telephone : (39)02-51650377
- Germany : **KUBOTA (DEUTSCHLAND) GmbH**
Senefelder Str. 3-5 63110 Rodgau /Nieder-Roden, Germany
Telephone : (49)6106-873-0
- U.K. : **KUBOTA (U.K.) LTD.**
Dormer Road, Thame, Oxfordshire, OX9 3UN, U.K.
Telephone : (44)1844-214500
- Spain : **KUBOTA ESPAÑA S.A.**
Avenida Recomba No.5, Poligno Industrial la Laguna, Leganes, 28914 (Madrid) Spain
Telephone : (34)91-508-6442
- Australia : **KUBOTA TRACTOR AUSTRALIA PTY LTD.**
25-29 Permas Way, Truganina, VIC 3029, Australia
Telephone : (61)-3-9394-4400
- Malaysia : **SIME KUBOTA SDN. BHD.**
No.3 Jalan Sepadu 25/123 Taman Perindustrian Axis,
Seksyen 25, 40400 Shah Alam, Selangor Darul Ehsan Malaysia
Telephone : (60)3-736-1388
- Philippines : **KUBOTA PHILIPPINES, INC.**
232 Quirino Highway, Baesa, Quezon City 1106, Philippines
Telephone : (63)2-422-3500
- Taiwan : **SHIN TAIWAN AGRICULTURAL MACHINERY CO., LTD.**
16, Fengping 2nd Rd, Taliiao Shiang Kaohsiung 83107, Taiwan R.O.C.
Telephone : (886)7-702-2333
- Indonesia : **PT KUBOTA MACHINERY INDONESIA**
Tower A at EightyEight@Kasablanka Lantai 16
Jalan Raya Casablanka Kav. 88, Jakarta 12870 Indonesia
Telephone : (62)-21-29568-720
- Thailand : **SIAM KUBOTA CORPORATION CO., LTD.**
101/19-24 Moo 20, Navanakorn Industrial Estate, Tambon Khlongnueng, Amphur Khlongluang,
Pathumthani 12120, THAILAND
Telephone : (66)2-909-0300
- Korea : **KUBOTA KOREA CO., LTD.**
41-27, Jayumyeok-gil, Baeksan-myeon, Gimje-si, Jeollabuk-do, Korea
Telephone : (82)-63-544-5822
- India : **KUBOTA AGRICULTURAL MACHINERY INDIA PVT. LTD.**
No.15, Medavakkam Road, Sholinganallur, Chennai-600119, T.N., India
Telephone : (91)44-6104-1500
- Vietnam : **KUBOTA VIETNAM CO., LTD.**
Lot B-3A2-CN, My Phuoc 3 Industrial Park, Ben Cat District, Binh Duong Province, Vietnam
Telephone : (84)-650-3577-507

KUBOTA Corporation

English (U.S.A.)
Code No. TD350-7956-2

OPERATOR'S MANUAL

KUBOTA TRACTOR

MODELS **L3560·L4060·L4760**
L5460·L6060



1AGAXAAP043A

L
3
5
6
0
·
L
4
0
6
0
·
L
4
7
6
0
·
L
5
4
6
0
·
L
6
0
6
0

ABBREVIATION LIST

Abbreviations	Definitions
2WD	2 Wheel Drive
4WD	4 Wheel Drive
API	American Petroleum Institute
ASABE	American Society of Agricultural and Biological Engineers, USA
ASTM	American Society for Testing and Materials, USA
DIN	Deutsches Institut für Normung, GERMANY
DT	Dual Traction [4WD]
fpm	Feet Per Minute
GST	Glide Shift Transmission
Hi-Lo	High Speed-Low Speed
HST	Hydrostatic Transmission
m/s	Meters Per Second
PTO	Power Take Off
RH/LH	Right-hand and left-hand sides are determined by facing in the direction of forward travel
ROPS	Roll-Over Protective Structures
rpm	Revolutions Per Minute
r/s	Revolutions Per Second
SAE	Society of Automotive Engineers, USA
SMV	Slow Moving Vehicle

California Proposition 65

▲ WARNING ▲

Engine exhaust, some of its constituents, certain vehicle components and fluids, contain or emit chemicals known to the State of California to cause cancer and birth defects or other reproductive harm.

KUBOTA Corporation is ...

Since its inception in 1890, KUBOTA Corporation has grown to rank as one of the major firms in Japan.

To achieve this status, the company has through the years diversified the range of its products and services to a remarkable extent, until today, 19 plants and 16,000 employees produce over 1,000 different items, large and small.

All these products and all the services which accompany them, however, are unified by one central commitment.

KUBOTA makes products which, taken on a national scale, are basic necessities. Products which are indispensable, products intended to help individuals and nations fulfill the potential inherent in their environment. For KUBOTA is the Basic Necessities Giant.

This potential includes water supply, food from the soil and from the sea, industrial development, architecture and construction, transportation.

Thousands of people depend on KUBOTA's know-how, technology, experience and customer service. You too can depend on KUBOTA.

FOREWORD

Thank you very much for choosing the L series tractor with CAB.

This operator's manual covers the operation, inspection and preventive maintenance instructions that are specific to the L series CAB models. For other information and instructions, refer to the separately issued operator's manual for their sister models.

Please read this manual carefully along with the tractor operator's manual, to operate the machine properly and safely.

Proper daily inspection, servicing and lubrication keeps your machine in good condition.

SAFETY FIRST

This symbol, the industry's "Safety Alert Symbol", is used throughout this manual and on labels on the machine itself to warn of the possibility of personal injury. Read these instructions carefully. It is essential that you read the instructions and safety regulations before you attempt to assemble or use this unit.



DANGER : Indicates an imminently hazardous situation which, if not avoided, will result in death or serious injury.



WARNING : Indicates a potentially hazardous situation which, if not avoided, could result in death or serious injury.



CAUTION : Indicates a potentially hazardous situation which, if not avoided, could result in minor or moderate injury.

IMPORTANT : Indicates that equipment or property damage could result if instructions are not followed.

NOTE : Gives helpful information.

CONTENTS

▲ SAFE OPERATION	▲ -1
SPECIFICATIONS	1
SPECIFICATION TABLE	1
CAB OPERATION	3
DOOR AND WINDOW	3
Locking and Unlocking the Door	3
Opening the Door	3
Rear Window	3
Side Window	4
Emergency Exit	4
DOME LIGHT	4
Dome Light	4
WORK LIGHT	4
Work Light Switch	4
Front Work Light	4
Rear Work Light (if equipped)	5
WIPER	5
Front Wiper / Washer Switch	5
Rear Wiper / Washer Switch (if equipped)	5
Using the Wipers in Cold Season	5
AIR CONDITIONER	5
Airflow	5
Air Control Vent	6
Control Panel	7
Operation	8
REAR / SIDE DEFOGGER WITH TIMER (if equipped)	10
ELECTRICAL OUTLET	10
Electrical Outlet	10
MAINTENANCE	11
SERVICE INTERVALS	11
PERIODIC SERVICE	12
DAILY CHECK	12
Cleaning Air Conditioner Condenser Screen	12
EVERY 200 HOURS	12
Cleaning Inner Air Filter	12
Cleaning Fresh Air Filter	12
Checking Air Conditioner Condenser	13
Adjusting Air-Conditioner Belt Tension	13
EVERY 1 YEAR	13
Checking Air-Conditioner Pipe and Hose	13
Checking CAB Isolation Cushion	13
EVERY 4 YEARS	13
Replacing Air Conditioner Hose	13
SERVICE AS REQUIRED	14
Lubricating Points	14

CONTENTS

Adding Washer Liquid..... 14
Checking the Amount of Refrigerant (gas) 14
APPENDICES..... 15
INDEX 15



SAFE OPERATION

Careful operation is your best insurance against an accident.

Read and understand carefully this section of the separately issued operator's manual before operating the tractor.

■ DANGER, WARNING AND CAUTION LABELS

(1) Part No. TD170-4933-1

▲ WARNING




BEFORE DISMOUNTING TRACTOR:

1. **ALWAYS SET PARKING BRAKE.**
Leaving transmission in gear with the engine stopped will not prevent tractor from rolling.
2. **PARK ON LEVEL GROUND WHENEVER POSSIBLE.**
If parking on a slope, position tractor across the slope.
3. **LOWER ALL IMPLEMENTS TO THE GROUND.**
Failure to comply to this warning may allow the wheels to slip, and could cause injury or death.
4. **STOP THE ENGINE.**

1AGAMAOAP079E


(2) Part No. TA040-4902-1

▲ WARNING



TO AVOID INJURY OR DEATH FROM ROLL-OVER:
Always use seat belt when driving.

1AGAMAOAP0780



1AGAXAAP049A

1AGAXAAP091A


(1) Part No. TD170-4938-1

▲ CAUTION

TO AVOID PERSONAL INJURY:

1. Read and understand the operator's manual before operation.
2. Before starting the engine, make sure that everyone is at a safe distance from the tractor and that the PTO is OFF.
3. Do not allow passengers on the tractor at any time.
4. Before allowing other people to use the tractor, have them read the operator's manual.
5. Check the tightness of all nuts and bolts regularly.
6. Keep all shields in place and stay away from all moving parts.
7. Lock the two brake pedals together before driving on the road.
8. Slow down for turns, or rough roads, or when applying individual brakes.
9. On public roads use SMV emblem and hazard lights, if required by local traffic and safety regulations.
10. Pull only from the drawbar.
11. Before dismounting, lower the implement to the ground, set the parking brake, stop the engine and remove the key.
12. Securely support tractor and implements before working underneath.

1AGAMAOAP0800



1AGAXAAP048A

1AGAXAAP092A

■ CARE OF DANGER, WARNING AND CAUTION LABELS

1. Keep danger, warning and caution labels clean and free from obstructing material.
2. Clean danger, warning and caution labels with soap and water, dry with a soft cloth.
3. Replace damaged or missing danger, warning and caution labels with new labels from your local KUBOTA Dealer.
4. If a component with danger, warning and caution label (s) affixed is replaced with new part, make sure new label (s) is (are) attached in the same location (s) as the replaced component.
5. Mount new danger, warning and caution labels by applying on a clean dry surface and pressing any bubbles to outside edge.

SPECIFICATIONS

SPECIFICATION TABLE

Model			L3560	L4060	L4760	L5460	L6060
			4WD				
Engine	Model		D1803-CR-E4	V2403-CR-E4		V2403-CR-TE4	
	Type		Direct injection vertical, water-cooled, 4-cycle diesel				
	Number of cylinders		3	4			
	Total displacement	L (cu. in.)	1.826 (111.4)	2.434 (148.5)			
	Bore and stroke	mm (in.)	87 x 102.4 (3.4 x 4.0)				
	Rated revolution	rpm	2600				
	Low idling revolution	rpm	800				
	Net power*	kW (HP)	26.1 (35.0)	29.8 (40.0)	35.1 (47.0)	40.3 (54.0)	44.8 (60.0)
	PTO power* (factory observed)	kW (HP)/ rpm	20.9 (28.0)/ 2600	24.2 (32.5)/ 2600	29.5 (39.5)/ 2600	34.7 (46.5)/ 2600	39.5 (53.0)/ 2600
	Maximum torque	N-m (ft-lbs.)	114.1 (84.2)	133.5 (98.5)	157.4 (116.1)	182.6 (134.7)	195.6 (144.3)
	Battery capacity		12V, RC: 133 min, CCA: 582A				
Capacities	Fuel tank	L (U.S.gals.)	51 (13.5)				
	Engine crankcase (with filter)	L (U.S.qts.)	6.7 (7.1)	8.2 (8.7)		9.4 (9.9)	
	Engine coolant	L (U.S.qts.)	7.5 (7.9)		8.2 (8.7)		
	Transmission case	L (U.S.gals.)	42 (11.1)	43 (11.4)		45 (11.9)	
Dimensions	Overall length (without 3p)	mm (in.)	2920 (115.0)	3085 (121.5)		3210 (126.4)	
	Overall width (min. tread)	mm (in.)	1520 (59.8)	1690 (66.5)		1710 (67.3)	
	Overall height	mm (in.)	2300 (90.6)	2315 (91.1)		2350 (92.5)	
	Wheel base	mm (in.)	1805 (71.1)	1895 (74.6)		1915 (75.4)	
	Min. ground clearance	mm (in.)	342 (13.5)	360 (14.2)		392 (15.4)	
	Tread	Front	mm (in.)	1155 (45.5)		1300 (51.2)	
		Rear	mm (in.)	1200 (47.2) 1300 (51.2) 1385 (54.5) 1480 (58.3)	1285 (50.6) 1435 (56.5) 1530 (60.2)		1325 (52.2) 1430 (56.3)
Weight (with CAB)		kg (lbs.)	1760 (3880)	1875 (4134)	1915 (4222)	1980 (4365)	

2 SPECIFICATIONS

Model			L3560	L4060	L4760	L5460	L6060
			4WD				
Traveling system	Standard tire size	Front	7-16	8.3-16		9.5-16	
		Rear	12.4-24	14.9-24		14.9-26	
	Clutch		---				
	Steering		Hydrostatic power steering				
	Transmission		Hydrostatic transmission (3 speeds)				
	Braking system		Wet disk type				
	Min. turning radius (with brake)	m (feet)	2.7 (8.9)			2.8 (9.2)	
Hydraulic unit	Hydraulic control system		Position control				
	Pump capacity	L (U.S.gals)/min.	30.4 (8.0)	35.6 (9.4)			
	3-point hitch		SAE category 1			SAE category 1, 2	
	Max. lift force	At lift points	kg (lbs.)	1700 (3750)	1750 (3860)		
		24 in. behind lift points	kg (lbs.)	1200 (2650)	1250 (2760)		1350 (2980)
	System pressure		MPa (kgf/cm ²)	17.7 (180)			
PTO	Rear PTO			SAE 1-3/8, 6 splines			
		PTO/Engine speed	rpm	540/2426	540/2476		540/2403
	MID-PTO (if equipped)			USA No.5 (KUBOTA 10-tooth) involute spline			
	PTO/Engine speed	rpm	2000/2451	2000/2502		2000/2429	

NOTE : *Manufacturer's estimate

The company reserve the right to change the specifications without notice.


CAB OPERATION

DOOR AND WINDOW

■ Locking and Unlocking the Door

From the outside Insert the key into the door lock. Turn the key clockwise to unlock the door. To lock the door, turn the key in the opposite direction. The key can be removed when it is in the vertical direction.

From the inside Push down the lock knob to lock the door. Pull up the lock knob to unlock the door.




1AGAWABAP007A

- (1) Inner door handle
- (2) Lock knob
- (A) "PULL"
- (B) "PUSH" (Lock)
- (C) "PULL" (Unlock)

■ Opening the Door

From the outside Unlock the door, and pull the outer door handle.




1AGAXAAP084A

- (1) Outer door handle
- (2) Door lock
- (A) "PULL"

From the inside Unlock the door and pull the inner door handle.

■ Rear Window

Turn the rear window handle clockwise to the vertical position and push the handle. The rear window is opened by the gas spring cylinder.




1AGAXAAP085A

- (1) Rear window handle
- (A) "OPEN"
- (B) "CLOSE"

Side Window

Pull the side window handle and push the side window to open the window.



(1) Side window handle

Emergency Exit


1. Open the right door of the cab if the left door is blocked, and vice versa in an emergency situation.
2. Exit through rear window if CAB doors are blocked in an emergency situation.

DOME LIGHT

Dome Light

Sliding the dome light switch will give the following light condition:

- OFF The light does not turn on when the door is opened.
- ON The light remains on regardless of the door position.




(1) Dome light
 (2) Dome light switch
 (A) "OFF"
 (B) "ON"

WORK LIGHT


Work Light Switch

Turn on the key switch and press the top half of the work light switch. The work light and the switch's indicator light up. Press the bottom half of the work light switch to turn off the light and indicator.




(1) Front work light switch
 (2) Rear work light switch (if equipped)
 (A) Indicator for work lights

Front Work Light



(1) Front work light

■Rear Work Light (if equipped)



(1) Rear work light


WIPER

■Front Wiper / Washer Switch

1. Turn on the key switch and press the top half of the wiper switch to the first step, and the wiper is activated. When the switch is pressed further to the second step, washer liquid jets out. The jetting continues while the switch is pressed and the wiper is activated continuously.
2. Press the bottom half of the wiper / washer switch, washer liquid only jets out.

■Rear Wiper / Washer Switch (if equipped)

See "Front wiper / Washer switch" section, for instructions to use this switch.



(1) Front wiper / washer switch
(2) Rear wiper / washer switch

IMPORTANT :

- Do not activate the wipers when the windows are dry, they may be scratched. Be sure to jet washer liquid first and then activate the wipers.

■Using the Wipers in Cold Season

1. While not used in cold season, keep the wiper blades off the windshield to prevent them from being stuck with ice.
2. If the windshield is covered with snow, scrape it off the windshield before using the wipers.
3. If the wiper blades are stuck on the windshield with ice and fail to move, be sure to turn the main key switch to "OFF" and remove the ice off the blades. Then place the main key switch back to "ON".
4. When commercially available cold-season wiper blades are used, make sure their size is the same as or smaller than that of the standard ones.


IMPORTANT :

- In cold season, the wiper blades and the wiper motor might get overloaded causing damage. To avoid this, be sure to take the above precautions.


AIR CONDITIONER

■Airflow

Air in the CAB and fresh air introduced into the CAB flow as shown below. Adjust the eight air ports to obtain the desired condition.



(1) Control panel
(2) Side air outlet (face area)
(3) Front air outlet
(4) Door air outlet
(A) Inner air recirculation




(A) Fresh air inlet

■ Air Control Vent

◆ Front air outlet

The front air outlets can be independently adjusted as required. To defrost the windshield, rotate the outlets toward the windshield.




(1) Front air outlet

- (A) "OPEN"
- (B) "CLOSED"
- (C) "WINDSHIELD"

◆ Side air outlet and door air outlet

The side and door air outlets can be adjusted to direct air on to the operator, door window or the rear of the CAB.



- (1) Side air outlet
- (2) Door air outlet

NOTE :


- If the airflow rate at the face is too low, close the door air outlet.

CAUTION

To avoid personal injury;

- Replace the water hoses every 2 years.
- Daily inspection
Have the tractor repaired immediately if any of the following defects are discovered. (Such defects may cause burns or injury. They may also cause engine seizure or other serious failure.)
 - Scratches, cracks or swelling in water hoses.
 - Water leakage at water hose joints.
 - Missing or damaged water hose protective wrap or grommets.
 - Loose mounting bolts, damaged brackets.
- Do not touch the water hoses and the heater with your hand. You may get burned.
- If the window fails to defrost in extreme conditions or becomes cloudy when dehumidifying the CAB, wipe off moisture with a soft cloth.
- Do not block all the air outlets of the air conditioner. A problem could occur.

Control Panel



- (1) Temperature control dial (A) "WARM"
- (2) Recirculation / fresh air selection switch (B) "COOL" with indicator light
- (3) Air conditioner switch with indicator light
- (4) Blower switch

Temperature Control Dial

Set this dial at the desired position to obtain the optimum air temperature. Turn the dial in the "WARM" direction to obtain warmer air. Turn it in the "COOL" direction to obtain cooler air.

Blower Switch

Air volume can be changed in 4 steps. At the "4" position, the largest air volume is obtained.

Air Conditioner Switch

Push this switch to activate the air conditioner. An indicator light will light up when the switch is set to "ON". Push the switch again to turn the air conditioner off, in which case the indicator light will be off.

NOTE :

- With the blower switch at the "OFF" position, the indicator light will not light up even when the air conditioner switch is set to "ON".

IMPORTANT :


- To operate the air conditioner after the tractor has not been used for one week or longer, run the engine at idling speed first and then set the air conditioner switch to "ON". Keep this for one minute or so. If the air conditioner switch is set to "ON" with the engine running at high rpm, the compressor may get in trouble.

Recirculation / fresh air selection switch

Each time the switch is pressed, the air flow position changes for "RECIRCULATION" or "FRESH AIR". An indicator light will light up when the switch is set to "RECIRCULATION". And the indicator light will be off when the switch is set to "FRESH AIR".

FRESH AIR: Fresh air will flow into the CAB. (Indicator: OFF) This is helpful when you work in dusty conditions or if the glass windows get foggy.

RECIRCULATION: In-CAB air will be recirculated. (Indicator: ON) This is useful for cooling or heating the CAB quickly or keeping it extra cool or warm.



- (1) Recirculation / fresh air selection switch with indicator light (A) "RECIRCULATION"
- (B) "FRESH AIR"


NOTE :

- When heating, do not keep the switch at the "RECIRCULATION" position for a long time. The windshield easily gets foggy.
- While working in a dusty conditions, keep the switch at the "FRESH AIR" position. This increases the pressure in the CAB, which helps prevent dust from coming into the CAB.

■ Operation


◆ Heating

1. Set the recirculation / fresh air selection switch to the "FRESH AIR" position. To raise the temperature in the CAB quickly, set this switch to the "RECIRCULATION" position.
2. Adjust the blower switch and the temperature control dial to achieve a comfortable temperature level.



1AGAXAAP042C

- (1) Temperature control dial
- (2) Recirculation / fresh air selection switch with indicator light
- (3) Blower switch




1AGAXAAP039G

◆ Cooling or dehumidifying-heating

1. Set the recirculation / fresh air selection switch to the "FRESH AIR" position. To lower the temperature in the CAB quickly, set this switch to the "RECIRCULATION" position.
2. Press and turn on the air-conditioner switch with indicator.
3. Turn on the blower switch.
4. Adjust the temperature control dial to the "COOL" or an intermediate position to achieve a comfortable temperature level.


NOTE :

- In summer when the heater is not used, keep the temperature control dial at the max "COOL" (end of counterclockwise) position. Otherwise, hot air will raise the temperature in the CAB.



1AGAXAAP042B


- (1) Temperature control dial
 - (2) Recirculation / fresh air selection switch with indicator light
 - (3) Air conditioner switch with indicator light
 - (4) Blower switch
- (A) "WARM"
(B) "COOL"




1AGAXAAP039G

◆ **Foot warming and head cooling**

1. In the cooling or dehumidifying-heating mode, set the temperature control dial at the center position area.
2. Open the front air outlet and the door air outlet direct it to your feet. Close the side air outlet.
3. You can feel your head cool and your feet warm.



(1) Temperature control dial (A) Center position area




(A) "OPEN"
(B) "CLOSED"


◆ **Defrosting or demisting**

To defrost or demist the windshield, take the following steps.

1. Open the front air outlet and the door air outlet direct it to the windshield. Close the side air outlet.
2. Set the recirculation / fresh air selection switch to the "FRESH AIR" position.
3. Set the blower switch and the temperature control dial to the "4" and max "WARM" (end of clockwise) positions, respectively.





(1) Temperature control dial (A) "WARM"
(2) Recirculation / fresh air selection switch with indicator light



(A) "OPEN"
(B) "CLOSED"

REAR / SIDE DEFOGGER WITH TIMER (if equipped)

To activate the rear / side window defoggers, press the switch marked  while the key switch is in the "ON" position. Then, the yellow light on the switch turns on. After about 15 minutes, the defoggers automatically turn off as well as the yellow light. To turn the defogger off, press the switch once more.



- (1) Defogger switch
(2) Yellow light


IMPORTANT :

- The battery will discharge if the defogger and the key switch remain in the "ON" or "ACC" positions with the engine stopped.
Always use the defogger with the engine running.

ELECTRICAL OUTLET

■ Electrical Outlet

A electrical outlet is supplied for use with implement.



- (1) Accessory electrical outlet (Total 20 A)

MAINTENANCE

SERVICE INTERVALS

(Only the Check Points for Tractors with CAB)

No.	Items		Daily	Indication on hour meter								Interval	Ref. page
				100	200	300	400	500	600	700	800		
1	Clogging of air conditioner condenser screen	Clean	○										12
2	Tension of air conditioner drive belt	Adjust			○		○		○		○	every 200 Hr	13
3	Clogging of inner air filter	Clean			○		○		○		○	every 200 Hr	12
4	Clogging of fresh air filter	Clean			○		○		○		○	every 200 Hr	12
5	Clogging of air conditioner condenser	Check			○		○		○		○	every 200 Hr	13
6	Air conditioner pipes and hoses	Check										every 1 year	13
		Replace											every 4 years
7	CAB isolation cushion	Check										every 1 year	13
8	Washer liquid	Check										service as required	14
9	Amount of refrigerant (gas)	Check										service as required	14

PERIODIC SERVICE

DAILY CHECK

■ Cleaning Air Conditioner Condenser Screen




WARNING

To avoid personal injury or death:

- Be sure to stop the engine before removing the screen.
- The condenser and receiver become hot while the air conditioner is running. Before checking or cleaning them, wait enough until they cool down.

1. Detach the air conditioner condenser screen and remove all foreign materials.



(1) Air conditioner condenser screen

IMPORTANT :


- Grill and screen must be clean from debris to prevent engine from overheating and to allow good air intake for air cleaner.

EVERY 200 HOURS

■ Cleaning Inner Air Filter

Press the inner air filter in the arrow-marked directions to unlock it and remove the inner filter, and blow air from the direction opposite to the filter's normal air flow.

Pressure of compressed air must be under 205 kPa (2.1 kgf/cm², 30 psi).




(1) Inner air filter

(A) "PUSH"

■ Cleaning Fresh Air Filter

Remove the knob bolts and pull out filter.



(1) Fresh air filter

(A) Air inlet port

(2) Cover

(3) Knob bolt

NOTE :


- Attach the filter and cover as the illustration above.

◆ **Cleaning the air filter**

- Normal use
Blow air from the opposite direction to the filter's normal air flow.
Pressure of compressed air must be under 205 kPa (2.1 kgf/cm², 30 psi).

IMPORTANT :

- Do not hit the filter. If the filter becomes deformed, dust may enter into the air-conditioner, which may cause damage and malfunction.



(A) "AIR CONDITIONER AIRFLOW"

NOTE :


- If the filter is very dirty:
Dip the filter in lukewarm water with mild dish washing detergent.
Move it up and down as well as left and right to loosen dirt. Rinse the filter with clean water and let it air-dry.

IMPORTANT :

- Do not use gasoline, thinner or similar chemicals to clean the filter as damage to the filter may occur.
- It may also cause an unpleasant odor in the CAB when the system is used next.

■ **Checking Air Conditioner Condenser**

Check air conditioner condenser to be sure it is clean of debris.



(1) Air conditioner condenser

■ **Adjusting Air-Conditioner Belt Tension**




To avoid personal injury or death:

- Be sure to stop the engine before checking belt tension.

Proper air-conditioner belt tension	A deflection of between 10 to 12 mm (0.4 to 0.48 in.) when the belt is pressed (98 N [10 kgf, 22.1 lbs.]) in the middle of the span.
-------------------------------------	--

1. Stop the engine and remove the key.
2. Apply moderate thumb pressure to belt between pulleys.
3. If tension is incorrect, loosen the tension pulley mounting nut and turn the adjusting bolt to adjust the belt tension within acceptable limits.
4. Replace air-conditioner belt if it is damaged.



(1) Adjusting bolt

(A) Check the belt tension

(2) Tension pulley mounting nut

EVERY 1 YEAR

■ **Checking Air-Conditioner Pipe and Hose**

1. Check to see that all lines and hose clamps are tight and not damaged.
2. If hoses and clamps are found worn or damaged, consult your local KUBOTA Dealer for this service.

■ **Checking CAB Isolation Cushion**

Check the cushion for any breakage or fatigue. Replace them if they are deteriorated.


EVERY 4 YEARS

■ **Replacing Air Conditioner Hose**

Consult your local KUBOTA Dealer for this service.

SERVICE AS REQUIRED


■ Lubricating Points



- (1) Door hinge
- (2) Rear window hinge

■ Adding Washer Liquid

Add a proper amount of automobile washer liquid.



- (1) Washer liquid tank

Washer tank capacity	2.0 L (2.1 U.S.qts.)
----------------------	----------------------

■ Checking the Amount of Refrigerant (gas)



WARNING

To avoid personal injury or death:


- Liquid contact with eyes or skin may cause frostbite.
- In the event of a leakage, wear safety goggles. Escaping refrigerant can cause severe injuries to eyes.
- In contact with a flame, R134a refrigerant gives a toxic gas.

- Do not disconnect any part of the refrigeration circuit of the air conditioning system. Consult your local KUBOTA Dealer for assistance and service.




A shortage of refrigerant impairs the air-conditioner performance. Check the following points. If it is indicated that the amount of refrigerant is extremely low, ask your dealer to inspect and charge.

◆ Checking procedure

1. Run the air-conditioner in the following conditions.
 - Engine speed: About 1500 rpm
 - Temperature control dial: Maximum cooling position
 - Fan switch: Highest blow (HI)
 - Air-conditioner switch: ON
2. Look into the sight glass to see if the refrigerant is flowing through its circuit.



- (1) Sight glass

	Proper	Little or no air bubbles in the refrigerant flow.
	Low	Lots of air bubbles in the refrigerant flow (air bubbles or foam passing continuously).
	Overfull or no refrigerant	Colorless and transparent.

1AGAMAOP077A

IMPORTANT :

- Charge only with R134a not R12 refrigerant (gas).

APPENDICES

INDEX

Air Conditioner Condenser	13
Air Conditioner Condenser Screen.....	12
Air Conditioner Hose	13
Air Control Vent.....	6
Air-Conditioner Belt Tension	13
Air-Conditioner Pipe and Hose.....	13
Airflow.....	5
CAB Isolation Cushion	13
Control Panel.....	7
Dome Light.....	4
Door.....	3
Door.....	3
Electrical Outlet	10
Emergency Exit	4
Fresh Air Filter.....	12
Front Wiper / Washer Switch.....	5
Front Work Light.....	4
Inner Air Filter.....	12
Lubricating Points.....	14
Operation.....	8
Rear Window.....	3
Rear Wiper / Washer Switch (if equipped)	5
Rear Work Light (if equipped)	5
Refrigerant (gas)	14
Side Window	4
Washer Liquid	14
Wipers in Cold Season.....	5
Work Light Switch.....	4