

# RA2072 / RA2072 Hydro

## Operator's manual Original operator's manual

Edition	01.2018
Date of print	09.2019
Language	EN
Machine number	VF69671582 –
Model	VF6967
Document number	A131785140

# Machine identification

In order for your dealer to assist you as efficiently as possible, you will need to provide some information about your machine. Please enter the details here.

Designation	RA2072 / RA2072 Hydro
Working width	6.20 - 7.30 m
Weight	1,640 kg
Machine number	VF6967 _ _ _ _ _
Accessories	
Address of supplier	
Address of manufacturer	Kverneland Group Kerteminde AS Taarupstrandvej 25 DK-5300 Kerteminde Denmark  Tel: +45 65 19 19 00

# Table of contents

<b>Preface</b> .....	<b>4</b>	<b>Preparations on the field</b> .....	<b>65</b>
Target group for this operating manual	4	Safety	65
Symbols used	5	General	66
<b>Safety</b> .....	<b>7</b>	Folding the machine into the work position	67
For your safety	7	<b>Operation</b> .....	<b>71</b>
Warning signs	8	Safety	71
Who is allowed to operate the machine?	11	General	72
General safety information	11	Swathing	73
Coupling	15	Swath deposit	74
Hydraulics	16	Adjusting the swath width	76
Road transport	17	Driving on headlands	76
Operation	19	<b>Cleaning and care</b> .....	<b>77</b>
Uncoupling	20	Safety	77
Care and maintenance	21	General	78
Further regulations	23	Cleaning	78
<b>Getting to know the machine</b> .....	<b>24</b>	Care	78
Range of application	24	<b>Parking and storage</b> .....	<b>79</b>
Features	24	Setting down the machine in a secure position	79
Designation of components	25	General	79
Technical specifications	26	Uncoupling and securing the machine	80
Pilotbox – Hydro version	30	Locking and securing	81
Function overview	31	After the end of the season	81
<b>Delivery and assembly</b> .....	<b>36</b>	<b>Maintenance</b> .....	<b>82</b>
Checking the scope of delivery	36	Safety	82
Checking the machine	37	General	83
Checking the tandem axles [+]	37	Screwed connections	86
PTO shaft length	38	Lubrication points for grease	89
Checking the steering	40	Lubricating the PTO shafts	89
<b>Coupling the machine</b> .....	<b>41</b>	Filling quantities	91
Safety	41	Tyres	92
General	41	Hydraulics	93
Coupling the lower link	42	Checking the track	95
Swivelling in the parking stand	43	<b>Accessories</b> .....	<b>96</b>
Coupling the PTO shaft	44	Additional equipment	96
Wheel chocks	45	<b>Fault elimination</b> .....	<b>98</b>
Connections	46	Faults	98
<b>Preparing for use</b> .....	<b>50</b>	Emergency manual function	100
Safety	50	<b>Circuit diagrams</b> .....	<b>101</b>
General	51	Hydraulic circuit diagram	101
Adjusting the machine	51	Pilotbox circuit diagram	103
Frame pitch	52	Lighting circuit diagram	104
Rotor pitch	53	<b>Decommissioning</b> .....	<b>105</b>
Working depth	57	Disposal	105
<b>Road transport</b> .....	<b>58</b>	<b>Original EC Conformity Declaration</b> .....	<b>106</b>
Safety	58	Conforms to EC Directive 2006/42/EC	106
General	59	<b>Index</b> .....	<b>107</b>
Prior to road transport	60		
Road transport	64		

## Target group for this operating manual



### **Simplified illustrations for better understanding**

Illustrations of the machine in the operator's manual are shown without protective equipment – or with the protective equipment open – for better understanding. Be sure to observe the safety information and follow the handling instructions in the operator's manual. Serious or fatal injury may be caused as a result.

This operator's manual is intended for trained agriculturists and persons who are otherwise qualified for agricultural activities and have received instruction in working with this machine.

### **For your safety**

You must familiarise yourself with the contents of this operating manual before assembly or initial operation of the machine. In this way, you will achieve optimum work results and operational safety. The operating manual forms an integral part of the machine and must always be kept to hand. This will ensure that you:

- avoid accidents.
- comply with warranty conditions.
- have a fully functional machine in good working order at all times.

## Training and instruction

You will receive training from your dealer concerning using the controls and care of the machine.

### **Information for the employer**

All personnel are to be regularly, but at least once a year, instructed on the use of the machine, in accordance with the regulations of the national organisation for Health and Safety at Work. Untrained or unauthorised persons are not permitted to use the machine.

You are responsible for ensuring that the machine is operated and maintained safely. Make sure that you and all other persons that operate, maintain or work in close proximity with the machine are familiar with the operating and maintenance regulations, as well as the corresponding safety instructions in this operator's manual.

## Symbols used

In this operator's manual, the following symbols and terms have been used:

- A bullet point accompanies each item in a list.
- ▶ A triangle indicates operating functions which must be performed.

→ An arrow indicates a cross-reference to other sections of this manual.

[+] A plus sign indicates additional equipment which is not included in the standard version.



The warning triangle indicates warning information. Failure to observe these safety instructions can result in:

- Moderate to serious injury
- Fatal injury

The warning information in the operator's manual is specifically associated with individual operations and instructions. It is important to observe the warning information before these operations are carried out.

In the »Safety« chapter, you will also find safety information which is not related to individual operations, but rather is designed to encourage safety-conscious behaviour in various situations.



The information triangle indicates important information. Failure to observe these safety instructions can result in:

- Serious faults in the correct operation of the machine
- Damage to the machine

We have also used pictograms to help you find instructions more quickly:



The "Information" pictogram indicates tips and additional information.



The "Examples" pictogram indicates examples that assist understanding of the instructions.

# Preface



The spanner indicates tips for assembly or adjustment work.



This arrow in the diagram shows the direction of travel.



The brush indicates the points that must be lubricated using the brush.




The grease gun indicates the points that must be lubricated using the grease gun.



▶ Switch on the tractor engine.



▶ Switch off the tractor engine, put the parking brake in the park position, remove the ignition key and secure the tractor against rolling away.



Open the ball valve.



Close the ball valve.



Switch the pilotbox on.



Switch off the pilotbox.



## For your safety

Familiarise yourself with your equipment and its limitations. Read the entire manual before attempting to put the machine into operation and to use it.

This chapter contains general safety instructions. Each chapter of the operator's manual contains additional specific safety information which is not described here. Observe the safety information:

- in the interest of your own safety.
- in the interest of the safety of others.
- to ensure the safety of the machine.

Numerous risks can result from handling agricultural machinery in the wrong way. Therefore, always work with particular care and never under time pressure.

### **Information for the employer**

Persons who work with the machine must be regularly informed of the safety information in this operator's manual. Staff must also be regularly trained in accordance with statutory regulations regarding occupational health and safety. Untrained or unauthorised persons are not permitted to use, maintain, repair or service the machine.


# Safety



## Warning signs

Safety-related stickers attached to the machine indicate potential hazards. The stickers must not be removed. Illegible or missing stickers should be replaced. You can obtain new stickers as replacement parts from your dealer.

## Warning signs on the machine







## Meaning of the warning signs



### **Read the operator's manual**

Read and follow the operating and safety instructions before using the machine for the first time. The machine must not be used for the first time until the operator's manual has been read and understood. This applies in particular to the safety information. Otherwise, serious or fatal injury may be caused as a result.



### **Switch off the engine**

Only perform maintenance, repair and adjustment work when the machine is shut down. Otherwise, serious or fatal injury may be caused as a result.



### **Distance from the rotor**

Maintain a safe distance from the rotor when it is rotating. Nobody may remain in close proximity to the machine when tedders and rakes are running. Otherwise, serious or fatal injury may be caused as a result.



### **Distance from the tractor**

When the machine is being coupled, uncoupled or operated, there should be no-one between the tractor and the machine. Otherwise, serious or fatal injury may be caused as a result.



### **Risk of crushing**

Never reach into an area where there is a risk of crushing if parts in that area are still likely to move. Otherwise, serious or fatal injury may be caused as a result.



### Caution, parts ejected at speed

Hazard caused by parts which may become detached when the drive is in operation, and ejected at speed. Maintain a safe distance. Otherwise, serious or fatal injury may be caused as a result.



### No persons within the slewing range

There is an acute risk of injury within the slewing range from machine parts which are slewing or folding. Otherwise, serious or fatal injury may be caused as a result.



### Caution, high voltage

Maintain a sufficiently safe distance from high-voltage lines. Otherwise, serious or fatal injury may be caused as a result.



### Secure the machine with wheel chocks

Always secure the machine with wheel chocks to ensure it cannot roll away when it is in park or stop position. Otherwise, serious or fatal injury may be caused as a result.



### PTO shaft speed 540 rpm

The specified maximum PTO shaft speed of 540 rpm must not be exceeded. Otherwise, damage to the machine may be caused as a result.



### Do not exceed the maximum hydraulic pressure

The tractor's hydraulic pressure on the machine's hydraulic system must not exceed 210 bar. Otherwise, damage to the machine may be caused as a result.



### Check tyre pressures

Check tyre pressure on a regular basis. Incorrect tyre pressures reduce the service life of a tyre and cause unstable driving characteristics. Accidents with serious or fatal injuries may be caused as a result.



### Lubrication points

Lubrication points are marked with an information label. Lubricate the machine in accordance with the instructions in the "Maintenance" chapter.



## Who is allowed to operate the machine?

### Only qualified persons may operate the machine

Only qualified persons who have been informed of the dangers associated with handling the machine are permitted to operate, service or repair the machine. The necessary knowledge can be gained in the course of agricultural vocational training, professional training or intensive instruction.

## General safety information

The general safety information and warning signs apply to every phase of the life cycle of the machine and to every application.



### Switch off the tractor and secure it

Before you dismount:

- ▶ Switch off the PTO shaft drive.
- ▶ Lower all implements.
- ▶ Switch all operating controls to the neutral or park position.
- ▶ Put the tractor's parking brake into the park position.
- ▶ Switch off the tractor.
- ▶ Remove the ignition key.
- ▶ Secure the tractor against rolling away.

An unsecured tractor can run you over or trap you. Otherwise, serious or fatal injury may be caused as a result.

### Operate for the first time only after proper training

The machine may only be put into operation if thorough training has been carried out by an authorised dealer or by an employee of the manufacturer. Operation without proper training can lead to damage to the machine due to incorrect operation, or may cause accidents.

### Safety is your responsibility

Follow the safety instructions. Ensure that all operators comply with the safety instructions. Prevent serious or fatal accidents by following the safety instructions.

### Instructions in the event of malfunctions

In the event of a malfunction

- ▶ shut down,
- ▶ stop and secure the machine immediately.
- ▶ Immediately rectify the faults, if you are qualified to do so,
- ▶ or commission an authorised dealer.

Operating a faulty machine can cause accidents or damage.



## **No persons in the working area**

Ensure that no persons – children in particular – are present in the slewing and working area of the machine. Persons could be caught by the machine within this area. Extremely serious or fatal injury may be caused as a result.

## **Correct working conditions**

Ensure that the tractor and the machine are always in perfect working condition. Make sure that the tractor brakes work in synchronisation with the machine. Also follow the instructions in your tractor's operator's manual.



## **Switch off the PTO shaft drive when lifting the machine**

Switch off the PTO shaft drive on the tractor if people could enter the working area of the machine when you

- raise the machine,
- raise the rotors to the headland position.

Rotating, unprotected parts can damage the machine and cause life-threatening injuries.



## **Switch off the tractor PTO shaft drive**

Switch off the tractor's PTO shaft drive when changing from work to transport position (and vice versa). Wait for moving parts to come to a stop. If this requirement is ignored, the consequence may be damage to the machine and even life-threatening injuries.



## **No reversing while the drive is running**

Never drive in reverse with the PTO shaft drive switched on and in the work position if people could enter the working area of the machine. Switch off the PTO shaft drive. Rotating, unprotected parts can damage the machine and cause life-threatening injuries.



### **Specified workwear**

Do not wear baggy, loose-fitting or other unsuitable clothing. Loose fitting items of clothing may become caught in rotating parts. Wear workwear and protective clothing which is suitable for the working environment and the operating conditions. Wear workwear and protective clothing, as specified by the Accident Prevention and Insurance Association. Serious or fatal injury may be caused as a result.

### **No riding on the machine**

Persons or objects must never be transported on the machine. Carrying passengers – particularly children – on the machine is life-threatening and prohibited. Serious or fatal injury may be caused as a result.

### **Safety for children**

Never assume that children will remain where you last saw them. Be alert and shut down the machine if children are in the working area of the machine. Prohibit children from playing on or around the machine and from operating the machine.

### **Never work on the machine while it is running**

No operations may be performed on the machine while it is running. Objects or persons can be caught, drawn in or crushed. Serious or fatal injury may be caused as a result.

### **Safe distance from raised and unsecured loads**

Never work under suspended loads. Maintain a sufficient distance from raised and unsecured loads. Serious or fatal injury may be caused as a result.

### **Only use the PTO shaft specified**

Use only the PTO shafts specified by the manufacturer and read the attached operator's manual carefully. Adjust the length of the PTO shaft as required. Incorrect PTO shaft lengths can cause damage to the machine and personal injury.



## **Check and fasten the PTO shaft guard in position**

The rotating PTO shaft is protected by the PTO shaft guard. Ensure that the guard is not damaged. Fasten the PTO shaft guard in position by connecting the chains on the implement and the tractor. Unguarded PTO shafts can cause life-threatening injuries.

## **Make sure the machine is standing level**

Before changing from the transport to the work position (and vice versa), make sure the machine is standing level. The machine could tip over, particularly on hillside locations. Damage to the machine and serious or fatal injury may be caused as a result.

## **Do not make any modifications to the machine**

No modifications of any kind may be made to the machine. Unauthorised modifications can adversely affect the correct operation and safety of the machine and shorten its service life. Unauthorised modifications to the machine render the manufacturer's guarantee null and void and free the manufacturer from all liability.

## **Maximal PTO shaft speed: 540 rpm**

The specified maximum PTO shaft speed of 540 rpm must not be exceeded. A higher PTO shaft speed will damage the machine.

## **Do not use PTO shafts with disconnect couplings**

Only use PTO shafts which have been specified by the manufacturer. PTO shafts with disconnect couplings may allow higher disconnect torques. Higher disconnect torques may cause damage to the machine.

## **Unrestricted field of vision to the rear**

After it has been coupled, ensure that you have an unrestricted view of the machine, in both its work and transport positions. Otherwise, dangerous situations may not be detected in good time, resulting in accidents or damage.

## **Check the steering angle**

On machines with a 2-point attachment carrier, a steering angle of 90° is possible. This angle must not be exceeded. Otherwise, damage to the PTO shaft may be caused as a result.



## Coupling



### Increased risk of injury

When the machine is being coupled to the tractor, there is an increased risk of injury. Therefore:

- Secure the tractor against rolling away, shut off the engine and remove the ignition key.
- Never stand between the tractor and machine.
- Lock the PTO shaft securely on the PTO stub shafts of the tractor and the machine.

If this requirement is ignored, the consequence may be damage to the machine and even life-threatening injuries.

### Attaching electrical connections after assembly

The electrical supply to the tractor must not be connected when the lighting equipment is being fitted. Otherwise, short circuits may occur and the electronic system may be damaged.

### Observe the operator's manual of the PTO shaft manufacturer

Observe the operator's manual of the PTO shaft manufacturer. It will provide you with instructions on how to handle the PTO shaft correctly. If these instructions are ignored, damage may be caused to the PTO shaft and machine.

### Risk of tipping due to unsecured quick-release couplings

When the machine is coupled to tractors with lower link quick-release couplings, the quick-release couplings must be secured against unintentional opening. If the quick-release couplings open unintentionally, the tractor and machine may tip over. If this requirement is ignored, the consequence may be damage to the machine and even life-threatening injuries. Also follow the instructions in your tractor's operator's manual.



## Hydraulics

### **Only connect hydraulics at zero pressure**

Only connect hydraulic hoses to the tractor hydraulic system if the tractor and machine hydraulic system is at zero pressure. A pressurised hydraulic system can trigger unpredictable movements of the machine and can cause serious damage to the machine and personal injury. Serious or fatal injury may be caused as a result.

### **High pressures in the hydraulic system**

The hydraulic system is under high pressure. Regularly check all lines, hoses, and screwed connections for leaks and externally visible damage. Only use suitable equipment when looking for leaks. Rectify any damage immediately. Oil escaping under pressure may result in injuries and fires. Seek medical attention immediately if injuries occur.

### **Uniquely coded hydraulic connections**

The hydraulic connections are uniquely coded. Only matching hydraulic couplings between the tractor and machine must be connected. Wrongly connected hydraulic couplings can trigger unpredictable movements of the machine.

### **Replace hydraulic hoses every six years or sooner**

Hydraulic hoses age without showing externally visible signs. Replace hydraulic hoses every six years. Use hydraulic hoses only with the same technical specifications. The required information is printed on the hydraulic hose. Defective or incorrect hydraulic lines can cause serious or fatal injuries.





## Road transport

### Ensuring road safety

The machine must conform to current national traffic regulations if you intend to drive with it on public roads. Ensure the following:

- Lighting, warning and protective equipment must be fitted.
- The permissible transport widths and weights, axle loads, tyre load-bearing capacities, laden weights and national speed restrictions must be complied with.
- The maximum permissible road transport speed must be complied with, but not exceed 40 km/h (25 mph).
- Before driving on public roads, fold in all guard bars and rotors and secure the machine.
- All tine supports which have tips that point at right angles to the direction of travel and which are at a height of less than 2 metres must be safeguarded using the tine covers provided, or otherwise detached.
- The machine should only be towed by agricultural or forestry tractors.

The empty weight of the tractor must be greater than the weight of the machine. The driver and keeper of the vehicle are liable should these conditions not be observed.



### Close the ball valve

Close the ball valve before driving on the road. If the ball valve is open and there is an operating error, the machine may drop or swing out unexpectedly. This can result in traffic accidents and accidents causing serious or fatal injuries.

### Check the tyre pressures

Check tyre pressure on a regular basis. Incorrect tyre pressures reduce the service life of a tyre and cause unstable driving characteristics. Accidents with serious or fatal injuries may be caused as a result.



### **Altered driving and braking performance**

Driving and braking performance are altered when the machine is coupled or hitched to the tractor. When cornering, take the overall width and balancing weight of the machine into consideration. Adjust your driving speed accordingly. A driving style which is not adapted to conditions can cause accidents. Accidents with serious or fatal injuries may be caused as a result.

### **Speed adjustment**

In poor road conditions and at high speeds, significant forces can be generated which subject the tractor and machine material to high or excessive stresses. Adjust your driving speed to the road conditions. A driving style which is not adapted to conditions can cause accidents. Accidents with serious or fatal injuries may be caused as a result.

### **Check hitch pins**

Hitch pins must be in perfect condition. Hitch pins must show no signs of wear and be properly secured. Otherwise, hitched machines may detach themselves of their own accord. Accidents with serious or fatal injuries may be caused as a result.

### **Check release cables on quick-release couplings**

Release cables must hang loose and must not trigger a release in their lowered position. Hitched machines may otherwise detach themselves from the lower link hitching system of their own accord. Accidents with serious or fatal injuries may be caused as a result.



## Operation

### **Operate for the first time only after proper training**

The machine may only be put into operation after proper training has been provided by an employee from a dealership or the manufacturer, or by a factory representative. Operation without training can lead to damage to the machine due to incorrect operation, or cause accidents.

### **Ensure that the machine is in perfect working condition**

Do not operate the machine unless it is in perfect working condition. Check all key components and their correct operation before use. Replace defective components. Defective components can cause material damage and personal injury.

### **Check the protective equipment**

The protective equipment must not be removed or by-passed. Check all protective equipment before using the machine. Unprotected machine parts can cause serious or fatal injury.

### **Check the immediate vicinity**

Check the area immediately surrounding the machine before driving off, and continually during operation. Make sure that you have an adequate view. Only begin work when the immediate vicinity is cleared of any persons or objects. Serious or fatal injury may be caused as a result.

### **Retighten all nuts, bolts and screws**

Regularly check that nuts and bolts are correctly tightened. Retighten bolts if necessary. Nuts and bolts can work loose when the machine is used. Otherwise, the machine may be damaged or accidents caused as a result.

→ Observe the correct torque specifications in chapter »Screw and bolt tightening torques« on page 86.



## **The PTO shaft drive continues turning after it has been switched off**

After the PTO shaft drive on the tractor has been switched off, the machine continues to run due to the moment of inertia. Maintain a sufficiently safe distance until all moving parts have come to a complete standstill. Damage to the machine and serious or fatal injury may be caused as a result.

## **Cornering and turning manoeuvres**

Centrifugal forces are in operation during cornering. The machine's centre of gravity at the rear of the tractor is displaced. Be aware of the turning radius and the moment of inertia. A driving style which is not adapted to conditions can cause accidents. Accidents with serious or fatal injuries may be caused as a result.

## **Uncoupling**

### **Increased risk of injury**

There is an increased risk of injury when uncoupling the machine from the tractor.

Therefore:



- Switch off the tractor engine, put the parking brake in the park position, remove the ignition key and secure the tractor against rolling away.
- Never stand between the tractor and machine.
- Set the machine down on firm, secure and level ground.
- Ensure that the parking stand is securely locked.
- Place the PTO shaft in the holder provided.
- Secure the machine against rolling away.

Failure to observe these instructions can result in serious or fatal injury.



## Care and maintenance

### Observe the care and maintenance intervals

Observe the periods specified in the operator's manual for recurrent checks and inspections. If these periods are not observed, damage to the machine and accidents may be caused as a result.

### Use original parts

Many components have special properties that are essential for the stability and correct operation of the machine. Only spare parts and accessories supplied by the manufacturer have been tested and approved. Other products may adversely affect the correct operation of the machine and safety. Using non-OEM replacement parts renders the manufacturer's guarantee null and void and frees the manufacturer from all liability.

### When performing care and maintenance work:



- Switch off the PTO shaft drive.
- Depressurise the hydraulic system.
- Whenever possible, uncouple the tractor.
- Switch off the tractor engine, put the parking brake in the park position, remove the ignition key and secure the tractor against rolling away.
- Ensure the machine is standing on firm, secure and level ground, and provide additional support, if necessary.
- Secure the machine against rolling away.

Only if these regulations are observed can safe working be ensured during care and maintenance work.

### Turn off the electrical supply

Disconnect the power supply before working on the electrical system. Systems being supplied with electrical power can cause damage to equipment and injury to persons.

**Caution when cleaning with a high-pressure cleaner**

Exercise caution when cleaning with a high-pressure cleaner. Bearings, seals and pipe unions are not waterproof. In order to prevent damage to the machine, the bearings, seals and pipe unions must not be exposed to direct contact with the high-pressure water jet.

**No aggressive washing additives**

Do not use any aggressive washing additives for cleaning. Uncoated metal surfaces can be damaged.

**Before carrying out welding work**

Disconnect all electrical connections from the tractor when carrying out welding on the hitched machine. Damage may otherwise be caused to the electrical system.

**Retighten all nuts, bolts and screws**

All pin and screwed connections that are loosened during maintenance and repair operations must be retightened. Serious injury and damage to equipment can be caused by loose pin and screwed connections.

→ Observe the correct torque specifications in chapter »Screw and bolt tightening torques« on page 86.



## Further regulations

### Observe the regulations

In addition to the safety information listed above, observe the following:

- Regional accident prevention regulations.
- Generally recognised safety regulations, occupational health requirements and road traffic regulations.
- The instructions provided in this operator's manual.
- Standards and instructions relating to operation, maintenance and repair.

## Warranty

The warranty and manufacturer's liability will no longer be valid if the instructions provided in the chapter on Safety are not observed, if maintenance is inadequate or faulty, if the machine is used for purposes other than those for which it was intended and if it is overstressed, or if impermissible modifications are made to the machine.

# Getting to know the machine

## Range of application

This product is classified as replaceable equipment in accordance with EC directive 2006/42/EC and agricultural implement in accordance with ASABE S390.

The machine is a two-wheel rake that is solely to be used for raking together mown, stalked material (for example, hay or straw).

## Proper use

Any use other than the use described above – such as silo spreading, any type of soil preparation, sweeping, or transmitting power to other machines – is not permitted. The manufacturer and dealers are not liable for damage caused by improper use. The risk is borne solely by the user.

## Features

### Flexible in operation

This central rake, which has a working width of approximately 7,80 metres, meets all the requirements of modern crop harvesting engineering. All the important functions for field use are controlled during operation. The following functions should be set without leaving the tractor:

- Deposit of crop in single rotor operation via the hydraulic single lift.
- Individual working depth of both rotors.
- Swath width.

The rake can be pulled by tractors of 35 kW (47 hp) or more.

### Extensive equipment

The machine is equipped with low-maintenance gearboxes and 11 tine supports on each rotor. The cranked tines achieve an excellent raking quality.

The “TerraLink” support ensures outstanding adjustment to the contours of the land.


The automatic system swivels the swath former into the selected transport or work position.

### Easy changeover from work to transport position

The rake is easily changed over from the work to the transport position. Hydraulic cylinders lift the rotors into the transport position to maintain the transport width of less than 2.80 m.



## Designation of components



# Getting to know the machine




## Technical specifications

### Dimensions

Transport position		Standard transport chassis [m]	With hydraulic transport chassis [m]
$L_R$	Length in transport position	5.90 (16.36 ft)	5.90 - 6.06** (16.36 ft - 21.65 ft)
$H_R$	Height with all tine supports in the transport position	3.65 * - 3.90 (11.76 ft - 12.80 ft)	3.44** - 3.90 (11.29 ft - 12.80 ft)
$W_R$	Width in transport position	2.80 (9.19 ft)	
T	Tractor chassis track width	2.51 (8.25 ft)	

\* Attachment point on the machine's lower link in transport position (min. cat 2): 400 mm (1.32 ft)



\*\* Machine completely lowered for transport position with hydraulic chassis.



# Getting to know the machine

## Dimensions

Work position		Standard transport chassis [m]	With hydraulic transport chassis [m]
$L_W$	Length in work position	5.90 (16.36 ft)	
$H_W$	Height in work position	1.79 (5.88 ft)	
$W_W$	Width in work position	6.35 - 7.45 (20.84 ft - 24.45 ft)	
X	Distance between the rotors	0.20 - 1.30 (0.66 ft - 4.27 ft)	



# Getting to know the machine

## Weights

Weights		[kg]
M <sub>M</sub>	Total weight according to EC Directive 2006/42/EC	1 640 kg (3 638 lbs)
M <sub>EU</sub>	Technical total weight according to EU Regulation 167/2013. Total axle loads on the transport chassis	1085 kg (2 392 lbs)
H <sub>L</sub>	Supported load on the 2-point attachment carrier. (category 2)	655 kg (1 445 lbs)

## Required tractor equipment

Output / connections		
	Minimum output of the tractor	35 kW (47 hp)
	Lighting power supply	Lighting equipment: 12 V, 7-pin plug socket ISO 1724 Pilotbox [+] 12 V, 3-pin plug socket DIN 9680
	Hydraulic connections	1 x single-acting hydraulic control device with floating position 1 x double-acting hydraulic control device
	Hydraulic pressure	150–210 bar (2175–3046 psi)
	PTO shaft speed	max. 540 rpm
	Coupling device	2-point attachment carrier (at least category 2) Fixable laterally

# Getting to know the machine

## Machine equipment

Machine version		Standard	Hydro
<b>Swath deposit</b>			
	Swath former with auto-swivel	Standard	
<b>Rotors / tine supports / tines</b>			
	Number of rotors	2	
	Number of tine supports per rotor	11 swaths on the left 11 swaths on the right	
	Number of tines per tine support	4	
	Tine guard	6	
	Rotor height adjustment	Mechanical	
	Hydraulic single lift	[+]	Standard
	Tine saver	[+]	
<b>Wheels</b>			
	Rotor chassis	16 x 6.50-8 6 PR	
	Tandem axles on rotor chassis	[+]	
	Transport chassis	15.0 / 55x17 10PR	
	Hydraulic transport chassis	Not available	Standard
<b>Safety accessories</b>			
	Lighting equipment	Standard	
	Warning signs	Standard	
<b>PTO shaft</b>			
	PTO shaft with freewheel	Standard	

## Measurement of airborne sound emissions

The airborne sound emissions from the machine are below the levels stipulated by machinery directive 2006/42/EC.

- A-weighted sound level in the workplace:  
< 70 dB(A)
- Currently C-weighted sound level:  
< 63 Pa (130 dB based on 20 µPa)
- A-weighted sound level on the machine:  
< 80 dB(A)

# Getting to know the machine

## Pilotbox – Hydro version






### Protect electrical parts against moisture

The electronic control system, pilotbox and electrical plug connections must be protected against damp and penetrating moisture. Dampness in electronic devices can lead to leakage current, which results in malfunction.

The rotary rake Hydro version is fitted with an electro-hydraulic control device – the pilotbox. The following functions can be selected from the tractor seat and controlled using a single-acting hydraulic control device:



Preselection	Function
<b>Pilotbox OFF</b>	Raise and lower both rotors using the single-acting hydraulic control device. Telescope both lift arms using the double-acting hydraulic control device.
<b>Pilotbox ON</b>	Control LED lights up. The A, B and C functions are available.
	A: Raise and lower the left-hand rotor using the single-acting hydraulic control device.
	B: Raise and lower the transport chassis using the double-acting hydraulic control device. Caution: During this process, the lift arms are also extended or retracted.
	C: Raise and lower the right-hand rotor using the single-acting hydraulic control device.

Operate the rotary rake with the pilotbox as follows:

- ▶ Mount the pilotbox in the tractor cab so that it is easily reachable and secure it.
- ▶ Switch it on and off with the switch. The control LED lights up when the pilotbox is switched on.
- ▶ Use the switch to select the function, then execute the function using the corresponding hydraulic control device.








The pilotbox is included in the scope of delivery for the Hydro version. The pilotbox is not included in the scope of delivery for the standard version.






## Function overview

### Standard version

The table below provides a summary of the functions. Be sure to follow the other instructions and note the safety information in the operator's manual.

Steering	Machine position	Function
<ul style="list-style-type: none"> <li>Single-acting hydraulic control device.</li> </ul>	<p style="text-align: center;"><b>Standard</b></p> 	<p><b>Transport</b></p> <ul style="list-style-type: none"> <li>Switch off the PTO shaft drive.</li> <li>Clean the machine.</li> <li>Use the single-acting hydraulic control device to raise rotors into the transport position.</li> </ul>
<ul style="list-style-type: none"> <li>Single-acting hydraulic control device.</li> </ul>	<p style="text-align: center;"><b>Standard</b></p> 	<p><b>Work position</b></p> <ul style="list-style-type: none"> <li>Use the single-acting hydraulic control device to release the lift arm locking mechanism.</li> <li>Pull the rope on the mechanical lock and keep the rope tensioned.</li> <li>Lower the rotors using the single-acting hydraulic control device.</li> </ul>
<ul style="list-style-type: none"> <li>Single-acting hydraulic control device.</li> </ul>	<p style="text-align: center;"><b>Standard</b></p> 	<p><b>Headlands</b></p> <ul style="list-style-type: none"> <li>Using the single-acting hydraulic control device, raise both rotors to the headland position, then lower them.</li> </ul>
<ul style="list-style-type: none"> <li>Pilotbox [+] is switched on.</li> <li>Select position A on the pilotbox.</li> </ul>  <ul style="list-style-type: none"> <li>Single-acting hydraulic control device.</li> </ul>	<p style="text-align: center;"><b>Standard [+]</b></p> 	<p><b>Swathing with left rotor [+]</b></p> <ul style="list-style-type: none"> <li>The right rotor remains in the headland position.</li> <li>Raise the machine to the headland position using the single-acting hydraulic control device.</li> <li>Pull the rope on the right rope pull ball valve once.</li> <li>Lower the left rotor using the single-acting hydraulic control device.</li> </ul>

# Getting to know the machine





Steering	Machine position	Function
<ul style="list-style-type: none"> <li>Pilotbox [+] is switched on.</li> <li>Select position C on the pilotbox.</li> </ul>  <ul style="list-style-type: none"> <li>Single-acting hydraulic control device.</li> </ul>	<p style="text-align: center;"><b>Standard [+]</b></p> 	<p><b>Swathing with right rotor [+]</b></p> <ul style="list-style-type: none"> <li>The left rotor remains in the headland position.</li> <li>Raise the machine to the headland position using the single-acting hydraulic control device.</li> <li>Pull the rope on the left rope pull ball valve once.</li> <li>Lower the right rotor using the single-acting hydraulic control device.</li> </ul>
<ul style="list-style-type: none"> <li>Double-acting hydraulic control device.</li> </ul>	<p style="text-align: center;"><b>Standard</b></p> 	<p><b>Swath width</b></p> <ul style="list-style-type: none"> <li>Raise the machine to the headland position using the single-acting hydraulic control device.</li> <li>Adjust the swath width using the double-acting hydraulic control device.</li> <li>Lower the machine to the work position using the single-acting hydraulic control device.</li> </ul>
<ul style="list-style-type: none"> <li>Crank on left rotor.</li> </ul>	<p style="text-align: center;"><b>Standard</b></p> 	<p><b>Working depth of left rotor</b></p> <ul style="list-style-type: none"> <li>Switch off the PTO shaft drive.</li> <li>Switch off the tractor and secure it.</li> <li>Set the working depth (raking height) using the crank on the left rotor.</li> </ul>
<ul style="list-style-type: none"> <li>Crank on right rotor.</li> </ul>	<p style="text-align: center;"><b>Standard</b></p> 	<p><b>Working depth of right rotor</b></p> <ul style="list-style-type: none"> <li>Switch off the PTO shaft drive.</li> <li>Switch off the tractor and secure it.</li> <li>Set the working depth (raking height) using the crank on the right rotor.</li> </ul>











# Getting to know the machine

## Hydro version



The table below provides a summary of the functions. Be sure to follow the other instructions and note the safety information in the operator's manual.

Steering	Machine position	Function
<ul style="list-style-type: none"> <li>Pilotbox switched off.</li> <li>Single-acting hydraulic control device.</li> </ul>	<p style="text-align: center;"><b>Hydro</b></p> 	<p><b>Transport</b></p> <ul style="list-style-type: none"> <li>Machine in work position.</li> <li>Switch off the PTO shaft drive.</li> <li>Clean the machine.</li> <li>Use the single-acting hydraulic control device to lift the rotors into the transport position.</li> </ul>
<ul style="list-style-type: none"> <li>Pilotbox switched off.</li> <li>Single-acting hydraulic control device.</li> </ul>	<p style="text-align: center;"><b>Hydro</b></p> 	<p><b>Work position</b></p> <ul style="list-style-type: none"> <li>Switch off the PTO shaft drive.</li> <li>Use the single-acting hydraulic control device to release the lift arm locking mechanism.</li> <li>Pull the rope on the mechanical lock and keep the rope tensioned.</li> <li>Lower the rotors using the single-acting hydraulic control device.</li> </ul>
<ul style="list-style-type: none"> <li>Pilotbox switched off.</li> <li>Single-acting hydraulic control device.</li> </ul>	<p style="text-align: center;"><b>Hydro</b></p> 	<p><b>Headlands</b></p> <ul style="list-style-type: none"> <li>Using the single-acting hydraulic control device, raise both rotors to the headland position, then lower them again.</li> </ul>
<ul style="list-style-type: none"> <li>Pilotbox switched off.</li> <li>Double-acting hydraulic control device.</li> </ul>	<p style="text-align: center;"><b>Hydro</b></p> 	<p><b>Swath width</b></p> <ul style="list-style-type: none"> <li>Raise the rotors to the headland position using the single-acting hydraulic control device.</li> <li>Adjust the swath width using the double-acting hydraulic control device.</li> <li>Lower the rotors into the work position using the single-acting hydraulic control device.</li> </ul>

# Getting to know the machine

Steering	Machine position	Function
<ul style="list-style-type: none"> <li>Pilotbox switched on.</li> <li>Select position A on the pilotbox.</li> </ul>  <ul style="list-style-type: none"> <li>Single-acting hydraulic control device.</li> </ul>	<p style="text-align: center;"><b>Hydro</b></p> 	<p><b>Swathing with left rotor [+]</b></p> <ul style="list-style-type: none"> <li>Switch the pilotbox on.</li> <li>Select position A on the pilotbox.</li> <li>Using the single-acting hydraulic control device, raise the right rotor and then lower it.</li> </ul>
<ul style="list-style-type: none"> <li>Pilotbox switched on.</li> <li>Select position C on the pilotbox.</li> </ul>  <ul style="list-style-type: none"> <li>Single-acting hydraulic control device.</li> </ul>	<p style="text-align: center;"><b>Hydro</b></p> 	<p><b>Swathing with right rotor [+]</b></p> <ul style="list-style-type: none"> <li>Switch the pilotbox on.</li> <li>Select position C on the pilotbox.</li> <li>Using the single-acting hydraulic control device, raise the left rotor and then lower it.</li> </ul>
<ul style="list-style-type: none"> <li>Pilotbox switched on.</li> <li>Select position B on the pilotbox.</li> </ul>  <ul style="list-style-type: none"> <li>Double-acting hydraulic control device.</li> </ul>	<p style="text-align: center;"><b>Hydro</b></p> 	<p><b>Lower the transport chassis [+]</b></p> <ul style="list-style-type: none"> <li>Switch the pilotbox on.</li> <li>Select position B on the pilotbox.</li> <li>Lower the transport chassis using the double-acting hydraulic control device.</li> <li>Caution: During this process, the lift arms are also retracted.</li> </ul>
<ul style="list-style-type: none"> <li>Pilotbox switched on.</li> <li>Select position B on the pilotbox.</li> </ul>  <ul style="list-style-type: none"> <li>Double-acting hydraulic control device.</li> </ul>	<p style="text-align: center;"><b>Hydro</b></p> 	<p><b>Raise the transport chassis [+]</b></p> <ul style="list-style-type: none"> <li>Switch the pilotbox on.</li> <li>Select position B on the pilotbox.</li> <li>Raise the transport chassis using the double-acting hydraulic control device.</li> <li>Caution: During this process, the lift arms are also extended.</li> </ul>

# Getting to know the machine

Steering	Machine position	Function
<ul style="list-style-type: none"> <li>• Crank on left rotor.</li> </ul>	<p style="text-align: center;"><b>Hydro</b></p> 	<p><b>Working depth of left rotor</b></p> <ul style="list-style-type: none"> <li>• Switch off the PTO shaft drive.</li> <li>• Switch off the tractor and secure it.</li> <li>• Set the working depth (raking height) using the crank on the left rotor.</li> </ul>
<ul style="list-style-type: none"> <li>• Crank on right rotor.</li> </ul>	<p style="text-align: center;"><b>Hydro</b></p> 	<p><b>Working depth of right rotor</b></p> <ul style="list-style-type: none"> <li>• Switch off the PTO shaft drive.</li> <li>• Switch off the tractor and secure it.</li> <li>• Set the working depth (raking height) using the crank on the right rotor.</li> </ul>

# Delivery and assembly

## Checking the scope of delivery

### Delivery is in the fully assembled state

The machine is delivered fully assembled. Using the check list, check the loose parts on delivery. If any parts of the machine have not been fitted or are missing, please contact your dealer.



### Do not assemble the machine yourself.

Trained personnel are required to assemble the machine. Do not perform assembly work yourself. The following points are required to be met for the machine to be in proper condition:

- Observance of a sequence of worksteps.
- Compliance with tolerances and torques.
- Knowledge of work safety during assembly.


Incorrect assembly can result in damage to the machine or accidents.



If parts are missing or have been damaged during transportation, please inform the dealer, importer or manufacturer immediately.

Check list for parts which were supplied loose	Quantity
PTO shaft for drive	1
PTO shaft for auxiliary drive	2
Tine support, CCW delivery	11
Tine supports, CW delivery	11
Tine guard	6
Swath former	1
Operator's manual	1
Spare part manual	1
Additional equipment	See delivery note

## Operator's manual



The operator's manual is a safety component. The document belongs with the machine and must always be kept on board. A document box for the operator's manual and spare part manual is mounted on the main frame.

## Checking the machine

Before using the machine for the first time, the alignment of the optional tandem axles [+], the PTO shaft length and the steering setting must be checked and corrected if necessary.

The following checks are described in this section:

- »Checking the tandem axles [+]«
- »PTO shaft length«
- »Checking the steering«


## Checking the tandem axles [+]



### Ensure that the tandem axles are aligned correctly

Make sure that the tandem axles are aligned correctly. Incorrect assembly and alignment will damage the machine.

- ▶ Check that the tandem axles [+] are aligned correctly.
  - The wide track is in the forward direction of travel.
  - The narrow track is in the reverse direction of travel.



# Delivery and assembly

## PTO shaft length

The length of the PTO shaft was selected at the factory to suit almost all types of tractor. Only in exceptional cases is a correction of the PTO shaft length required on individual tractors. Check the length of the PTO shaft on each tractor prior to first use.

A manufacturer's operator's manual for the PTO shaft is enclosed. This includes detailed information on the relevant version of the PTO shaft and must be observed.

## Safety



### Switch off the tractor and secure it

Before you dismount:

- ▶ Lower all implements to the ground.
- ▶ Switch all operating controls to their neutral or park position.
- ▶ Put the tractor's parking brake into the park position. Switch off the tractor.
- ▶ Remove the ignition key.
- ▶ Secure the tractor against rolling away.



An unsecured tractor can run you over or trap you. Serious or fatal injury may be caused as a result.



### Check the steering angle

The tractor's PTO shaft has a wide hinge joint, allowing an angle of lock of up to 80°. Make sure that the PTO shaft is not damaged during sharp cornering. The machine may be damaged as a result.

### Correct length

A PTO shaft that is too long must not be used. This would result in damage to the drive bearings of the tractor and the machine.


## Checking the length of the PTO shaft

- ▶ Couple the machine to the tractor without the PTO shaft.
- ▶ Lower the tractor's lower link.
- ▶ Set the combination (tractor and machine) to the smallest steering angle.
- ▶ Switch off the tractor engine, put the parking brake in the park position, remove the ignition key and secure the tractor against rolling away.




If the PTO shaft has been shortened, the minimum overlap and the minimum distance must be checked again when it is operated with another tractor.

## Shortening the PTO shaft



- ▶ Pull the PTO shaft apart and connect one half to the tractor PTO shaft drive and one to the machine and secure them.
- ▶ Place the two shaft halves next to each other and:
  - Check for a minimum of 250 mm (10 in) overlap (b).
  - Check that the PTO shaft does not block at one end (minimum clearance (a) = 20 mm (1 in))
- ▶ Shorten the slide tube and guard tube by the same dimension.
- ▶ Deburr the ends of the tubes.
- ▶ Remove the swarf.
- ▶ Grease the sliding surfaces well.


## Fitting the PTO shaft



Make sure that you fit the PTO shaft in the correct installation position. There is a marking on the guard tube of the PTO shaft.

- ▶ Check the length of the PTO shaft and shorten it if necessary.
- ▶ Place the PTO shaft onto the PTO stub shaft of the machine.
- ▶ Secure the PTO shaft with a locking pin.
- ▶ Secure the guard cone to the machine frame using a jubilee clip.

## Checking the steering



### **Never carry out work on the steering**

Contact your dealer if specifications differ. Never carry out any work on the steering or track yourself. This could cause traffic accidents and accidents with fatal consequences.

The steering is fitted and preset in the factory. Check the adjustment of the steering with a hitched machine.

- ▶ Drive along a straight line with the entire combination (tractor with hitched machine). For example, a straight kerb.
- ▶ Check if the machine follows the tractor in the same track.

When driving in a straight line, if the machine swerves to the side or does not run in the same track as the tractor, or if the wheels do not run parallel, the tracking and steering must be readjusted at an authorised workshop.

- ▶ Check if the target measurements are correct.
- ▶ If discrepancies are found, consult your dealer.
  - See chapter »Checking the track«, page 95.



## Safety



### Observe the safety information

Disregard for safety information can lead to serious or fatal injury. See chapter »Safety«, page 7.

### Increased risk of injury

When the machine is being coupled to the tractor, there is an increased risk of injury. Therefore:

- Never stand between the tractor and machine.
- Secure the tractor against rolling away.
- Actuate the three-point power lift system slowly and carefully.

Failure to observe these instructions can result in serious or fatal injury.

## General

The machine is equipped at the factory for coupling to the lower link (attachment carrier) of the three-point power lift system.

The following worksteps are described in this section:

- »Coupling the lower link«
- »Swivelling in the parking stand«
- »Coupling the PTO shaft«
- »Wheel chocks«
- »Electrical connections«
- »Hydraulic connections«

# Coupling the machine

## Coupling the lower link




### Secure the lower link at the sides

Secure the lower link so that there is no lateral play. Otherwise, the machine may swing out behind the tractor. Failure to secure it may lead to traffic accidents, damage to the machine or life-threatening injuries.

The machine can be used on tractors with lower link quick-release coupling and on tractors with no quick-release coupling.

## Tractors with quick-release couplings



### Follow the instructions for the quick-release coupling

Follow the instructions below for tractors with quick-release couplings. Also note the instructions and warnings in the operator's manual of the tractor manufacturer.

If this requirement is ignored, the consequence may be damage to the machine and even life-threatening injuries.

- ▶ Slide guided cone balls suitable for the tractor onto the lower link hitching system of the machine.
- ▶ To couple the machine, raise the lower link until the catch engages.
- ▶ Secure the quick-release coupling with lynchpins.
- ▶ Secure the catch with pins.
- ▶ Follow the instructions for »Tractors without quick-release coupling«.



Note the instructions and warnings in the operator's manual of the tractor manufacturer for tractors with lower link quick-release couplings.


## Tractors without quick-release coupling

The following applies to all tractors, with or without quick-release couplings:


- ▶ Couple the machine to the lower link - in accordance with the operator's manual of the tractor manufacturer - lift slightly and secure.
- ▶ Slightly raise the lower link.
- ▶ Switch off the tractor engine, put the parking brake in the park position, remove the ignition key and secure the tractor against rolling away.
- ▶ Swivel in the parking stand.  
→ See »Swivelling in the parking stand«, page 43.
- ▶ With the lower link in the work position, lift it off the ground until the main frame of the machine is tilted approximately 1 degree forwards.
- ▶ Engage the lower link at the sides.
- ▶ Adjust the lower link such that a uniform ground clearance is maintained.



## Swivelling in the parking stand



After coupling to the tractor, raise the lower link slightly to relieve the load on the parking stand. Then swivel in and secure the parking stand.




- ▶ Raise the tractor's lower link slightly to relieve the load on the parking stand.
- ▶ Switch off the tractor engine, put the parking brake in the park position, remove the ignition key and secure the tractor against rolling away.
- ▶ Pull the pin on the parking stand.
- ▶ Swivel in the parking stand.
- ▶ Release the pin on the parking stand and lock it in place.

# Coupling the machine

## Coupling the PTO shaft

Make sure that you fit the PTO shaft in the correct installation position. There is a marking on the guard tube of the PTO shaft.




### Do not use force

When coupling the PTO shaft, do not use a hammer or any similar tools. Using these types of tool can severely damage the PTO shaft. A damaged PTO shaft can cause damage to the tractor and the machine.

When coupling the PTO shaft, make sure it is in the correct position.

- ▶ Check whether the PTO shaft must be shortened before coupling.
- ▶ Shorten the PTO shaft if necessary.
  - See »PTO shaft length«, page 38.




### Check and fasten the PTO shaft guard in position

The rotating PTO shaft is protected by the PTO shaft guard. Ensure that the guard is not damaged. Unguarded PTO shafts can cause damage to the machine and life-threatening injuries.

- ▶ Check that the tractor's PTO stub shaft is clean and lubricated.
- ▶ Couple the PTO shaft to the tractor and the machine.
  - Observe the fitting instructions embossed on the PTO shaft.
- ▶ Ensure that the PTO shaft is engaged on the shaft ends.


Secure the guard cone to the machine frame using a jubilee clip.

## Wheel chocks



### Secure the tractor against rolling away

Never remove the wheel chocks from in front of the wheels if the tractor is not otherwise secured against rolling away. Persons could be run over by the machine or the tractor. Serious or fatal injury may be caused as a result.



- ▶ Switch off the tractor engine, put the parking brake in the park position, remove the ignition key and secure the tractor against rolling away.
- ▶ Remove the wheel chocks from in front of the wheels.
- ▶ Place them in the brackets provided on the left and right behind the warning plates on the transport chassis and engage them securely.

# Coupling the machine

## Connections

### Electrical connections



#### Checking the electrical cables

Check the electrical cables. The electrical cables must not chafe or hang loose. Electrical cables that have been torn away or worn through must be replaced. Otherwise, damage to the machine may be caused as a result.

Attach the following electrical cables to the tractor:

### Lighting equipment




- ▶ Connect the plug for the 12 V power supply to the 7-pin plug socket on the tractor.

### ISO 1724 plug arrangement



A connection in accordance with ISO 1724 must be present on the tractor. If your tractor does not have the corresponding connection, a corresponding connection must be retrofitted. Consult your dealer.



PIN	Cable	Connection to
1	Yellow	Left-hand indicator (amber)
2		Not used
3	White	Earth; all lights
4	Green	Right-hand indicator (amber)
5	Brown	Right rear light (red)/right position light (white)
6	Red	Brake lights
7	Black	Left rear light (red)/left position light (white)

## Pilotbox [+]



### Switch off the pilotbox for all tasks on the machine

Always switch off the pilotbox when coupling or uncoupling and when carrying out service or maintenance work or any task on the machine. If the pilotbox is switched on and accidentally actuated, unpredictable movements of the machine may be triggered. Accidents with serious or fatal injuries may be caused as a result.

- ▶ Connect the optional pilotbox plug for the 12 V power supply to the 3-pin plug socket on the tractor.



Pilotbox	Solenoid valve connection	Function
A	Y1	Raise and lower the left-hand lift arm.
B	Y2	Raise and lower the transport chassis.
C	Y3	Raise and lower the right-hand lift arm.



The pilotbox is included in the scope of delivery for the Hydro version. The pilotbox is not included in the scope of delivery for the standard version.

## Hydraulic connections



### Check hoses and couplings

Check all hydraulic hoses for damage before connecting them. Check all hydraulic couplings for firm seating after connecting them. Defective hydraulic hoses and poorly fitting hydraulic connections can trigger unpredictable movements of the machine, causing severe damage to the machine as well as personal injury. Serious or fatal injury may be caused as a result.

### Secure the tractor's control devices

In the transport position, secure the control devices on the tractor against unintended actuation and lock them if possible. Unintentional activation of a control device can trigger unpredictable movements of the machine and cause serious machine damage and personal injury. Serious or fatal injury may be caused as a result.

### Check the routing of the hydraulic hoses

Close or disconnect the quick-release couplings with great care. Remove any dirt or air which has entered the hydraulic system. The hydraulic system may otherwise be seriously damaged. Material damage or personal injury may be caused as a result.

### Avoid mixing oils

If the machine is used on different tractors, an impermissible mixing of oil may occur. Impermissible oil mixtures can irreparably damage tractor components.

# Coupling the machine



## Hydraulic connection at zero pressure only

Only connect hydraulic hoses to the tractor hydraulic system if the tractor and machine hydraulic system is at zero pressure. A hydraulic system which is under pressure can cause unforeseen movements on the machine. Serious or fatal injury may be caused as a result.

## High pressures in the hydraulic system

The hydraulic system is under high pressure. Regularly check all lines, hoses, and screwed connections for leaks and externally visible damage. Never use your hands to search for suspected leaks; only use suitable equipment. Rectify any damage immediately. Fluid escaping under pressure can penetrate skin may result in injuries and fires. Seek medical attention immediately if injuries occur.

## Connecting the hydraulic couplings



## Connect the hydraulics correctly

Make sure that the hydraulics are connected correctly. Otherwise, damage to the machine and personal injury may be caused as a result.



- ▶ Close the ball valve.



- ▶ Set the tractor hydraulics to "free float".

- ▶ Switch off the tractor engine, put the parking brake in the park position, remove the ignition key and secure the tractor against rolling away.

- ▶ Roll up the control ropes and store them in the tractor cab.




- ▶ Connect the machine's hydraulic coupling to the single-acting hydraulic control device when it is set to the floating position.

- ▶ Connect the machine's hydraulic coupling to the double-acting hydraulic control device.



# Coupling the machine

## Standard version




The rotors are raised and lowered and single-swath mode controlled using the single-acting hydraulic control device.

The swath width is controlled using the double-acting hydraulic control device.

Hydraulic line	Marking
Single-acting hydraulic control device pressure line	No marking
Double-acting hydraulic control device pressure line	Red
Double-acting hydraulic control device return line	Yellow

## Hydro version



The rotors are raised and lowered using the single-acting hydraulic control device. Single swath operation is controlled by switching on and actuating the pilotbox.

The swath width is controlled using the double-acting hydraulic control device. Raising and lowering the transport chassis is controlled by switching on and actuating the pilotbox.

Hydraulic line	Marking
Double-acting hydraulic control device pressure line	Red
Double-acting hydraulic control device return line	Yellow
Single-acting hydraulic control device pressure line	Black

## Safety

The following applies to all preparations for operation:



### **Observe the safety information**

Disregard for safety information can lead to serious or fatal injury. See chapter »Safety«, page 7.

### **Secure the machine**

Secure the machine against accidental starting and rolling away. Use wheel chocks. The machine must stand on a level, firm and secure surface and be supported during the work, if necessary. Unsecured or non-supported machines can cause accidents. Serious or fatal injury may be caused as a result.

### **Switch off the pilotbox for all tasks on the machine**

Always switch off the pilotbox for any task carried out on the machine. If the pilotbox is switched on, unpredictable movements of the machine may be triggered. Accidents with serious or fatal injuries may be caused as a result.

### **No persons in the working area**

Ensure that no persons – children in particular – are present in the slewing and working area of the machine. Persons could be caught by the machine within this area. Serious or fatal injury may be caused as a result.

### **Avoid the hazard area**

The rotors are considered a hazard area. Do not stand in the hazard area. The rotors may lower or turn. This can lead to serious or fatal injuries.


### **Unfold fully and evenly**

Ensure that the side devices are evenly unfolded. If there is a malfunction, fold the side devices back in and repeat the process at a higher engine speed. The hydraulic cylinders must be completely extended in the work position. Otherwise, damage to the machine may be caused as a result.

## General

The following applies when performing all adjustment work:

- ▶ Check the tyre pressure.
- ▶ Secure the machine.
- ▶ Lower the machine to the work position.
- ▶ Remove unrequired tine supports.
- ▶ Undo appropriate bolts and/or screws.
- ▶ Make the required adjustment.
- ▶ Retighten the bolts.
- ▶ Fit and secure the tine supports.
- ▶ Activate the floating position on the tractor's lower link.




The following worksteps are described in this section:

- »Rotor pitch«
- »Working depth«


## Adjusting the machine

The machine is preset at the factory. The following illustration shows an overview of the basic settings. Detailed information can be found on the following pages.



# Preparing for use

## Raising the hydraulic transport chassis



### Use the hydraulic transport chassis safely

Actuate the hydraulic transport chassis only in the transport position and only when the tractor and machine are shut down. Ensure that the hydraulic transport chassis is always fully raised or lowered. Never move the machine in an intermediate position. Otherwise, damage to the machine, road accidents or accidents with serious or fatal injuries may be caused as a result.




The machine must be in the transport position.

- ▶ Switch on the tractor engine.



- ▶ Select position "B" on the pilotbox.
- ▶ Fully raise the hydraulic transport chassis using the double-acting hydraulic control device.


## Frame pitch



For improved pick-up of the crop, use the three-point power lift system to incline the main frame approx. 1° further to the front.

- ▶ Use the three-point power lift system to incline the main frame approx. 1° further to the front.

## Rotor pitch



### Close the ball valve

Close the ball valve before working on the machine or carrying out any adjustment work. If the ball valve is open and there is an operating error, the machine can lower itself and cause serious injuries.

The rotors are inclined transversely to the chassis. The rotor is already inclined obliquely ex-factory. If the crop is not picked up cleanly, the raking quality can be improved by adjusting the rotor pitch.




The optimum raking quality is achieved when the tips of the tines in the front working area and before the crop is deposited have the lowest possible ground clearance (see adjacent illustration).



The machine settings must be adjusted to suit the crop and the condition of the soil. If the machine is set incorrectly, this will make the work results untidy.

Reasons for untidy raking:

- Incorrect rotor pitch of the rotor chassis in the transverse axis.
- Incorrect rotor pitch of the rotor axle in the longitudinal axis.




# Preparing for use

## Adjusting the rotor pitch



### Secure the machine

Secure the machine against accidental starting and rolling away. Use wheel chocks. The machine must stand on a level, firm and secure surface and be supported during the work, if necessary. Unsecured or non-supported machines can cause accidents. Serious or fatal injury may be caused as a result.



- ▶ Raise the machine to the headland position using the hydraulic control device.
- ▶ Switch off the tractor engine, put the parking brake in the park position, remove the ignition key and secure the tractor against rolling away.
- ▶ Close the ball valve.
- ▶ Secure the rotors with suitable lifting accessories using supports.

### Proceed as follows:


- ▶ Adjust the rotor pitch for a single axle  
→ »Adjusting the rotor pitch for a single axle«, page 55.

– or –

- ▶ Adjust the rotor pitch for a tandem axle [+]  
→ »Adjusting the rotor pitch for a tandem axle [+]«, page 56.




Check the rotor pitch: the tines in the clearing area should lightly touch the ground.



Crop pick-up increases the distance (a) between the tines and the ground.


## Adjusting the rotor pitch for a single axle



- ▶ Loosen the M 20 nut.
- ▶ Remove the M20 nut and washer.
- ▶ Remove the wheel.
- ▶ Fit the wheel in the desired position.
- ▶ Put the washer and M 20 nut back on.
- ▶ Tighten the M20 nut to 450 Nm (332 ft.lbs).




- ▶ The inner wheels (on the swath former side) must be fitted one hole higher than the outer wheels.



- ▶ Tighten the bolt to at least 450 Nm (332 ft.lbs). The axle plate must sit securely on the pin.

## Adjusting the rotor pitch in the direction of travel



The rotors can be tilted on the front axle in the direction of travel.

- ▶ Remove the dowel pin on the front axle.
- ▶ Adjust the height of the chassis by switching the position of the washers.
- ▶ Refit the dowel pin on the front axle.



Basic setting ex works:


- 2 washers under the pin in the front axle.



By raising the front axle, crop pick-up for straw is improved.

# Preparing for use


## Adjusting the rotor pitch for a tandem axle [+]



- ▶ Remove the M20 nut.
- ▶ Remove the tandem axle.
- ▶ Fit the tandem axle in the desired position.
- ▶ Fit the securing pin in the opposite hole.
- ▶ Tighten the M20 nut to 450 Nm (332 ft.lbs).




The inner tandem axle (on the swath former side) must be fitted one hole higher than the outer tandem axle so that the rotor on the swath former side is inclined.



Tighten the M20 nut to at least 450 Nm (332 ft.lbs). The axle plate must sit securely on the stop plate of the securing pin.



## Working depth




Adjust the working depth (raking height) as follows:

- ▶ Fully lower the machine into the floating position using the hydraulic control device and advance approximately two metres (6.6 ft).
- ▶ Switch off the tractor engine, put the parking brake in the park position, remove the ignition key and secure the tractor against rolling away.
- ▶ Check the working depth to the ground.



## Basic working depth setting



The working depth (raking height) is set using the crank on the rotor.

- ▶ Turn the crank on the rotor chassis to adjust the working depth (raking height).
  - Basic setting: the tines slightly touch the ground.
- ▶ Adjust the working width on the second rotor in the same way.
- ▶ Readjust the working depth to suit the field conditions if necessary.



Ten turns of the crank equate to a rotor tine height adjustment of about 15 mm (0.6 in). The thread is left-handed.

Further influencing factors for the working depth (raking height) are:

- The soil condition and stubble length.
- The type and quantity of crop.

Tines that are set too low will soil the crop. The load on the rotor tines and the drive is increased.

## Safety

Before transporting the machine on public roads, please read the following safety information. Compliance is mandatory and will help you to avoid accidents.



### Observe the safety information

Disregard for safety information can lead to serious or fatal injury. See chapter »Safety«, page 7.

### Ensuring road safety

The machine must conform to current national traffic regulations if you intend to drive with it on public roads. Ensure the following:

- Lighting, warning and protective equipment must be fitted.
- The permissible transport widths and weights, axle loads, tyre load-bearing capacities, laden weights and national speed restrictions must be complied with.
- The maximum permissible road transport speed must be complied with, but not exceed 40 km/h (25 mph).
- Before driving on public roads, fold in all guard bars and rotors and secure the machine. All tine supports which have tips that point at right angles to the direction of travel and which are at a height of less than 2 metres (6.6 ft) must be safeguarded using the tine covers provided.
- The machine should only be towed by agricultural or forestry tractors.
- The empty weight of the tractor must be greater than the weight of the machine.

The driver and keeper of the vehicle are liable should these conditions not be observed.

### Observe transport width

Observe the permissible transport widths. Fold the machine into the transport position and attach lights, warning signs and protective equipment. The driver and keeper of the vehicle are liable for any non-compliance with national traffic regulations.



### Close the ball valve

Close the ball valve before driving on the road. If the ball valve is open and there is an operating error, the machine may drop or swing out unexpectedly. This can result in traffic accidents and accidents causing serious or fatal injuries.

**Observe the contour of the terrain**

Move the machine onto ground that is as flat as possible before changing from work to transport position. Avoid inclines on which the combination (tractor and machine) could slip or overturn. There is an increased risk of tipping and injury in a position at right angles to the direction of the slope.

**Clean lighting equipment before travelling on the road**

All lighting equipment must be cleaned before road transport. Crop residue or dirt may cover up the lighting equipment and adversely affect its correct operation. This can result in traffic accidents and accidents causing serious or fatal injuries.

**Clean the machine before travelling on the road**

Before travelling on the road, remove all coarse dirt, crop residues and clods of earth from the machine and clean it. Crops or dirt that drop onto the road can cause slippery road conditions. Traffic accidents and accidents with fatal injuries may be caused as a result.

**Protect the tines**

When driving with the machine on public roads and in the park position, all tine supports must be secured using the tine covers provided. This can result in traffic accidents and accidents causing serious or fatal injuries.


## General

The following worksteps are described in this section:

- »Prior to road transport«
- »Lifting the rotors into the transport position«
- »Checking the machine«
- »Road transport«

# Road transport

## Prior to road transport



When driving on public roads, the machine must be in the transport position. To prepare the machine for road transport, carry out the following steps:

- ▶ »Setting the lowest transport height«
- ▶ »Folding in the guard bar«
- ▶ »Lifting the rotors into the transport position«
- ▶ »Attaching the tine cover«
- ▶ »Checking the machine«
- ▶ Move the machine onto ground that is as flat as possible before changing from work to transport position.

## Setting the lowest transport height


- ▶ Using the single-acting hydraulic control device, raise the machine to the headland position.
- ▶ Adjust the swath to the smallest width using the double-acting hydraulic control device.

## Hydro version



- ▶ Using the single-acting hydraulic control device, raise the machine to the headland position.
- ▶ Adjust the swath to the smallest width using the double-acting hydraulic control device.
- ▶ Switch on the pilotbox and set the 3-way switch to B.
- ▶ Lower the hydraulic transport chassis using the double-acting hydraulic control device.
- ▶ Switch the 3-way switch to the neutral position and switch off the pilotbox.

## Folding in the guard bar



Before removing the tine supports, move all protective devices around the rotors from transport to work position, and lock them in place. Fold in the guard bar as follows:



- ▶ Lower the machine into the work position using single-acting hydraulic control device.
- ▶ Switch off the tractor engine, put the parking brake in the park position, remove the ignition key and secure the tractor against rolling away.
- ▶ Release the guard bar by pulling it out of the latch for the work position.
- ▶ Fold the guard bar through 180° and engage it in the latch for the transport position.

# Road transport

## Lifting the rotors into the transport position



### No persons within the slewing range


Ensure that no persons – children in particular – are present in the slewing and working area of the machine. Persons can be trapped by the machine. Serious or fatal injury may be caused as a result.

### Make sure the machine is standing level


Before changing from the transport to the work position (and vice versa), make sure the machine is standing level. The machine could tip over, particularly on hillside locations. Damage to the machine and serious or fatal injury may be caused as a result.

- ▶ Observe the instructions in »Prior to road transport«, page 60.

- ▶ Switch on the tractor engine.





- ▶ Open the ball valve.



- ▶ Pull the rope on the mechanical lock and keep tensioned.

- ▶ Use the single-acting hydraulic control device to lift the rotors into the transport position.

- ▶ Release the mechanical lock rope to secure the rotors.



- ▶ Check that the locks of both lifting arms are engaged.

- ▶ Switch off the tractor engine, put the parking brake in the park position, remove the ignition key and secure the tractor against rolling away.



- ▶ Close the ball valve.




Before swivelling the rotors into the transport position, switch off the PTO shaft drive and wait for the rotors to come to a stop.

## Attaching the tine cover



### Exercise caution when close to unprotected tines

Maintain a sufficiently safe distance from exposed tines. When working in the vicinity of the tines, ensure that you have a firm footing (risk of slipping on wet ground). Serious or fatal injury may be caused as a result.




Position of the tine covers



All tine supports which have tips that point at right angles to the direction of travel and which are at a height of less than 2 metres (6.6 ft) must be safeguarded using the tine covers provided.


- ▶ On each side of the machine, fit tine covers to the three tine supports whose tines project beyond the width of the chassis when in the transport position and in relation to the direction of travel (see illustration).



Tine cover holder



When in the work position, the tine guards are stowed in two holders to the right and left of the main frame.



Proceed as follows to complete the assembly:

- ▶ Take a tine cover from the holder.
- ▶ Fit all tine covers on the tine supports provided.

# Road transport

## Checking the machine



Prior to driving on the road, check the machine against the check list:

- PTO shaft drive off?
- Rotor in transport position?
- Guard bar folded?
- Tine covers attached?
- Tyre pressures correct?
- Lower link secured at the sides?
- Crop residue and dirt removed?
- Lighting cables routed so that they are not strained and cannot become caught in the tractor's wheels when cornering?
- Lighting equipment in good working order?

## Road transport



**Follow the instructions below for road transport. Otherwise, traffic accidents and accidents with fatal injuries may be caused as a result.**



- ▶ Before pulling away, check the immediate vicinity. Always make sure that you have a clear field of vision and, in particular, look out for children within the operating area of the machine.
- ▶ When the vehicle is in motion, lock the control devices on tractor.
- ▶ Close the ball valve.
- ▶ Do not transport people or objects on the machine.
- ▶ Adjust your speed to road conditions.
- ▶ Do not exceed a maximum speed of 40 km/h (25 mph). Comply with the national speed limits.
- ▶ Ensure sufficient steering and braking capability. Driving characteristics, steering, and braking capability are all influenced if the machine is coupled (increased braking distance as a result of greater inertia).
- ▶ There is a danger of tipping on slopes and if corners are taken too fast. Ensure that you drive in a careful manner, which is adapted to the road conditions.



## Safety

The following applies for all preparations on the field:



### Observe the safety information

Disregard for safety information can lead to serious or fatal injury. See chapter »Safety«, page 7.



### Switch off the tractor and secure it

Before you dismount:

- ▶ Switch off the PTO shaft drive.
- ▶ Lower all implements to the ground.
- ▶ Switch all operating controls to their neutral or park position.
- ▶ Put the tractor's parking brake into the park position.
- ▶ Switch off the tractor.
- ▶ Remove the ignition key.
- ▶ Secure the tractor against rolling away.

An unsecured tractor can run you over or trap you. Serious or fatal injury may be caused as a result.

### Avoid the hazard area

The rotors are considered a hazard area. Do not stand in the hazard area. The rotors may lower or turn. Serious or fatal injury may be caused as a result.



### Close the ball valve

Close the ball valve before adjusting. If the ball valve is open and there is an operating error, the machine may drop or swing out unexpectedly. Damage to the machine or accidents with serious or fatal injuries may be caused as a result.

# Preparations on the field



## **Secure the machine**

Secure the machine against accidental starting and rolling away. Use wheel chocks. The machine must stand on a level, firm and secure surface and be supported during the work, if necessary. Unsecured or non-supported machines can cause accidents. Serious or fatal injury may be caused as a result.

## **No persons in the working area**

Ensure that no persons – children in particular – are present in the slewing and working area of the machine. Persons could be caught by the machine within this area. Extremely serious or fatal injury may be caused as a result.



## **Observe the slewing process**

Observe the rotors during the slewing process. If the machine behaves unusually during the process, stop immediately to avoid damage.

## **Change the swath width in the headland position**

When the rotors are extended with the machine at a standstill, the tines must not be in contact with the ground. Only change the swath width in the headland position. Otherwise, the machine may be damaged.

## General

The following worksteps are described in this section:

- »Folding the machine into the work position«
- »Removing the tine covers«
- »Adjusting the swath board«

## Folding the machine into the work position


After road transport, the machine is brought into the work position on the field. Follow the handling instructions below:

## Shutting the machine down



- ▶ Place the machine onto ground that is as flat as possible.
- ▶ Switch off the tractor engine, put the parking brake in the park position, remove the ignition key and secure the tractor against rolling away.


## Removing the tine covers



### Firmly secure the accessories

Accessories not in use must always be stowed and secured in the holders provided. When the machine is in motion, unsecured accessories can come loose. Damage to the machine and serious or fatal injury may be caused as a result.


- ▶ Remove all of the tine covers.



- ▶ Place the tine covers in the two holders on the left and right of the main frame.
- ▶ Secure the tine covers in the holder with safety splints.

# Preparations on the field



## Lowering the rotors





### No persons in the working area

Ensure that no persons – children in particular – are present in the slewing and working area of the machine. Persons could be caught by the machine within this area. Extremely serious or fatal injury may be caused as a result.

- ▶ Place the machine onto ground that is as flat as possible.




- ▶ Switch on the tractor engine.
- ▶ Use the single-acting hydraulic control device to release the lift arm locking mechanism.
- ▶ Pull the rope on the mechanical lock and keep the rope tensioned.



- ▶ Lower the machine into the work position using single-acting hydraulic control device.
- ▶ Release the mechanical lock rope.
- ▶ Switch off the tractor engine, put the parking brake in the park position, remove the ignition key and secure the tractor against rolling away.

## Folding out the guard bars



After the tine supports have been attached, all protective devices must be moved from transport to work position.


Fold out the guard bar as follows:

- ▶ Release the guard bar by pulling it out of the lock for the transport position.
- ▶ Fold the guard bar through 180° and engage it in the latch for the work position.

# Preparations on the field

## Adjusting the swath board

### Adjusting the swath former in relation to the direction of travel




The swath former is folded into the correct position when changing from the transport to the work position.

It is possible to adjust the direction of travel of the swath former as follows:

- ▶ Remove the bolts.
- ▶ Move the swath former into the desired position.
- ▶ Fit the bolts and tighten them in the new position.

### Adjusting the swath former's height



It is possible to adjust the height of the swath former as follows:

- ▶ Loosen the bolts.
- ▶ Adjust the height of the swath former.
- ▶ Tighten the bolts in the new position.

## Safety



### **Observe the safety information**

Observe the safety information. Disregard for safety information can lead to serious or fatal injury. See chapter »Safety«, page 7.

### **No riding on the machine**

Persons or objects must never be transported on the machine. Carrying passengers – particularly children – on the machine is life-threatening and prohibited. Serious or fatal injury may be caused as a result.

### **No persons in the working area**

Ensure that no persons – children in particular – are present in the slewing and working area of the machine. Persons could be caught by the machine within this area. Extremely serious or fatal injury may be caused as a result.

### **Maximum PTO stub shaft speed 540 rpm**

The PTO stub shaft speed must not exceed 540 rpm and must be adapted to the condition of the crop. Higher revolution rates can cause damage to the machine.

### **Only allow the PTO shaft clutch to respond for a short time**

Do not allow the slip clutch to respond for longer than 3 seconds. If the clutch responds for a longer period of time, it will become worn and the disconnect torque will drop.

### **Do not compress the PTO shaft**

The PTO shaft between the tractor and machine must not be compressed when in the work position or transport position. If compressed, PTO shafts can cause damage to the machine and tractor.

### **Observe the contour of the terrain**

Pay even more attention when driving on an incline. Avoid inclines on which the combination (tractor and machine) could slip or overturn. There is an increased risk of tipping and injury in a position at right angles to the direction of the slope.

### **Changes in the centre of gravity**

The machine's centre of gravity changes in the single rotor work position. Pay even more attention when driving on an incline. Avoid inclines on which the combination (tractor and machine) could slip or overturn. There is an increased risk of tipping and injury in a position at right angles to the direction of the slope.

## General

The following worksteps are described in this section:

- »Swathing«
- »Dual rotor operation«
- »Single rotor operation with ?hydraulic single lift [+]«
- »Adjusting the swath width«
- »Driving on headlands«



### **Suitable working speeds**

Select a driving speed (approx. 4 to 12 km/h / 2.5 to 7.5 mph) at which the crop is picked up cleanly and completely. The working speed depends on the machine settings and the particular crop.

### **Swath width**

The swath width depends on working width, working speed, tine lifting settings and transverse rotor pitch as well as crop condition.

The swath width is between approx. 1.20 m and approx. 2.00 m (3.94 and 6.56 ft).



## Swathing



### No persons in the working area

Ensure that no persons – children in particular – are present in the slewing and working area of the machine. Persons could be caught by the machine within this area. Extremely serious or fatal injury may be caused as a result.

## Requirements


After setting the machine as described in chapter »Preparations on the field« page 65, you can start swathing.

The machine is set correctly as follows:

- Swath former adjusted.
- Tine supports attached and secured.
- The single-acting hydraulic control device is set to the floating position.
- Adjust the lowering speed for the tractor hydraulics so that the machine is not damaged while setting it down.
- Machine in work position.



## Starting work



- ▶ Open the ball valve.
- ▶ Check that there is nobody in the working area of the machine.
- ▶ Switch on the tractor engine.



- ▶ Switch on the PTO shaft at a low engine speed.
- ▶ Slowly increase the speed.  
Do not exceed the maximum speed of 540 rpm.
- ▶ Select a driving speed at which the crop is picked up cleanly and completely.



Start swathing at the edge of the field and at headlands to avoid subsequently driving over the crop.

The slip clutch of the machine may also respond at low speed if resistance is increased due to excess crop or obstacles.

# Operation

## Working speed



### Avoid crossing over swathes

As a general rule, avoid crossing over swathes. The crop is distributed unevenly and the machine is subjected to abrupt stresses. Otherwise, damage to the machine may be caused as a result.

### Allow ample space when driving around obstacles

Obstacles must be circumnavigated in good time and at a distance. Due to the large width and length of the machine, it reacts slowly and tends to overrun. Otherwise, damage to the machine may be caused as a result.

A constant working speed is essential for uniform crop processing. The working speed should be set between 4 and 12 km/h (between 2.5 and 7.5 mph). The working speed depends on ground and crop conditions.

- ▶ Select a working speed at which the crop is picked up cleanly and completely.

## Swath deposit




### Distance from the rotor

Maintain a safe distance from the rotor when it is rotating. Nobody may remain in close proximity to the machine when tedders and rakes are running. Serious or fatal injury may be caused as a result.

The following basic types of swath deposit are possible:

- »Dual rotor operation«, page 74.
- »Single rotor operation with hydraulic single lift [+]<«, page 75.


## Dual rotor operation



Create a central swath with two rotors.

- ▶ Switch on the PTO shaft drive at low speed.
- ▶ Select a driving speed at which the crop is picked up cleanly and completely.

## Single rotor operation with hydraulic single lift [+]



### Distance from the rotor

Maintain a safe distance from the rotor when it is rotating. Nobody may remain in close proximity to the machine when tedders and rakes are running. Otherwise, serious or fatal injury may be caused as a result.

The optional hydraulic single lift on the standard machine is included in the scope of delivery for the Hydro version. The hydraulic single lift makes it possible to deposit the crop using either the right-hand or left-hand rotor.

## Single swath with left rotor



▶ Switch on the pilotbox and set the 3-way switch to C.



▶ Raise the right rotor using the single-acting hydraulic control device.

▶ Switch the 3-way switch to the neutral position and switch off the pilotbox.

The left rotor picks up the crop.

## Single swath with right rotor



▶ Switch on the pilotbox and set the 3-way switch to "A".




▶ Raise the left rotor using the single-acting hydraulic control device.

▶ Switch the 3-way switch to the neutral position and switch off the pilotbox.

The right rotor picks up the crop.

# Operation

## Adjusting the swath width



By extending the rotors, the swath width can be adjusted to suit the crop volume and the swath type using the double-acting hydraulic control device. This function applies to both the standard and Hydro versions.




For adjustment of the swath width, the machine should be in the headland position. Otherwise, the machine may be damaged.



- ▶ Switch off the pilotbox.
- ▶ Using the single-acting hydraulic control device, raise the machine to the headland position.
- ▶ Using the double-acting hydraulic control device, extend the telescopic arm in order to increase the swath width.
- ▶ Using the double-acting hydraulic control device, retract the telescopic arm in order to reduce the swath width.

## Driving on headlands



The rotors can be raised for crossing swaths that have already been deposited.



- ▶ Switch off the pilotbox.
- ▶ Using the single-acting hydraulic control device, raise the machine to the headland position.
- ▶ Lower the rotor again, in order to create new swath.

## Safety

The following applies to all cleaning and care work:



### Observe the safety information

Observe the safety information. Disregard for safety information can lead to serious or fatal injury. See chapter »Safety«, page 7.



### Secure the machine

- Switch off the PTO shaft drive.
- Depressurise the hydraulic system.
- Whenever possible, uncouple the tractor.
- Switch all operating controls to their neutral or park position.
- Put the tractor's parking brake into the park position.
- Switch off the tractor and remove the ignition key.
- Ensure the machine is standing on firm, secure and level ground, and provide additional support, if necessary.
- Secure the machine against rolling away.



Only if these regulations are observed can safe working be ensured during care and maintenance work. Unsecured or non-supported machines can cause accidents. Extremely serious or fatal injury may be caused as a result.

### No persons in the working area

Ensure that no persons – children in particular – are present in the slewing and working area of the machine. Persons could be caught by the machine within this area. Extremely serious or fatal injury may be caused as a result.



### Clean the bearings and hydraulic parts with care

Exercise caution when cleaning with a high-pressure cleaner. Bearings, seals and pipe unions are not waterproof. The bearings, seals and pipe unions must not come into direct contact with a high pressure water jet. Metal surfaces can corrode. After each cleaning procedure, lubricate the bearing points and grease uncoated parts. Otherwise, damage to the machine may be caused as a result.

# Cleaning and care

## General

The following worksteps are described in this section:

- »Cleaning«
- »Care«

## Cleaning



- ▶ Switch off the tractor PTO shaft drive.
- ▶ Using the hydraulic control device, fold the machine into its work position.
- ▶ Leave the machine coupled to the tractor's lower links.
- ▶ Lock the hydraulic control device.



- ▶ Switch off the tractor engine, put the parking brake in the park position, remove the ignition key and secure the tractor against rolling away.
- ▶ Do not clean the bearings and piston rods of hydraulic cylinders using a high-pressure cleaner.
- ▶ After each use, clean the machine of any coarse dirt and crop residue.

## After cleaning

- ▶ Lubricate all bearings after cleaning.  
→ Observe the chapter »Maintenance« and the following pages.
- ▶ Replace missing warning signs and stickers.

## Care

For a long service life, we recommend the following:

- ▶ Apply a protective layer of oil to all uncoated work tools. Only use approved, biodegradable oil, e.g. rapeseed oil.
- ▶ Repair any paint damage.

## Setting down the machine in a secure position



When setting down and parking the machine, special safety precautions have to be observed:

### **Observe the safety information**

Observe the safety information. Disregard for safety information can lead to serious or fatal injury. See chapter »Safety«, page 7.

### **Keep children away from the machine**

Forbid children from playing on or around the machine. Select a parking area to which no unauthorised persons have direct access. Metal edges and machine work tools can cause serious injury.

### **Make sure the machine is standing level**

Before changing from the transport to the work position (and vice versa), make sure the machine is standing level. The machine could tip over, particularly on hillside locations. Damage to the machine and serious or fatal injury may be caused as a result.


## General

The machine must be uncoupled in the reverse order to that in which it was coupled.

- Chapter »Lifting the rotors into the transport position« page 62.
- Chapter »Coupling the machine«, section »Coupling the lower link« page 42.

# Parking and storage

## Uncoupling and securing the machine



To uncouple the machine from the tractor, proceed as follows:



- ▶ Switch off the tractor PTO shaft drive.
- ▶ Set the machine down on a firm, level surface and lower it to the work position.



- ▶ Switch off the tractor engine, put the parking brake in the park position, remove the ignition key and secure the tractor against rolling away.



- ▶ Secure the machine against rolling away.
- ▶ Pull off the PTO shaft and place it on the holder provided.
- ▶ Close the ball valve and release the hydraulic couplings.
- ▶ Place hydraulic couplings in storage pockets.
- ▶ Secure all tine supports which have tips that point at right angles to the direction of travel and which are at a height of less than 2 metres (6.6 ft) with the tine covers.

- ▶ Disconnect the plug for the lighting equipment and place it in the storage pocket.

- ▶ Lower the parking stand and secure with pins.

- ▶ Wind the electrical cables onto the hook.



- ▶ Switch on the tractor engine.

- ▶ Lower the lower link until the parking stand rests safely on the ground.

- ▶ Release the latch for the lower link on the attachment carrier.

- ▶ Lower the lower link and unhitch the machine.

- ▶ Drive the tractor forwards slightly.




- ▶ Switch off the tractor engine, put the parking brake in the park position, remove the ignition key and secure the tractor against rolling away.

- ▶ Secure the machine against unauthorised use.



## Locking and securing



To secure the machine against unauthorised use, an anti-theft device corresponding to the type of coupling is included in the scope of delivery.

- ▶ Place the square tube on the pin of the lower link and secure with the u-lock.

## After the end of the season

After the end of the season and if the machine is to be stored for a long period of time, perform the following work:

- ▶ Clean the machine thoroughly.
- ▶ Check all the screwed connections and tighten the bolts.
  - Observe the correct torque specifications in chapter »Screw and bolt tightening torques« on page 86.
- ▶ Repair or replace any damaged components.
- ▶ Repair any paint damage.
- ▶ Lubricate the machine in accordance with the lubrication schedule.
- ▶ Check the tyre pressures.
- ▶ Replace missing warning signs and stickers.

## Safety

The following applies to all maintenance work:



### Observe the safety information

Observe the safety information. Disregard for safety information can lead to serious or fatal injury. See chapter »Safety«, page 7.

### Requirements for maintenance work

Only perform the maintenance work if you have the required expert knowledge and suitable tools. The absence of technical knowledge or suitable tools can cause accidents and injuries.

### Protect the machine against unintended starting

The following conditions must be observed for carrying out repairs and maintenance work and rectifying malfunctions on the machine when it is coupled:

- Switch off the PTO shaft drive.
- Switch all operating controls to the neutral or park position.
- Put the tractor's parking brake into the park position.
- Switch off the tractor engine, put the parking brake in the park position, remove the ignition key and secure the tractor against rolling away.
- Ensure the machine is standing on firm, secure and level ground, and provide additional support, if necessary.
- Secure the machine against rolling away.

Serious accidents may be caused if the machine starts accidentally.

### Use OEM replacement parts

Many components have special properties that are essential for the stability and correct operation of the machine. Only spare parts and accessories supplied by the manufacturer have been tested and approved. Other products may adversely affect the correct operation of the machine and safety. The use of non-OEM replacement parts renders the manufacturer's guarantee null and void and frees the manufacturer from all liability.

### Secure moving parts

Moving parts must be secured with lifting gear against sliding, folding or swivelling. Otherwise, serious injury to persons or damage to the machine may be caused as a result.

### Disconnect electrical connections before performing welding work

Disconnect all electrical connections from the tractor when carrying out welding on the hitched machine. Otherwise, electrical and hydraulic systems may be damaged as a result.



## Protective measures when handling oils or lubricants

Additives in oils and lubricants may have adverse effects on health. As marking in accordance with the hazardous goods regulation is not necessary, please always ensure the following:



### **Avoid skin contact**

Avoid skin contact with these materials. Protect your skin by means of protective skin cream or oil-resistant gloves. Contact can result in skin damage.

### **Do not use oils for cleaning**

Do not use oils or lubricants to clean your hands. Swarf and abraded material in these materials can also result in injuries.

### **Change out of soiled clothing**

Change out of clothing that is heavily soiled with oil as soon as possible. Oils can be hazardous to your health.



- Used oil must be collected and disposed of.
- If the skin is damaged by oil or lubricant, seek medical advice immediately.

## General

This information relates to general maintenance work. For all servicing work, the machine must be locked in the work position. If transport position is required for maintenance work, you will find appropriate information for the maintenance work.

- ▶ Lower the machine to the work position.
- ▶ Secure the machine against rolling away by using chocks.

## Direction information

Direction information (right, left, front, rear) is given in relation to the direction of travel. Rotary direction is defined as follows:

- Rotary direction right = clockwise.
- Rotary direction left = counterclockwise.
- Rotation about a vertical axis, viewed from top to bottom.
- Rotation about a horizontal axis, viewed at right angles to the direction of travel, from left to right.
- The rotation of bolts and nuts, etc. is always viewed from the operating side.

# Maintenance

## Maintenance terms

Listed in this table are short explanations of the most important maintenance terms.

Task	Explanation
Greasing	Apply grease to the slide surfaces using a brush.
Lubrication	One or two presses of the grease gun, unless specified otherwise.
Oiling	Unless specified otherwise, use only plant-based oils, such as rapeseed oils. The use of used oil will endanger your health and is also strictly prohibited.
Replacement	Replace the appropriate part in accordance with the instruction in the Maintenance chapter.
Inspection	Check the tyre pressures, adjustment dimensions and seal tightness as required, and replace any worn parts or seals.
Observe the maintenance intervals.	The specifications relate to an average usage of the machine. If subjected to heavier duty (e.g. by contracting companies), select the maintenance intervals to be shorter. Also, for extreme working conditions (for example heavy dust creation), shorter maintenance intervals are possible.

## Lubricant

Lubricant used on this machine must meet the following requirements:

Lubricant	Specifications
Gear oil	SAE 90 API-GL-4 or 5
e.g.: KUBOTA HEAVY DUTY 80W-90 GEAR OIL	
Grease	NLGI GC/LB
e.g.: KUBOTA Polyurea Grease	

## Maintenance intervals

	After the first 5 hours of operation	Daily	After 20 hours of operation	After 30 hours of operation	After 250 hours of operation	Once per season	After heavy use	As required	In case of wear	Lubrication	Greasing	Inspection	Replacement	Cleaning	Page
<b>General</b>															
All screws	●					●		●							86
Visual inspection		●					●					●			
Bearing				●			●			●					89
Hose connections						●						●			
Air pressure		●						●				●			92
Lighting equipment								●				●		●	
<b>Hydraulics</b>															
Hydraulic hoses every 6 years						●		●					●		93
Hydraulic cylinders						●	●	●				●			
Hydraulic couplings								●						●	
<b>PTO shafts</b>															
Single joints		●	●			●	●			●					89
PTO shaft guard		●			●	●				●		●			89
Profile section tube		●	●			●					●				89
<b>Gear box</b>															
Rotor gear								●				●			91
Angular gear box								●				●			91

# Maintenance


## Screwed connections

### Tightening bolts

All bolts must be retightened:

- After the first 5 hours of operation.
- According to the frequency of use.
- At least once a season.

### Screw and bolt tightening torques



#### Use the correct screw and bolt tightening torques

Securely tighten screws, nuts and bolts to the specified torques. The machine could be damaged and serious or fatal injuries could be caused.

#### Never oil or grease bolts before use

Never treat bolts and nuts with grease or oil before using them. This changes the coefficient of friction and the bolts may break off. Damage to the machine and serious or fatal injury may be caused as a result.





All bolt connections must be tightened in accordance with the table below, if no other torques are specified. On this machine, bolts with a minimum quality of "8.8" (can be seen on the bolt head) are used. The torque specifications refer to a dry coefficient of friction (0.12).

Bolt size	Bolt quality		
	8.8	10.9	12.9
<b>M6</b>	9.9 Nm (7.3 ft.lbs)	14 Nm (10.3 ft.lbs)	17 Nm (12.5 ft.lbs)
<b>M8</b>	24 Nm (17.7 ft.lbs)	34 Nm (25 ft.lbs)	41 Nm (30.3 ft.lbs)
<b>M10</b>	48 Nm (35.4 ft.lbs)	68 Nm (50.2 ft.lbs)	81 Nm (59.8 ft.lbs)
<b>M12</b>	85 Nm (62.7 ft.lbs)	120 Nm (88.6 ft.lbs)	145 Nm (107 ft.lbs)
<b>M14</b>	135 Nm (99.6 ft.lbs)	190 Nm (140 ft.lbs)	230 Nm (166 ft.lbs)
<b>M16</b>	210 Nm (155 ft.lbs)	290 Nm (214 ft.lbs)	350 Nm (258 ft.lbs)
<b>M20</b>	410 Nm (302 ft.lbs)	580 Nm (428 ft.lbs)	690 Nm (509 ft.lbs)



Tighten safety bolts and lock nuts to a 10% higher value.


## Special tightening torques




Observe the special tightening torques for the following screwed connections:

- Tine arm clamping bolt: 90 Nm (67 ft.lbs).
- Tine arm fixing bolt: 110 Nm (81 ft.lbs).
  
- Spring tines: 90 Nm (67 ft.lbs).
  
- 290 Nm (215 ft.lbs) Chassis wheel nuts.
  
- Wheel nuts on the rotor chassis: 20 Nm (15 ft.lbs).


# Maintenance



- M20 nut, rotor chassis wheel stud: 450 Nm (332 ft.lbs).



- ▶ M14 serrated flange bolt for the rotor gear: 230 Nm (170 ft.lbs).



- ▶ On a level surface, tighten the bolts evenly, alternating between the bolts. This ensures that the connection is distortion-free. Otherwise, damage to the machine may be caused as a result.



## Lubrication points for grease

### Working with a grease gun




- Before applying the grease gun
- ▶ clean grease fittings and
  - ▶ grease gun attachment fitting.


- Lubrication points are marked with an information label.
- Lubricate the bearings with one or two presses of the grease gun. If you feel resistance at the second press, do not press a second time. Too much grease will force the bearings apart. Dust and dirt can penetrate into the bearings. This leads to premature wear.

Lubricate the places listed in the illustration as follows:


- After the first 5 hours of operation.
- after 50 hours of operation.
- before and after the season.
- Each time after cleaning with a high-pressure cleaner




Steering rod




Bearing housing



Steering




Transport chassis




Rotor chassis


Attachment carrier and steering




2x lifting cylinder, lower side



4 x lifting arm bearings



4x tandem axles [+]



## Lubricating the PTO shafts

The PTO shaft manufacturer's own operator's manual is included with each PTO shaft. This includes detailed information on the relevant version of the PTO shaft.




## Check the guard components

Check all guard components of the PTO shafts for wear or damage (visual inspection). Replace any defective guard components. An unguarded PTO shaft or damaged guard components can cause very serious injuries during operation.

Lubricate the single joints and their couplings as follows:

- after 50 hours of operation.
- before and after the season.
- each time after cleaning with a high-pressure cleaner.



Grease the profile section tubes:


- after 50 hours of operation.
- before and after the season.
- each time after cleaning with a high-pressure cleaner.

Lubricate the guard as follows:


- after 250 hours of operation.
- before and after the season.
- each time after cleaning with a high-pressure cleaner.

## PTO shaft for rotors (side shaft)

To lubricate the PTO shaft, remove it on the coupling side and slide the profile section tubes together.



## PTO shaft for main drive



## Filling quantities



### Observe the correct fill quantities

Observe the correct lubricant fill quantities. Check them regularly. A lubricant level which is too low or too high may result in damage to the machine.

The main gear box and rotor gear require no maintenance.

Gear box	Oil volume [litres] SAE 90 API-GL-4
Angular gear box	1.0 (1.07 US qt)
Rotor gear, left	6.2 (5.46 US qt)
Rotor gear, right	6.2 (5.46 US qt)



- No oil change is required.
- The maintenance-free gear box is filled ex works with sufficient oil.
- ▶ Only check the oil level, with the machine in the work position (positioned horizontally), if there is visible oil loss.

# Maintenance

## Tyres



### **Do not drive with worn or damaged tyres**

Replace worn or damaged tyres immediately. There is a high risk of accident when driving on the road with such tyres.

## Tyre pressure

Check the tyre pressures on a regular basis:

- daily.
- before any road transport
- as required (for example before setting the tine height).
- before and after the season.

	<b>Tyre pressure [bar]</b>
Rotor chassis	1.5 (22 psi)
Transport chassis	2.5 (36 psi)

## Hydraulics



### Hydraulic system at zero pressure

Work must only be performed on the hydraulic system if the tractor and machine hydraulic system is at zero pressure. A pressurised hydraulic system can trigger unpredictable movements of the machine and can cause serious damage to the machine and personal injury. Serious or fatal injury may be caused as a result.

### Exercise caution when welding

Do not perform any welding work in the vicinity of the hydraulic hoses. Hydraulic oil can catch fire very easily.

### Clean hydraulic system

Close or disconnect the quick-release couplings with great care. Remove any dirt or air which has entered the hydraulic system. The hydraulic system may otherwise be seriously damaged. Material damage or personal injury may be caused as a result.

### Collect escaping oil

Escaping oil must be collected and disposed of in accordance with national regulations. Otherwise, damage may be caused to the environment.

## Hydraulic hoses



### Replace hydraulic hoses every six years or sooner

Hydraulic hoses age without showing externally visible signs. Replace hydraulic hoses every six years or sooner. Use hydraulic hoses only with the same technical specifications. The required information is printed on the hydraulic hose. Defective or incorrect hydraulic lines can cause serious or fatal injuries.


Hydraulic hoses age without showing externally visible signs. We therefore recommend replacing the hydraulic hoses every six years.



- ▶ Lower the machine to the work position.
- ▶ Depressurise the system.
- ▶ Switch off the tractor engine, put the parking brake in the park position, remove the ignition key and secure the tractor against rolling away.
- ▶ Disconnect the hydraulic hoses.
- ▶ Replace hydraulic hoses.

# Maintenance


## Checking sliding elements



The sliding elements on the two lifting arms ensure smooth and even running of the telescopic arms. The sliding elements must be checked on a regular basis, and readjusted and the sliding surfaces lubricated if necessary.

- ▶ Check that the telescopic arms retract and extend correctly in the headland position. Readjust the sliding elements in the case of:
  - Uneven or jerky movements of the lift arms in the headland position.
  - Inclined position of the telescopic arm in the lift arm.
  - Large vibrations of the rotor in the headland position.

## Adjusting the sliding elements



- ▶ Fold the machine into its work position.
- ▶ Undo the lock nut.
- ▶ Adjust the sliding element by means of bolts so that the telescopic arm moves in and out evenly and freely in the headland position.
- ▶ Tighten the lock nut.
- ▶ Using a brush, apply grease to the sliding surfaces of the telescopic arms.




When readjusting the sliding elements, make sure that you first tighten the screws until they lock (max 20 Nm), then slacken them slightly (approx. 1/2 turn).

- If the sliding elements are fastened too tightly, the telescopic arms will not travel smoothly.
- If the sliding elements are not fastened sufficiently, the rotor will vibrate.
- In both cases, this may result in damage to the machine.

## Checking the track

If the machine rolls at an offset angle to the tractor when driving a straight line, the directional stability must be re-adjusted.




### Never carry out work on the steering

Contact your dealer if specifications differ. Never carry out any work on the steering or tracking yourself. This can result in traffic accidents and accidents causing serious or fatal injuries.



Check the tracking as follows:

- ▶ Switch off the tractor engine, put the parking brake in the park position, remove the ignition key and secure the tractor against rolling away.
- ▶ Check the values in accordance with the tables.




	Designation	Target value
L1	Control length of the front steering rod	2019 mm (79.50 in)
LH	Control length of the rear steering rod	2612 mm (102.84 in)
S	Lengths of the track rods	1015 mm (39.96 in)
A	Track A at the front sides of the tyres	A
A'	Track A at the rear sides of the tyres	A + 3 mm (0.12 in)

# Accessories

## Additional equipment

Optional additional equipment does not form part of the standard scope of delivery, and, in this manual, is indicated by a plus symbol [+]. Additional equipment is available to order from your dealer.

### Tine saver




For a good swath deposit, both tine legs must run parallel to one another. This must also be ensured after fitting the tine saver.

Proceed as follows:

- ▶ Fit one tine saver on each tine.
- ▶ Check the direction of rotation of the rotor. The nuts must be attached against the rotor direction.
- ▶ Check the tine position. The tine legs must be parallel.
- ▶ If necessary, loosen the screwed connection until both tine legs run parallel.

### Hydraulic single lift [+]




The optional hydraulic single lift enables single rotor operation.



The hydraulic single lift must be fitted by an authorised workshop. Separate assembly instructions are supplied.

### Spare wheel




The optional spare wheel is fitted to the guard bar of the machine.



- The spare wheel is fitted to the machine's guard bar.
- Separate assembly instructions are supplied.



## Tandem axles



The optional tandem axles make for better contours. Note: the wide track is in front.



- The tandem axles replace the rear running wheels of the rotor chassis.
- Separate assembly instructions are supplied.

# Fault elimination

## Faults

Faults can often be eliminated quickly and easily. Before contacting Customer Service, refer to the table to check whether you can remedy the fault yourself.



### What to do in the event of a fault

In case of a fault, proceed as follows:

- ▶ Immediately stop operation.
- ▶ Switch off the tractor PTO shaft drive.
- ▶ Switch off the tractor and secure it.

The fault must be repaired before work can be resumed. Otherwise, damage to the machine and serious or fatal injury may be caused as a result.

Problem	Cause	Solution
Rotor is leaving crop behind on one side and is digging too deeply into the ground on the other side.	Incorrect adjustment of rotor pitch.	→ Chapter »Preparing for use«, section »Rotor pitch«, page 53.
Rotor is leaving crop behind across the entire width.	Working depth (raking height) set too high.	→ Chapter »Preparing for use«, section »Rotor pitch«, page 53.
Crop is heavily contaminated.	Rotor tines set too low.	→ Chapter »Preparing for use«, section »Rotor pitch«, page 53.
		→ Chapter »Coupling the machine«, section »Coupling the lower link«, page 42.
Machine not operating cleanly at high speed.	Rotor tines set too high. Uneven terrain.	→ Chapter »Preparing for use«, section »Rotor pitch«, page 53.
	Speed too high to process crop mass	Reduce speed.
Rotor dragging crop along – Unclean swath form	Crop mass too large.	Reduce speed.
	Rotary speed too high.	Reduce speed.
PTO shaft coupling responding frequently	Crop mass too large or uneven.	Reduce speed.
	Rotor tines set too low.	→ Chapter »Preparing for use«, section »Rotor pitch«, page 53.
Noise production during work	Loose screwed connections or worn-out tine supports.	Check tine supports and screwed connections on tines.
	Tine support bent	
Machine rolls offset behind the tractor when driving in a straight line.	Steering/tracking incorrectly adjusted or worn out.	Contact dealer.

Problem	Cause	Solution
Rotor not working cleanly.	Poor adaptation to the contours of the land due to severe rotor load relief	Please consult your dealer. You will find assistance under »Circuit diagrams«, page 101.
Inner lifting arms have stiff and heavy action	Sliding elements wrongly adjusted	Adjust sliding elements correctly. See »Checking sliding elements«, page 94.

## Electronic system faults


Problem	Cause	Solution
Pilotbox is not functioning.	The control device has no power.	<ul style="list-style-type: none"> <li>▶ Switch the pilotbox on.</li> <li>▶ Check the power supply for the system.</li> <li>▶ Check the fuses.</li> </ul>
	Internal pilotbox problem.	Please consult your dealer.

## Hydraulic system faults















Problem	Cause	Solution
No functions are carried out via the hydraulic control device using the control box.	Defective solenoid valve	<ul style="list-style-type: none"> <li>▶ If required, carry out the emergency function.</li> <li>▶ Check the solenoid valve.</li> <li>▶ Replace the defective solenoid valve.</li> </ul>

# Fault elimination

## Emergency manual function




A defective solenoid valve can be switched manually. Do not continue working. Fold the machine to the transport position in order to replace the defective valve.

-  ▶ Switch off the PTO shaft drive.
  -  ▶ Switch off the pilotbox.
  -  ▶ Switch off the tractor engine, put the parking brake in the park position, remove the ignition key and secure the tractor against rolling away.
  -  ▶ Close the ball valve.
  -  ▶ Loosen the hexagon socket bolt on the solenoid valve.
  -  ▶ Screw in the hexagon socket bolt of the solenoid valve concerned. The solenoid valve switches.
  -  ▶ Leave the hazard area.
  -  ▶ Open the ball valve.
  -  ▶ Switch on the tractor engine.
  -  ▶ Perform the desired functions using the hydraulic control device.
    - Bring the machine into the transport position.
    - Fully lower the hydraulic transport chassis.
    - The defective solenoid valve must be depressurised.
  -  ▶ Switch off the tractor and secure it.
  -  ▶ Close the ball valve.
  -  ▶ Replace the defective solenoid valve.
-  No emergency manual function is necessary for the lift arm solenoid valves. These valves are “normally open”.


## Hydraulic circuit diagram

### Standard version




# Circuit diagrams

## Hydro version




## Pilotbox circuit diagram



Pilotbox	Solenoid valve connection	Function
A	Y1	Raise and lower the left-hand lift arm.
B	Y2	Raise and lower the transport chassis.
C	Y3	Raise and lower the right-hand lift arm.

# Circuit diagrams

## Lighting circuit diagram





## Disposal

During decommissioning, the individual parts must be disposed of properly and in an environmentally friendly manner. Please observe the waste disposal guidelines that are currently in force.

### Plastic parts

Plastic parts can be disposed of in normal household waste (residual waste), depending on the laws specific to your country.

### Metal parts

All metal parts can be sent for recycling.

### Oil


In terms of waste legislation, environmentally-compatible hydraulic oils must be stored, collected and disposed of separately in accordance with regulations.

### Rubber

Rubber parts, such as hoses or tyres, must be brought to a rubber recycling centre.

# Original EC Conformity Declaration

**Conforms to EC  
Directive  
2006/42/EC**



Type plate and CE marking

We

**Kverneland Group Kerteminde AS  
Taarpstrandvej 25  
DK-5300 Kerteminde  
Denmark**

declare with sole responsibility that the product

**Andex 724, 724 Hydro  
RA2072, RA2072 Hydro  
9472 C, 9472 Hydro  
and its accessories**

**Model: VF6967**

**Valid from machine number:  
VF69671582 –**

in accordance with the above-mentioned EC Directive.

The following harmonised standards have been quoted:

- EN ISO 4254-1:2015
- EN ISO 4254-10:2009 + AC:2010

Kverneland Group Kerteminde AS  
Kerteminde, 13.11.2017

Uwe Kellermeier

CEO  
and authorised representative\*

\* person who is responsible for compiling the technical documentation and resides in the European Community. See address above.

<b>A</b>		<b>M</b>	
Adjusting		Machine	
Chassis	53	Putting away after the season	81
Rotor pitch	53	Setting down	79
Single-pass swath	74	Uncoupling	79
Swath former	76	Maintenance	82
Working depth	53	Screwed connections	86
Anti-theft device	81	Maintenance intervals	85
		Maintenance terms	84
<b>C</b>		<b>O</b>	
Care	78	Oil	
Check list		Filling quantities	91
Headlands	76	Protective measures	83
Road transport	64	Operation	71
Circuit diagram			
Hydraulics	101	<b>P</b>	
Lighting equipment	104	Preparation	
Cleaning	78	Transport position	60
Connection		Work position	66
Electrical	46	Preparations on the field	65
Hydraulic couplings	48	Proper use	24
Coupling		PTO shaft	
PTO shaft	44	Attaching	44
		Lubrication	89
<b>D</b>		<b>R</b>	
Declaration of Conformity	106	Range of application	24
Designation of components	25	Road transport	58
Direction information	83		
Disposal		<b>S</b>	
Metal parts	105	Safety	7
Plastic parts	105	Care and maintenance	21
Dual rotor operation	74	Operation	19
		Pictorial symbols	9
<b>E</b>		Road transport	17
EC Declaration of Conformity	106	Unhitching	20
<b>F</b>		Scope of delivery	
Filling quantities	91	Checking	36
		Screw and bolt tightening torques	86
<b>L</b>		Speed	64
Lower link		Swath deposit	74
Coupling	42	Dual rotor operation	74
Lubricant	84	Swath former	
Lubrication points	89	Adjusting the direction of travel	70
General	89	Adjusting the height	70
Machine	89	Swath width	
PTO shafts	89	Adjusting	76

# Index

## T

Target group	4
Technical specifications	
Dimensions in transport position	26
Dimensions in work position	27
Implement equipment	29
Machine equipment	29
Tractor equipment	28
Weights	28
Tightening torques	
Rotor gear	88
Spring tines	87
Tine arms	87
Wheel stud on the rotor chassis	88
Wheels on the rotor chassis	87
Wheels on the transport chassis	87
Two-wheel rake	24
Tyres	92
Replacing tyres	92
Tyre pressure	92

## W

Wheel chocks	45
--------------	----