

OPERATOR'S MANUAL

KUBOTA TRACTOR

MODELS M8-181 KVT

M8-201 KVT



READ AND SAVE THIS MANUAL

Kubota

Foreword

To the Owner

This manual contains information concerning the operation, adjustment, and maintenance of tractors. You have purchased a dependable machine. With proper care and operation, you can expect to receive the performance and long service we have built into this tractor.

MAKE SURE ALL OPERATORS READ THIS MANUAL CAREFULLY AND KEEP IT AVAILABLE FOR READY REFERENCE.

The tractor was designed to power and propel itself and common agricultural equipment in normal and customary agricultural applications. Safe operation of the tractor requires that all operators are familiar with the instructions in this manual and follow guidance herein for correct use of the tractor. The dealer will instruct you in the general operation of your tractor. The dealer's staff of factory-trained service technicians will be glad to answer any questions that may arise regarding tractor operation.

For engine maintenance not covered in this manual, follow instructions provided in the Cummins Engine Operator's Manual. Before putting the tractor in service, become familiar with all operating functions and procedures outlined in both manuals.

The warranty coverage extended to the tractor is explained in the Warranty and Limitation of Liability Agreement form. The dealer will provide you with a copy of the warranty and retain a copy which you have signed. After you read the warranty, ask the dealer to explain any points that you may not understand.

Do not modify, alter, or permit anyone else to modify or alter this tractor or any of its components, or any tractor function, without first consulting a dealer. To find a dealer, visit KUBOTA.com. Contact a dealer for any questions regarding tractor modifications.

Your safety, and the safety of those around you, depends upon the care and good judgment you use while operating this equipment. Read the safety precautions carefully.

For a complete list of the delivery service checks performed by the dealer, refer to the Delivery Report in this manual. The first copy is your record of service performed by the dealer, which is to be removed from the manual, the second copy is the dealer's record. Make sure that you and the dealer sign both copies.

After you have operated the tractor for 50 hours, have the dealer perform the factory recommended First 50-hour service. Return this manual with your tractor to the dealer so the "First 50-hour Service" checklist can be filled out. You will be responsible for the cost of transport, lubricants, fluids, filters and other items replaced as part of normal maintenance. Prior to taking the tractor to your selling dealer for service, it is recommended that you contact the dealer to determine if there are any other charges you will be responsible for.

All data given in this book is subject to production model variations. Dimensions and weights are approximations only, and illustrations do not necessarily show tractors in standard condition. For exact information about any particular tractor, please contact the dealer.

Improvements

KUBOTA is continually striving to improve our products. We reserve the right to make improvements or changes when it becomes practical and possible to do so, without incurring any obligation to make changes or additions to the equipment sold previously.

This Page Is Intentionally Left Blank.

Cummins Engine Information

Engine Manual - KUBOTA tractors are powered by Cummins™ engines. You are provided with a copy of the Cummins owner's manual. If you do not have a copy of the Cummins engine manual for your tractor, you may request one from your KUBOTA dealer or contact Cummins Inc. at:

Box 3005, Columbus, IN 47202-3005. Telephone 800-343-7357, fax 800-232-6393, internet www.cummins.com

Modification and Warranty

Any attempt to alter or modify the engine or engine sub-systems is a violation of the warranty terms and will result in immediate termination of the engine and tractor warranty.

Any attempt to modify the tractor or tractor sub-components without specific instruction to do so from service support may, at the sole discretion of KUBOTA, result in loss of warranty.

Disclaimer

KUBOTA Corporation makes no warranty or guarantee of any kind, written or expressed, implied or otherwise with regard to the information contained within this manual. KUBOTA Corporation assumes no responsibility for any errors that may appear in this manual and shall not be liable under any circumstances for incidental, consequential or punitive damages in connection with, or arising from, the use of this manual. KUBOTA reserves the right to make changes to this manual at any time without obligation or notice.

KUBOTA

Since its inception in 1890, KUBOTA Corporation has grown to rank as one of the major firms in Japan. To achieve this status, the company has through the years diversified the range of its products and services to a remarkable extent. 30 plants and 35000 employees produce over 1000 different items, large and small.

All these products and all the services which accompany them, however, are unified by one central commitment. KUBOTA makes products which, taken on a national scale, are basic necessities. Products which are indispensable. Products which are intended to help individuals and nations fulfill the potential inherent in their environment. KUBOTA is the Basic Necessities Giant.

This potential includes water supply, food from the soil and from the sea, industrial development, architecture and construction, and transportation.

Thousands of people depend on KUBOTA's know-how, technology, experience and customer service. You too can depend on KUBOTA.

You are now the proud owner of a KUBOTA Tractor. This tractor is a product of KUBOTA quality engineering and manufacturing. It is made of fine materials and under a rigid quality control system. It will give you long, satisfactory service. To obtain the best use of your tractor, please read this manual carefully. It will help you become familiar with the operation of the tractor and contains many helpful hints about tractor maintenance. It is KUBOTA's policy to utilize as quickly as possible every advance in our research. The immediate use of new techniques in the manufacture of products may cause some small parts of this manual to be outdated. KUBOTA distributors and dealers will have the most up-to-date information. Please do not hesitate to consult with them

California Proposition 65



WARNING



Diesel engine exhaust and some of its constituents are known to the State of California to cause cancer, birth defects, and other reproductive harm.

Battery posts, terminals and related accessories contain lead and lead compounds, chemicals known to the State of California to cause cancer and birth defects or other reproductive harm. Wash hands after handling.

Canadian Electromagnetic Compatibility (EMC)

This machine complies with Industry Canada ICES-002.

Part Number: LBT00-13943	
First Release:	03/11/2020

Units of Measurement

The following chart lists the standard units and their abbreviations used in this manual.

NOTE: All Imperial fluid measurements are in U.S. customary units.

Abbreviation	Description
~	Approximately
≈	Approximately Equal
°C	Degree Celsius
°F	Degrees Fahrenheit
A	Ampere
AWG	American Wire Gauge
bar	Bar (barometric pressure unit)
BTU	British Thermal Unit
cca	Cold Cranking Amps
ccw	Counter Clockwise (rotation)
cfm	Cubic Feet Per Minute
cid	Cubic Inch Displacement
cm	Centimeter
cm³	Cubic Centimeter
cu	Cubic (with U.S. customary units)
cw	Clockwise (rotation)
dB	Decibel (sound pressure unit)
dB(A)	Decibel A Scale
dia	Diameter
fl oz	Fluid Ounce
ft	Foot
ft-lb	Foot Pound
g	Gram
gal	Gallon
gpm	Gallons Per Minute
GVWR	Gross Vehicle Weight Rating
ha	Hectare
hp	Horsepower
Hz	Hertz
in	Inch
in-lb	Inch Pound
J	Joule
kg	Kilogram
kg/ha	Kilograms Per Hectare

Abbreviation	Description
kg/m²	Kilograms Per Square Meter
km	Kilometer
km/h	Kilometers Per Hour
kPa	Kilopascal
kW	Kilowatt
L	Liter
L/min	Liter Per Minute
L/s	Liter Per Second
lb	Pound
m	Meter
m³	Cubic Meter
mA	Milliamp
mg	Milligram
mi	Mile
min	Minute
mL	Milliliter
mm	Millimeter
mPa	Megapascal
mph	Miles Per Hour
N·m	Newton Meter
oz	Ounce
ppm	Parts Per Million
psi	Pounds Per Square Inch
pt	Pint
qt	Quart
rpm	Revolutions Per Minute
s	Second
sq	Square (with U.S. customary units)
V	Volt
W	Watt
yd	Yard
yr	Year
Ω	Ohm
2WD	2 wheel Drive

Abbreviation	Description
4WD	4 Wheel Drive
API	American Petroleum institute
ASABE	American Society of Agricultural and Biological Engineers, USA
ASTM	American Society for Testing and Materials, USA
CVT	Continuously Variable Transmission
DEF	Diesel Exhaust Fluid
DT	Dual Traction (4WD)
fpm	Feet per Minute
DPF	Diesel Particulate Filter
GST	Glide Shift Transmission
Hi-Lo	High Speed-Low Speed
HST	Hydrostatic Transmission
m/s	Meter Per Second
PTO	Power Take Off
RH/LH	Right-hand and left-hand
ROPS	Roll-Over Protective Structures
rpm	Revolutions Per Minute
r/s	Revolutions Per Second
SAE	Society of Automotive Engineers, USA
SCR	Selective Catalytic Reduction
SMV	Slow Moving Vehicle

Operator's Manual – Contents

Section 1: Safety1-1
Section 2: Controls and Instruments2-1
Section 3: Tractor Operation3-1
Section 4: Hydraulic Operation4-1
Section 5: Lubrication and Maintenance5-1
Section 6: Troubleshooting6-1
Section 7: Specifications7-1
Index7-25
First 50-hour Service Report	
Notes	

This Page Is Intentionally Left Blank.

Section 1: Safety – Contents

Introduction	.1-3
Safety Symbols	.1-4
Safety Icons	.1-5
Precautionary Safety Statements	1-13
General Safety	1-14
Cab ROPS Safety	1-15
Avoid Crystalline Silica (quartz) Dust	1-16
Before Operating the Tractor	1-16
Operating Safety	1-17
PTO Safety	1-21
Service Tractor Safety	1-22
Maintenance and Storage Safety	1-24
Electrical Safety	1-25
Battery Safety	1-26
Hydraulic System Safety	1-27
Welding Safety	1-28
Transport and Towing Safety	1-28
Diesel Fuel Handling Safety	1-29
Safety Labels	1-30
Safety Equipment and Functions	1-42
Horn	1-42
Emergency Exit	1-43
Cab/Roll-over Protection Structure (ROPS)	1-44
Roll Over Protection Structure	1-44
ROPS Maintenance and Inspection	1-44
Damage to the Cab/ROPS	1-45
Falling Object Protection System	1-45
Noise Levels	1-45
Protective Shielding	1-46
Engine Hood	1-46
Engine Side Cowlings	1-47
Battery Box	1-48
Battery Shut-off Switch	1-48
Power Off Indicator Light	1-49
Fuse Panel	1-50
Master PTO Shield	1-51
PTO Output Shaft Cover	1-51

This Page Is Intentionally Left Blank.

Introduction

This manual was prepared to assist the operator in the correct procedures for breaking in, driving, operating and maintaining this new piece of equipment. Read this manual carefully and keep it for future reference with other related information in the storage pocket (1), attached to the rear of the seat.

The manual is configured to help the operator find information in a fast, easy process. The manual is divided into the following sections:

1. Safety
2. Controls and Instruments
3. Operation
4. Hydraulic Operation
5. Lubrication and Maintenance
6. Troubleshooting
7. Specifications


Contact a Kubota dealer with any questions regarding the operation or maintenance of your Kubota equipment. Dealers have the factory trained personnel, equipment, genuine replacement parts and professional experience to meet all service and maintenance needs.

Kubota equipment is designed for performance, economy and ease of operation under a variety of operating conditions. The equipment was carefully inspected at the factory and by the dealer to make sure it is in optimum condition prior to delivery.

It is important that routine maintenance and service, as specified in this manual, is carried out at recommended intervals to maintain this condition and ensure trouble-free operation.

At Kubota our company policy is one of continuous improvement. We reserve the right to change prices, specifications or equipment at any time without notice.

IMPORTANT: Read and follow the guidelines set out in this section before operating the tractor.



The data in this manual is subject to production variations. Dimensions and weights are approximate only, and illustrations do not necessarily show equipment in standard condition. Contact a Kubota dealer for exact information about any particular piece of equipment.

Statement of Use

Kubota designed this new piece of equipment for conventional agricultural applications. Damage caused by use of the equipment in non-conventional applications, industrial applications (i.e., road building) or due to improper weights or ballast will not be covered by warranty.

Failure to follow the information contained in this manual may lead to excessive wear, premature failure and deterioration of your equipment. Personal injury and property damage may also occur.

The new piece of equipment requires proper operation service and maintenance to achieve long life and owner satisfaction.

Safety Symbols

This is the Safety Alert Symbol. It means that attention is required and that the safety of people nearby is involved. It is shown with a Signal Word (DANGER, WARNING and CAUTION) indicating that a hazard exists and with instructions to avoid the hazard.



The Signal Word DANGER indicates a hazardous situation that, if not avoided, will result in death or serious injury.



The Signal Word WARNING indicates a hazardous situation that, if not avoided, could result in death or serious injury.



The Signal Word CAUTION indicates a hazardous situation that, if not avoided, could result in minor or moderate injury.



The Signal Word *NOTICE* indicates information considered important but not hazard related (ex. messages relating to property damage).



Other Information

The following general text may also appear in the manual. The NOTE and IMPORTANT statements draw awareness to recommended procedures that will assist the operator.

NOTE: Indicates an important installation, operation and/or maintenance procedure which should be followed.

IMPORTANT: Indicates an important or specific step within the operation or maintenance procedure.

Safety Icons

The safety icons used in this manual are approved according to ISO 11684, ANSI ASABE AD11684. The icons have general meanings and are not intended to replace the text that accompanies each safety message box. Table 1-1 and Table 1-2 shows a list of safety icons that may be used in this manual.


Table 1-1: Safety Icons	
Icon	Description
	Stand back; keep a safe distance
	Risk of impact from small flying objects
	Risk of crushing; pinching of hands
	Risk of electric shock
	Risk of burns from hot surfaces
	Risk of entanglement with moving parts. Be careful of moving parts
	Vehicle may move; stand clear of moving vehicle
	Risk of fluid impingement from pressurized fluid or gas
	Risk of battery explosion
	Particles in the air; risk of inhaling dangerous substances

Table 1-1: Safety Icons	
Icon	Description
	Wear eye protection
	Wear ear protection
	Wear protective shoes
	Wear head protection
	Wear gloves
	Risk of fire; flammable substances
	Risk of rollover, tipping or overturning
	Risk of fall; falling from a height
	Seat belt; always wear a seat belt
	Reading required; read carefully; also used as a generic icon

Icon	Description
 A black icon showing a hand being crushed between two vertical bars, with an arrow pointing towards the hand.	Risk of crushing, particularly for body
 A black exclamation mark inside a triangle.	Master System Warning
 A black silhouette of a rabbit.	Fast
 A black silhouette of a turtle.	Slow
 A black silhouette of a snail.	Creep
 A black outline of a padlock.	Lock
 A solid black vertical bar.	ON (engaged)
 A black outline of a circle.	OFF (disengaged)
 A black silhouette of a wrench.	Service

Table 1-2: Engine Icons	
Icon	Description
	Diesel Fuel
	Hourmeter/Elapsed Operating Hours
	Engine Coolant-Temperature
	Engine Intake/Combustion Air-Filter
	Engine Oil-Pressure
	Water Separator
	Engine-Warning
	Engine-Rotational Speed n/min
	Engine-Rev Limiter n/min
	Engine-Over Speed n/min
	Engine-RPM Memory A n/min
	Engine-RPM Adjuster n/min

Table 1-2: Engine Icons	
Icon	Description
	Engine-RPM Increase n/min
	Engine-Run
	Engine-Start
	Engine-Stop
	Electrical Power-accessories
	Diesel Preheat/Glow Plugs (Low Temperature Start Aid)
	High Exhaust Lamp
	Regeneration
	Regeneration inhibit
	DEF/AdBlue-Level
	DEF/AdBlue-Low Level
	DEF/AdBlue-Poor Quality

Icon	Description
	DEF/AdBlue-Trouble
	DEF/AdBlue-Freeze

Icon	Description
	Travel Direction - Forward
	Travel Direction - Rearward
	Travel Direction
	4-Wheel Drive-On
	4-Wheel Drive-On
	4-Wheel Drive-Automatic
	Headland Management System
	Cruise Control
	Limp Home
	Escape

Table 1-3: Vehicle Body Icons	
Icon	Description
	Transmission Oil Filter
	Low Temperature Regulation
	Gear Shifting Warning
	Clutch
	Brake
	Parking Brake
	Parking Brake/Brake Oil
	Air Brake
	Differential Lock
	Differential Lock - Automatic

Table 1-3: Vehicle Body Icons	
Icon	Description
	Steering Wheel - Tilt
	Steering Wheel - Telescope
	Automatic Steering Control
	Steering Oil Filter
	Front Suspension
	Front Suspension - Lock

Table 1-4: PTO Icons	
Icon	Description
	PTO-Off (Disengaged)
	PTO-On (Engaged)
	PTO-540 rpm
	PTO-540E rpm
	PTO-1000 rpm
	PTO-1000E rpm
	PTO-Front
	PTO-Front
	PTO-Rear
	PTO-Rear



Table 1-5: Hydraulic Icons	
Icon	Description
	Draft Control
	Position Control
	Hydraulic Oil Filter
	Lift Arm Control-Up/Transport
	Lift Arm Control-Up
	Lift Arm Control-Down
	Lift Arm Control-Down
	Lift Arm Control-Block
	Lift Arm Control-Float
	Lift Arm Control-Lock

Table 1-5: Hydraulic Icons	
Icon	Description
	3-Point Lifting/Lowering
	Lift Arm Height
	Remote Cylinder - Retract
	Remote Cylinder - Extend
	Remote Cylinder - Float
	Remote Cylinder - Lock
	Remote Cylinder - Lock

Table 1-6: Electric Icons	
Icon	Description
	Battery Charging Condition
	Master Lighting Switch
	Headlight - Low Beam
	Headlight - High Beam
	Headlight - Flashing
	Worklight
	Position Lamps
	Turn Signal
	Turn Signal - Trailer
	Hazard Warning Lights

Table 1-6: Electric Icons	
Icon	Description
	Audible Warning Device
	Beacon Light
	Windshield Wiper
	Windshield Wiper - Intermittent
	Windshield Washer
	Rear Window Defroster

Precautionary Safety Statements

This section details the following in order:

- General safety
- Operating safety
- Maintenance and storage safety
- Electrical safety
- Battery safety
- Hydraulic system safety
- Welding safety
- Transport and towing safety
- PTO safety
- Cab safety
- Diesel fuel handling safety
- Diesel exhaust fluid handling safety



WARNING

Careful operation is your best insurance against an accident.

Read and understand this manual carefully before operating the tractor.



All operators, no matter how much experience they may have, should read this and other related manuals before operating the tractor or any implement attached to it. It is the owner's obligation to instruct all operators in safe operation

General Safety

- Use personnel protection equipment that is appropriate for the task and/or mandated by Federal, State or Local Laws or Regulations including: gloves, hard hats, boots, face and eye shields, respirators, etc.
- Use seatbelts at all times.
- New operators must read and understand the manual before using the equipment or be instructed on its use and operation.
- Do not allow unqualified persons to operate or work on the equipment.
- Review the safety precautions and operation instructions in this manual at least once a year.
- Have a first-aid kit and a Class C fire extinguisher available in the work area.
- Do not modify the equipment.
- Keep the equipment clean. Make sure all decals and warning labels are legible. Clear all debris and chaff from around the engine and all hot spots.
- Perform a proper equipment inspection as described in this manual before each use of the equipment.
- Do not by-pass or disable safety locks or devices at any time.
- If lightning is close, take the following precautions to avoid personal injury:
 - It is safe for the operator to wait in the cab. Never attempt to step off of the tractor and onto the ground as there is a serious risk of electrocution.
 - Pull over to the side of the road, turn off the engine and turn on the hazard lights. Sit in the operator's seat with your hands in your lap and wait for the storm to end.
 - Avoid touching any metal inside to outside controls or objects such as door handles, steering wheels, shift levers, radio controls. If lightning is far away where it is not an immediate danger, close the cab door.
 - Rubber tracks or tires do not provide appropriate insulation from lightning strikes.

**DANGER**

Always make sure the jack is capable of carrying the weight of the tractor. Using an inappropriate jack will result in damage to the tractor and possible injury or death of anyone working near or under it.

- If the tractor must be raised using jacks, place the jacks under the axles.
 - This tractor is not designed to be lifted off the ground (such as with a crane).
-

Cab ROPS Safety

- Kubota recommends the use of a cab or Roll Over Protective Structures (ROPS) and seat belt in almost all applications. This combination will reduce the risk of serious injury or death, should the tractor be upset. Check for overhead clearance which may interfere with a cab or ROPS.
 - If the cab or ROPS is loosened or removed for any reason, make sure that all parts are reinstalled correctly before operating the tractor.
 - Never modify or repair any structural member of a cab or ROPS because welding, bending, drilling, grinding, or cutting may weaken the structure.
 - A damaged cab or ROPS structure must be replaced, not repaired or revised.
 - If any structural member of the cab or ROPS is damaged, replace the entire structure at your local Kubota Dealer.
 - Always use the seat belt if the tractor has a cab or ROPS.
 - Do not use the seat belt if a foldable ROPS is down or there is no ROPS. Check the seat belt regularly and replace if frayed or damaged.
 - The cab is not tested for FOPS (Falling Object Protection Structure).
 - Keep the cab maintained and in clean serviceable condition. Be careful when driving through garage doorways or working in confined spaces with low headroom so as not to contact obstacles.
 - Do not drill, weld, modify or alter the cab in any way. Modifications may weaken the structure and endanger operator safety. Unauthorized modifications may be illegal in some jurisdictions and could lead to fines or prosecution.
 - Never attach chains or ropes to the cab or main frame for pulling purposes.
 - Never take unnecessary risks even though the cab affords the maximum protection possible.
 - Never carry harmful chemicals in the cab. Chemicals may spill from the container and cause damage to the cab and fumes could incapacitate the operator.
 - Never allow mud, crop residue, tools and equipment to accumulate inside the cab or on steps. They may interfere with pedal operation or entry/exit from the cab.
 - The cab is not designed to provide a “sprayer safe” environment for the operator. The cab air filtration system does not provide a specified level of protection against hazardous substances. When applying chemicals with a sprayer, do not rely on the cab filter to provide protection from airborne chemicals. When working in an area that may have vapors or aerosols in the air, refer to the product MSDS sheet for information on appropriate personal protective equipment.
 - If clothing or footwear has come into contact with harmful chemicals, remove the items before entering the cab.
-

Avoid Crystalline Silica (quartz) Dust



WARNING



Avoid exposure to dust containing crystalline silica particles. This dust can cause serious injury to the lungs (silicosis).

If dust which contains crystalline silica is present, there are guidelines which should be followed.

1. Be aware of the health effects of crystalline silica and that smoking adds to the damage.
2. Be aware of and follow OSHA (or other) guidelines for exposure to airborne crystalline silica.
3. Know the work operations where exposure to crystalline silica may occur.
4. Participate in air monitoring or training programs offered by the employer.
5. Be aware of and use optional equipment controls such as water sprays, local exhaust ventilation, and enclosed cabs with positive pressure air conditioning if the machine has such equipment. Otherwise respirators shall be worn.
6. Where respirators are required, wear a respirator approved for protection against crystalline silica-containing dust. Do not alter the respirator in any way. Workers who use tight-fitting respirators cannot have beards/mustaches which interfere with the respirator seal to the face.
7. If possible, change into disposable or washable work clothes at the work site; shower and change into clean clothing before leaving the work site.
8. Do not eat, drink, use tobacco products, or apply cosmetics in areas where there is dust containing crystalline silica.
9. Store food, drink and personal belongings away from the work area.
10. Wash hands and face before eating, drinking, smoking, or applying cosmetics after leaving the exposure area.

Before Operating the Tractor

- Know your equipment and its limitations. Read this entire manual before attempting to start and operate the tractor.
 - Pay special attention to the danger, warning and caution labels on the tractor.
 - Do not operate the tractor or any implement attached to it while under the influence of alcohol, medication, controlled substances or while fatigued.
 - Before allowing anyone to use your tractor, explain how to operate and have them read this manual before operation.
 - Never wear loose, torn or bulky clothing around tractor. It may catch on moving parts or controls, leading to the risk of an accident. Use additional personal protection equipment (PPE), e.g. hard hat, safety boots or shoes, eye and hearing protection, gloves, etc., as appropriate or required.
 - Do not allow passengers to ride on any part of the tractor at anytime. The operator must remain in the tractor seat during operation.
 - Check brakes, clutch, linkage pins and other mechanical parts for improper adjustment and wear. Replace worn or damaged parts promptly. Check the tightness of all nuts and bolts regularly. (For further details, see “Maintenance” section.)
 - Keep your tractor clean. Dirt, grease, and trash build up may contribute to fires and lead to personal injury.
 - Use proper weights on the front or rear of the tractor to reduce the risk of upsets. When using the front loader, put an implement or ballast on the 3-point hitch to improve stability. Follow the safe operating procedures specified in the implement or attachment manual.
 - The narrower the tread, the greater the risk of a tractor upset. For maximum stability, adjust the wheels to the widest practical tread width for your application. “Wheels and Tires” on page 3-83.
 - Do not modify the tractor. Unauthorized modification may affect the function of the tractor, which may result in personal injury.
-

Operating Safety

Operator safety is a priority. Safe operation, specifically with respect to overturning hazards, entails understanding the equipment and environmental conditions at the time of use. Some prohibited uses which can affect overturning hazards include traveling and turning with implements and loads carried too high etc. This manual sets forth some of the obvious risks, but the list is not, and cannot be, exhaustive. It is the operator's responsibility to be alert for any equipment or environmental condition that could compromise safe operation. Do not exceed the designed speed, pressure or load capacity ratings for the equipment at any time.

Tractor Start Up

- Always sit in the operator's seat when starting engine or operating levers or controls. Adjust seat per instructions in the operating the tractor section. Never start engine while standing on the ground.
 - Before starting the engine, make sure that all levers are in their neutral positions, that the parking brake is engaged.
 - Fasten the seat belt if the tractor has a cab or a foldable ROPS in the upright and locked position.
 - Do not start engine by shorting across starter terminals or bypassing the safety start switch. Machine may start in gear and move if normal starting circuitry is bypassed.
 - Do not operate or idle engine in a non-ventilated area. Carbon monoxide gas is colorless, odorless, and deadly.
 - Check before each use that operator presence controls are functioning correctly. Test safety systems.
 - For trailing PTO-driven implements, set the drawbar to the towing position.
 - Attach pulled or towed loads to the drawbar only.
 - Keep all shields and guards in place. Replace any that are missing or damaged.
 - Avoid sudden starts. To avoid upsets, slow down when turning, on uneven ground, and before stopping.
 - The tractor cannot turn with the differential locked and attempting to do so could be dangerous.
- Do not operate near ditches, holes, embankments, or other ground surface features which may collapse under the tractor's weight. The risk of tractor upset is even higher when the ground is loose or wet. Tall grass can hide obstacles, walk the area first to be sure.
 - Watch where you are going at all times. Watch for and avoid obstacles. Be alert at row ends, near trees, and other obstructions.
 - When working in groups, always let the others know what you are going to do before you do it.
 - Never try to get on or off a moving tractor.
 - Always sit in the operator's seat when operating levers or controls.
 - Do not stand between tractor and implement or trailed vehicle unless parking brake is applied.
 - Never utilize the Headland Management System, if anyone is in the work area of the tractor.
-

Tractor Operation Safety

- Pull only from the drawbar. Never hitch to axle housing or any other point except drawbar; such arrangements will increase the risk of serious personal injury or death due to a tractor upset.
- For trailing PTO-driven implements, set the drawbar to the towing position.
- Attach pulled or towed loads to the drawbar only.
- Keep all shields and guards in place. Replace any that are missing or damaged.
- Avoid sudden starts. To avoid upsets, slow down when turning, on uneven ground, and before stopping.
- The tractor cannot turn with the differential locked and attempting to do so could be dangerous.
- Do not operate near ditches, holes, embankments, or other ground surface features which may collapse under the tractor's weight. The risk of tractor upset is even higher when the ground is loose or wet. Tall grass can hide obstacles, walk the area first to be sure.
- Watch where you are going at all times. Watch for and avoid obstacles. Be alert at row ends, near trees, and other obstructions.
- When working in groups, always let the others know what you are going to do before you do it.
- Never try to get on or off a moving tractor.
- Always sit in the operator's seat when operating levers or controls.
- Do not stand between tractor and implement or trailed vehicle unless parking brake is applied.
- Never utilize the Headland Management System, if anyone is in the work area of the tractor.

Instruction Seat Safety (if equipped)

- Instructional seat is provided only for training and instructing operators or diagnosing machine problems.
- It is not intended to carry children nor any other person for any other purpose.
- Always wear your seat belt and stabilize your body by holding the handrail on the cab frame.
- Use caution to avoid the risks of obstructing operator's view, falling from the machine and interfering with controls.

Safety for children

Tragedy can occur if the operator is not alert to the presence of children. Children generally are attracted to machines and the work they do.

- Never assume that children will remain where you last saw them.
 - Keep children out of the work area and under the watchful eye of another responsible adult.
 - Be alert and shut your machine down if children enter the work area.
 - Never carry children on your machine. There is no safe place for them to ride. They may fall off and be run over or interfere with your control of the machine.
 - Never allow children to operate the machine even under adult supervision.
 - Never allow children to play on the machine or on the implement.
 - Use extra caution when backing up. Look behind and down to make sure the area is clear before moving.
-

Tractor Operation on Slopes

Slopes are a major factor related to loss-of-control and tip-over accidents, which can result in severe injury or death. All slopes require extra attention.

- To avoid upsets, always back up steep slopes. If you cannot back up the slope or if you feel uneasy on it, do not operate on it. Stay off slopes too steep for safe operation.
 - Driving forward out of a ditch, mired condition or up a steep slope increases the risk of a tractor to be upset backward. Always back out of these situations. Extra caution is required with 4-wheel drive models because their increased traction can give the operator false confidence in the tractor's ability to climb slopes.
 - Keep all movement on slopes slow and gradual. Do not make sudden changes in speed, direction or apply brake and make sudden motions of the steering wheel.
 - Avoid disengaging the clutch or changing gears speed when climbing or going down a slope. If on a slope disengaging the clutch or changing gears to neutral could cause loss of control.
 - Special attention should be made to the weight and location of implements and loads as such will affect the stability of the tractor.
 - To improve stability on slope, set widest wheel tread as shown in "Wheels and Tires" on page 3-83.
 - Follow recommendations for proper ballasting.
 - To avoid free wheeling:
 - Do not shift the shuttle lever while on a slope.
 - Stop completely by using the brake and by depressing the inching pedal, then shift the shuttle lever.
 - Start off after selecting shuttle direction, by releasing the inching pedal.
 - When driving down a slope, make sure the 4-wheel drive is engaged to increase traction (if equipped).
-

Tractor Operation on Road

- Lock the 2 brake pedals together to help assure straight-line stops. Uneven braking at road speeds could cause the tractor to tip over.
 - Check the front wheel engagement. The braking characteristics are different between 2 and 4-wheel drive. Be aware of the difference and use carefully.
 - Always slow the tractor down before turning. Turning at high speed may tip the tractor over.
 - Make sure that the Slow Moving Vehicle (SMV) sign is clean and visible. Use hazard lights and turn signals as required.
 - Observe all local traffic and safety regulations.
 - Turn the headlights on. Dim them when meeting another vehicle.
 - Drive at speeds that allow you to maintain control at all times.
 - Do not apply the differential lock while traveling at road speeds. The tractor may run out of control.
 - Avoid sudden motions of the steering wheel as they can lead to a dangerous loss of stability. The risk is especially great when the tractor is traveling at road speeds.
 - Do not operate an implement while the tractor is on the road. Lock the 3-point hitch in the raised position. For travelling with the ride control on, however, keep the 3- point hitch unlocked.
 - When towing other equipment, use a safety chain and place an SMV emblem on it as well.
 - Set the 3-point hitch lock button in the lock position to hold the implement in the raised position. If traveling with the ride control on, unlock the 3-pt hitch lock button.
 - If you drive the tractor with a trailer loaded with something heavy in tow and step on the brake pedal, the tractor is pushed forward by the trailer due to an abrupt slowdown. This may fail to keep the tractor under control.
 - Before stepping on the brake pedal, press the transmission ratio lock button for smooth slowdown.
-

Parking the Tractor

- Disengage the PTO, lower all implements to the ground, place all control levers in their neutral positions, set the parking brake, stop the engine, remove the key from the ignition and lock the cab door (if equipped). Leaving transmission in gear with the engine stopped will not prevent tractor from rolling.
- Make sure that the tractor has come to a complete stop before dismounting.
- Avoid parking on steep slopes, if at all possible park on a firm and level surface; if not, park across a slope and chock the wheels.
- Failure to comply with this warning may allow the tractor to move and could cause injury or death.

PTO Safety

- When operating stationary PTO driven equipment, always apply the tractor parking brake and place chocks behind and in front of the rear wheels. Stay clear of all rotating parts. Never step over rotating parts.
 - Wait until all moving components have completely stopped before getting off the tractor, connecting, disconnecting, adjusting, cleaning, or servicing any PTO driven equipment.
 - Keep the PTO shaft cover in place at all times. Replace the PTO shaft cap when the shaft is not in use.
 - Before installing or using PTO driven equipment, read the manufacturer's manual and review the safety labels attached to the equipment.
 - To prevent PTO driven equipment from improper or unsafe use, select the lower speed (540 rpm) unless the higher one is specifically recommended as safe by the equipment manufacturer.
-

Service Tractor Safety

Before servicing the tractor, park it on a firm, flat and level surface, set the parking brake, lower all implements to the ground, place the shuttle lever in neutral, stop the engine and remove the key.

- Allow the tractor time to cool off before working on or near the engine, muffler, radiator, etc.
 - Do not remove radiator cap while coolant is hot. When cool, slowly rotate cap to the first stop and allow sufficient time for excess pressure to escape before removing the cap completely. If the tractor has a coolant recovery tank, add coolant or water to the tank, not the radiator.
 - Always stop the engine before refueling. Avoid spills and overfilling. Make sure the equipment is properly grounded before refueling.
 - Do not smoke when working around battery or when refueling. Keep all sparks and flames away from battery and fuel tank. The battery presents an explosive hazard, because it gives off hydrogen and oxygen especially when recharging.
 - Before “jump starting” a dead battery, read and follow all of the instructions.
 - Keep first aid kit and fire extinguisher handy at all times.
 - Disconnect the battery’s ground cable before working on or near electric components.
 - To avoid the possibility of battery explosion, do not use or charge the refillable type battery if the fluid level is below the LOWER (lower limit level) mark. Check the fluid level regularly and add distilled water as required so that the fluid level is between the UPPER and LOWER levels.
 - To avoid sparks from an accidental short circuit, always disconnect the battery’s ground cable (-) first and reconnect it last.
 - Do not attempt to mount a tire on a rim. This should be done by a qualified person with the proper equipment.
 - Always maintain the correct tire pressure. Do not inflate tires above the recommended pressure shown in the operator’s manual.
 - Securely support the tractor when either changing wheels or adjusting the wheel tread width.
 - Make sure that wheel bolts have been tightened to the specified torque.
 - Disconnect the battery’s ground cable and stop the engine to avoid the possibility of the machine runaway due to four wheel drive (4WD) braking system during testing, service or repair with only rear wheels off the ground.
 - Do not work under any hydraulically supported devices. They can settle, suddenly leak down, or be accidentally lowered. If it is necessary to work under tractor or any machine elements for servicing or adjustment, securely support them with stands or suitable blocking beforehand.
 - Escaping hydraulic fluid under pressure has sufficient force to penetrate skin, causing serious personal injury. Before disconnecting hydraulic lines, be sure to release all residual pressure. Before applying pressure to the hydraulic system, make sure that all connections are tight and that all lines, pipes, and hoses are free of damage.
 - Fluid escaping from pinholes may be invisible. Do not use hands to search for suspected leaks; use a piece of cardboard or wood. Use of safety goggles or other eye protection is also highly recommended. If injured by escaping fluid, see a medical doctor at once. This fluid will produce gangrene or severe allergic reaction.
 - Do not open high-pressure fuel system.
 - High-pressure fluid remaining in fuel lines can cause serious injury. Do not disconnect nor attempt to repair fuel lines, sensors, or any other components between the high-pressure fuel pump and injectors on engines with high pressure common rail fuel system.
 - To avoid hazardous high voltage, turn the key switch to the OFF position if it is necessary to check to repair the computer, harness or connectors.
 - During Diesel Particulate Filter regenerating operations, exhaust gases and exhaust filter components reach temperatures hot enough to burn people, or ignite or melt common materials.
 - Keep the tractor away from people, animals or structures which may be susceptible to harm or damage from hot exhaust gases.
 - To prevent fires, keep the DPF/SCR (Selective Catalytic Reduction) muffler and its surroundings clear of anything flammable and keep clean at all times.
-

- During regeneration, white exhaust gas may be visible. Do not allow regeneration in a non-ventilated space.
 - During regeneration, do not leave the tractor.
 - Before servicing a tractor equipped with the front suspension, be sure to lower the machine to the lowest position.
 - The front suspension hydraulic circuit is still under high pressure after the engine has stopped. Do not disconnect the pipes and/or hoses because you may get injured by high-pressure oil. If pipes and/or hoses are found worn or damaged, consult your local Kubota Dealer for this service.
-

Maintenance and Storage Safety

- Do not attempt any repairs that are beyond your abilities or understanding.
 - Refer procedures that require special tools and equipment to a Kubota dealer.
 - Place all controls in neutral, turn engine off, engage parking brake and block equipment wheels before attempting any equipment inspections or repairs.
 - Allow equipment to cool before inspecting.
 - Use the correct blocking and support to prevent unintended equipment movement during repairs or maintenance.
 - Use the proper tools and have sufficient light in the work area.
 - Keep the service area clean and dry.
 - Do not substitute fasteners and hardware with different or unknown grades.
 - Follow the proper short-term and long-term storage instructions as described in this manual.
 - Do not look directly into High Intensity Discharge (HID) lights or radar units. Damage to your eyes may occur.
 - Do not handle LED or quartz light bulbs with your bare hands. Use clean and dry gloves to protect the bulbs from dirt and oil on your hands.
 - Use caution when handling LED light ballast. High voltage may be present even with the engine off.
 - Do not remove the radiator cap when the radiator is hot and under pressure. Always allow the engine to cool before servicing. To remove the radiator cap, always wear gloves and eye protection. Turn the cap slowly to the first stop and allow pressure to escape before fully removing the cap.
 - Always dispose of all drained fluids and removed filters using environmentally safe procedures. Always follow local and national environmental laws governing the disposal of used engine oil, fluids and filters.
 - Do not attempt to service the air conditioning system. Severe skin and eye injury may result from escaping refrigerant. Special equipment and procedures are required to service the air conditioning system. See a Kubota dealer for service.
 - Do not permit modifications of the equipment or any of its components or functions without first contacting a Kubota dealer.
 - Always store heavy wheels properly with care and attention making sure they cannot fall causing damage or injury.
-

Electrical Safety

- Ideally, use a qualified Kubota service representative to conduct electrical testing and repairs on the equipment.
 - Unplug attached electrical devices before conducting repairs.
 - Turn the battery shut-off switch to OFF before repairing or servicing the electrical system.
 - Remove battery cables before repairing or servicing the electrical system. Refer to this manual for the procedures on removing and reattaching battery cables.
 - Use caution when handling HID light ballast. High voltage may be present even with the engine off.
-

Battery Safety



DANGER

- Batteries contain corrosive acid and generate highly flammable corrosive gas.
- Always wear protective clothing and safety glasses to protect eyes when working with batteries. In case of contact with skin, flush the affected area with water for 5 minutes and seek immediate medical attention.
- Follow all battery safety precautions to avoid death, serious personal injury, explosions or fire.



WARNING

All batteries generate hydrogen gas, which is highly flammable. If ignited by a spark or flame, the gas may explode violently causing a spray of acid, fragmentation of the battery, and possible severe personal injury, particularly to the eyes. Therefore, as a safety precaution, wear protective clothing and goggles. Do not smoke or expose the battery to open flame. Do not connect or disconnect live circuits. Follow the connection procedure as outlined above.



- Do not smoke or expose the battery to open flame. Batteries generate hydrogen gas, which is highly flammable. If ignited by a spark or flame, the gas may explode causing a spray of battery acid and fragments, causing severe personal injury.
 - Do not open sealed valve regulated batteries (AGM or Gel types).
 - Always cover vents with a damp cloth to minimize gas seepage.
 - Never lean over battery while testing, boosting or charging.
 - Do not remove or damage vent caps.
 - Do not connect or disconnect live circuits.
 - Never make or break any of the charging circuit connections, including the connection at the batteries, when the engine is running.
 - Never short any of the charging components to ground.
 - Do not use a booster battery of higher than 12 V nominal voltage.
 - Always observe correct polarity when installing the batteries or using a booster battery to jumpstart the engine. Follow the precautions in this manual for boosting the tractor. Connect positive to positive and negative to negative.
-

Hydraulic System Safety



DANGER



During normal operation, the engine may pressurize diesel and hydraulic fluid to extreme levels. Escaping fluids under high pressure can penetrate the skin and cause serious and life threatening injury.

Never use hands to check for fluid leaks. Use a piece of cardboard or paper to search for a suspected leak.

Obtain immediate medical attention if hydraulic fluid penetrates skin.

-
- Hydraulic oil is flammable. Do not expose oil or oil vapor to a flame or sparks.
 - Do not heat or weld near hydraulic lines or components.
 - Do not overfill the hydraulic fluid tank.
 - Inspect hoses and fittings before each use. Hoses with leaking fittings, cuts, abrasions or bulges, and hoses that are soft, twisted or crushed must be replaced.
 - Lower hydraulic components to ground level or support components before relieving the system pressure. Use hydraulic cylinder rod locks when applicable.
 - Relieve system pressure before disconnecting any hoses or components.
 - Clean all components and fittings before removal using a non-volatile cleaner. Cap all openings immediately to prevent system contamination.
 - Some hydraulic components are heavy. Use sufficient lifting and carrying devices for moving these components.
 - Make sure that replacement parts and hoses have the same pressure rating as the original parts.
 - Remove and replace components one at a time to avoid misrouting of connections.
 - Reinstall all clips, retainers and strain relief in their original locations.
 - Do not reuse contaminated hydraulic oil. Use new hydraulic oil when refilling the system.
 - Make sure that all connections are tight before applying pressure to the system.
 - Accumulators may store hydraulic pressure even when the engine is not running. Some accumulators require special instructions to relieve this pressure. Refer to this manual before disconnecting.
-

Welding Safety

- Follow the safe handling and use guidelines for welding with either gas or electric welding equipment.
- Have a first-aid kit and a Class C fire extinguisher available near the work area.
- Arc flash can cause retinal burning and cataracts. Protect your eyes with approved welding safety glasses.
- Protect your body from welding spatter and arc flash with protective clothing.
- Make sure there is adequate ventilation available when welding in confined areas or where there are barriers to air movement.
- Do not weld near hydraulic or pneumatic lines.
- Always completely clean the area to be welded so that it is free of grease, fuel or oil before welding. Remove any paint from the weld area before welding. Some paints can release toxic fumes.
- Attach the welder ground cable at least four feet away from the weld area.
- Never weld on one frame member (i.e., front or rear frame) and have the ground cable of the welder on the other frame.
- Always disconnect the ground cable from the batteries before carrying out arc welding on the machine or on any attached implement.
- Never allow welding cables to lay on, near or across any electrical wiring or electronic component while welding is in progress.
- Remove the electrical connectors attached to the transmission control module, even when the negative cable of the battery is disconnected, to provide additional protection to the transmission controller on continuous variable transmission units.
- Arc/MIG welding equipment and processes create magnetic waves which may affect pacemakers and other sensitive electronics.

Transport and Towing Safety**DANGER**

Always use extreme caution when attempting to free a mired piece of equipment. Attempting to free a mired piece of equipment involves potential safety hazards such as roll over, tipping or overturning. In addition, tow cables can fail in the stretched overworked conditions and in extreme cases, tow bars may even fail.

-
- Do not allow passengers on the equipment.
 - Ensure that all lights and mirrors are clean and functioning correctly.
 - Use safety chains with sufficient rating when towing.
 - Always lift and engage safety locks raised position (toward the towed implement) to make sure it remains in position in the advent of a hydraulic line failure.
 - Maintain a clear line of sight to all parts of the towed equipment.
 - Do not tow equipment over 34 kph (20 mph) that is not equipped with brakes.
 - Equipment that weighs 3 300 lb (1 500 kg) or over 1.5 times the weight of the towing vehicle must have brakes.
 - Make sure that the implement is in transport condition with all components lowered, retracted or folded into designated transport positions.
 - Install additional lighting to the sides of wide implements and to the rear of implements to alert passing traffic.
 - Maintain the correct tire air pressures.
 - Make sure that hitches and receivers are properly rated and installed correctly. Check the hitch connection before towing.
 - Be aware of overhead obstacles and power lines when transporting and positioning equipment.
 - Follow all local laws and requirements when driving and towing on public roads.
-

Diesel Fuel Handling Safety

- The engine is designed to run efficiently on ultra-low-sulfur diesel (ULSD) fuel. Using a fuel with high sulfur content will damage the engine and after-treatment system. Contact a Kubota dealer for more information and suppliers of ULSD fuels.
 - Do not add gasoline, alcohol or blended fuels to diesel fuel. These combinations create an increased fire and explosive hazard. These fuel blends, in an enclosed fuel tank, are more explosive than pure diesel. Do not use these blends.
 - Bio-diesel blends up to B20 can be used as fuel provided the blend does not exceed a sulfur content of greater than 15 ppm.
 - For more information on the proper use of bio-diesel fuels, contact a Kubota dealer.
 - Do not smoke while refueling equipment or when standing near fuel. Keep any type of open flame or sparks away.
 - Do not remove the fuel cap or refuel with the engine running. Allow the engine to cool before fueling.
 - Always use the proper fuel transfer hose and nozzle. Make sure the nozzle and hose are grounded to dissipate static electric charges.
 - When refueling, make sure the nozzle is in contact with the filler neck of the fuel tank before fuel starts to flow and during the entire time fuel is flowing.
 - Always maintain control of the fuel filler pipe nozzle when filling the tank.
 - Do not fill the fuel tank to capacity. Allow room for expansion.
 - Always wipe up spilled fuel immediately.
 - Always tighten the fuel tank cap securely. If the original fuel tank cap is lost, replace it with a genuine replacement cap. A non-approved cap may not be safe.
 - Always keep equipment clean and properly maintained.
 - Do not drive equipment near open fires.
 - Do not use fuel for cleaning purposes.
 - Always arrange fuel purchases so that summer grade fuels are not held over and used in the winter.
 - Always ground fuel storage tanks to prevent static buildup.
-

Safety Labels

The following safety labels are installed on the tractor at the indicated areas. Labels will vary depending on the options associated with the selected model. They are intended for the safety of anyone working on or near the equipment. Please become familiar with the location of these safety labels and the information contained on them.

IMPORTANT: If safety labels have been damaged, removed, become illegible or parts replaced without safety labels, new labels must be applied. Obtain replacement safety labels from a Kubota dealer.

1




Seat Belt: Use seat belt when operating the tractor.

Posted Locations:

- (A) Front right cab post



2



Emergency Exit: You can use the door latch on the the right side of the tractor to leave the cab in an emergency. See page 1-42

Posted Locations:

- (B) Emergency exit



1



Engage Parking Brake: Engage parking brake before exiting the cab. See page 3-22 for parking brake operation instructions.

Posted Locations:

- (A) Front left cab post



1



Instructional Seat: Consult the operator's manual for information on the appropriate use of the instructional seat. (See page 2-24).

Posted Locations:

- (A) Front left cab post






1



Read Operator's Manual: Read the operator's manual before performing maintenance or operating.

Posted Locations:

- (A) Front left cab post
- (B) Hydraulic Tank
- (C) DEF Supply Module Access Panel





1



3-pt Hitch and PTO: Stay clear of 3-pt hitch and PTO shaft. Keep all shields in place.

Posted Locations:

- (A) Rear left fender
- (B) Rear right fender




1



Hot surface: Allow engine/ components to cool before servicing.

Posted Locations:

- (A) Exhaust




1



Engine Guards: Do not open while engine is running. Contact with belts and rotating parts will result in serious personal injury.

Posted Locations:

- (A) Hood Shroud left side
- (B) Hood Shroud right side




2



Engine Running Warning: Do not open while engine is running. Contact with rotating fan or belts will result in serious personal injury.

Posted Locations:

- (A) Hood Shroud left side
- (B) Hood Shroud right side




3



Engine Start Warning: Do not bypass the starter safety switch. The tractor may move suddenly and result in serious injury.

Posted Locations:

- (C) Engine right side, near battery





1



Pressure Warning: Do not remove the radiator cap when the radiator is hot and under pressure. Always allow the engine to cool before servicing. To remove the radiator cap, always wear gloves and eye protection. Turn the cap slowly to the first stop and allow pressure to escape before fully removing the cap.

- (A) Top of engine coolant reservoir







Power On Indicator Light: The battery indicator light (2) is located beside the battery shut-off switch. The indicator light will illuminate after the engine has shut down. Do not turn the battery switch to OFF until Power On Indicator light goes off to allow the engine ECM to shut down.

Posted Locations:


- (A) Aftertreatment base, near battery



Battery Boosting: Do not connect jumper cable to negative post of discharged battery. Read service procedures before boosting the batteries.

Posted Locations:


- (A) Hydraulic reservoir




Battery Boost Warning: Do not boost batteries with 24 volts. Damage to electrical components can occur.

Posted Locations:

- (A) On battery cover.




1




Accumulator Warning: Contents under pressure. Accumulators may store hydraulic pressure even when the engine is not running. Read service procedures before performing maintenance.

Posted Locations:

- (A) Multiple locations and varies based on tractor.






Wheel Nut Torque Sequence: Tighten all wheel nuts in a criss-cross sequence. Refer to the operator's manual for wheel hardware maintenance information:


- During the break-in period (first 50 hours of operation): Tighten the wheel nuts to 739 N·m (545 ft-lb) after the first hour of operation and after every 3 hours of operation for the first day. Re-tighten to the specified torque daily until wheel hardware maintains the specified torque.
- Check wheel hardware every 250 hours of operation.

Posted Locations:



- (A) Inner rim of every wheel (2 shown).



1




- Serpentine Belt Decal (A)
- Posted Location: Fan Shroud



Safety Equipment and Functions

Horn

Push at the end of the lever to activate the horn (1).



Emergency Exit



WARNING





Do not operate the tractor with the emergency exit open.

The emergency exit handle (1) is located on the right side of the cab.

To operate:

1. Open the right door if the left door is blocked or exit through the rear window (2) if cab doors are blocked in an emergency situation.



Cab/Roll-over Protection Structure (ROPS)



DANGER



Always use the safety belt with the cab/ROPS to prevent being ejected from the tractor in the event of rollover. Safety belts save lives only when used correctly.

Roll Over Protection Structure

The tractor incorporates a Roll Over Protective Structure (ROPS). The ROPS certificate is located on the inside cab and can be accessed through the back deck.

Factory installed safety belts are also installed as standard equipment. The safety belt, when properly used by the operator, maximizes the protection offered by the ROPS.

ROPS Maintenance and Inspection

NOTE: The ROPS must be inspected by a certified technician.

After the first 50 hours of operation and every 1 500 hours of operation (or yearly, whichever comes first):

- Check the torque of the cab/ROPS mounting bolts, as detailed in the Lubrication and Maintenance section of this manual
 - Check the operator seat's mounting bolts and safety belt mounting bolts. Tighten the seat mounting bolts to 40 N·m (30 ft-lb). Replace any worn or damaged parts.
-

Damage to the Cab/ROPS



DANGER

Never attach chains, ropes or cables to the cab/ROPS for pulling purposes. Always tow from the tractor drawbar. Be careful when driving through door openings or under low overhead objects. Make sure there is sufficient overhead clearance for the cab/ROPS.



Do not try to weld or straighten the cab/ROPS. If the cab/ROPS is removed or replaced, make certain the proper attachment hardware is used and torqued to the proper specification. Contact a Kubota dealer for parts and service.

Falling Object Protection System

Model M8-181 and M8-201 tractors are not equipped with a Falling Object Protection System (FOPS).

Noise Levels

The following levels are produced by the tractor.

In-cab Noise level at 7 km/h:

- 1200 rpm - 71.2 db (A)
- 1800 rpm - 71.5 db (A)
- 2250 rpm - 72 db (A)

Always wear appropriate ear protection when working in or around a tractor.

Operator's seats are component type approved in accordance with 78/764/EEC.

If the tractor has rolled over or the cab has been seriously damaged (such as striking an overhead object during operation or transport), it must be replaced to provide the original level of protection.

Check for damage to the cab/ROPS, operator's seat, safety belt and safety belt mountings after an accident. Replace all damaged parts before operating the tractor.

Protective Shielding




WARNING



Always make sure protective shielding is installed, operational and in place before starting or operating the tractor.

The protective shielding around the engine, the operator and other vital components such as batteries are important safety features of the tractor. These shields protect the operator from contact with moving parts, hot gases and other dangers that will cause critical injury if not properly secured in place.



Engine Hood

The engine hood (1) protects the operator from hot gases and moving parts.

Do not start the engine unless engine hood is closed and in the locked position.

To open engine hood:

1. Hold the hood and pull the release lever (2).

To close the engine hood:

2. Pull down on the strap (not shown) and push the hood into position with both hands.

Engine Side Cowlings




CAUTION



Always firmly grasp the engine hood when opening and closing to avoid pinching. The engine hood may close quickly.

The engine side cowlings (1) protect the moving parts in the engine compartment and direct air flow through the cooler package. Do not start the engine unless engine side cowlings are in place.



Battery Box

The battery box (1) is mounted beside the hydraulic reservoir on the right side of the tractor. The cover for the box is held in place with 2 knobs (one on each side) (2).

The battery box protects the 2 tractor batteries and the electrical connections.



Battery Shut-off Switch

NOTICE

The battery shut-off switch shall not be used as an emergency engine shut-off switch. Turning the battery shut-off switch to OFF while the engine is running may result in damage to vehicle electronics.

Located above the tool box (not shown), the battery shut off switch (3) provides the control needed to terminate electrical power. This switch can be disengaged and padlocked when the tractor is parked, or when there is a need to disconnect the main batteries.

- Turn the battery shut off switch to the OFF position to disconnect battery power.
- Turn the battery shut off switch to the ON position to connect battery power.



Power Off Indicator Light





DANGER



Turn the battery shut-off switch to OFF and disconnect all battery cables before welding or servicing the electrical system. The alternator is still live when only the battery shut-off switch is turned to OFF.

NOTICE

- The battery shut-off switch can not be used as an emergency engine shut-off switch. Turning the battery shut-off switch to OFF while the engine is running may result in damage to vehicle electronics.
- Wait for the Power-off Indicator (POI) lamp (1) to shut off before turning the battery shut-off switch to OFF.



Battery switch turned OFF

The battery shut-off switch (2) provides the immediate control needed to terminate electrical power. This switch can be disengaged and padlocked when the tractor is parked, or when there is a need to disconnect the main batteries.

- To disconnect battery power, turn the battery shut-off switch to OFF (3) (switch pointing up as shown).
- To connect the battery power turn the battery shut-off switch to ON (4) (switch pointing to your right).






Battery switch turned ON

Fuse Panel

The fuse panels are located in the following below:

- Behind operator's seat (1)
- Right side bottom of the cab (2)
- Behind the upper radio and climate control bezel (3)
- Left side under hood (4)



Master PTO Shield

The master Power Take-off (PTO) shield (1) will cover the tractor PTO stub shaft when the PTO option is available with the tractor. The shield can be pivoted to make installing the PTO shaft easier. Master PTO shield must be in place when the PTO is engaged.


Refer to PTO in Section 3: Tractor Operation for information on PTO operations.

PTO Output Shaft Cover

The PTO output shaft cover (2) is pressed onto the housing and protects against accidental contact with the shaft when there is no equipment in use.

Always install the cover over the tractor's PTO tube shaft whenever the shaft is not attached to an implement. The cover turns clockwise into the mounting plate to install and counterclockwise to remove.

NOTE: Be sure to store the cover in a safe place when it is removed.



This Page Is Intentionally Left Blank.

Section 2: Controls and Instruments – Contents

Tractor Orientation	2-3
Tractor Terminology	2-3
Tractor Identification	2-5
Cab and ROPS Plate	2-5
Tractor Serial Number	2-5
Engine Serial Numbers	2-6
Front Axle Serial Number	2-7
Transmission Serial Number	2-8
Steering Column and Pedals	2-9
Adjust Steering Wheel Position	2-11
Multifunction Switch	2-12
Hazard Warning Lights	2-13
Foot and Floor Controls	2-14
Parking Brake (not in picture)	2-14
Inching Pedal	2-14
Left Wheel Foot Brake Pedal	2-14
Right Wheel Foot Brake Pedal	2-14
Brake Interlock Lever	2-14
Foot Throttle	2-14
Steering Column Release Pedal	2-14
Operator Seating	2-15
Seat Belts	2-15
Standard Seat	2-16
Deluxe Seat	2-18
Instructional Seat	2-20
Electronic Instrument Cluster (EIC) and Display Monitor	2-21
Introduction: Uses, Similarities, Differences	2-21
EIC — Functional Area Identification	2-22
EIC — Signal Light Identification	2-23
Navigating the EIC Tractor Information Screens	2-28
EIC: Summary of All LCD Screens	2-29
DPF Modes of Configurations	2-30
PTO Modes of Configurations	2-31
Override Configuration	2-32
Reverse Configuration	2-33
Next Button	2-34
Tire Size Configuration	2-35
3PT Hitch Configuration	2-36
Steering Angle Calibration	2-37
Tire Size Calibration	2-40
Zero Slip Calibration	2-42
Front Axle Suspension Calibration	2-44
Cab Suspension Calibration	2-51
Transmission Calibration	2-57
EIC Overview: Unit of Measure Screen	2-58
EIC Overview: Language	2-59
EIC Overview: Software Version	2-60
K Monitor	2-61
K Monitor Pro	2-62
Touch-based Operation	2-63
Screen switch	2-66

ISOBUS emergency shut-off switch	2-66
Basic Operation	2-67
Selection Dial Button	2-70
Function of the F buttons	2-73
Allocating the F buttons	2-73
Function of the HOME button	2-74
Function of the ESC button	2-74
Operator Console (CVT)	2-75
Operator Console	2-76
Speed Mode shift	2-77
Hand Throttle	2-78
Arm Rest/Option Controls	2-78
Transmission Operation	2-79
Remote Valve Controls	2-81
3pt Hitch Lock Button	2-82
3-pt Hitch Controls	2-83
3-pt Hitch Quick Raise/Lower Switch	2-84
Depth Control Dial (Hydraulic Dial)	2-84
Field in and out buttons	2-84
Headland Management System Display Icons	2-85
Headland Management System	2-86
Headland Management System Operation	2-86
Field out and in buttons	2-87
PTO Controls	2-88
PTO Speed Control Levers	2-88
Fender-mounted PTO Switches	2-89
Cab Accessory Panel	2-90
Cab Air Vents	2-91
Inside Cab Air Filter	2-92
Interior Dome Light	2-93
Sun Blinds (option)	2-93
Radio Options	2-94
Heating and Cooling Controls (Manual)	2-95
Heating and Cooling Controls (ATC) Identification	2-96
Heating and Cooling Controls (ATC)	2-97
System Parameters	2-102
Power Mirrors (option)	2-103
Heated Mirrors	2-103
Horn	2-104
Power Outlets	2-105
Rear Windshield Washer/Wiper Switches	2-106
Windshield Wipers	2-107
Rotary Beacon	2-108

Tractor Orientation

The model M8-181 and M8-201 tractors are classified as mechanical front-wheel-drive vehicles.



The main components include:

- The transmission and rear differential which are bolted together. The rear axles are attached to the rear differential. The rear differential has a separate auxiliary shaft that supplies power for the tractor to stay stationary but the PTO can still be functional. The power to the front driveshaft is supplied by a clutch pack which runs off the main clutch gear.
- The front frame which supports the engine components and the front axle. The hood support frame and cooler package also mount onto the front frame.
- The cab which mounts onto the transmission and the rear axle.


Tractor Terminology

In this manual, the direction Front means as viewed from the driver's seat when facing forward in the normal manner. Left Side and Right Side are viewed in the same sense. Exceptions to this rule may be found where the wording As viewed from is used.


1	Front: The engine end of the tractor; also known as the Forward Direction of Travel.
2	Rear: The drawbar end of the tractor; implements are attached to this end.
3	Left: The doorway side of the cab.
4	Right: The right view of the tractor.



3



4



Tractor Identification

NOTE: Tractor identification data shall be supplied to the dealer when requesting parts or service. This data is also needed to identify the tractor if it is ever stolen.

The tractor and its major components are identified using serial numbers and/or manufacturing codes. These codes are recorded on the vehicle identification plate (ID plate) (1).

1. Record the tractor's identification data in this manual using the sample ID plate, right.
2. On a separate piece of paper, record the tractor's identification data.
3. Keep this data in a safe place for easy access if the tractor is ever stolen.

Cab and ROPS Plate


The cab and rops plate is located on the cab.

Kubota TRACTOR TRACTEUR	
MODEL/MODELE	M8-201
PIN/CODE PIN SERIAL NO./NO DE SERIE	*BVP45678901580111*
MADE IN CANADA KUBOTA Corporation	



Tractor Serial Number

The tractor serial number is stamped on the front frame. Use this serial number stamp if the ID Plate is removed or mutilated.



Engine Serial Numbers

The engine identification data plate is located on the right-hand top of the engine (1).

The plate provides, the serial number, control parts list, model number and rated horsepower.



NOTE: Engine serial number can be found on the ECM plate as well.

NOTICE

The engine is under the manufacturer's warranty at the time of delivery.

Only authorized Cummins dealers and service providers are permitted to perform maintenance and repairs under the warranty terms. Any unauthorized repairs may void the warranty.


Contact Kubota dealer for more information.



Front Axle Serial Number

The axle serial number and axle type are on the plate located on the front left of the axle housing (1).

Record the information on the sample front axle ID plate, below.




- Axle Type
- Differential Ratio
- Total Ratio
- Serial Number
- Axle Number

SPICER	
	
TYPE	SERIAL No.
<input type="text"/> AXLE	<input type="text"/> RATIO
<input type="text"/>	<input type="text"/>
MFG. BY DANA ITALIA S.P.A.	
MADE IN ITALY	

Transmission Serial Number

The transmission serial number and type are located on the plate on the lower right side of the transmission (1).

- Record the information on the sample transmission serial number ID plate, below.
- Transmission type
- Total ratio of the transmission
- Unit number
- ZF parts list number
- Customer code
- ZF List of Lubricants



Steering Column and Pedals

Table 2-7 identifies pedals and the functional parts of the steering column.




Table 2-7: Overview of Steering Column and Pedals

Ref	Description	Use / instructions
1	Steering Wheel	Steers the tractor.
2	Electronic Instrument Cluster (EIC)	Shows gauge and indicator lights. Use to monitor and control the aftertreatment system, calibrate equipment and customize settings such as units of measure. See “Electronic Instrument Cluster (EIC) and Display Monitor” on page 2-21.
3	Steering Column Adjusting Knob	Used for adjusting the height of the steering wheel. See “Adjust Steering Wheel Position” on page 2-11.
4	Hazard Warning Light Switch	Press to activate hazard lights. See “Hazard Warning Lights” on page 2-13.
5	Rear Defrost Switch	Press to activate the rear defrost switch.
6	Multifunction Switch	Used for signalling turns, honking the horn, flashing/locking high beams and wiper controls. Push the button at the end of switch to honk the horn. See Table 2-8 on page 2-12.
7	Ignition Switch	Starts the engine. See “Tractor Start-up” on page 3-13.




Table 2-7: Overview of Steering Column and Pedals

Ref	Description	Use / instructions
8	Inching Pedal	Used for slowly hooking up implements. See “Inching Pedal” on page 2-14.
9	Tilt Control Pedal	Used for adjusting the angle of the steering wheel. See “Adjust Steering Wheel Position” on page 2-11.
10	Left Brake Pedal	Stops the tractor. See “Stopping the Tractor” on page 3-19
11	Right Brake Pedal	Stops the tractor. See “Stopping the Tractor” on page 3-19.
12	Brake locking plate	Used for locking the brake pedals together. See Brakes in Section 3: Tractor Operation for details.
13	Foot Throttle	Foot pedal is an accelator pedal only and can not be configured.

Adjust Steering Wheel Position


Adjust the height and angle of the steering wheel (1) as required.

To adjust the height of the steering wheel:

1. Unlock the wheel by turning the knob (2) counterclockwise.
2. Pull or push the steering wheel to the desired height.
3. Lock the wheel by turning the knob clockwise.

To adjust the angle of the steering wheel:

4. Press and hold the tilt control pedal (3).
5. Tilt the steering wheel up or down to the desired position.
6. Release the tilt control pedal.



Multifunction Switch


The multifunction switch (1) is located on the left side of the steering column. Table 2-8 explains how to operate the switch.

Table 2-8: Multifunction Switch Operation

Ref	Description
2	OFF: To deactivate the lights, rotate the multifunction to Off  .
3	Worklights: Rotate the switch forward to activates the roadlights and back lighting.
4	Low beams/Night Mode EIC: To activate the low beams and night mode on EIC, rotate the switch into position.
5	Signal Left Turn: Pull the switch backward. This will activate the EIC that will flash in unison with tractor left turn signal light. Signal right turn: Push switch forward. This will activate the right turn flasher on the EIC that will flash in unison with tractor right turn signal light.
6	Windshield Wiper Controls: Rotate the switch to activate the front and rear wipers. See “Windshield Wiper – Operation” on page 3-55 for more information.
7	Horn: Push to activate the horn.

To activate high beams:

- Pull the multifunction switch up to momentarily activated high beams.
- Push the multifunction down to keep high beams on.



Hazard Warning Lights



WARNING




Always look before exiting the cab on a public roadway. Turn hazard warning lights on to signal other motorists to give the tractor a wide berth when passing or to slow down.

The hazard warning lights switch (1) activates the tractor hazard warning lights located on the extremity bar.

- Push the hazard light switch to activate and deactivate.

The hazard warning lights warn other drivers the tractor is traveling at a reduced speed on a public road, is pulling off to the side of the road or is already on the shoulder.

The turn signal light indicators on the dash will flash.



Foot and Floor Controls



WARNING



Always lock the brakes together when traveling on the highway or if a hydraulically braked trailer is attached. Never use the brakes to aid turning at high speed.

Parking Brake (not in picture)

The parking brake uses a conventional lever to operate brake discs located in the rear axle planetary. The lever is located to the left of the driver's seat. See Brakes in Section 3: Tractor Operation for details.

NOTE: A two-minute pulsating audible alarm will sound in unison with a flashing parking brake light to remind the operator to apply the parking brake if the operator leaves the seat without applying the parking brake.

Inching Pedal


The inching pedal (1) is installed in place of the clutch pedal found on tractors with conventional transmissions.

The inching pedal operates like a clutch for safe, accurate positioning of the tractor when attaching implements or operating in confined spaces, etc.

Pressing the pedal interrupts power flow from the engine to the rear axle. Release the pedal slowly to restore power flow. Refer to Inching Operations in Section 3: Tractor Operations for details.

Left Wheel Foot Brake Pedal

The left foot brake (2) may be operated independently of the right foot brake to aid turning in confined spaces or together with the right foot brake for normal stopping. Unlock the brake pedals when operating in the field. Refer to Service Brakes - Foot Brakes in Section 3: Tractor Operation for details.



Right Wheel Foot Brake Pedal

The right foot brake (3) may be operated independently of the left foot brake to aid turning in confined spaces or together with the left foot brake for normal stopping. Unlock the brake pedals when operating in the field. Refer to Service Brakes - Foot Brakes in Section 3: Tractor Operation for details.

Brake Interlock Lever

To lock the brake pedals together:

1. Move the brake interlock lever (4) up or down to engage and disengage the service brake pedals together. Refer to Brakes in Section 3: Tractor Operation for details.

Foot Throttle

The foot throttle (5) is an accelerator only and can not be configured.

NOTE: Set the hand throttle to the idle position whenever the foot throttle is to be used.

Steering Column Release Pedal

Use the steering column release pedal (6) to adjust the tilt on the steering wheel.

Operator Seating



CAUTION



- Seat belts save lives. Always wear the seat belt when operating the tractor.
- Passengers must sit in the instructional seat (if equipped) with the seat belt fastened at all times. Do not allow passengers if the tractor is not equipped with an instructional seat. Do not permit children to ride in or on the tractor.

NOTE: Adjust the seat, steering wheel and controls to the most comfortable position before operating the tractor.

The tractor will be equipped with either a standard seat or optional deluxe seat. There is also an option for an instructional seat.


- The standard seat (View A) is designed to provide maximum operator comfort. See “Standard Seat” on page 2-16.
- The deluxe seat is designed to provide maximum operator comfort and is also equipped with:
 - Electrical Lumbar Adjustment (Leather Seat Only);
 - Heated Seat Cushion (Fabric Seat);
 - Heated and Cooled Seat Cushion (Leather Seat) ; and
 - Semi-Active Air Suspension System

See “Deluxe Seat” on page 2-18.


Seat Belts

Tractors are equipped with a retractable seat belt for the operator seat and a non-retractable seat belt for the instructional seat.

1. To fasten/release seat belts, pull the belt forward from the reel.
2. Push the tongue of the buckle (1) into the buckle (2) until a click indicates it is properly engaged.
3. To release the belt, push the red release button (3) on the buckle and remove the tongue from the buckle.



View A: The standard operator's seat



View B: Detail of seat belt


Standard Seat


NOTICE

Make all adjustments in order. Turn the ignition key to the ACC position. Do not start the engine.

The standard seat is equipped with the following power and manual controls. Adjust the seat using the following procedures:

- 1**  **Height Adjustment**
Raise or lower the seat. Release when desired height is achieved.
- 2**  **Seat Depth Adjustment**
Pull the right handle upwards and move the seat backwards or forwards.
- 3**  **Fore/Aft Position Adjustment**
Lift handle to release and move the seat forward or backward. Let go to lock in position.
- 4**  **Fore/Aft Isolation Locking Lever**
Lift the lever to float through the 51 mm (2 in) fore and aft positions. Push down to lock in position.
- 5**  **Weight Handle Adjustment**
Pull or push the lever until the green marking is visible in the weight and height indicator.
- 6**  **Locking Lever for Lateral Horizontal Isolation**
Lift the lever to float through the 51 mm (2 in) fore and aft positions. Push down to lock in position.
- 7** **Weight and Height Indicator**
Indicates the weight and height of the operator seat.





8



Lift the lever and tilt the backrest to the desired position. Release to lock in position.

9



Lumbar Adjustment

Rotate the wheel clockwise to increase lumbar support and counterclockwise to decrease lumbar support.

10

Swivel Adjustment

Pull up on the lever to adjust. Push down to lock in 1 of 4 positions.

To adjust seat swivel:

1. Move the swivel lever to the rear.
2. Swing the seat into the desired position.
3. Release the lever to lock the seat into position.
4. Moving the swivel lever fully rearward will allow the seat to swivel freely.

11

Armrest Angle Adjustment

Rotate the roller on each armrest to adjust to the desired angle. Armrests can also be raised up to the full vertical position for easy access.

12

Headrest Adjustment

Pull the headrest upward using the handle incorporated in the back of the headrest.

Deluxe Seat




WARNING

This seat is equipped with a seat heater and ventilation system. There is a possibility that some people may suffer heat-induced burns or excessive cooling when using the system. Do not use either of these systems if you have a diminished ability to sense temperature, a reduced ability to feel pain or have sensitive skin.



When using the seat heater or ventilation system, do not place anything on the seat that insulates against heat or cooling, such as a blanket, cushion or similar item. This may cause the seat heater or ventilation system to overheat which may cause a heat-induced burn or may damage the seat.



NOTICE

Make all adjustments in order. Turn the ignition key to the ACC position. Do not start the engine.

The deluxe seat is equipped with the following power and manual controls. Adjust the seat using the following procedures:

- 1**  **Height/Weight Adjustment**
Raise or lower the seat. Release when desired height is achieved.
- 2**  **Seat Depth Adjustment**
Pull the right handle upwards and move the seat backwards or forwards.
- 3**  **Fore/Aft Position Adjustment**
Lift handle to release and move the seat forward or backward. Let go to lock in position.

- 4**  **Fore/Aft Isolation Locking Lever**
Lift the lever to float through the 51 mm (2 in) fore and aft positions. Push down to lock in position.
- 5**  **Locking Lever for Lateral Horizontal Isolation**
Lift the lever to float through the 51 mm (2 in) fore and aft positions. Push down to lock in position.
- 6**  **Weight Handle Adjustment**
Pull or push the lever until the green marking is visible in the weight and height indicator.
- 7** **Armrest Angle Adjustment**
Rotate the roller on each armrest to adjust to the desired angle.
- 8** **Armrest Vertical/Horizontal Position**
Armrests can also be raised up to the full vertical position for easy access.

9 Swivel Adjustment

Pull up on the lever to adjust. Release to lock in 1 of 4 positions.

To adjust seat swivel:

1. Move the swivel lever to the rear.
2. Swing the seat into the desired position.
3. Release the lever to lock the seat into position.
4. Moving the swivel lever fully rearward will allow the seat to swivel freely.

10 Headrest Adjustment

Pull the headrest upward using the handle incorporated in the back of the headrest.

11 Backrest Adjustment

Lift the lever and tilt the backrest to the desired position. Release to lock in position.

12 Seat Fan or Heated Seat Cushion (leather type seat only)


Press this switch to select either the built-in fans (12) or the heated seat cushion (13). Only 1 of these options can be turned on at a time.

The deluxe fabric seat is equipped with only heated seat cushion.

14 Lumbar Adjustment

Press the (+) switch (14) to increase lumbar support and (-) switch (15) to decrease lumbar support.

The deluxe fabric seat is equipped with mechanical lumbar adjustment same as standard seat.



Instructional Seat



WARNING

- Do not permit children to ride in or on the tractor.
- The instructional seat is for training purposes only.
- Passengers must sit in the instructional seat (if equipped) with the seat belt fastened at all times. Do not allow passengers if the tractor is not equipped with an instructional seat.



An instructional seat (1), with seat belt, is available for the purpose of training new operators on the tractor. When not in use, this instructional seat will fold away for convenience.

The seat will fold up and can be held in place with a strap to secure the seat cushion. Alternately, the back of the instructional seat can be folded down. This configuration allows a laptop computer to be placed on the back rest in the lowered position.

Electronic Instrument Cluster (EIC) and Display Monitor


Introduction: Uses, Similarities, Differences

Use the electronic Instrument cluster (1) (EIC) to do the following:

- Control and monitor the aftertreatment system.
- Check if equipment is engaged (differential locks, PTO, transmission auto shift).
- Configure equipment such as dpf, pto, override, reverse and tire size)
- Calibrate equipment software as radar, steering angle sensor, front suspension, cab suspension, etc.

Use the display monitor (2) to do the following:

- Configure the hydraulic system (setting flow rate limits and hydraulic operation mode of the implement valve).
- Configure equipment such as the 3-pt hitch, Power Take-Off (PTO), differential locks.
- Operate the tractor performance monitoring (TPM) system.
- Check monitor parameters such as engine temp, wheel speed, engine hours, etc).
- Use the headland management system (HMS).
- Check all warning lamps such as critical engine lamps and presence of active fault codes.



EIC — Functional Area Identification

“Table 2-9: Functional Parts of the Electronic Instrument Cluster (EIC)”, identifies the functional areas of the EIC. See the following pages for signal light identification and LCD display usage instructions.





Table 2-9: Functional Parts of the Electronic Instrument Cluster (EIC)

Ref	Description	Instructions
1	<ul style="list-style-type: none"> Warning light display area Some special equipment signal lights 	All signal lights identified in “Table 2-10: EIC Signal Lights (A = Aftertreatment Warning, E = Equipment Status, S = Service Required)” on page 2-23. LCD display usage instructions detailed in Table 2-11.
2	<ul style="list-style-type: none"> LCD display for tractor information screens 	
3	<ul style="list-style-type: none"> Transmission temperature 	
4	<ul style="list-style-type: none"> Tachometer/Engine RPM 	
5	Buttons to use the LCD display / tractor information screens	
6	Engine temperature gauge	Blue = Cold, Red = Hot
7	Diesel Exhaust Fluid (DEF) gauge level	If the DEF level is low an amber solid light will appear.
8	Fuel guage	E = Empty, F = Full



EIC — Signal Light Identification


Table 2-10 identifies the all signal lights that may appear on the EIC.

- If you see a “Service Required” indicator lamp (Type “S”), contact KUBOTA dealer if you do not find a solution in either the lubrication and maintenance section (Section 5) or in the troubleshooting section (Section 6) in this manual.

NOTICE

Only authorized Cummins dealers and service providers are permitted to perform repairs on engines. Customers/Operators are advised to contact a KUBOTA dealer for assistance in locating a Cummins dealer.

Table 2-10: EIC Signal Lights (A = Aftertreatment Warning, E = Equipment Status, S = Service Required)

Ref	Indicator	Type	Description	Recommended Action
1	 ALTERNATOR	S	Alternator Charge Indicator: Illuminates steady and sounds an alarm if alternator is not charging battery.	Check electrical connections. Check alternator belt.
2		S	Engine Oil Pressure: Illuminates when low engine oil pressure is detected.	Check engine oil level.
3		E	Inlet Heater/Ready to Start: Illuminates when key is turned to the run position and is cold enough outside to activate grid heater.	See “Cold Weather Starting” on page 3-17.
4		S	Coolant Level Low: Illuminates when coolant in reservoir is low.	Stop the tractor and refill the coolant reservoir.




Table 2-10: EIC Signal Lights (A = Aftertreatment Warning, E = Equipment Status, S = Service Required)

Ref	Indicator	Type	Description	Recommended Action
5		S	Air Filter Restriction: Illuminates if a fault has existed for 10 seconds.	Stop the tractor and service the air filter.
6		S	Transmission Oil Temperature: Flashes when high transmission oil temp detected (above 99 °C (210 °F)).	Stop the tractor. Check the transmission oil level. Check the coolers for blockage.
7		S	Transmission Oil Pressure: Illuminates and sounds an alarm indicating low transmission oil pressure.	Stop the tractor. Check the transmission oil level.
8		S	Transmission Oil Filter: Illuminates indicating a filter bypass condition due to a blocked filter.	Service within 1 hour.
9		S	Hydraulic Oil Filter: Illuminates indicating a filter bypass condition and no longer filtering oil returning to the reservoir.	Service within 1 hour.
10		S	Stop Engine: Illuminates when a critical condition has been detected.	Stop the engine immediately. NOTE: The engine may shut down automatically.
11		S	Engine Warning Light: Yellow for non-critical and maintenance and red for critical faults.	Check service indicators and perform necessary maintenance. Consult a KUBOTA dealer.







Table 2-10: EIC Signal Lights (A = Aftertreatment Warning, E = Equipment Status, S = Service Required)

Ref	Indicator	Type	Description	Recommended Action
12		E	Differential Locks (option): Illuminates when the differential lock button is engaged on tractors equipped with differential locks.	See “Differential Lock” on page 3-50 for instructions.
13		A	Diesel Particulate Filter (DPF) light: DPF filter is filling — MAY BE FLASHING AND / OR USED WITH THE ENGINE STOP OR WARNING LIGHT.	See “Aftertreatment System Operation” on page 3-171.
14		A	Regeneration inhibit light on: Regeneration has been stopped.	See “Aftertreatment Indicator Lamp Identification: Exhaust System Cleaning Disable (Inhibit) Lamp” on page 3-190 for instructions on responding to the aftertreatment system.
15		A	High exhaust temperature light on: Higher than normal exhaust temperatures may exist due to DPF regeneration.	Stop tractor and service.
16		E	Seat Belt: Illuminates when the ignition switch is turned to the RUN position and stays illuminated for 5 seconds to remind the operator to fasten the seat belt.	Fasten your seat belt.
17		E	High Beams: Illuminates when tractor lights are switched to high beam.	See “Table 2-8: Multifunction Switch Operation” on page 2-12.




Table 2-10: EIC Signal Lights (A = Aftertreatment Warning, E = Equipment Status, S = Service Required)

Ref	Indicator	Type	Description	Recommended Action
18		E	<p>Parking Brake: Illuminates when the parking brake is applied.</p> <p>Absent Operator Warning: If you leave the operator seat for more than 3 seconds while the engine is running, the parking brake lamp will flash and an audible alarm will sound.</p>	For operation instructions, see “Parking Brake” on page 3-22
19		E	<p>Front Wheel Assist: When the service brake pedals are applied, the front wheel assist is automatically activated so that both front and rear wheels assist in braking.</p>	For operation instructions, see “Service Brakes – Foot Brakes” on page 3-21.
20		E	<p>Front PTO: Illuminates when front pto is enabled.</p>	See “Power Take-off (PTO) (Front and Rear)” on page 3-156
21		E	<p>Rear PTO: Illuminates when rear pto is enabled.</p>	See “Power Take-off (PTO) (Front and Rear)” on page 3-156.
22		E	<p>Engine Coolant Temperature: Illuminates when engine coolant temperature has risen above acceptable limits.</p>	<p>Check coolant level</p> <p>Check cooler for obstructions</p>




Table 2-10: EIC Signal Lights (A = Aftertreatment Warning, E = Equipment Status, S = Service Required)

Ref	Indicator	Type	Description	Recommended Action
23		A	Diesel Exhaust Fluid (DEF): DEF level is low.	See “Diesel Particulate Filter Regeneration” on page 3-181.
24		A	Brake Pressure is Normal: This icon will appear if the brake pressure is normal.	No action is required from the operator.

Navigating the EIC Tractor Information Screens

Table 2-11 explains how to use the buttons on the dash to cycle through the tractor information screens (1). The next page lists all the screens available and where their instructions are in this manual.




Table 2-11: Controls for Navigating Tractor Information Screens

Screen Type	Press	Resulting Screen Type	Notes
Main Menu Screen		Next Top Level Screen	
	<p>2</p>		Press to access the menu screen. After menu appears, use (2) to scroll through the menus.
Top Level Screen with Submenu		Next Submenu	
	<p>3</p>		Press (3) to select a screen such as Configuration, Calibration, Units, etc.
Top Level Screen with a Subscreen		Subscreen	
	<p>2</p> <p>3</p>		Some top level screens such as Config has subscreens within subscreens. Use the scroll button (2) and select button (3) to access these screens.

EIC: Summary of All LCD Screens





The tractor information screens are described in order of appearance starting from the default screen.

1. **Config** – Shows configurations that are present in the tractor. Configuration screens are organized into subscreens as follows:
 - **DPF:** Configure Diesel Particulate Filter.
 - **PTO:** Configure Power Take-Off.
 - **Override:** Tractor shutdown.
 - **Reverse:** Configure reverse characteristics.
 - **Tire Size:** Configure the tractor's tire size .
 2. **Calibration** – Calibration settings are organized as follows:
 - **Wheel Angle Calibration (requires steering angle sensor):** Calibrate the steering sensor option (if equipped). The steering sensor automatically disengages differential locks and front wheel assist (FWA) when the tractor turns.
 - **Tire Size Calibration:** Calculates the tire size.. This value is used to calculate ground speed.
 - **Zero Slip Calculation (requires ground speed sensor):** Use this screen to derive tire size using the ground speed sensor (radar). Wheel slip % is calculated from the difference between the ground speed calculated by the radar and the ground speed calculated by the tire size.
 - **Suspended Axle Calibration:** If the tractor is equipped with a suspended axle, re-calibrate the axle after updating software.
 - **Suspended Cab Calibration:** If the tractor is equipped with a suspended cab, re-calibrate the cab after updating software.
 3. **Unit of Measure:** Change unit of measure to metric or imperial.
 4. **Language:** Shows different types of language that can be set to.
 5. **Version:** Check the software installed on the tractor for EIC and VCU.
-

DPF Modes of Configurations

The 3 following DPF mode of configurations (1) located in the EIC screen (2) allows the operator to set the regeneration mode of the DPF to either:





- Inhibit (3)
- Forced (4)
- Automatic (5)



PTO Modes of Configurations



The 3 following PTO configurations (1) located in the EIC screen (2) allows the operator changes to the engagement characteristics of the PTO based on the size of implement load and type of soil.

- Light (3)
- Medium (4)
- Heavy (5)





Override Configuration

The override function (1) located in the EIC screen (2) prevents engine shut down (3) for 30 seconds. Typically, the engine will shut down for 30 seconds after the red stop engine lamp has illuminated. The override switch can be pressed any time during this 30 second duration to prevent the engine from shutting down for another 30 seconds in order to move the vehicle to a desirable location. This feature should be only used in an emergency situation.






Reverse Configuration

The reverse function (1) located in the EIC screen (2) allows the operator to customize the behavior of reverse gear engagement during shuttle shifting. The settings ranges from aggressive to quick engagement behavior to a longer duration very smooth engagement.






Next Button

Select Config (1) on the EIC screen to locate the Next Button (2). This consists of the Tire Size and 3PT Hitch functions (3).






Tire Size Configuration

Select the Next (1) function on the EIC screen (2) for the tire size function (3). This allows the operator to manually enter SRI (speed radius index) (4) of the rear tires into VCU (vehicle control unit) and is used to calculate ground speed. The default or previous value will remain in the VCU if the value entered is out of range.



3PT Hitch Configuration

Select the Next (1) function on the EIC screen (2) for the 3PT Hitch function (3). This allows the operator to manually enter the hitch in-work height (4).




Steering Angle Calibration

NOTE: If the steering angle sensor is replaced, a calibration must be performed.


To perform a STEERING ANGLE Calibration, perform the following instructions:

Park the tractor on a level area, shut the engine off and apply the parking brake.

1. Start the engine.
2. Press the left button (1) once on the EIC to access the main menu.




3. Press the left button to scroll down till the "CALIB" (2) is highlighted
4. Press the right button (3) to select the sub-menu.




NOTE: If VCU software or angle sensor is replaced. Perform a calibration.

5. Press the left button (1) to scroll down till ANGLE Calibration (2) is highlighted.
6. Press the right button to select the STEERING Calibration sub-menu (3).




7. Turn the steering wheel till the front wheels are straight and parallel with the centerline of the tractor. Drive in a straight line to ensure the wheels are straight before continuing.

NOTE: A tape measure can be used to measure from the center of the tractor to the center of each tire to ensure the wheels are straight. Make sure X1 and X2 are around the same measurement within a 1/4".





8. Press the left button to scroll down till CALIBRATE (4) is highlighted
9. Press the right button to calibration.
10. Once the right button has been pressed the controller will store the sensors value for center and the calibration is complete.



11. Press the left button to scroll till BACK (1) is highlighted.
12. Press the right button to exit the calibration and go back to the calibrations menu. Using the left button scroll till BACK is highlighted again; press the right button to get back to the main menu.
13. Press the left button to scroll till HOME (2) is highlighted.
14. Press the right button to exit the main menu and back to the main screen.

NOTE: There is no indicator to tell you that the calibration has been completed or was successful. To see if the calibration worked engage the auto FWA and diff lock. Turn the steering wheel all the way to the left and see if diff lock and FWA turn off. If they do the steering angle sensor is working. If they do not turn off then there maybe something wrong with the sensor.

NOTE: Key cycle should be done to properly store calibration.





Tire Size Calibration

To perform a TIRE SIZE Calibration, perform the following instructions:


Park the tractor on a level area, shut the engine off and apply the parking brake.

1. On a smooth, hard surface, mark off a 100 m (328 ft) distance in a straight line. Make sure the start and finish lines are clearly marked.
2. Start the engine.
3. Press the left button (1) once on the EIC to access the main menu.
4. Press the left button to scroll down till the CALIB (2) is highlighted
5. Press the right button (3) to select the sub-menu.


NOTE: If VCU software is changed. Perform a calibration.




6. Press the left button (1) to scroll down till TIRE SIZE Calibration (2) is highlighted.



7. Press the right button (3) to select the TIRE SIZE Calibration sub-menu (4).
8. Select a low gear and range and drive the tractor forward.
9. Press the left button to highlight START (5).
10. As the tractor crosses the start line, press the right button to start the calibration.



11. Press the left button on the EIC to highlight STOP (6).
12. As the tractor crosses the finish line, press the right button on the EIC to end the calibration.
13. Once the tire size calibration is complete, key off and wait till the vehicle controller is off. This will let the calibrated tire size to be stored in the vehicle controller.




Zero Slip Calibration


To perform a ZERO SLIP Calibration, perform the following instructions:

Park the tractor on a level area, shut the engine off and apply the parking brake.

1. Start the engine.
2. Press the left button (1) once on the EIC to access the main menu.




3. Press the left button to scroll down till the CALIB (2) is highlighted
4. Press the right button (3) to select the sub-menu




5. Press the left button to scroll down till ZERO SLIP Calibration (4) is highlighted.


NOTE: If VCU software is changed. Perform a calibration.




6. Press the right button (1) on the EIC to select the ZERO SLIP Calibration sub-menu (2).
7. Press the left button to highlight START (3).



8. Select a low gear and range and drive the tractor forward.



9. Press the right button (1) to start calibration.
10. This will take 100m of travel distance to complete. Once calibration is completed cycle the power OFF and ON to save the new tire size in the VCU.
11. Zero Slip Calibration will automatically stop after the 100m has been reached. Make sure the full 100m was driven or calibration will not be saved.



Front Axle Suspension Calibration

NOTE: If the  appears on the front suspension button or on the indicator symbol the system must now be calibrated.

NOTE: If the position sensor is replaced, perform a calibration.

To perform a Front Axle Suspension Calibration, perform the following instructions:

Park the tractor on a level area, shut the engine off and apply the parking brake.

Calibration State

The calibration state is entered when the operator activates the calibration through the EIC and monitor. The system will command a raise to the upper mechanical stop and record position. Then it will then command a lower to the lower mechanical stop and record position. The algorithm will calculate the mid-position of the specific system. Therefore, removing mechanical and electronic tolerances. Once the calculations are complete the algorithm re-enters the start up state.

Calibration can occur concurrently for both cab and axle systems if selected through the EIC or monitor. The software will have two independent sub routines for cab and axle for fluctuation in calibration time. However the same procedure applies for both.

Suspension State

The suspension state is the default state and the normal operating state which consists of 3 sub-states:

- Neutral State
- Raise State
- Lower State

NOTE: System will not enter Suspension State until 2 kph (1 mph).

Lockout State (Axle only)

The lockout state is entered when the vehicle operator activates the Axle lockout switch and the suspension is in it's neutral position. In lockout state all Axle solenoid valves are off. Axle Leveling is disabled and the accumulator is segregated from the circuit eliminating cylinder movement. This is known as Axle Mid-position Lockout. The usage of this mode is foreseen when the operator want to precisely control the height of a front attachment.

NOTE: To avoid system running in LockOut high speed (with potential safety issues), if 25 kph (15 mph) is reached will enter Suspension State and return to LockOut once speed drops below 25 kph (15 mph).

NOTE: The operator will not be able to exit LockOut mode until 2 kph (1 mph) is reached (to avoid unpredictable movement when stationary).

Error State

The error state is entered when position correction commands are active for more than 1 minute. This will cover errors due to cut wires, hydraulic errors and position sensor errors. Once the error state is entered all coils are de-energized. The error state can only be exited by entering the calibration state.


Lockdown State (Axle only)

The LockDown state is the second axle suspension off state. The axle is lowered all the way to its mechanical stops and all the solenoid valves are off. This state is desirable if the front axle load is high enough to open the relief valve in lockout state.


NOTE: To avoid system running in LockDown high speed (with potential safety issues), if 25 kph (15 mph) is reached will enter Suspension State and return to LockDown once speed drops below 25 kph (15 mph).

NOTE: The operator will not be able to exit LockDown mode until 2 kph (1 mph) is reached (to avoid unpredictable movement when stationary).


1. Start the engine.
2. Press the left button (1) once on the EIC to access the main menu.




3. Press the left button to scroll down till the CALIB (2) is highlighted
4. Press the right button (3) to select the sub-menu.




5. Press the left button (1) on the EIC to scroll down till FAS (2) is highlighted.
6. Press the right (3) button on the EIC to select the FRONT AXLE SUSPENSION CALIBRATION sub-menu (4).




7. Press the left button till CALIBRATE (5) is highlighted
8. Press the right button to start calibration.






9. The  symbol (1) will be displayed beside the front suspension switch.
10. The controller will now bring the front suspension all the way up to its max position and record the value; this will take a few seconds. Once the upper value is recorded the controller will signal the suspension to go down all the way to its lowest position and record the value; this will take a few seconds. Once the lower value is recorded the controller will now bring the suspension to the middle of its travel position.



11. If the calibration was successful the system will now be active. The front suspension switch will be on and the symbol  (1) should have disappeared.


NOTE: If suspension controller is replaced. Perform a calibration.

12. Press the left button (1) on the EIC to scroll till BACK (2) is highlighted.
13. Press the right button (3) on the EIC to exit the SUSPENDED AXLE Calibration sub-menu (4) and back to the calibrations menu.




14. Press the left button (1) on the EIC till BACK (2) is highlighted again

15. Press the right button (3) to get back to the main menu.



16. Press the left button to scroll till HOME (4) is highlighted.

17. Press the right button to exit the main menu and get back to the main screen .



Cab Suspension Calibration

NOTE: If the  appears on the indicator symbol, the system must now be calibrated.



NOTE: If the position sensor or control module is replaced, perform a calibration.

NOTE: Make sure all tire pressures are equal as it can cause the tractor to be unlevelled.


To perform a cab suspension calibration, follow the instructions below:

Park the tractor on a level area, shut the engine off and apply the parking brake.


1. Start the engine.
2. Press the left button (1) once on the EIC to access the main menu.
3. Press the left button to scroll down till the CALIB (2) is highlighted.
4. Press the right button (3) to select the sub-menu.




- 5. Press the left button (1) on the EIC to scroll down till  FCS (2) is highlighted.
- 6. Press the right button (3) on the EIC to select the CAB SUSPENSION CALIBRATION sub-menu.




- 7. Press the left button on the EIC till CALIBRATE (2) is highlighted.
- 8. Press the right button (3) on the EIC to start calibration.







NOTE: It takes 1 minute and 30 seconds to complete the calibration process. There is no indication that the calibration is complete.

9. The  symbol (1) will be displayed beside the cab suspension switch.
10. The controller will now bring the cab suspension all the way up to its max position and record the value; this will take a few seconds. Once the upper value is recorded the controller will signal the suspension to go down all the way to its lowest position and record the value; this will take a few seconds. Once the lower value is recorded the controller will now bring the suspension to the middle of its travel position.




11. If the calibration was successful the system will now be active. The cab suspension switch will be on and the symbol  (1) should have disappeared.
12. Press the left button on the EIC to scroll till BACK is highlighted.


13. Press the left button (1) on the EIC to scroll until BACK (2) is highlighted.
14. Press the right button (3) to exit calibration and back to the calibrations menu (4).



15. Press the left button (1) on the EIC till BACK (2) is highlighted again
16. Press the right button (3) on the EIC to get back to the main menu.




17. Press the left button (1) to scroll till HOME (4) is highlighted.



18. Press the right button to exit the main menu and get back to the main screen (5).

NOTE: The values for the cab position sensor should be between 0.7v when the cab is at its lowest position and 4.0v when the cab is at its highest position. This will insure the connecting rod is at the correct length.

NOTE: Sensor range is from 0.5v to 4.5v, but the sensor reading must be below 4.3v or the suspension will not calibrate.




Transmission Calibration

Contact a KUBOTA dealer for assistance.


EIC Overview: Unit of Measure Screen

Use the Unit of Measure screen (1) to change the units to Metric or Imperial:

1. Press the left button to scroll down till the Units (2) is highlighted.
2. Press the right button (3) to select the sub-menu.




3. The subscreen (4) appears.
4. Press the left button (1) to select Metric (5) or Imperial (6).
5. Select Back to save the settings.




EIC Overview: Language

Use the Language screen (1) to change the language to English or French:

1. Press the left button to scroll down till Language (2) is highlighted.
2. Press the right button (3) to select the sub-menu.




3. The subscreen (4) appears.
4. Press the left button to select English or French (5).
5. Select Back to save the settings.




EIC Overview: Software Version

Use the Version Information (1) screen to check software details and to confirm if the correct software is installed in the tractor:

1. Press the left button to scroll down till Version (2) is highlighted.
2. Press the right button (3) to select the sub-menu.



3. The subscreen (4) appears.
4. The software version appears (5).
5. Select Back to save the settings.




K Monitor

The K-monitor features

- Screen switch (1)
- ISOBUS emergency shut-off switch (2)
- Main menu select switch (3)
- USB port (4)
- LAN port (5)
- External camera input terminal (“S” terminal) (6)
- Sub-menu select icon (7)
- Sub-menu display switch (8)

Screen switch

Touch the screen switch to change between screen ON and screen OFF. Turn the screen OFF for night driving, etc.




K Monitor Pro

The K-monitor Pro features

- ISOBUS emergency shut-off switch (1)
- Sub-display screen (2)
- Screen switch (3)
- Sub-menu select icon (4)
- Main display screen (5)
- Main menu select icon (6)
- LAN port (7)
- USB port (8)
- External camera input terminal (S terminal) (9)
- Microphone/earphone terminals (10)

Main menu display

On the screen there are 4 different switchable main menus that are routinely used can be displayed.



Touch-based Operation

To use the monitor:

1. Turning the ignition key only to RUN will also turn on the monitor but will limit the functionality of the monitor.
2. A splash screen will temporarily appear (not shown).

Touch the monitor screen to operate it:

- Menu bar (1).
- Main screen (2). Use this screen to configure settings for the option selected.


NOTE: Settings can only be configured using the main screen (2). The sub-display screens (3) are for watching information only.

To display a main screen icon to the main screen:

- Touch one of the main screens icons (1) and touch the main display screen (2).


To display a main screen icon to the sub-display screen:

- Touch one of the main screen icons (1) and touch the sub-display screen (2).
- Side panels (3) (12-inch model only): Use these screens to monitor information from 2 other menu options at all times. If available, press and drag the side panel icon (4) from the main screen onto 1 of the side panels. Dragging a main screen onto a side panel that is already populated with information will cause the screens to swap positions.




To switch main display screen to sub-display screen:

- Touch the main display screen (1) and touch the sub-display (2).




To switch between sub-display screen to main display screen:

- Touch the sub-display (1) and touch the main display screen (2).



To switch between sub-display screen to menu bar:

- Touch the sub-display (1) to store and touch the menu bar (2).

**Screen switch**

1. Touch the switch to switch between screen ON and screen OFF.
2. Turn the screen OFF for night driving, etc


ISOBUS emergency shut-off switch

With an ISOBUS compatible implement in motion, press this switch to stop the implement in case of emergency. Emergency stop methods vary according to the type of implement. For details, check with the instruction manual of the implement in question.

Basic Operation

The figure below shows an example in which “3-point hitch” is selected from the main menu.

Familiarize yourself with the basic procedures, such as changing the settings, as discussed below.



To change the settings on each screen, use any of the following procedures.

1. Touch the "-" or "+" button.

The diagram illustrates five rows of control panels. Each row consists of an icon on the left, a bar graph with a slider, a percentage value, and two buttons labeled '-' and '+'. The rows are as follows:



- Row 1: Icon of a lever with a lock. Bar graph shows 32% with a slider at the 32% mark. Percentage value is 32%. Buttons are '-' and '+'. A small inset shows the lever icon on a screen.
- Row 2: Icon of a lever. Bar graph shows 0% with a slider at the 0% mark. Percentage value is 0%. Buttons are '-' and '+'. A small inset shows the lever icon on a screen.
- Row 3: Icon of a hand adjusting a lever. Bar graph shows 11% with a slider at the 11% mark. Percentage value is 11%. Buttons are '-' and '+'. A small inset shows the hand icon on a screen.
- Row 4: Icon of a lever with 'AUTO' text. Bar graph shows 28% with a slider at the 28% mark. Percentage value is 28%. Buttons are '-' and '+'. A small inset shows the lever icon on a screen.
- Row 5: Icon of a tractor. Bar graph shows 12% with a slider at the 12% mark. Percentage value is 12%. Buttons are '-' and '+'. A small inset shows the tractor icon on a screen.

2. Touch a target point on the bar graph and the slider of the graph will move to the touched point.

The diagram shows a control panel with a bar graph and a percentage value of 28%. A dashed circle highlights a target point on the bar graph. An arrow points to this target point from below.

The diagram shows the same control panel as above, but the slider has moved to the target point, and the percentage value is now 83%.

3. Touch the right or left side of the setting-pointing slider and the slider will move to the touched point.





Selection Dial Button



1. Turn the selection dial button (1) until the orange selected frame reaches the desired item.





2. Press the selection dial button to make a selection. The orange selected frame turns yellow-green (1), which means the editing mode.



- Turn the selection dial button clockwise or counterclockwise to change the setting.



- 4. Press the selection dial button to complete the setting (1). Now the new setting is effective.
- 5. To cancel a new item or a new setting, just press the ESC button.



Function of the F buttons

Routinely-used setting screens can be programmed to the buttons F1 thru F4 (1).


Regardless of the information currently displayed, press an F button and the allocated setting screen appears.

The operator can modify and check the settings quickly.

Press the F button again and the previous screen comes back.

Allocating the F buttons

Select the setting screen for allocation and hold down any of the F1 thru F4 buttons 2 seconds or longer to allocate that screen.



Function of the HOME button


Hold down the home button (1) for 2 seconds and the preset HOME screen appears again. If the HOME screen has not been made yet, the factory-set “Engine, transmission” screen reappears.

Hold down the home button between 2 and 4 seconds and the currently shown screen replaces the HOME screen.

Hold down the home button for more than 4 seconds and the same HOME screen as at the time of purchase is resumed.

Function of the ESC button

Press the ESC button (2) and the previous screen reappears. This works in the same way as with the “Previous screen resume” switch.



Operator Console (CVT)

The operator console is located to the right of the driver's seat. It supports the following controls:




Table 2-12: Operator Console CVT

Ref	Description
1	EZ-command center
2	Cruise button
3	Remote control valve switch
4	Ratio lock button
5	Forward and Reverse buttons
6	3-pt hitch quick raise/lower switch
7	Depth control dial
8	3-pt hitch lock button
9	Hand throttle

Table 2-12: Operator Console CVT

Ref	Description
10	Remote control valve controls
11	Selection button for remote control valve and loader (Loader type)
12	Joystick lock button (Loader type)
13	Joystick for remote control valve and loader (Loader type)
14	Front PTO clutch control switch (if equipped)
15	Rear PTO clutch control switch
16	Selection dial button
17	Speed Mode shift (Turtle and Rabbit speed modes)

Operator Console

Each button has indicator lights that light up depending on the function and state of that button. See Table 2-13 below.




Table 2-13: Operator Console

Ref	Description
1	Function buttons (4 in total)
2	Home button
3	Esc button
4	4WD button
5	Differential button
6	Engine RPM memory button
7	Remote control valve lock button
8	Headland Management System field out button

Table 2-13: Operator Console

Ref	Description
9	Headland Management System field in button
10	Shuttle neutral button

Speed Mode shift

Press the speed mode shift button (1) to toggle between Turtle and Rabbit speed modes.

- Turtle speed mode will allow speeds up to 20 km/h (12 mph).
- Rabbit speed mode will allow speeds up to 40 or 50 km/h (31 mph).



Hand Throttle

The hand throttle (1) provides the operator with instantaneous throttle control over the engine.


1. Push the throttle forward to progressively increase the engine speed
2. Pull the throttle back to reduce engine speed.

Complete instructions for adjusting speed: See “Adjusting Speed” on page 3-25.

Arm Rest/Option Controls

An operator’s arm rest (2) is provided with the side operator console. Rest the right forearm on the arm rest to easily control the auto shift controller and the hand throttle.

Lift the arm rest to open the storage compartment and provide access to optional controls if installed.



Transmission Operation

Transmission operation can be performed in 2 ways, either by the FNR lever (1) on the steering console or by pressing and holding down the shuttle enable button (2) and pressing F or R on button (3) on the EZ-command center (4).

Table 2-14: Transmission Operation with FNR Lever

F	Forward: Lift the FNR lever and push the lever forward to engage forward motion.
R	Reverse: Lift the FNR lever from neutral and pull the lever back to engage reverse motion.
N	Neutral: Push and hold down the FNR lever or press the neutral button on the armrest console.





Table 2-15: Transmission Operation with EZ-Command Center

1	Cruise: To activate cruise, press the button (1) once this will activate the last saved settings.
F	Forward: Press and hold the shuttle enable button (2) on the back of the EZ-Command Center. Then press the Forward button (3).
R	Reverse: Press and hold the shuttle enable button (2) on the back of the EZ-Command Center. Then press the Reverse button (4).
5	Ratio Lock: To activate ratio lock button, press the button (5). For more information. refer to “Operating Ratio Lock Button” on page 3-44.

Push the EZ-Command Center to speed up, the longer it's held the faster the travel speed will be. Release the lever to stay at the correct speed.

Pull the EZ-Command lever back to reduce speed, the longer it's held, the slower the slower the travel speed will be. Release the lever to stay at current speed.





Remote Valve Controls

The tractor is equipped with 3 or 5 hydraulic levers that control the movement of the implement. Depending on different-destination models and mounted options, however, the number of ports varies.

Carefully check the relation between each valve and control switch before connecting the hydraulic hoses.

- (1) Remote control valve switch 1.
- (2) Remote control valve switch 2.
- (3) Remote control valve switch 3.
- (4) Remote control valve switch 4.
- (5) Remote control valve switch 5.
- (6) If Loader is installed - Remote control valve switch (5)/Loader joystick.

Refer to "Remote Valve Controls" on page 4-8 for complete instructions.






3pt Hitch Lock Button

The 3pt hitch lock button (1) locks the 3-pt hitch out for travel if not in use.

Press the 3pt hitch lock button (1) on the operator console (2) to enable/disable the 3pt hitch. Alternatively press the right side of 3pt hitch button (3) on the monitor to unlock 3pt hitch and press the left side to lock.

The 3pt hitch lock button (3) and icon (4) will be illuminated when 3pt hitch is locked and off when it is unlocked.






3-pt Hitch Controls

The 3-pt hitch controls is located on the EZ-Command Center (1) and Operator Console (2).

- Fast raise and lower switch (3)
- Depth control dial (Hydraulic dial) (4)
- 3-pt hitch lock button (5)
- External Raise/ Lower Switches (6) (Located on each rear fender).
- The rear 3-pt will only drop or raise to the height set in the dials or on the monitor.
- The upper limit can only be set using the sliding bar in the monitor.
- The lower limit can only be set with the dials on the armrest.
- Drop speed can only be changed in the monitor, with the rabbit image, no dial to control drop speed.

NOTE: Fender switches override height and lower settings.




3-pt Hitch Quick Raise/Lower Switch

The 3-pt hitch quick raise/lower switch (1) is located on the EZ Command Center (2). This brings the 3-pt hitch to working depth or travel height.

Depth Control Dial (Hydraulic Dial)

The manual control lever (3) controls the working depth of the hitch.


- The implement height (plowing depth) can be adjusted.
- For traveling on public roads, keep the implement raised with the dial.
- When the dial is preset for the implement to get to the lower limit, the 3-pt hitch quick raise/lower switch can be used to raise and lower the implement.



Field in and out buttons

When the indicators of both buttons are on, press either the Field out (1) or Field in (2) buttons to activate the Headland Management System.

With the Headland Management System lock/unlock switch at lock position	Indicators of both buttons: OFF
With the Headland Management System program ready to run	No indicators for Out and In field buttons
With the field out button pressed and the program running	Indicator of field out button: ON Indicator of field in button: OFF




Headland Management System Display Icons

The following icons are the “HMS Icons” displayed on the monitor when HMS is enabled. Refer to “Headland Management System” on page 3-186.

Table 2-17: Road Mode Screen Icons

Icon	
1	Headland Management System lock indicator
2	Program code display indicator
3	Headland Management System lock/unlock switch
4	Program select switch





Headland Management System

The purpose of the Headland Management System (HMS) is to reduce the number of actions performed by the operator while turning the vehicle at the end of the field. This is accomplished by recording the actions performed during the first turn and then replaying those actions during subsequent turns.


Headland Management System Operation

1. Get the engine started and touch the right half of the Headland Management System lock/unlock switch (1) to unlock the system. Once unlocked, the indicator (2) goes off.
2. Using the program select switch (3), choose the recorded program code (I or II) (4). Once selected, the program code display indicator (4) lights up and stays on.
3. When the headland has been reached, press the Field out button (5). The recorded program will be carried on. After swiveling the machine, press the Field in button (6).
4. To interrupt the program execution, press the Field out or Field in button, for which the indicator stays on.



Field out and in buttons

When indicators of the Field out (1) and Field in button (2) are on, press either of the buttons to activate the Headland Management System.




PTO Controls

Use the PTO switches (1) inside the cab to operate the front or rear power take-off (PTO).

Lift and push the rocker switch forward to activate only when the engine is running.

Refer to PTO Operation in Section 3: Tractor Operation.



PTO Speed Control Levers



WARNING




The PTO lever release locks are to be lifted to move the lever forward or backward and released immediately after this movement. Failure to release can cause the over-travel of the lever past the end of travel detent.

Choose from the following 4 PTO operating modes according to the type of implement or the workload.

Set the Mode Selector Lever (1) to the NORMAL mode for general work and the ECONOMY mode for light-duty work only.

In the ECONOMY mode, the engine runs at a lower speed for energy saving operation.

Use PTO Speed Lever (2) to select either a 540 or 1 000 rpm to suit the implement in use.





Fender-mounted PTO Switches

The fender-mounted PTO switches (1) are located near the rear brake lights.

- Press the external PTO switches to turn off the PTO.

NOTE: PTO fender switches are shut-off switches only and does not engage the PTO. They are only use to turn the PTO off. These functions are for both the front and rear PTO.

Refer to PTO Operation in Section 3: Tractor Operation.




Cab Accessory Panel

The cab accessory panel (1) contains controls for the following:

- (2) Heating and cooling controls (ATC).
- (3) Radio.
- (4) Heated mirrors.
- (5) Power mirrors.
- (6) Exterior Lights.

See the following pages for details.






Cab Air Vents

There are 10 air vents (1) in the inside of the cab located in the following locations:

- Steering column (4 in total)
- Lower part of steering column (2 in total)
- Left side of the cab (1 in total)
- Right side of the cab (1 in total)
- Front window of the cab (2 in total)

These vents deliver heated or cooled air and can be rotated and adjusted to operator preference.

1. Air vents can be closed and air directed down or up by pushing down on the louvered vent
2. Air can be directed 360° degrees by rotating the exterior ring except the 2 at the top of the steering console.




Cab Roof Outside Air Filter

There is 1 air filter (1) located on the left side of the cab roof which filters the outside air coming into the cab.



Inside Cab Air Filter

There is 1 cab air filter (2) located behind the operators seat on the right side which filters the recirculated air in the cab.



Interior Dome Light

An interior dome light is located above the driver on the left side of the headliner. It is either activated manually by pushing the switch to position (1) or can be activated when the door is opened by switching it to position (2).


1. Push on either side of the light (2) to turn the dome light on or off. This overriding the door switch.

NOTE: *In this position if the door is left open the light will stay on. If switch is left in the center the light wont come on.*

Sun Blinds (option)

Front and rear sun blinds are available as factory-installed options or as dealer-installed accessories.

The sun blind can be pulled down to provide shade from the direct glare of the sun. Push up to retract.




Radio Options

Depending on the options selected, the tractor will come equipped with a AM/FM radio with CD and MP3 or satellite radio with CD, MP3 and USB.

NOTE: Satellite radios require either an XM or Sirius satellite radio subscription and antenna.

The radio (1) is located above the operator seat. Speakers are behind the headliner at the rear of the cab above the operator. The radio can be controlled using the fade option. Follow the supplied radio instruction manual for correct radio operation. Contact a KUBOTA dealer for more information.

NOTE: The appearance of the radio varies depending on the type. The below image is an example.



Heating and Cooling Controls (Manual)



CAUTION




The air conditioning system (A/C) uses R-134A refrigerant. Do not mix with other refrigerants. Consult a qualified technician for all air conditioning repairs.

Cab heating and cooling controls are located above the driver seat, on the right side, to the left of the radio.

NOTE: *The appearance of the controls may vary slightly from the illustrations but the operating instructions remain the same.*

Manual Controls

1. Rotate the temperature control (1) to the right to turn on the temperature.
2. Adjust temperature by rotating the temperature control.
3. Adjust fan settings using the control knob located on the left (2).



Heating and Cooling Controls (ATC) Identification



CAUTION





The air conditioning system (A/C) uses R-134A refrigerant. Do not mix with other refrigerants. Consult a qualified technician for all air conditioning repairs.

- Vent key (9)
- Vent Up key (10)
- Main (11)
- Auxiliary (12)
- Coil Defrost (13)
- Cooling (14)

Cab heating and cooling panel (1) are located above the driver seat, on the right side, to the left of the radio. The control panel consists of a keypad and a display for viewing parameters, operating status and temperature.

NOTE: The appearance of the controls may vary slightly from the illustrations but the operating instructions remain the same.

- Up key (2)
- Auto key (3)
- Down key (4)
- Heating/Back key (5)
- Menu (6)
- Maintenance/Enter key (7)
- Vent Down key (8)




Heating and Cooling Controls (ATC)

- Power** - When the panel is powered at 12VDC/ 24 VDC, the main screen appears displaying the set point or internal temperature value in the main field. The control will assume the last option selected before shutdown when the P217 parameter is set to "Last State". If P217 is set to "ON", automatic mode will be assigned both for control and ventilation. And finally, if P217 is set to "OFF", control and ventilation are initialized in OFF status.
- Main Screen (1)** - On the main screen, the display shows two values in the main and auxiliary fields (2). Main can be set to display the setpoint or internal temperature depending on the value of P248 parameter. In this case, to display the setpoint, press Up and Down keys (3). Auxiliary can be set to display the external temperature or internal temperature by means of P249 parameter. The main screen also display the current time and coil defrost status.




- AUTO Key (4)** - The AUTO key enables automatic temperature control. It means that, depending on the internal temperature (see chart). The control could be only in ventilation, cooling or heating mode. The control status can be viewed by the colors of the indication bars in AUTO: if the color is green, this means the module is in ventilation mode only (water valve is closed and compressor is OFF); if blue, it is in cooling mode and red color indicates the control is in heating/warming mode. Note heating is achieved using a hot water valve, where its opening is controlled by a PID controller. The error signal for this PID is the difference between internal temperature and setpoint. The constants K_p , K_i and T_s (differential portion K_d is zero) are given by parameters P700, P701 and P703 respectively.
- Setpoint** - Setpoint is the desired temperature inside the vehicle. To adjust, press Up or Down on the left side of the panel. The setpoint temperature will be displayed. Press one of the keys again until it reaches the desired temperature. If the parameter P248 is set to display the internal temperature, the respective value will be displayed after adjusting the setpoint. Otherwise, the setpoint value will remain exhibited on the screen.





- Ventilation (Manual)** - The panel as the manual ventilation option. This function has 3 speeds (low, medium and high) when the P261 parameter is set to “3 speed”. In this configuration, module GL-M1HRT001 activates 3 individual outputs corresponding to low, medium and high speeds. The system can be also set for PWM evaporator when P261 is set to “PWM”. In this case, we have 6 speed levels available, which can be adjusted via P402-P407 parameters. To change the speed, press Vent Up or Vent Down keys (1). When the buttons are pressed, a pop-up panel appears on the screen indicating the selected option. In addition, the color sidebar rolls up and down based on the selection or remains off if the speed is automatic or off.

NOTE: Manual ventilation can be activated even when the temperature control is off.


- Ventilation (Automatic)** - Ventilation will always start in automatic mode when any of the (AUTO, HEATING or COOLING) functions is enabled. Its control depends on the setpoint and P400 and P401 parameters, as shown in the charts.
- The ventilation can be deactivated in heating mode by setting the P259 parameter. The manual ventilation mode stil remains available.



- Cooling key (2)** - Cooling is enabled by the COOLING key and its operation is illustrated by the chart. The indication bar of the cooling key will change to blue color. A 30 second hysteresis occurs for compressor to be turned off and turned on again.
- “AC ON” Output** - The module GL-M1HRT001 has an output called “AC ON” that allows the vehicle’s condenser blower be turned ON. This output is ON when the controller is in heating mode (either by HEATING key or AUTO mode) or in ventilation only mode. The “AC ON” is an independent output. Its state is not determined by pressure failure, coil defrost or even compressor state. It is turned ON/OFF just considering the actual controller/system operating mode.
- Heating key (3)** - Heating/warming is enabled by the HEATING key. The indication bar of the heating key will change to red color. The module GL-M1HRT001 actuates in a water valve to control the heating temperature. Similar to heating in AUTO mode, a PID controller is used to keep internal temperature as close as possible to the setpoint. The error signal for the PID is the difference between internal temperature setpoint. The constants K, Ki and Ts (differential portin Kd is zero) are given by parameters P700, P701 and P703 respectively.



- **Pressure Monitoring** - The cooling system pressure is monitored by a pressure switch inlet on the GL-M1HRT001 module where low and high pressure switches can be connected in series. After an out-of-range event, the compressor will take 3 min to restart if the pressure has been reestablished to normal values.
- **Coil Defrost** - The controller provides the coil defrost function, which is enabled via parameter P521. Parameters P510 and P511 define the defrost start and end temperatures with defrost enabled. When coil defrost is enabled, the compressor outlet will be turned off. The coil defrost on/off status is indicated by the "DEF" symbol on main screen.




System Parameters

To access the system parameters, perform the following instructions.

1. Press the Menu key (1).
2. Press the Vent Down key (2) to reach the Parameters option.
3. Enter password 1041 by using the Vent Down key (2) and Vent Up key (3). Confirm the password entry using the Enter key (4).
4. Select the desired parameter by using either Vent Down or Vent Up keys (2 and 3). Press the Enter (4) to edit the parameter.
5. Change the parameter by pressing Vent Down or Vent Up keys. Press Enter to confirm.
6. Return to the main screen by pressing the Back key.

NOTE: The parameter values can be reset to their default values via Reset Parameters tab with password 0370.




Power Mirrors (option)

Power mirror control is located above the operator seat on the extreme right of the radio. The power mirror option allows the operator to adjust the position of the external mirrors without exiting the cab.

1. Switch the control lever (1) to L to control the left mirror
2. Switch the control lever (2) to R to control the right mirror
3. Move the control lever (3) up/down/left/right to control the pitch and yaw of the selected external mirror.


The power mirror option includes the heated mirror function.



Heated Mirrors


The heated mirror switch is located above the operator seat on the extreme right of the mirror controls. The heated mirror option allows the operator to heat the external mirrors without exiting the cab.

1. Push the rocker switch (4) to activate the heated mirror option. Green light indicates active.
2. Push the rocker switch (4) to deactivate the heated mirror option.



Horn

Push to activate the horn (1).



Power Outlets



IMPORTANT: A mating plug assembly for the three-pin outlet is available from a KUBOTA dealer.

Power outlets are installed on the pillars, located on the left and right sides of the cab to the rear of the operator's seat.

4 power outlets are located on the right pillar. One outlet is provided on the left pillar. Optional devices may also be installed at the bottom of the left pillar.

Table 2-18: Power Outlet Locations

1	ISOBUS Connection – Located on the main cab power bar on the right rear cab pillar.
2	12V, 3-pin – A 12V alternate power supply outlet is located on the main cab power bar on the right rear cab pillar.
3	12V Alternative Power Connector - Located on the main cab power bar on the right rear cab pillar.
4	Dual 5V USB Power Outlets – Located on the main cab power bar on the right rear cab pillar.
5	12V 3-Pin Accessory Connector – Located on the main cab power bar on the right rear cab pillar.
6	12V Accessory Power Outlet – Located above the main fuse/relay panel on the right side.
7	9 Pin Diagnostic Connector – Located above the main fuse/relay panel on the right side.
8	14 Pin Diagnostic Connector – Located above the main fuse/relay panel on the right side.



Rear Windshield Washer/Wiper Switches

There are 2 switches for the rear washer/wiper control located on the left rear cab pillar.

Rear windshield washer control:

- Press the rear windshield washer momentary switch (1) to activate the rear windshield washer fluid pump.

Rear windshield wiper control:

- Press the rear wiper switch (2) up to activate the rear windshield wipers continuously, and down to activate the interval wiper speed desired.




Table 2-19: Power Outlet Locations



3	110V Power outlet – Located on the main cab power bar on the left rear cab pillar.
4	12V Plug – A 12V alternate power supply outlet is located on the main cab power bar on the left rear cab pillar.
5	USB port - Located on the main cab power bar on the left rear cab pillar.

Windshield Wipers

Front (1) and rear (2) wipers are provided and they have a washer/spray attachment.

Wiper controls are located on the front wiper/washer switch.


Refer to Section 3: Windshield Operation.



Rotary Beacon

A safety beacon can be bolted onto the back of the cab base on the left and right sides.

The rotary beacon kit (1) is available from a Kubota dealer.



Section 3: Tractor Operation – Contents

Pre-operation Checks and Maintenance	3-7
Safety Concerns	3-7
Pre-start Considerations	3-8
First 50-hour Service	3-9
Break-in Precautions	3-10
Preventing System Contamination	3-10
Flexible Maintenance Intervals	3-10
Lubrication and Maintenance Chart	3-10
Entering/Exiting the Cab	3-11
Emergency Exit	3-13
Tractor Start-up	3-14
Starter Motor Protection Switch	3-15
Starting the Tractor	3-15
Engine Block Heater	3-16
Cold Weather Starting	3-17
Tractor Boosting	3-18
Check and Charge the Batteries	3-20
Stopping the Tractor	3-21
Stopping under Normal Circumstances	3-21
Stopping in an Emergency	3-21
Service Brakes – Foot Brakes	3-22
Service Brakes - Brake Interlock Switch	3-23
Parking Brake	3-24
Emergency Stop	3-24
Adjusting Speed	3-25
Adjusting Speed with the Foot Throttle	3-26
Continuously Variable Transmission (CVT) Operation	3-27
Introduction	3-27
Before Start Up	3-28
During Initial Start Up	3-28
Inching Pedal: Rules of Operation	3-29
Continuously Variable Transmission (CVT) Travel Operation	3-30
Main shift (Speed Up and Slow Down) EZ-Command Lever	3-30
Main shift (Speed Up and Slow Down) Foot Throttle	3-30
Automatic mode	3-31
Setting Automatic mode	3-31
Foot throttle operation in automatic mode	3-31
Command lever operation in automatic mode	3-31
Manual mode	3-32
Setting Manual mode	3-32
Operation	3-32
Enhance deceleration	3-32
Speed Mode shift	3-33
Turtle Max Speed Adjustment	3-34
Transmission Operation	3-35
Park Brake Operation	3-35
Shifting Gears: Overview	3-37
Engine Rpm Preset	3-38
Engine/Transmission Continuously Variable Transmission (CVT) Settings	3-39
CVT (Continuously Variable Transmission) Control	3-40
Traveling Operation	3-40

Main shift	3-40
Modifying the CVT Droop setting	3-41
Modifying the CVT Response setting	3-41
Modifying the CVT Low-range max. speed setting	3-42
Operation of the Manual Engine Speed Setting Mode	3-43
Switching to the manual engine speed setting mode	3-43
Operation	3-43
Operating Ratio Lock Button	3-44
CVT (Continuously Variable	3-45
Transmission) Droop Setting	3-45
Automatic mode	3-45
Manual Engine Speed Setting mode	3-45
CVT (Continuously Variable	3-46
Transmission) Response Setting	3-46
Cruise Control	3-47
Setting the cruise control	3-47
Setting cruise control with ez-command center	3-47
Calling the memory speed	3-47
Setting the traveling speed with the foot throttle	3-47
Increasing/Decreasing cruise once set	3-48
Re-calling saved cruise speed setting	3-48
Exterior and Interior Lights	3-50
Exterior Light Identification	3-51
Exterior Worklights	3-51
Multifunction Switch	3-52
Hazard Warning Lights	3-53
Extremity/Hazard and Turn Signal Lights	3-54
Interior Cab Lights	3-54
Windshield Wiper – Operation	3-55
Auto Steer	3-56
Rotary Beacon (option)	3-57
Differential Lock	3-58
Differential Lock Operation	3-59
Front Wheel Drive Setting	3-60
TCS – Steering Angle and Speed Charts	3-61
Steering Angle Sensor	3-62
Suspended Axle	3-63
Identification Plate	3-63
Component Identification and Function	3-64
Front Axle (Lockable Differential shown)	3-64
Front Axle Dimensions	3-65
Front Axle Specifications	3-66
Front Axle Lubricants	3-67
Front Suspension Setting	3-68
Language and Units of Measurement	3-69
Method 1: Use Display Monitor to Change Language, Units of Measurement or Display Brightness	3-69
EIC Overview: Language	3-72
EIC Overview: Unit of Measure Screen	3-73
Software	3-74
Use EIC to Check Software	3-75
Trailer Socket	3-76
Tires	3-77

Tire Selection	3-78
Tire Maintenance Procedures	3-78
Factors Determining Best Tire Performance	3-78
Tire Combinations	3-79
Radial Tire Identification	3-79
Tire Pressures and Permissible Loads	3-79
Wheels and Tires	3-84
Tire Selection	3-84
Approved Tire Sizes and Combinations	3-85
Recording Tire Size to Measure Ground Speed: Introduction	3-86
Recording Tire Size to Measure Ground Speed Method 1: Tire Size Adjustment Screen	3-87
Recording Tire Size to Measure Ground Speed Method 2: Wheel Speed Calibration Screen	3-89
Recording Tire Size to Measure Ground Speed Method 3: Zero Slip Calculation (Ground Speed Sensor)	3-91
Mechanical Front Wheel Drive (MFWD) Front Axle Track Spacing	3-93
Front Wheel Positions	3-94
Wheel Toe-in	3-95
Adjusting Toe-in – Standard Steer MFWD	3-95
MFWD Steering Stops	3-96
Rear Wheel Track Spacing	3-97
Axle Lengths	3-97
Rear Wheel Track Adjustment	3-101
Adjusting Rear Wheels	3-102
Adjusting Pressed Steel Wheel	3-103
Adjusting Cast Center Wheel	3-103
Dual Rear Wheels	3-104
Outer Wheels	3-104
Tire Clearance	3-105
Wheel Removal/Installation	3-105
Inner Wheels	3-105
Adjusting Front Fenders (Suspended Axle)	3-106
Adjust Fender Height and Pitch	3-107
Adjust the Distance between the Fender and the Side of the Tractor	3-108
Fender Spacing Specifications	3-109
Spacing Position A (480 mm Fender, Single Wheels)	3-110
Spacing Position B (480 mm Fender, Single Wheels)	3-111
Spacing Position C (540 mm Fender, Single Wheels)	3-112
Spacing Position D (620 mm Fender, Single Wheels)	3-113
Spacing Position E (620 mm Fender, Single Wheels)	3-114
Ballasting and Tires	3-115
Ballast	3-115
Total Weight	3-115
Static Weight Distribution	3-115
Tire and Ballast Factors	3-116
Ballast Benefits and Limitations	3-117
Selecting Ballast	3-118
General Weight-Split Guidelines	3-118
Towed Draft Implements	3-118
Trailers and Towed Tanks	3-118
Integral and Semi-integral Implements	3-118
Adapting Ballast to Work Load and Ground Speed	3-118
Ballasting Decisions	3-119
Checking Wheel Slippage	3-120

Automatic Wheel Slip Monitor	3-120
Manual Wheel Slip Measurement	3-120
Ballast Limitations	3-120
Estimating Ballast Requirements	3-121
Weighing the Tractor	3-121
Rear Tire Weighting	3-122
Calculating Tire and Axle Loads	3-122
Rear Wheel Cast Iron Weights	3-123
Installing Cast Iron Rear Wheel Weights	3-123
Ballasting Front End for Transport	3-124
Determining Maximum Front Ballast	3-125
Front Weights – Cast Iron	3-125
Adjust for Type of Load	3-125
Installing Front Weights	3-126
Front Tires - Liquid Weight	3-127
Tires	3-128
3-pt Hitch	3-129
3-pt Hitch Overview	3-130
3-pt Hitch Control System (Rear)	3-131
3-pt Hitch Settings (Rear) Display Screen	3-132
Switching between 3-point hitch lock and unlock	3-133
Adjusting the lift arm top limit control (17)	3-133
Adjusting the lift arm bottom limit control (15)	3-133
Displaying the lift arm height (16)	3-133
Adjusting the 3-point hitch lowering speed control (14)	3-133
Switching the automatic draft control	3-133
Adjusting the draft sensitivity control (13)	3-134
Setting the ride control	3-134
Setting the wheel slip control (9)	3-134
3-Point hitch status indicator (2)	3-135
Calibrate 3PT Hitch	3-136
Fender-mounted 3-pt Hitch Switches	3-137
Enable 3-pt Hitch	3-138
External raise/ lower switches	3-139
Position/Mix Draft Mode Select	3-140
Depth Control Dial (Hydraulic Dial)	3-141
Position Control Mode	3-141
Mix Draft Control Mode	3-142
Position Control Mode	3-142
Draft sensitivity adjustment switch	3-143
Float Control	3-143
Lift Arm Top Limit Adjustment	3-143
Adjust Lift Rods	3-144
Adjust Top Link	3-144
Sway Blocks	3-145
Guide Blocks, Spacers and Shims	3-145
Category II or Category III Position	3-145
Category III Position	3-146
Linkage Category Conversion	3-146
Hook-end Hitch	3-146
Stabilizers	3-147
Adjusting the Stabilizers	3-147
Implement Hook-up	3-148

Hydraulic Trailer Brake Coupling	3-149
Towing Attachments and Drawbar Operation	3-150
Swinging Drawbar	3-151
Automatic Hitch Pin	3-152
Drawbar Length Adjustment	3-154
Drawbar Length	3-154
Adjusting Drawbar Length	3-155
Towing Operations	3-156
Safety Chain	3-157
Attaching and Detaching Trailed Equipment	3-158
Power Take-off (PTO) (Front and Rear)	3-159
PTO Requirements	3-159
Rear Power Take-off (PTO)	3-160
PTO Controls	3-161
Handling the levers	3-163
Front PTO Clutch Control Switch	3-167
PTO Options	3-168
PTO Master Shield	3-169
Changing the PTO Output Shaft	3-170
Attaching Equipment to the PTO Shaft	3-171
PTO Operation	3-172
PTO EIC Configuration	3-173
PTO icon Settings	3-175
PTO Settings	3-176
Rear PTO Operation	3-177
Auto PTO Operation	3-179
Rear PTO Calibration (TMT20)	3-180
Diesel Particulate Filter Regeneration	3-181
Regeneration process	3-181
DPF Regeneration Overview	3-181
Aftertreatment System Operation	3-182
Selective Catalytic Reduction (SCR)	3-183
Diesel Exhaust Fluid	3-184
Modes of Regeneration	3-185
Regeneration Triggers	3-186
What is Diesel Particulate Filter Regeneration?	3-187
What is Diesel Exhaust Fluid?	3-187
Aftertreatment Indicator Lamp Identification: Exhaust System Cleaning	3-188
Aftertreatment Indicator Lamp Identification: High Exhaust Temperature (HEST) Lamp:	3-189
Aftertreatment Indicator Lamp Identification: Exhaust System Cleaning Disable (Inhibit) Lamp	3-190
Aftertreatment Indicator Lamp Identification: Diesel Exhaust Fluid (DEF)	3-191
Aftertreatment Indicator Lamp Identification: Diesel Exhaust Fluid (DEF) Quality Operation	3-192
Aftertreatment Indicator Lamp Identification: Diesel Exhaust Fluid (DEF)/SCR Malfunction Operation	3-193
DEF/SCR System Override	3-194
Final Inducement Overview/Summary	3-194
PM Warning Level and Required Procedures	3-195
Introduction to Inhibiting, Forcing and Re-enabling DPF Regeneration	3-197
Inhibiting DPF Regeneration	3-198
Forcing DPF Regeneration	3-199
Auto Regeneration Mode	3-200
Headland Management System	3-201

Operating Restrictions	3-201
Preprogram Operating Procedure sample	3-202
Headland Management System Display Icons	3-203
Headland Management System Settings	3-204
Preparations for recording the program	3-205
Headland Management System Recording Icons	3-206
Recording Program	3-207
HMS Delete Program Icons	3-208
Deleting Program	3-209
HMS Modifying Program Icons	3-210
HMS Modifying PTO to Differential Lock Program Icons	3-211
HMS Modifying Program	3-212
HMS Modifying PTO to Differential Lock Program Icons	3-214
HMS Modifying Differential program to PTO program	3-215
Loader Introduction	3-217
Loader Identification	3-218
Description And Definitions	3-219
Description	3-219
Loader Operating Status Icons	3-220
Setting the Loader Control Valve	3-221
How to use the screen	3-221
Detailed Settings of Loader Speed	3-222
Setting the oil flow rate	3-222
Valve Lock	3-223
Tractor Towing	3-224
Freeing a Mired Tractor	3-225
Jacking Points	3-226
Transporting the Tractor	3-227

Pre-operation Checks and Maintenance

Before starting the engine during daily operation always perform a walk around inspection of the tractor. Pay particular attention to the following items:

- Inspect and engage the parking brake. Open all engine access panels. Walk around the tractor and perform a visual inspection looking for possible signs of equipment failure.
- Inspect the condition of all belts, hoses, the fan and other engine accessories. Replace, tighten or repair as necessary.
- Make sure the following areas are clean of debris and obstructions:
 - Engine
 - Radiator and oil coolers
 - Front grille
- Check the following fluids. Make sure the fluid level is the correct type and is full. Inspect the fluids for contamination and quality. Replace as necessary:
 - Engine oil
 - Coolant
 - Hydraulic oil
 - Differential oil (NOTE: also check for leaks around the wheel hubs).
 - Transmission oil (NOTE: check oil level with the engine off). Check all hoses, lines and fittings for leaks or damage.
- Make sure all attached hardware is fastened tightly to the tractor.
- Check drive line and hydraulic pump areas for leaks or accumulated debris.
- Make sure the tractor is correctly ballasted for the work it will be doing. See “Ballasting and Tires” on page 3-112.
- Check tires for possible damage and correct tire pressure.
- Check wheel mounting nuts for correct torque.
- Inspect the drawbar and 3-pt hitch for wear, especially around metal-to-metal contact parts.
- Make sure all necessary repairs have been completed before operating the tractor.

Safety Concerns



WARNING



Make sure all operators read this manual and are aware of all the safety precautions and operating controls before starting the engine. Otherwise damage to the tractor or serious injury to bystanders or operator may occur.

Safe tractor operation is essential to prevent injury to the operator and bystanders. Before operating the tractor consider the following:

- Do not operate the tractor in a closed building.
- Before starting the engine, make sure all operating controls are off or in neutral and the parking brake is engaged.
- Always operate the tractor from the operator's seat.
- Stop the engine before servicing the tractor and raise engine side shields.
- Make sure all safety shields are in place and operational.
- Always use hand holds and steps when mounting and dismounting the tractor.
- Always use turn signals when turning or slowing the tractor.
- Always use proper safety devices to warn of slow-moving vehicle when driving on public roads. Check with local authorities concerning highway travel.
- Always use wide transport marker lights when required.

Pre-start Considerations

Take the following into consideration before starting the tractor:

- Do not pull loads immediately after starting. Always allow the engine to warm up prior to pulling heavy loads.
 - Do not apply excessive rpm. Avoid excessive idle speeds during warm up to extend engine life.
 - Do not push the inching pedal down for at least 20 seconds after engine startup. This allows the transmission to purge air from the transmission clutches which will provide smoother gear shifting.
 - Do not crank the engine for more than 30 seconds if the engine does not start. Wait two minutes to cool the starter motor before re-cranking if the engine does not start.
 - Do not ignore warning lights. Pay attention to the warning light bar and electronic monitor for any indication of a problem. Stop the tractor immediately and investigate the problem.
-

First 50-hour Service

The first 50 hours of tractor operation are the most critical for ensuring long and dependable tractor life. The tractor will provide long and dependable service given proper care during the initial 50 hour break-in period and if the recommended service operations are performed and the schedules followed.

Ensure the following steps are carried out during the first 50 hours of operation.

- Review the tractor Pre-delivery Checklist with the Kubota dealer and make sure all the items on the list have been inspected and checked off.
 - Become familiar with the instructions for operation of the controls.
 - Read and understand all safety warnings.
 - Check all fluid levels and ensure the systems are filled with the correct fluids suitable for the tractor operating conditions.
 - Check the engine, transmission and hydraulic oil levels hourly during the first 10 hours of operation.
 - Inspect the tractor for leaks hourly during the first 10 hours of operation.
 - Tighten the wheel hardware to the torque values provided in Section 5: Lubrication and Maintenance after the first hour of operation and at the end of each day for the first 50 hours of operation.
 - Operate the engine at 3/4 load as much as possible during the first 50 hours (3/4 load is approximately one gear lower than would be normally used to pull a matched load).
 - Do not operate the engine at idle speed or full throttle for more than five minutes at a time for the first 50 hours.
 - Check the instruments frequently during operation.
-

Break-in Precautions

The Cummins engine has been run on a dynamometer before installation but not enough to be considered broken in.

- Do not operate the engine at more than 3/4 load for the first 24 hours of operation. Hold a full load only for short intervals during the next 24 hours of operation.
- Check the oil level every 8 to 10 hours for the first 100 hours of operation.
- Follow the recommendations outlined in the Cummins owner's manual supplied with the tractor.

Preventing System Contamination

To prevent contamination when changing oils and filters:

- Clean the area around the filler caps, level plugs, drain plugs, dipsticks and filters prior to removal.
- Check that the oil is clean and has not degenerated in storage before connecting remote cylinders.
- Wipe the grease fittings before greasing to prevent the entry of dirt.

Flexible Maintenance Intervals

The intervals listed in the Lubrication and Maintenance Chart in this section are guidelines to be used when operating in normal working conditions. Adjust the intervals for environmental and working conditions. Shorten intervals under adverse (wet, muddy, sandy or extremely dusty) working conditions.

Lubrication and Maintenance Chart

The chart lists the intervals for routine checks, lubrication, service and/or adjustments. Use the chart as a quick reference guide when servicing the tractor.

Entering/Exiting the Cab



CAUTION



Always use the handrails and safety steps. Do not jump from the cab as it can cause serious personal injury. Use extreme care when entering and exiting the tractor.

NOTICE

Use extreme care when opening or closing the glass door. Avoid allowing the door to swing freely.



WARNING



Lower the machinery before leaving the tractor.



IMPORTANT: Use extreme care when opening or closing the glass door. Do not allow the door to swing freely.

The cab is designed for the operator's comfort and convenience. Enter the cab through the door on the left side.

1. Climb on to the first step (1). Grab the hand rails (2) located on the left side of the tractor.
2. Hold the upper hand rail with your left hand, insert the ignition key into the door lock (4) in the handle (3) and turn the key clockwise to unlock the door.
3. Pull the latch handle (5) outward with your right hand. The lever will extend lifting the lock latch.
4. Pull the door outward and then enter the cab.


NOTE: Do not let the door hit your head when it swings out.

5. To exit the cab, put your hand on the horizontal bar inside the left-hand door, lift up the latch (6) and open the door.



In the event of a major accident in which the driver's left side door is blocked, the tractor is equipped with an emergency exit on the tractor's right side.

6. Open the right door (1) of the cab if the left door is blocked, and vice versa in an emergency situation.
7. Exit through rear window if cab doors are blocked in an emergency situation.



Emergency Exit



WARNING




Do not operate the tractor with the emergency exit open.

The emergency exit handle (1) is located in the rear window of the cab.

To operate:

1. Turn the lever and allow the window to open fully.



Tractor Start-up



WARNING



Do not start the engine by shorting across starter terminals. The engine can start and the machine can move causing possible injury and death if the starting safety switch is bypassed.



CAUTION



Before starting the tractor, ensure that neither PTO (front or rear) is engaged before turning the key.



WARNING



Ensure that the cab door is fully closed before driving the tractor. Do not move the tractor with door open.



CAUTION



Inadvertent tractor or implement movement can cause possible machine damage and/or serious injury.

- Make sure all hydraulic control levers are in neutral and the 3-pt hitch is set to the lowest position before starting the tractor.
 - Make sure that all persons are clear of the tractor before starting. The tractor can move as soon as the engine is started, even with the parking brake engaged and the transmission in neutral.
-

Model M8-181 and M8-201 tractors are large machines that if misused can cause serious injury and/or death. Safe tractor operation starts every day and continues everyday throughout the life of the tractor. Before starting the tractor, ask yourself if you are ready today to safely operate this large machine.

Starter Motor Protection Switch



NOTICE

It is necessary to rotate the switch back to the OFF position before making another attempt to start the engine when the engine does not start after the switch has been rotated to the start position and then released to the run position.

The tractor has a built-in starter protection feature. This feature prevents accidental engagement of the engine starter motor when the engine is running.

Starting the Tractor

1. Turn the battery shut-off switch to ON.
2. Fasten the seat belt and make sure the parking brake is engaged.
3. Place the transmission in neutral.
 - Make sure the PTO switch is in the OFF position
 - Make sure all remote hydraulic levers are in the neutral position
 - Make sure all hitch controls are set to the lowest position on tractors equipped with a 3-pt hitch.
4. Insert the ignition key (1) in the ignition (2) and turn the ignition key clockwise to the RUN position to activate the electrical accessories.
 - Visually check for warning lights and listen for audio alarms to make sure they are functioning. Carry out repairs if required. Refer to Electronic Instrument Cluster (EIC) in Section 2: Controls and Instruments.
 - Wait until the Inlet Heater/Ready to Start light  goes off before operating the starter.
5. Turn and hold the ignition key fully clockwise to the START position to crank the engine. Release when the engine starts. Allow tractor to idle and warm up before adding a working load.




Ignition Switch Positions

Engine Block Heater

Block heaters are shipped as standard equipment on Kubota tractors. The block heater is located on the right hand side of the engine beneath the turbocharger.

An extension cord with ground connection is required to plug the block heater to a grounded electrical outlet.

1. Attach the extension cord (1) to the block heater and plug the extension cord into an electrical outlet.
2. Wait four hours; this should be sufficient time for the coolant and block to warm.
3. Start the engine. Never crank the engine for more than 30 seconds. Wait 2 minutes between attempts to allow the starter motor to cool if the engine does not start within 30 seconds.



Voltage varies by region:

North America	115V
Europe	220V
Asia	220V



WARNING

- Do not use ungrounded extension cords. Use a grounded three-wire extension cord rated for at least a 15A load, protected by a suitable fuse or circuit breaker.
- Do not handle block heater cords if wet.
- Do not plug in the block heater with low coolant levels. An overheated element can cause an electrical short circuit and electrocution hazard. An overheated element can burst the heater core causing engine damage.



Cold Weather Starting



WARNING



Do not use starter fluid of any type to start a Cummins QSB6.7 engine. The use of highly flammable starter fluids is extremely dangerous and can lead to serious injury. Using a starter fluid will void your engine warranty.

NOTICE

The tractor is equipped with an engine warm-up protection system. The system employs sensors and an air inlet heater. This system operates from 3 to 25 seconds as required.

NOTICE

Do not engage the starting motor for more than 30 seconds to prevent damage to the starting motor. Wait two minutes between each attempt to start.

NOTE: The cold start system does not eliminate the need for standard cold weather starting preparation. Follow recommendations for block heaters, transmission heaters, #1 diesel fuel and lower viscosity oil as described in Cummins maintenance recommendations.

Cold weather starting aids may be required to assist engine start up at temperatures at or below 0 °C (32 °F). The 25 second preheat cycle will begin shortly as long as the predetermined conditions are measured by the sensors and the Engine Control Module (ECM).

The air inlet heater will also operate automatically after engine start up under control of the ECM.

NOTE: The ECM will limit the speed of the engine during the warm up to 900 rpm.

The throttle control will have no effect until the ECM determines that engine temperature and pressures are achieved. This helps to ensure reliable performance and service from the engine and to minimize start-up wear.

1. Review and complete steps 1 to 4 under Starting the Tractor in this section before proceeding with these steps.
2. Turn the ignition key to the On position with the PTO switch in the Off position and the parking brake applied. The Inlet Heater/Ready to Start icon  (1) will illuminate on the EIC. Wait for this light to go out before you start the engine.
3. Stop immediately and investigate the cause of the problem if warning lights appear at any time during the cold weather start process.
4. Once the engine has started, allow it to warm up before putting it under load. Engine warm up idle speed is 1000 rpm. Normal idle speed is 900 rpm.

Tractor Boosting





CAUTION

- Do not connect the jumper cable to the negative post of the discharged battery.
- Do not lean over the batteries while making the connections
- Do not allow the positive and negative jumper cable clamps to come in contact.
- Do not allow the vehicles to come in contact.





It is not necessary to remove the battery cover to boost the tractor. However, it is good practice to check starting and charging system connections before proceeding with the following steps.

1. Engage the parking brake, put the transmission in neutral, turn off the PTO clutch control and all electrical accessories. Set the power disconnect switch (1) to the ON position.
2. Remove the battery cover (2) by removing a screw (3) on each side.



3. Attach one end of the positive jumper cable (red) to the positive terminal of the booster battery and the other end to the external booster.
4. Attach one end of the negative jumper cable (black) to the negative terminal on the booster battery and the other end to the external booster terminal.
5. Make sure that the clamps from one cable do not touch the other cable clamps or any other connectors. Do not lean over the battery when making connections.
6. Start the engine following normal engine starting procedures. Remove the booster cables when the tractor starts. Disconnect the negative cable (black), then the positive cable (red). Charge the batteries if the tractor fails to start.



Check and Charge the Batteries

Check the battery voltage. The battery voltage should read over 13V when fully charged and 12V minimum.

To charge the batteries:

- Use an approved charging device with fast and slow charge settings. The charger must be rated for 12V batteries. A suitable charger should have charge indicators and automatic shut-off features.
- When a quick charge is needed to start and run the tractor, set the charger to the fast charge mode and attach the negative (-) lead to the negative (-) tractor battery post. Connect the positive (+) lead to the positive (+) battery post.
- Turn the charger on and allow the batteries to charge for at least one hour or until the charge indicator shows full charge.
- Connect the leads to the battery posts as described and set the charger to slow charge mode to fully charge the batteries.
- Turn the charger on and allow the batteries to charge for at least eight hours or until the charge indicator shows full charge.
- Replace batteries that will not fully charge and hold the charge.



DANGER

EXPLOSIVE HAZARD

Batteries generate hydrogen gas, which is highly flammable. If ignited by a spark or flame, the gas may explode causing a spray of battery acid and fragments causing severe personal injury.



- Always follow the proper connect and disconnect procedures. Always disconnect the negative (-) black cables before the positive (+) red cables. Always connect the positive (+) red cables before the negative (-) black cables to reduce the possibility of sparking and an explosion.
 - Always wear protective clothing and safety glasses to protect eyes when working with batteries.
 - Do not smoke or expose the battery to open flame.
 - Do not boost with 24 V or electrical damage may occur.
-

Stopping the Tractor



DANGER



- Do not leave the operator's seat without first bringing the tractor to a complete stop.
- Do not operate the tractor if the foot brake or parking brake does not function properly. Contact a Kubota dealer for assistance.
- Do not rely solely on the transmission to hold the tractor stationary when parked.
- Always engage the parking brake when stopping the tractor.



CAUTION



Always keep the cab floor area free and clean of debris or objects which may obstruct the operation of the brake pedal. Keep the brake pedal clean and dry to prevent the operator's foot from slipping off the pedal.

Stopping under Normal Circumstances


To stop the tractor:

- First press the inching pedal (1), then the foot brake pedal (2 and 3)
- or
- First shift the transmission into neutral and then press the foot brake pedals (2 and 3).

Under normal operations this will bring the tractor to a complete stop.

Apply the parking brake when the tractor comes to a complete stop. (see "Parking Brake" on page 3-24).

To shut the engine off, turn the ignition key to the OFF position.



Stopping in an Emergency

- You can also use the parking brake to slow the tractor down. See next page for details.
- You can use the emergency exit to leave the cab without exiting through the main door. See page 3-24 for details.

Service Brakes – Foot Brakes



CAUTION

Use extra caution when towing loads at transport speeds. Use slower speeds when the towed load approaches or exceeds tractor weight and when not equipped with brakes. Avoid hard braking situations. Refer to the implement operator's manual for recommendations and towing speeds.



CAUTION



Always keep the cab floor area free and clean of debris or objects which may obstruct the operation of the brake pedal. Keep the brake pedal clean and dry to prevent the operator's foot from slipping off the pedal.



WARNING


Always lock the service brake pedals for on road travel. Never attempt to use brakes for turning at road speeds.



All tractors are equipped with hydraulic assisted self-adjusting power brakes. The hydraulic assist functions only with the engine running. The service brakes (1) will still function but with higher pedal effort if the engine is off. Use both the parking (emergency) brake and the service brakes if the engine is not running.

Service brake pedals may be operated independently to assist turning or in tandem for maximum effect.

When operating in the field it is recommended that the service brake pedals be unlocked.



Service Brakes - Brake Interlock Switch



WARNING

If brakes are locked with the locking lever (1). The tractor is able to speed to 40 or 50 km/h (25 to 31 mph).




If brakes are unlocked, the max speed will be limited to 35 km/h (22 mph) for both 40 or 50 km/h (25 to 31 mph).

Move the brake interlock lever (1) up or down to engage and disengage the service brake pedals (2) together.

Rear brake lights will be illuminated when service brakes are applied.

Never ride the brakes by resting feet on the pedals as this causes undue wear on the brakes and wastes fuel.

Periodically test the service brake pedals by operating with the engine off to make sure that the manual brake system works.




Parking Brake



WARNING

Always apply the parking brake when the tractor is not in operation. An alarm will sound and the parking brake light will flash if the engine is stopped without applying the parking brake and if the operator has left the seat



DANGER

Never leave the operator's seat without first bringing the tractor to a complete stop using the foot brake and engaging the parking brake.



Never operate the tractor if the foot or parking brake does not function properly.


Never rely solely on the transmission to hold the tractor stationary when parked; always engage the parking brake.

NOTICE

The parking brake must be engaged before the engine will start.

Use the lever (1) located to the left of the operator's seat to apply the parking brake when the tractor is not moving or when the engine is stopped. The parking brake must be applied before the operator leaves the seat.

1. Pull the lever up to apply the parking brake.
2. Lift the lever up slightly, then press the button (2) and push the lever down to release the parking brake.



NOTICE

The transmission will not engage if the parking brake is applied. A flashing "P" will be displayed in the transmission LCD of the EIC and the parking brake warning light will flash along with a one second audible alarm.

Emergency Stop

Transmission will engage if the park brake is on and the clutch pedal has been cycled once. If the tractor is put into forward or reverse with the park brake up, a 1 second audible alarm will sound.

NOTE: The tractor will move with the park brake on.

The tractor does not shift to neutral when the park brake is engaged. It will stay in the driving direction and an alarm will sound. The tractor will still move if it's not put in neutral.


Adjusting Speed

You can control tractor speed with the hand throttle (1) and/or the foot throttle (see next page).

Rated operating speed is 2100 rpm. Idle speed is 850 rpm. High-idle no-load speed is 2200 rpm.

Adjusting Speed with the Hand Throttle


1. To increase engine speed, move the hand throttle forward carefully.
2. To reduce engine speed, pull the hand throttle back carefully. Fuel consumption can be reduced by operating at lower engine speeds under light load.



Adjusting Speed with the Foot Throttle

This tractor is equipped with a foot throttle pedal (1). Check with KUBOTA support before using this pedal because the pedal can be configured as follows:

- The foot throttle is as an accelerator pedal.



Continuously Variable Transmission (CVT) Operation



WARNING



Do not operate the engine below 1 200 rpm when pulling a heavy load. Failure to observe this precaution may void engine warranty.

NOTICE

To avoid damage to the transmission, operators must read and understand the basic transmission options associated with this tractor.

Introduction

This tractor is equipped with a Continuously Variable Transmission (CVT).

- The M8-181 and M8-201 is equipped with a Continuously Variable Transmission (CVT) Control and is fully computerized stepless type. Depending on the type of work, there are 2 modes to choose: Automatic and Manual Engine Speed Setting.
- The shift lever (1) provides operating control for forward/reverse shifting and gear selection.
- The inching pedal (2) is used to control slow speed movement such as coupling or decoupling equipment or implements. The inching pedal allows the transmission to partially disengage when pressed. Speed matching is always active.

The transmission clutches are controlled by the transmission control module and the transmission shifts in response to operator inputs (direction selector position, upshift/downshift requests, inching pedal position, autoshift mode, etc).

The following pages explain:

- Important notes before and during the initial startup of the engine.
- Conditions for using the inching pedal (2) and how to calibrate the pedal if required.
- Important shifting features.
- How to shift gears manually or automatically.




WARNING



The ez-command center has no neutral position. To bring the tractor to a complete stop, step on the brake pedal or set the shuttle lever to neutral.

NOTICE

- Calibration of the transmission directional clutches must be performed by a KUBOTA dealer.



Before Start Up

- Always refer to the Pre-operation Checks and Cab Features.
- Place shift lever in neutral.
- Fully apply parking brake.
- Make sure the PTO switch is in the disengaged position (option).

During Initial Start Up

NOTE: Do not press the inching pedal within 20 seconds after starting the engine. If you press the inching pedal during this time, proper clutch modulation will not be available. Cycle the inching pedal once to reset the pedal.

During power up the transmission control system initializes and ensures that the machines does not move until the direction selector is first moved to or in neutral and then moved to a non-neutral gear. Following successful completion of all power-up function, normal operation is established.

Cold Start Procedure

1. In the start temperature range of -30 °C (-22 °F) to -7 °C (-19 °F) a cold start procedure controls heating of the transmission. The hydrostatic unit is heated with limited speed and the directional clutches and range clutches of the first driving range are pulsed in succession.

All subsequent temperature values are measured by the TCU on the clutch control block.

Temperature classes	4	3	2	1
Temperature range (°C)	-30 °C to -21 °C (-22 °F to -6 °F)	-20 °C to -16 °C (-4 °F to -3 °F)	-15 °C to -8 °C (-5 °F to -18 °F)	>-7 °C (-19 °F)
Required total time for the cold start procedure	10 min	5 min	3 min	No delay

2. At low temperatures the range selection in the transmission is extended because of the extended filling times of the range clutches K1-K4 and the multi-disk brake BG.
3. Boundary conditions for the cold start procedure”
 - Parking brake engaged.
 - System pressure is available.
 - Engine speed range minimum 1 100 min-1 up to maximum 1 500 min-1.

NOTE: Plastic, wiring, sensors, oil glass and seals must not be located directly in the warm air flow.

NOTE: High suction pressure, a reduced flow rate of the transmission filter and a temporary opening of the cold start limiting valve are to be expected.

Inching Pedal: Rules of Operation



WARNING

- Always keep the cab floor area free from debris or objects which may obstruct the operation of the brake and inching pedal.
- Keep the pedals clean and dry to prevent feet from slipping.
- The ez-command center has no neutral position. To bring the tractor to a complete stop, step on the brake pedal or set the shuttle lever to neutral.
- Do not release the inching pedal before completing a turn when using the pedal for deceleration.



NOTICE

- Excessive use of the inching pedal may cause excessive heat damaging the transmission.
- Use the inching pedal at low throttle settings. Light draft loads will extend clutch life.
- Only use the inching pedal for hooking and unhooking equipment.


The inching pedal (1) operates like a clutch, for safe, accurate positioning of the tractor when attaching implements or operating in confined spaces, etc.

Pressing the pedal interrupts power flow from the engine to the transmission. Release the pedal slowly to restore power flow.

- Make sure the transmission is in neutral and the parking brake is not applied before using the inching pedal.

Inching Pedal: Calibration

NOTE: Calibration only needs to be performed when the operation of the pedal becomes erratic.



Continuously Variable Transmission (CVT) Travel Operation



WARNING



The EZ-Command center has no neutral position. To bring the tractor to a complete stop, step on the brake pedal or set the shuttle lever to neutral.

The traveling speed control with CVT transmission can be operated with either the ez-command center or the foot throttle according to the type of work.

NOTE: The control using the foot throttle requires the selection of “Automatic Mode”. The operator can control both the speed and the engine power by how deeply the foot throttle is pressed. This enables convenient operation of the trailer.

Main shift (Speed Up and Slown Down) EZ-Command Lever

The tractor can be sped up and slowed down easily with the ez-command center.

1. Push the ez-command lever forward to increase the speed of the tractor. The longer the lever is pushed forward the higher the travel speed. The travel speed is fixed at the speed where the lever is released.
 - For example, if the command lever is pushed and held till 5 km/h (3 mph) is reached then the lever is released. The tractor will now travel at 5 km/h (3 mph) until the lever is pulled back to decrease speed.
2. Pull the command lever backward to decrease the speed of the tractor.

NOTE: Every time the command lever is moved to speed up or slow down, an audible beep will be heard to inform the operator a change to the driving operation has been made.

Main shift (Speed Up and Slown Down) Foot Throttle

1. Press the foot throttle down to increase the speed of the tractor. The farther the foot throttle is pushed, the higher the travel speed. If the foot throttle is released the travel speed will drop down to default of 0.5 km/h (0.3 mph)
-

Automatic mode

1. The optimum travel speed and engine power are obtained according to the speed settings made with the command center or foot throttle.
2. This mode is mainly used for road travel and towing plows and other implements where speed needs to be maintained and engine rpm is not as critical.
3. Engine speed will increase or decrease based on load to maintain the desired speed.

Setting Automatic mode

1. Set the transmission to neutral by either pressing the FNR lever down or pressing the neutral button on the armrest.
2. Set the hand throttle to the “Minimum” setting. Automatic mode is now selected.

Foot throttle operation in automatic mode

1. Press the foot throttle down to increase the tractor speed and engine power. The deeper the pedal is pressed the faster the tractor will go and higher the engine RPM will be. Like a car with an automatic transmission.
2. Release your foot from the pedal and the tractor slows down and engine RPM decrease.
3. To come to a complete stop, step on both brake pedals. When the brake pedals are released, the tractor will start to move again at default speed setting of 0.5 km/h (0.3 mph).

Command lever operation in automatic mode

1. Push the command lever forward till the desired travel speed is reached. The engine rpm will automatically increase to keep up with speed setting.
2. To stop, pull back on the command lever to slow down the tractor then press both brakes to come to a complete stop. Alternatively, if both brake pedals are pressed while at set travel speed, the tractor will come to a complete stop. Once the brake pedals are released in both cases, the tractor will start to move at default speed setting at 0.5 km/h (0.3 mph).
3. If the clutch pedal is used to stop the tractor. Once the clutch pedal is released the tractor will continue to drive at the preset travel speed.

NOTE: The default travel speed of the tractor is 0.5 km/h (0.3 mph). If both brake pedals are applied while driving, the tractor will to a complete stop and the preset speed setting will go back to default. If only one brake pedal is pressed, the tractor will not stop or decrease speed as it thinks the tractor is trying to turn. Make sure both brake pedals are locked together when traveling down the road.

NOTE: If the brake pedals were activated as well during the stop, the travel speed will default to 0.5 km/h (0.3 mph).

Manual mode

1. The optimum travel speed and engine power are obtained according to the engine RPM settings made with hand throttle.
2. This mode is mainly used in PTO applications where engine RPM must be maintained and speed is not as critical. Towed implements may also be used in this mode.
3. Travel speed will increase or decrease based on load to maintain the desired engine RPM.

Setting Manual mode

1. Set the transmission to neutral by either pressing the FNR lever down or pressing the neutral button on the armrest.
2. Use the hand throttle to set the desired engine RPM setting. Manual mode is now selected.

Operation

1. Set the desired engine RPM and travel speed for the work being done.
2. If the load is increased or decreased, the constant engine RPM will be maintained. If load is too great to maintain engine RPM at current speed, the speed will drop to maintain the engine RPM.

Enhance deceleration


1. This feature turns on the FWA while decelerating with the command lever to help slow down the tractor by brake or diminishing power through the driveline. FWA will stay engaged until the command lever is pushed forward to being accelerating again at which time the FWA will turn off.
-

Speed Mode shift

Press the speed mode shift button (1) to toggle between Turtle and Rabbit speed modes. Depending on the selection will be shown on the K-Monitor (2).


- Turtle speed mode will allow speeds up to 20 km/h (12 mph).
- Rabbit speed mode will allow speeds up to 40 or 50 km/h (31 mph).

NOTE: Switching from the Rabbit speed mode to the Turtle speed mode is not possible if the current traveling speed is higher than the maximum traveling speed set in the low speed mode; a buzzer will sound if this is tried.



Turtle Max Speed Adjustment

To adjust Turtle MAX speed either touch and drag the slider to the desired km/h. Or used the + or - switches to move to the desired km/h.



Transmission Operation



Transmission operation can be performed in 2 ways, either by the FNR lever (1) on the steering console or by pressing and holding the shuttle enable button (2) then F or R on button (3) on the EZ Command center (4).

F	Forward: Lift the FNR lever and push the lever forward to engage forward motion.
R	Reverse: Lift the FNR lever from neutral and pull the lever back to engage reverse motion.
N	Neutral: Push and hold down the FNR lever or press the neutral button on the armrest console.

NOTE: When in operation mode, It will not switch to neutral when the operator pulls on the parking brake.

Park Brake Operation

If the park is on and the operator shifts to F or R, an audible alarm will sound. Park brake will not shift transmission from F or R to Neutral.



Forward and Reverse Operation

NOTE: Change of driving direction is only possible below speeds of 15 km/h (9.32 mph).

- If the driving speed transmitter fails, it is possible to change driving direction at speeds above 15 km/h (9.32 mph) however there is a risk of damage to the transmission since a failure of the speed sensor enables a higher reversing speed.
 - When changing driving direction above 15 km/h (9.32 mph) the transmission automatically shifts to Neutral. This is indicated to the driver on the display and an acoustic warning signal
 - Driving direction will not change until kept speed has fallen below the reversing speed limit 15 km/h (9.32 mph).
 - If the operator accidentally selects a direction change above 15 km/h (9.32 mph) and immediately shifts back to the original direction the transmission restores power flow.
-

Shifting Gears: Overview

Table 3-4: Transmission Operation with EZ-Command Center

1	Cruise: To activate cruise, press the button (1) once this will activate the last saved auto shift mode.
F	Forward: Press and hold the shuttle enable button (2) on the back of the EZ-Command Center. Then press the Forward button (3).
R	Reverse: Press and hold the shuttle enable button (2) on the back of the EZ-Command Center. Then press the Reverse button (4).
5	Ratio Lock: To activate ratio lock button, press the button (5). For more information. refer to “Operating Ratio Lock Button” on page 3-44.
Push the EZ-Command Center to speed up, the longer it's held the faster the travel speed will be. Release the lever to stay at the correct speed.	
Pull the EZ-Command lever back to reduce speed, the longer it's held, the slower the slower the travel speed will be. Release the lever to stay at current speed.	




Engine Rpm Preset

Buttons A (1) and B (2) are the engine rpm presets, which allow you to preset a desired engine rpm.

The operator can also use the virtual switches in the monitor.

- You cannot use the engine presets if the unit is at low idle as the presets will be locked out. To enable the engine rpm presets you must increase the engine rpm with the hand throttle to at least 1000 rpm.
- Once the engine rpm reaches 1000 rpm and one of the preset buttons is selected the engine rpm will increase to the desired rpm.




Engine/Transmission Continuously Variable Transmission (CVT) Settings

Various settings of the Continuously Variable Transmission (CVT) can be made and checked. The engine rev-limiter, engine rpm memory and other settings can also be set.

Icon	Description
1	Engine RPM (A/B indicator)
2	Engine rpm
3	Mode shift (Hi/Lo) indicator
4	Shuttle lever Indicator
5	Engine RPM memory (B) control
6	Engine RPM memory (A) control
7	CVT low-range max. speed

Icon	Description
8	CVT high-range max. speed
9	Cruise control low-range set speed (Forward)
10	Cruise control high-range set speed (Forward)
11	Cruise control low-range set speed (Reverse)
12	Cruise control high-range set speed (Reverse)
13	Engine RPM memory (B) control
14	Engine RPM memory (A) control
15	Engine rev-limiter control
16	CVT response control
17	CVT droop control



CVT (Continuously Variable Transmission) Control



WARNING

To avoid personal injury or death:



The ez-command center has no neutral position. To bring the tractor to a complete stop, step on the brake pedal or set the shuttle lever to neutral.

The CVT (Continuously Variable Transmission) is a fully computerized stepless type. Depending on the type of work, there are two modes to choose from: “Automatic” and “Manual Engine Speed Setting”.

Other settings are also possible at will, including CVT droop in response to engine load, response control for start and stop, and cruise control among others.

Traveling Operation

Traveling speed control for a tractor with CVT transmission can be operated with either the ez-command center or the foot throttle. Choose between them according to the job.

Note that control using the foot throttle requires the selection of “Automatic Mode” as discussed below. The operator can control both the speed and the engine power by how deeply you step on the foot throttle, as with an automatic transmission car; this enables convenient operation of the trailer and so on.

Main shift

With the ez-command center (1), the machine can be “sped up” and “slowed down” easily.


Push the lever forward and pull it backward, and the traveling speed will increase and decrease respectively.

The traveling speed is fixed at the position where you release the lever.

The traveling speed changes in proportion to the duration of moving the lever. The longer the lever is pushed forward, for instance, the higher the traveling speed becomes.


NOTE:

- The ez-command center has no neutral position. Even when the lever is set at the lowest speed position, the machine runs at the creep speed (about 0.5 km/h (0.3 mph). To bring the tractor to a complete stop, step on the brake pedal or set the shuttle lever to neutral.
- Allowing for conditions, use the “Cruise Mode” discussed below when you want to make fine adjustments to the traveling speed, or to keep the traveling speed steady for a job with a high traction load on the tractor.
- When the ez-command center is pushed forward during the tractor driving by using foot throttle, the traveling speed is set at the time of ez-command center operation. But this setting is effective for only when the tractor has a light load.




Modifying the CVT Droop setting

1. Touch the CVT droop control (1) and the setting screen shows up.
2. To adjust CVT response droop either touch and drag the slider (2) to the desired number. Or used the + or – switches to move to the desired number.
3. Press the switch (3), and the setting is saved and the previous screen reappears.





Modifying the CVT Response setting

1. Touch the CVT response control (4) and the setting screen shows up.
2. To adjust the CVT response setting either touch and drag the slider (5) to the desired number. Or used the + or – switches to move to the desired number. Ideally, set the response level to low for towing heavy-duty implements and operating on slopes.)
3. Press the switch (3), and the setting is saved and the previous screen reappears.



Modifying the CVT Low-range max. speed setting

1. Touch the CVT Low-range max. speed control (1) in the above figure, and the setting screen shows up.
2. Slide the graph (2) farther to the right (increasing value) to increase the traveling speed available in the low-speed range. The traveling speed in the low-speed range may be preset up to 20 km/h (12.4 mph). This setting cannot be modified for the high-speed range.
3. Press the switch (3), and the setting is saved and the previous screen reappears.



Operation of the Manual Engine Speed Setting Mode

This mode mainly serves for PTO-driven implements like harvesters. The optimum traveling speed and engine power are obtained according to the engine rpm setting made with the hand throttle as well as the setting made in “Setting the CVT (Continuously Variable Transmission) droop”.

Switching to the manual engine speed setting mode

1. Set the shuttle lever to neutral. Or press the shuttle neutral button.
2. Accelerate the engine using the hand throttle, and the manual engine speed setting mode is selected.

Operation


1. Select the PTO shaft rpm and traveling speed according to the implement in question.
 2. Even if the load is increased or decreased, a constant PTO shaft rpm is kept up.
 3. Needless to say, towed implements without any PTO shaft rotation may also be used in this mode.
-

Operating Ratio Lock Button

The ratio lock is used to lock the transmission ratio to aid in preventing the tractor from losing control when deceleration down a hill with a heavy load being towed behind the tractor. On a steep incline a sudden deceleration of the tractor via the foot throttle slows down the transmission abruptly. As a result due to the heavy load the tractor can be pushed down the hill and control can be lost. To prevent this:

Press the ratio lock button (1) to lock the transmission gear shift before releasing the foot throttle (2). This will allow the transmission and engine to slow down the load to some extent.

Afterwards press ratio lock button again to disengage the ratio lock and allow the transmission to gear shift down. Step on the brake pedals (3) to bring the tractor and load to a stop.



CVT (Continuously Variable Transmission) Droop Setting


The CVT droop setting (1) varies with a selected mode, “Automatic” or “Manual Engine Speed Setting”.

Automatic mode

1. As the droop setting in the graph below is increased, the machine can be sped up or slowed down in the low-level engine rpm range. In case of light-duty loads, high-speed energy-saving run is allowed even in the low engine rpm range.
2. As the droop setting in the graph is decreased, the machine can be sped up or slowed down in the highlevel engine rpm range. This is suited for heavy-duty operations.

Manual Engine Speed Setting mode

1. As the droop setting in the graph below is increased, the traveling speed is also controlled, even in the engine rpm range below the range preset with the hand throttle. In case of light-duty loads, high-speed energy-saving run is allowed even in the low engine rpm range.
2. As the droop setting in the graph is decreased, the traveling speed is controlled so as to remain within the rpm range of the hand throttle. This is suited for heavy-duty PTO-driven implements, such as harvesters, which are adversely affected by rpm fluctuations.



CVT (Continuously Variable Transmission) Response Setting




WARNING



While the trailer is running, the ez-command center cannot be used for a sudden slow down. For a sudden slow down, step on the brake pedals.

1. Touch the CVT response setting graph (1) and the slider in the graph moves to the touched point. Then the “+” or “-” to adjust the setting.
2. Slide the graph farther to the right to enable more responsive rev-up and slow-down. When the working efficiency is enhanced in light duty jobs, increase the response droop. For heavy duty jobs with a trailer or on a grassland, decrease the response droop.



Cruise Control

The traveling speed may be flexibly preset with the ezcommand center. To keep the traveling speed at a constant level, however, make the cruise control setting. The cruise control can be preset in 4 different conditions for high range speed and low range speed as well as for forward and reverse respectively. The respective preset speed value is memorized when the cruise control is activated once. Thus, the set speed is not memorized if there is no record for cruise activating. Set the cruise control to "ON", and "CRUISE" and "Cruise preset speeds" appear in the LCD indicator on the instrument panel.

Setting the cruise control

To set cruise control, use either of the following procedures.

Setting cruise control with ez-command center

1. Push the ez-command center (1) forward until a desired traveling speed is reached.
2. Press and hold down the cruise button (2) (for 3 seconds), and the cruise control is enabled. 2 audible sounds will be heard to inform the operator that the current speed is saved and the machine runs at this speed.




Calling the memory speed

A single touch on the cruise button (2) while in motion makes the machine run at the previously set cruise speed. Hold down the cruise button, and the current speed is recorded as cruise speed.

Setting the traveling speed with the foot throttle

1. Step on the foot throttle (3) until a desired traveling speed is reached.
2. Press and hold down the cruise button (2) (for 3 seconds), and the cruise control is enabled. 2 audible sounds will be heard to inform the operator that the the current speed is saved and the machine runs at this speed.



Increasing/Decreasing cruise once set

Once cruise is set, the operator can increase or decrease the set cruise speed with the ez-command center (1).

1. To increase cruise speed setting, bump the ez-command center (1) forward. The set cruise speed will increase.
2. To decrease cruise speed setting, bump the ez-command lever backward. The set cruise speed will decrease.

NOTE: The new cruise speed will not be automatically saved. To save the new cruise speed, press and hold the cruise button for 3 seconds till the audible beep is heard.



Re-calling saved cruise speed setting

Put the tractor in motion. Press the cruise control button (2) once on the ez-command center to activate the previously saved cruise setting. Press once again to de-activate cruise control. An audible beep will be heard when cruise is engaged.

1. Cruise control can be for turtle and rabbit speed modes and can also be set for forward and reverse.
2. Cruise control can only be activated when the tractor is in motion and traveling at, at least 10% of the saved cruise setting.
 - For example: If cruise preset speed is 20 km/h (12.4 mph) then tractor must be travelling faster the 2 km/h (1.2 mph) before cruise can be activated and tractor will travel at the cruise speed.



3. Cruise can be cancelled by performing one of the following:
- Stepping fully on both brake pedals (1).
 - Pressing the cruise button (2).
 - Putting the transmission into neutral (3).


NOTE: When cruise is cancelled the saved cruise setting is **NOT** erased.

NOTE: While cruise is active, if the foot throttle is pressed past the set point of cruise. The tractor will increase its speed till the foot pedal is release and the previous cruise speed is resumed.

NOTE: The memory value will not be deleted whichever method you use to clear cruise control. Even if you turn the key switch off, the memory value remains.

NOTE: Press the cruise button again while running, and the cruise control turns on. The machine can be run at the preset traveling speed.

NOTE: When the cruise control is activated in the state as which speed is not memorized, the tractor will stay at creep speed (approx. 0.5 km/h (0.3 mph)).



Exterior and Interior Lights

This section explains how to operate all of the lighting on the tractor.

Exterior lighting:

- Worklights (Halogen or LED if equipped)
- Turn signals / Hazard / Extermity lights
- High / Low Beams
- Brake lights (also rear turn signals)

Interior cab lighting:

- Dash lighting
- Ceiling dome light
- Overhead console light

NOTE: The brake and signal lights flash at double-speed if they are malfunctioning. See Section 5: Lubrication and Maintenance for information on replacing lights.

Exterior Light Identification





Table 3-6: Exterior Worklights

1	Front worklights x 6
2	Front cab worklights x 4
3	Cab side worklights x 4


Table 3-6: Exterior Worklights

4	Front Extremity / Hazard / Turn Signal Lights x 2
5	Rear cab worklights lights x 4
6	Brake lights/turn signal/hazards
7	Rear Extremity/Hazard Lights x 2

Exterior Worklights

Exterior worklights are controlled by worklight switch (7) located on the cab accessory panel (8) above the driver's seat. Press the button to activate front or rear worklights.

An indicator light will appear beside the button when to indicate active status.



Multifunction Switch


The multifunction switch (1) is located on the left side of the steering column. Table 3-7 explains how to operate the switch.

Table 3-7: Multifunction Switch Operation

Ref	Description
2	OFF: To deactivate the lights, rotate the multifunction to Off  .
3	Worklights: Rotate the switch forward once to activate road lights and back lighting.
4	Low beams/Night Mode EIC: To activate the low beams and night mode on EIC, rotate switch into position.
5	Signal Left Turn: Lift the switch up. The left turn flasher on the EIC will flash in unison with the left turn signal light. Signal right turn: Push the switch down. The right turn flasher on the EIC will flash in unison with the right turn signal light.
6	Horn: Push to activate the horn.

To activate high beams:

- Pull the multifunction switch up to momentarily activate high beams.
- Push the multifunction down to keep high beams on.



Hazard Warning Lights



WARNING




Always look before exiting the cab on a public roadway. Turn hazard warning lights on to signal other motorists to give the tractor a wide berth when passing or to slow down.

The hazard warning lights switch (1) activates the tractor hazard warning lights located on the extremity bar.

- To activate the lights, press the rocker switch forward.
- To deactivate the lights, press the rocker switch backwards.



The hazard warning lights warn other drivers the tractor is experiencing a problem. The hazard warning lights are designed to warn other drivers that the tractor is experiencing a problem. This could mean the tractor is traveling at a reduced speed on a public road, is pulling off to the side of the road or is already on the shoulder.

The turn signal light indicators on the dash will flash (when key switch is on).



Extremity/Hazard and Turn Signal Lights

The extremity lights (1) are installed on light bracket covers on the aftertreatment shield (2) and onto the air intake snorkel (3).



Interior Cab Lights



- An interior cab dome (1) light is activated by pressing the ends of the light.
- The console light is activated when the cab door is opened and remains on whenever the key switch is on.
- The interior dash display lighting is activated on the multifunction switch.



Windshield Wiper – Operation

The windshield wiper controls are controlled on the multifunction switch (1) located on the left side of the steering column.

- **OFF** (○): To deactivate the wipers, rotate the multifunction to Off ○ (2).
- **Front wiper control** : Rotate multifunction switch forward to activate front wiper (3). This activates intermittent wiper timing.
- **Front windshield washer control** : Rotate multifunction backward to activate front windshield washer (4).
- **Wiper settings L and H**: Rotate to adjust intermittent wiper timing (low or high) (5).
- **Rear wiper control** : Press the rear wiper rocker switch up to activate the rear wipers (6).
- **Rear intermittent wiper control** : Press the rear wiper rocker switch down to activate the rear wiper intermittent setting (7).
- **Rear windshield washer control** : Press the rear windshield washer rocker switch to activate the rear windshield washer (8).




Auto Steer

Consult the Auto Steer operator's manual for more information on Auto Steer operation and features.

Rotary Beacon (option)

Make sure the rotary beacon (1) is installed and operational:

- The rotary beacon can be mounted on the left or right side of the cab.
- To activate, press the button once (2).
- To deactivate, press the button again.



Differential Lock

The M8-181 and M8-201 tractor are equipped with front and rear axle differential locks. Differential locks improve traction on hillsides or wet ground.



CAUTION



Do not use the differential lock when driving the tractor on roads or steering may be impaired.

NOTICE

- Do not engage the differential lock when the tractor wheels are spinning or when the wheels are turning at different speeds, such as an end of the field turn. Drivetrain damage may result.
 - Reduce engine speed before engaging the differential lock to avoid shock loads to the driveline if a rear wheel spins at high speed.
 - Always disengage the differential lock when not required, such as during high speeds and road travel, turning and parking or when additional traction is not needed.
-

A self-holding differential lock is installed in the rear axle to lock the rear wheels together in conditions where wheel slip is encountered.



Units equipped with Traction Control System (TCS) traction management four-wheel drive also come with a fully locking electro-hydraulic engagement front axle differential lock.

The differential lock will lock the rear differential only in two-wheel drive mode. Both front and rear differentials will lock when the differential lock is engaged with the MFWA.

NOTE: In the auto operation mode, the differential lock will disengage if one brake is applied or if the unit is operated above 20 km/h (12.4 mph). In manual operation mode, the differential lock will not disengage.



Differential Lock Operation

1. Press the differential button (1) on the operator console (2) to enable/disable the differential lock.
2. Touch the left half of the differential lock switch (3) and the differential of the full-time front (if equipped) and rear wheels gets locked. The indicator (4) lights up and stays on.
3. Turn off the differential lock switch (3) and the differential gets unlocked and the indicator (4) goes off.
4. Touch the left half of the auto differential lock switch (5) and both indicator lights (3) and (6) lights up. Same procedure for disengaging.



Front Wheel Drive Setting

1. Press the differential button (1) on the operator console (2) to enable/disable the differential lock
2. Touch the left half of the 4WD switch (2) and the front and rear wheels are driven. The indicator (3) lights up and stays on.
3. Turn off the 4WD switch (2) and the front-wheel drive is disabled and the indicator (3) goes off.
4. Touch the left half of the Auto 4WD switch (4) and the automatic 4WD and both indicator lights (3) and (5) lights up. Same procedure for disengaging.



TCS – Steering Angle and Speed Charts

The TCS system uses the steering angle sensors and the ground speed to help keep the tractor within safe operating limits.

The TCS will switch off the mechanical front wheel assist and differential lock based on the steering angle measured at the front axle and the speed of the tractor.

NOTE: The differential lock and the MFWD are subject to different conditions and limits.

- MFWD will disengage when the tractor's speed is between 0 - 10 km/h (6.2 mph) in auto operation mode when the steering angle is at 18° to the left or to the right.
- MFWD will disengage when the tractor's speed is between 10 (6.2 mph) - 20 km/h (12.4 mph) in auto operation mode when the steering angle is at 13° to the left or to the right.
- MFWD will disengage permanently when the tractor's speed is more than 20 km/h (12.4 mph) in manual or auto operation mode.
- Differential lock will disengage when the tractor's speed is between 0 - 10 km/h (6.2 mph) in auto operation mode when the steering angle is at 15° to the left or to the right.
- Differential lock will disengage when the tractor's speed is between 10 - 15 km/h (9.3 mph) in auto operation mode when the steering angle is at 10° to the left or to the right.
- Differential lock will disengage permanently when the tractor's speed is above 15 km/h (9.3 mph). whether in manual or auto mode.

Turn off MFWD when a tight turn will be made. This will increase front tire life, decrease force put on the front axle and let the tractor turn more tightly.


Steering Angle Sensor

The M8-181 and M8-201 can be equipped with a steering angle sensor (1). This sensor measures the turning angle so that the differential locks disengage properly and FWA disengage and engage properly in auto mode.

If the locks are not disengaging when you turn the sensor 20°, then you need to:

- Check that the steering angle sensor (1) wiring harness is connected properly.
- Recalibrate the sensor. See "Steering Angle Calibration" on page 2-36.

NOTE: Recalibrate the sensor after updating any software.




Suspended Axle

The M8-181 and M8-201 can be equipped with a front suspended axle

The front axle consists of an axle housing, differential assembly and a final drive assembly at each end.

Identification Plate

The front axle identification plate (1) is located on the left rear of the front axle.



The following information is found on each identification plate (1):


- Axle Type
- Total Ratio
- Serial Number
- Model Number



Component Identification and Function



Front Axle (Lockable Differential shown)

- Final Drive Assembly (1)
- Wheel Hub (2)
- Swivel Housing (3)
- Axle Housing (4)
- Differential Assembly (5)
- Pinion Gear (6)
- Differential Housing (7)



Front Axle Dimensions

Ref	Description	mm (in)
A	Planetary Carrier to Planetary Carrier	2253 (88)
B	Swivel Housing to Swivel Housing	1930 (76)
C	Planetary Cover Diameter	279 (11)
D	Wheel Stud to Wheel Stud Diameter	305 (12)



Front Axle Specifications

Table 3-9: Dana Axle Code

Standard Steer/Limited Slip Differential	CA140490
Standard Steer/Lockable Differential	CA140491

Table 3-10: Dana Axle Model

Standard Steer/Limited Slip Differential	20.80 ACP
Standard Steer/Lockable Differential	20.80 ACP

Table 3-11: Dry Weight

Standard Steer/Limited Slip Differential	770 kg (1697 lb)
Standard Steer/Lockable Differential	778 kg (1715 lb)

Table 3-12: Lubrication Fluids

Oil	SAE80W/90 (API GL4 or GL5)
Grease	Lithium-based EF High Temperature with Moly

Table 3-13: Lubrication Fluid Capacity

Differential Oil	14.5 L (3.83 gal)
Final Drive Oil	5 L (1.32 gal) Each

Table 3-14: Measurements

Final Drive Reduction	7.000/1
Bevel Gear Reduction	3.083/1
Total Reduction	21.583/1
Input Rotation	Counterclockwise (CCW)
Steering Angle	Max 55
Toe-In	0 mm plus or minus 2mm (0–0.079 in.)
Ring and Pinion Gear Backlash	0.25–0.33 mm. (0.009–0.012 in)
Input Flange End Play	0.00–0.10 mm (0.00–0.004 in)
Swivel Housing Backlash	0
Pinion Bearings "P" Rotation Pull (measured D = 39.7 mm (1.59 in) (without seal)	2–4 N•m (1.4–2.9 lb-ft)
Total Pinion-Ring Gear Bearing Pull "T" (measured D = 39.7 mm (1.59 in) (without seal) Standard Steer/Lockable Differential	6–6.5 N•m (4.4–4.7 lb-ft)

NOTE: 1daN = 1kg = 2.2lb


Front Axle Lubricants

Brand	Type
Imperial Oil Esso	GX
Shell	Spirax S3 AX
Texaco	Multigear
Petro Canada	TRAXON
Exxon Mobil	Mobilube

Component	Fluid Type	Type
Differential	Gear Oil	SAE 80W/90 (API GL5)
Final Drive	Gear Oil	SAE 80W/90 (API GL5)
Miscellaneous	Grease	Lithium-Based EP High Temperature

Front Suspension Setting

1. The front suspension has the “Block” or “Active” modes.
2. Active mode is like auto mode, when the block switch (1) is pressed to the left and is turned on, the suspension is now in active mode and the indicator light (2) will turn on.
3. Press the block switch (1) to the right and the suspension is now blocked and the indicator light (2) will turn off. The axle will now act like a rigid axle.



Language and Units of Measurement

Using either the display monitor or the electronic instrument cluster (EIC) you can:

- Change the display language
- Change the units of measurement to metric or imperial


See the following pages for details.

Method 1: Use Display Monitor to Change Language, Units of Measurement or Display Brightness

NOTE: This only changes the setting in the monitor not on the EIC.


To adjust display settings, press the arrows buttons (1) and select the gear mark icon (2).

To switch from System settings screens 1 and 2, press the arrows buttons.



System settings screen 1


- Sound volume (1): Slide the graph farther to the right to increase the volume.
- Screen brightness (2): The brightness level can be selected from the following settings:
 - Sun icon: Daytime mode
 - Moon icon: Night time mode
 - AUTO: Automatic daytime/night time switching mode.
- Daytime mode screen brightness (3): Slide the graph farther to the right to increase the brightness.
- Nighttime mode screen brightness (4): Slide the graph farther to the right to increase the brightness.



System settings screen 2

- Units of measurement (1): Press the arrow buttons to change the units of measurement to metric or imperial.
- Decimal marker setting (2): Press the arrow buttons to change between (comma) and (period).
- Language (3): Press the arrow buttons to change the languages to 8 different languages
 - English, Dutch, German, French, Italian Spanish, Polish and Portuguese.
- Live view camera display switching (4):
 - Live view camera can be chosen from the following:


- “X”: When the camera is installed for front view.
- “V”: When the camera is installed for rear view.




EIC Overview: Language

Use the Language screen to change the language to English or French:

1. Press the left button (1) to scroll down till Language (2) is highlighted.
2. Press the right button (3) to select the sub-menu.




3. The subscreen (4) appears.
4. Press the left button to select English or French (5).
5. Select Back to save the settings.




EIC Overview: Unit of Measure Screen

Use the Unit of Measure screen to change the units to Metric or Imperial:

1. Press the left button (1) to scroll down till the Units (2) is highlighted.
2. Press the right button (3) to select the sub-menu.



3. The subscreen (4) appears.
4. Press the left button (1) to select Metric (5) or Imperial (6).
5. Select Back (7) to save the settings.



Software

Check the software currently installed on the EIC and VCU using the electronic instrument cluster (EIC).


- Check with a Kubota dealer for information on software updates.

See the following pages for details.


Use EIC to Check Software

Use the Version Information (1) screen on the EIC to check software details and to confirm if the correct software is installed in the tractor:

1. Press the left button to scroll down till Version (2) is highlighted.
2. Press the right button (3) to select the sub-menu.



3. The subscreen (4) appears.
4. The software version appears (5).
5. Select Back to save the settings.



Trailer Socket



The trailer socket (1) is attached to the hydraulic remote coupler bracket at the rear of the tractor. It is a 7-pin (ISO 1724) connector that can be used for a trailer light hookup. The accompanying 2-pole (ISO 4165) socket can be used as a convenient auxilliary power source.

All circuits have a maximum of 15A. The pins in the socket and the 2-pole socket are identified as follows:

Table 3-16: Trailer Socket Overview

2	Pin 1 – Ground
3	Pin 2 – Work Lights
4	Pin 3 – Left Flasher
5	Pin 4 – Stop Lights
6	Pin 5 – Right Flasher
7	Pin 6 – Tail Lights
8	Pin 7 – Auxiliary (key switched 12 V source protected by a 20 A fuse).

Contact a KUBOTA dealer to purchase a male connector to accommodate a trailer wire harness.



Tires

Check the tire air pressure and recheck every 50 hours or weekly.

Inspect for damaged tread and side walls when checking tire pressure.



WARNING

Inflating or servicing tires can be dangerous. Use trained personnel to service or install tires whenever possible. Follow the safety precautions below to avoid the possibility of serious or fatal injury:

Tractor wheels are very heavy. Handle with care and make sure that they cannot topple and cause injury when stored.

Never attempt tire repairs on a public road or highway.

Make sure the jack is placed on a firm, level surface.

Make sure the jack has adequate capacity to lift your tractor.



Use jack stands or other suitable blocking to support the tractor while repairing tires.

Do not put any part of your body under the tractor or start the engine while the tractor is on the jack.

Never hit a tire or rim with a hammer.

Make sure the rim is clean and free of rust or damage. Do not weld, braze, otherwise repair or use a damaged rim.

Do not inflate a tire unless the rim is mounted on the tractor or is secured so that it will not move if the tire or rim should suddenly fail.

When fitting a new or repaired tire, use a clip-on valve adaptor with a remote gauge that allows the operator to stand clear of the tire while inflating it. Use a safety cage, if available.

Tire air pressure affects the amount of weight that a tire may carry. Locate the tire size for your tractor in the Tire Pressure and Permissible Loads tables in Section 3. Do not exceed the load for the pressures listed. Do not over or under inflate the tires.



WARNING

Do not inflate a steering tire above the manufacturer's maximum pressure shown on the tire or beyond the maximum shown in the Tire Data Combinations Pressures and Loads tables in Section 7 if the tire is not marked.

Never inflate a traction tire (front tire on a four-wheel drive tractor or any rear tire) over 241 kPa (35 psi). Deflate the tire, re-lubricate the bead with a soap/water solution and reinflate if the bead does not seat on the rim by the time this pressure is reached,. Do not use oil or grease. Inflation beyond 241 kPa (35 psi) with unseated beads may break the bead or rim with explosive force sufficient to cause a serious injury.



Adjust inflation pressure to the recommended operating pressure after seating the beads.

Do not re-inflate a tire that has been run flat or seriously under inflated until it has been inspected for damage by a qualified person.

Torque wheel hardware after driving the tractor for 200 m, after one hour and 10 hours operation and thereafter at the 50-hour service intervals.

Refer to Ballasting and Tires in Section 3.

Tire Selection



WARNING

Always make sure the tires and wheels are properly spaced and do not interfere with other tractor components. Make sure the steering stop angle is within the turning range of the tires.



NOTICE

Do not attempt to mount tire sizes other than those factory listed for your tractor model. Unauthorized tire sizes will void your warranty and can cause damage to the drivelines.

Selecting tire size and type is important for achieving maximum tractor efficiency. Various tire size and types are available for the tractor. Refer to the tire selection table for approved tire sizes.

Tires selected for your tractor must be able to support the weight of the tractor and attached equipment. Tires must also supply adequate traction, yet minimize soil compaction, while maintaining an acceptable wheel slip when towing various implements with the drawbar.

Tire combinations, tire pressure, ballast and weight distribution need to be adjusted to achieve the best ride and performance. Soil condition and the type of work the tractor will perform will also affect tire choice and tractor adjustments.

Always maintain the proper air pressure. The tire must be able to safely support the load. Do not over inflate the tires. Radial tires work best with lower air pressures compared to bias ply tires. Radial tires will show up to 20% sidewall deflection (bulge) when properly inflated.

The force that enables the tires to drive the tractor must be transmitted through the sidewalls. The tractor will perform best when all the tires on the same axle have identical tire pressure. Spread the load from the implement evenly across the whole tractor so that the front and rear axles both support the same load.

Think of tires as shock absorbers. They must be able to respond equally to share and distribute your load.

Tire Maintenance Procedures

- Always maintain the proper air pressure in the tire to carry the load.
- Do not over inflate radial or bias ply tires.
- Radial tires will work with lower air pressures.
- Various tire types and sizes are available for the tractor. There is no such thing as the best tire for every job. Select tires according to their specific use. Selecting the correct tire ensures maximum tractor efficiency.

Factors Determining Best Tire Performance

Good Performance

- Proper air pressure for the load
- Proper sidewall deflection
- 8%–15% wheel slip
- Proper tire size for expected load
- Less than 50% fill of liquid ballast
- Maintaining equal tire pressure in all tires on a given axle

Poor Performance

- High or low air pressure
- Stiff sidewalls
- High or low wheel slip
- Overloaded or under loaded tire
- Treating tires on an axle differently

Refer to Ballasting and Tires later in this section for proper tractor weight procedures once the tire size has been selected.

Tire Combinations

The tires fitted to tractors with optional four-wheel drive have been carefully selected to match the gearing of the transmission and axles. When replacing worn or damaged tires, always install tires of the same make, model and size as those removed. The installation of other tire combinations may result in excessive tire wear, loss of usable power or severe damage to driveline components. If in doubt, contact a Kubota dealer.

Radial Tire Identification

Radial tires are identified by a star code on the tire sidewall:

1. Tires with ☆ are inflated to a maximum of 1.2 bar (18 psi).
2. Tires with ☆☆ are inflated to a maximum of 1.6 bar (24 psi).
3. Tires with ☆☆☆ are inflated to a maximum of 2.0 bar (30 psi).

Tire Pressures and Permissible Loads

NOTICE

The figures in the following tables are for guidance only. Tire specifications vary by tire manufacturer. For exact tire loading information, refer to the information provided by the manufacturer of the tires on the tractor.

To avoid the possibility of tire to rim creep, do not use tire pressures below 0.4 bar (6 psi) with radial tires and 0.8 bar (12 psi) with bias ply for operations having a high torque requirement (e.g., subsoiling, plowing, heavy cultivation, etc.).

Tire loading values in the following tables are for a single wheel. To determine the maximum tire loading for single wheel applications, multiply the load figure in the table by two and the total number of wheels on the axle.

Example:

Two rear wheels (singles) x table figure = maximum tire load

To determine the maximum tire loading for units with duals, multiply the load figure in the table by the total number of wheels on the axle, then multiply by 88%.

Example:

Four rear wheels (models with duals) x table figure x 88% = maximum tire load

Axle loading must be within the capacities listed in this manual.

Remember the information in the tables and the examples cited are for guidance only. For exact information regarding tire air pressures and tractor loading, contact a Kubota dealer or the tire manufacturer.

When front-mounted implements are fitted, front tire loads may be increased by up to 35% with no increase in inflation pressure when operated at speeds not exceeding 20 km/h (12 mph).

At speeds not exceeding 8 km/h (5 mph), the load on the front tires may be increased by 50% provided the tire air pressures are increased by 25%.

Table 3-17: Front Tire Pressures and Permissible Loads (four-wheel drive) Metric Units																			
Inflation Pressure (bar)																			
Radial Tire Size	Ply	☆Rating	0.40	0.50	0.55	0.60	0.70	0.80	1.00	1.10	1.20	1.40	1.50	1.60	1.80	1.90	2.00	2.20	2.30
Load Capacity (kg)																			
14.9-28	10	3	800	870	945	1010	1075	1195	1305	1415	1500	1615	1705	1800	1880	1960	2060		
16.9-28	8	2	965	1055	1145	1225	1300	1450	1590	1715	1850	1960	2070	2240					
14.9-30	10	3	820	900	970	1045	1105	1235	1345	1460	1550	1660	1760	1850	1940	2025	2120		
480/70-30		-	1180	1285	1400	1550	1650	1800	1900		2120	2360		2575	2800		3075	3350	3550
16.9-30	8	2	1000	1095	1180	1265	1345	1495	1640	1770	1900	2015	2130	2300					

Table 3-18: Front Tire Pressures and Permissible Loads (four-wheel drive) Imperial Units																			
Inflation Pressure (psi)																			
Radial Tire Size	Ply	☆Rating	6	7	8	9	10	12	14	16	18	20	22	24	26	28	30	32	34
Load Capacity (lb)																			
14.9-28	10	3	1760	1920	2080	2230	2370	2630	2880	3120	3300	3560	3760	3960	4140	4320	4540		
16.9-28	8	2	2130	2330	2520	2700	2870	3200	3500	3780	4080	4320	4560	4940					
14.9-30	10	3	1810	1980	2140	2300	2440	2720	2970	3220	3420	3660	3880	4080	4280	4460	4680		
480/70-30		-	2600	2830	3080	2420	3640	3960	4180		4680	5200		5680	6150		6800	7400	7850
16.9-30	8	2	2200	2410	2600	2790	3300	3620	3900	4180	4440	4700	5080						

Table 3-21: Rear Tire Pressures and Permissible Loads (Metric Units)																	
Inflation Pressure (bar)																	
Radial Tire Size	Ply	☆Rating	0.40	0.50	0.55	0.60	0.70	0.80	1.00	1.10	1.20	1.40	1.50	1.60	1.80	1.90	2.00
Load Capacity (kg)																	
18.4-38	8	2	1345	1470	1590	1705	1805	2015	2205	2385	2575	2715	2880	3000			
20.8-38	10	2	1625	1780	1925	2060	2195	2440	2665	2880	3075	3290	3470	3650			
710/70-38		-	2430	2650		2900	3150	3350	3875		4375	4875		5300			
18.4-42	10	2	1415	1550	1680	1795	1905	2125	2320	2515	2725	2860	3015	3150			
20.8-42	10	2	1715	1880	2030	2175	2315	2575	2810	3040	3250	3470	3675	3875			
14.9-46	8	3	1025	1120	1210	1295	1380	1535	1680	1815	1950	2070	2195	2300	2415	2520	2650
420/80R46		-	1320	1450		1600	1750	1850	2220		2430	2650		2900	3250		
480/80R46	10	3	1490	1635	1760	1885	2005	2230	2450	2640	2800	3015	3175	3350	3515	3675	3875

Table 3-22: Rear Tire Pressures and Permissible Loads (Imperial Units)																	
Inflation Pressure (psi)																	
Radial Tire Size	Ply	☆Rating	6	7	8	9	10	12	14	16	18	20	22	24	26	28	30
Load Capacity (lb)																	
18.4-38	8	2	2960	3240	3500	3760	3980	4440	4860	5260	5680	5980	6350	6600			
20.8-38	10	2	3580	3920	4240	4540	4840	5380	5880	6350	6800	7250	7650	8050			
710/70-38		-	5360	5840		6400	6950	7400	8550		9650	10700		11700			
18.4-42	10	2	3120	3420	3700	3960	4200	4680	5120	5540	6000	6300	6650	6950			
20.8-42	10	2	3780	4140	4480	4800	5100	5680	6200	6700	7150	7650	8100	8550			
14.9-46	8	3	2260	2470	2670	2860	3040	3380	3700	4000	4300	4560	4840	5080	5320	5560	5840
420/80R46		-	2910	3200		3520	3860	4080	4680		5360	5840		6400	7150		
480/80R46	10	3	3280	3600	3880	4160	4420	4920	5400	5820	6150	6650	7000	7400	7750	8100	8550

Table 3-23: Rear Tire Pressures and Permissible Loads (Metric Units)														
Inflation Pressure (bar)														
Bias Tire Size	Ply	☆Rating	0.80	1.00	1.10	1.20	1.40	1.50	1.60	1.80	1.90	2.00	2.20	2.30
Load Capacity (kg)														
480/80R46	8	-			2387	2559	2718							
R1 20.8-38	10	-			1663	3100	3295	3486						
R2 30.5L-32	12	-			4145	4440	4722							
R2 20.8-38	10	-			2980	3100	3295	3486						

Table 3-24: Rear Tire Pressures and Permissible Loads (Imperial Units)														
Inflation Pressure (psi)														
Bias Tire Size	Ply	☆Rating	12	14	16	18	20	22	24	26	28	30	32	34
Load Capacity (lb)														
480/80R46	8	-			5250	5630	5980							
R1 20.8-38	10	-			6360	6820	7250	7670						
R2 30.5L-32	12	-			9120	9770	10390							
R2 20.8-38		-			6360	6820	7250	7670						

Wheels and Tires

Tire Selection

IMPORTANT: See page 3-85 for approved tire sizes and combinations. Do not attempt to install any size or combination that is not listed.

NOTE: The size of tire shipped with the tractor is recorded into the electronic instrument cluster (EIC) to correctly measure ground speed (wheel speed). If you change the size of tire at anytime, record the new size into the EIC. For instructions see “Recording Tire Size to Measure Ground Speed: Introduction” on page 3-86.

To optimize tractor performance, follow these principles:

- Choose a tire size and type appropriate for the expected load. See “Tire Selection” on page 3-78.
- Wheel slip shall be between 8 % - 15 %. Too little wheel slip may indicate the drivetrain is working too hard. Too much wheel slip indicates the wheels are spinning too much. Adjust the ballast, tire combination, tire pressure and/or load on the tractor as required.

The optional ground speed sensor (radar) measures wheel slip and will display the wheel slip on the EIC WHEEL SLIP screen. A slip threshold can be set up to warn the operator if there is too much wheel slip. If the tractor is not equipped with the optional ground speed sensor then the wheel slip has to be measured manually.

- Distribute the weight properly across the tractor. For drawbar applications, distribute 55 % of the weight across the front axle and 45 % of the weight across the rear axle. For 3-pt hitch applications, distribute 65 % of the weight across the front axle and 35 % of the weight across the rear axle.

Ballast the tractor using weight kits and/or liquid ballast added to the tires to adjust the weight distribution. Distribute liquid ballast evenly across all tires installed on the same axle.

- Make sure the air pressure is equal on all tires installed on the same axle. Adjust all tire pressures to the manufacturer’s specification.
-

Approved Tire Sizes and Combinations

Selecting tire size and type is important for achieving maximum tractor efficiency. Various tire size and types are available for the tractor. Refer to the tire selection table for approved tire sizes.

IMPORTANT: Tires selected for your tractor must be able to support the weight of the tractor and attached equipment.

Front	Rear	
	Single	Dual
380/85R34	380/90R50	380/90R50
380/85R34	480/80R46	480/80R46
420/85/R30	480/80R46 520/85R42 620/70R42	480/80R46 520/85R42
480/70R30	520/85R42	520/85R42
480/70R30	620/70R42	620/70R42
600/65R28	710/70R38	N/A

Recording Tire Size to Measure Ground Speed: Introduction

The size of tire shipped with the tractor is recorded into the electronic instrument cluster (EIC) to correctly measure ground speed (wheel speed). If you change the size of tire at anytime, record the new size into the EIC using 1 of these calibration procedures:

- **Tire Size Adjustment**

Use the subscreen to set the tire size manually. The tractor can be stationary while you set the tire size. See “Recording Tire Size to Measure Ground Speed Method 1: Tire Size Adjustment Screen” on page 3-87.

- **Wheel Speed Calibration**

Use the subscreen to detect ground speed more accurately than a manually-set tire size. See “Recording Tire Size to Measure Ground Speed Method 2: Wheel Speed Calibration Screen” on page 3-89.

- **Zero Slip Calculation (Ground Speed Sensor)**

If the tractor is equipped with the ground speed sensor then calibrate the sensor to automatically detects the tire size, ground speed and wheel slip conditions. See “Recording Tire Size to Measure Ground Speed Method 3: Zero Slip Calculation (Ground Speed Sensor)” on page 3-91.

Recording Tire Size to Measure Ground Speed Method 1: Tire Size Adjustment Screen

Use the Tire Size Adjustment screen to set the tire size without having to move the tractor. This data is used to calculate ground speed. Ground speed is used as a reference for other Tractor Performance Monitor settings.





Calibrating the tire size manually will replace tire size and ground speed data automatically calculated through the wheel speed calibration process or by the ground speed sensor (if equipped).

NOTE: Detecting the ground speed through the Wheel Speed Calibration or Zero Slip Calculation subscreen gives a more accurate ground speed reading and will automatically re-adjust the tire size data. This requires the tractor to be moving.

To record the tire size:

1. Press the scroll  (1) to cycle through the menu on the EIC until the CONFIG menu (2) appears. Press the select  (3).
2. Press the scroll  (1) to cycle through the menu on the EIC until the Next menu (4) appears. Press the select  (3).
3. Press the  (1) to cycle to Tire Size Adjustment (4).
4. Press the select  (3). The subscreen (5) appears.
5. Know the tire size. The tire size is the circumference calculated from the:
 - Tire width (example: 710/70R38).
 - Aspect ratio (710/70R38).
 - Rim diameter (710/70R38).
 - Select Submit to save the setting.

Tire Size entered into the Config screen is not the circumference.






Recording Tire Size to Measure Ground Speed Method 2: Wheel Speed Calibration Screen

Use the Wheel Speed Calibration screen to accurately determine tire size and ground speed. This data is used as a reference for the TPM functions.


Using the wheel speed calibration process will replace any tire size and ground speed data calculated by a manually-set tire size or by the ground speed sensor (if equipped).

To record the tire size:

1. Press the scroll  (1) to cycle through the menu on the EIC until the CALIBRATION menu (2) appears. Press the select  (3).
2. Press the scroll  (1) until the TIRE SIZE is highlighted (2). Press the select  (3).
3. Press the select  until "Start" is highlighted and press the select  to start the calibration.
4. On a smooth, hard surface, mark off a 100 m (328 ft) distance in a straight line. Make sure the start and finish lines are clearly marked.



- 5. Select a low gear and drive the tractor forward.
- 6. As the tractor crosses the start line, select Start (1) to start the calibration.




- 7. As the tractor crosses the finish line, select Stop (2) to stop the calibration.

NOTE: If calibrated wheel speed is out of range, the default setting will remain.

- 8. Press to return to the Wheel Speed Calibration top screen.

To return to the top screen at any time, select Back.





Recording Tire Size to Measure Ground Speed Method 3: Zero Slip Calculation (Ground Speed Sensor)

On a smooth, hard surface, with a distance of at least 100m (328 ft) in a straight line, start the tractor and move the tractor so it is lined up straight where you are going to perform the calibration. Place the tractor in neutral and apply the park brake. Do not turn off tractor.


NOTE: The tractor will need to be running and driven to perform calibration.

To perform Zero Slip Calibration:

1. Press the scroll  (1) to cycle through the menu on the EIC until the CALIBRATION menu (2) appears. Press the select  (3).
2. Press the scroll  (1) until the Zero Slip Calibration is highlighted (4). Press the select  (3).





3. Press the select  (1) until “Start” (2) is highlighted and press the select  (3) to start the calibration.
4. Push down the clutch pedal, release the park brake, select a low gear and range and slowly drive the tractor forward.
5. Press the select  (3) to start the calibration. Drive the tractor in a straight line for at least 100 m (328 ft). The calibration will automatically STOP once it has finished.



6. Press the select  (1) until “Back” (2) is highlighted and press the select  (3) to return to the Wheel Speed Calibration top screen.
7. Select “Back” (4) to exit the calibrations menu and return to the home screen.
8. Once the tire size calibration is complete, key off and wait till the vehicle controller is off. This will let the calibrated tire size to be stored in the vehicle controller.

NOTE: It only takes 10 seconds for the VCU to power down but wait till the EIC has completely twin of before keying back on.



Mechanical Front Wheel Drive (MFWD) Front Axle Track Spacing

Mechanical front-wheel drive (MFWD) tractors have fixed axle assemblies. However, the track width is adjustable to eight different settings by changing the wheel rim relative to the center disc, the rim and/or disc relative to the axle hub or by interchanging both front wheels.

The chart to the right shows the track spacings available by changing the wheel rim and disc positions relative to the hub.

Each drawing represents either a left hand wheel viewed from the rear or a right hand wheel viewed from the front.

NOTICE

Adjust the steering stops to maintain turning diameter and to provide clearance between the tractor, the tires and the fenders when the track adjustment is changed.

Table 3-26: Track Settings Hub and Wheel Placement

Track Settings Hub and Wheel Placement	Tire Size
1 549.4 mm (61 in)	380/85R34
1 651 mm (65 in)	480/70R30 380/85R34
1 752.6 mm (69 in)	480/70R30 380/85R34
1 854.2 mm (73 in)	600/65R28 480/70R30 380/85R34
1 955.8 mm (77 in)	600/65R28 480/70R30 380/85R34
2 057.4 mm (81 in)	600/65R28 480/70R30 380/85R34
2 159 mm (85 in)	600/65R28 480/70R30 380/85R34
2 260.6 mm (89 in)	600/65R28 480/70R30 380/85R34
2 057.4 mm (81 in)	600/65R28 480/70R30 380/85R34
2 159 mm (85 in)	600/65R28 480/70R30 380/85R34
2 260.6 mm (89 in)	600/65R28 480/70R30 380/85R34


Front Wheel Positions



WARNING



Do not rotate the wheel or start the engine when a front wheel on a four-wheel drive tractor is supported on a stand. The rear wheels may move and cause the tractor to fall off the stand. Always support wheels so that the tires are only just clear of the ground.



Use the following procedure to position the front wheels to obtain the desired track adjustment:

1. Position the front wheels straight ahead
2. Apply the parking brake and place blocks at the front and rear of the rear wheels
3. Jack up the front axle and place on jack stands
4. Remove the front wheel
5. Position the wheel disc and rim as required to achieve the desired track adjustment
6. Reinstall the wheel and torque the hardware in a diagonal pattern to the following:

Disc to hub (1) – 700 N·m (515 ft-lb)

Disc to rim (2) – 345 N·m (255 ft-lb)

NOTE: Torque all rim, disc and wheel bolts as specified. Operate for 200 m (218.72 yd) and re-torque. Repeat torque check after one hour, then at 10 hours or daily intervals until bolt torque remains constant. Check torque at 50-hour intervals thereafter.

NOTE: Make sure the V of the tire tread remains pointing in the direction of forward travel when interchanging left and right hand wheel assemblies.

7. Check the front wheel toe-in and steering stops for correct adjustment.

Wheel Toe-in


Checking Toe-in on Axles

Use the following procedure to check and adjust toe-in:

The correct toe-in is 0 to 6 mm (0 to 0.25 in).

1. Position the front wheels straight ahead
2. Mark the inside front of each rim at hub height; mark the rim where the tire and rim meet
3. Measure the distance (A) between the two marks
4. Drive the tractor forward until the tires rotate 180 degrees and the marks are at hub height at the rear of the wheels
5. Measure the distance (B) between the two marks
6. Subtract the front measurement from the rear measurement to get the toe-in
7. Ensure the toe-in is 0 to 6 mm (0 to 0.25 in).


Follow the procedure for the MFWD axle adjustment if adjustment is required.



Adjusting Toe-in – Standard Steer MFWD

To adjust the toe-in:

8. Loosen the jam nuts (1) on each side of the tie rod
9. Turn the tie rod tube (2) to adjust the toe-in to 0 to 6 mm (0 to 0.25 in)
10. Tighten the jam nuts (1) on each side of the tie rod
11. Check the adjustment of the steering stops.



MFWD Steering Stops



WARNING




Maintain all steering components in a reliable and satisfactory condition to ensure they operate safely and comply with legal requirements.

NOTE: The new type steering angle stop has a tapered head. Install these stops with the thick side (1) at the top.

A steering stop is incorporated at each end of the axle. The stops are adjustable and must be set to provide a minimum clearance of 38 mm (1.5 in) between the tires or fenders if installed and any part of the tractor with the wheels turned full left and right with the axle fully oscillated.


NOTE: If your tractor is equipped with optional front fenders, make sure there is adequate clearance under all operating conditions. Adjust the steering stops, as necessary. Fenders may have to be removed for 1524 mm (61 in) track spacing.



Adjust the steering stops at both ends of the axle to the same turn angle.

Loosen jam nut (2). Use a wrench on the head (3) of the steering angle stop and thread the stop in or out so it will contact the fixed axle stop (4) when there is at least 38 mm (1.5 in) clearance between the tire and tractor as previously described to adjust the steering angle stop. Lock the jam nut to maintain the adjustment.

Adjust the steering stop on the opposite side to the same turn angle. Check that both stops are adjusted to provide the specified clearance.



Rear Wheel Track Spacing



WARNING

Never operate the tractor with a loose wheel rim, disc or hub. Always tighten hardware to the specified torque and at the recommended intervals.

Tractor wheels are very heavy. Handle with care and make sure that they cannot fall and cause injury when stored.



The tractor is produced with lights that meet lighting regulations when operating or traveling on the public highway. You may be required to reposition the lights to comply with legal requirements. Before traveling on the highway, ensure that the overall tractor width does not exceed the local maximum permitted.

NOTE: Read this section completely before adjusting track width.

NOTE: The track width dimensions (width from tire center to center) shown may vary from actual measurements depending on specific wheel and tire combination and tire manufacturer.

Axle Lengths

Model M8-181 and M8-201 tractors are supplied with 2 rear axle specification:

Straight type axle 105 mm (100 in) in diameter, 2489 mm (98 in) overall length.

Straight type axle 105 mm (100 in) in diameter, 2997 mm (118 in) overall length.

NOTE: The rear wheel track spacings are shown in the following charts. Each drawing represents either a left-hand wheel viewed from the rear or a right-hand wheel viewed from the front.

A range of track settings are available by moving the wheel assembly in or out on the axle shaft at each disc-to-rim position.

Spacing dimensions indicate the distance between the center points of the tire tread.

Model M8-181 and M8-201 Tractors

Track Settings Hub and Wheel Placement	Tire Size
1 549.4 mm (61 in)	380/85R34
1 651 mm (65 in)	480/70R30 380/85R34
1 752.6 mm (69 in)	480/70R30 380/85R34
1 854.2 mm (73 in)	600/65R28 480/70R30 380/85R34
1 955.8 mm (77 in)	600/65R28 480/70R30 380/85R34
2 057.4 mm (81 in)	600/65R28 480/70R30 380/85R34
2 159 mm (85 in)	600/65R28 480/70R30 380/85R34
2 260.6 mm (89 in)	600/65R28 480/70R30 380/85R34
2 057.4 mm (81 in)	600/65R28 480/70R30 380/85R34
2 159 mm (85 in)	600/65R28 480/70R30 380/85R34
2 260.6 mm (89 in)	600/65R28 480/70R30 380/85R34

Table 3-28: Track Settings (Rear Tires 98" bar axle Estimate)




Track Settings Hub and Wheel Placement	Tire Size	Minimum Track Setting	Maximum Track Setting
	380/90R50 480/80R46	1 549.4 mm (61in)	1 701.8 mm (67 in)
	A380/90R50 480/80R46 520/85R42 620/70R42	1 750 mm (68.8 in)	1 968.5 mm (77.5 in)
	380/90R50 480/80R46 520/85R42 620/70R42 710/70R38	2 354 mm (92.6 in)	2 489.2 mm (98 in)

Table 3-29: Track Settings Hub and Wheel Placement (Rear Tires 118" bar axle Estimate)

Tire Size	Minimum Track Setting	Maximum Track Setting
380/90R50 480/80R46	1549.4 mm (61 in)	2209.8 mm (87 in)
380/90R50 480/80R46 520/85R42 620/70R42	1750 mm (68.8 in)	2476.5 mm (97.5 in)
380/90R50 480/80R46 520/85R42 620/70R42 710/70R38	2352 mm (92.6 in)	2794 mm (110 in)
380/90R50 480/80R46 520/85R42 620/70R42 710/70R38	2667 mm (105 in)	2794 mm (110 in)

Rear Wheel Track Adjustment



WARNING



Take suitable precautions, including the use of safety glasses, against the possibility of flying metal particles.



NOTICE

Do not use a torque greater than 407 N·m (300 ft·lb) on the pusher bolts. The use of penetrating oil between the wedge and axle shaft will be of benefit. Place a shaft protector over the end of the axle shaft and strike with a hammer to shock the wedge free if difficulty is experienced.

Adjustment of track spacing is achieved by sliding the complete wheel assembly on the axle shaft and/or by changing the rim and disc position.

To reposition the wheel on the axle shaft or to completely remove the wheel:

- Block the front wheels, front and rear and jack up the rear of the tractor until both rear wheels are off the ground. Support the rear of the tractor with blocking or stands. Position wheels with hole in the rim at the top.
- Loosen the two center wedge bolts (1) about 12 mm (0.5 in). Remove the four outer wedge bolts (2).
- Clean the bolts and threaded holes in the wedges before lubricating and installing the outer wedge bolts (1) for pushing the wedges. Tighten the outer wedge bolts evenly until the wedges loosen on the axle shaft. The wheel assembly will now be free to slide in or out on the axle shaft.




An optional wheel adjustment tool is available to move the loosened wheel in or out as required. Slide the stepped end (1) into the notch (2) between the wedges to use the tool. Attach the block (3) to the axle with one of the removed wedge bolts (4). Turn the adjusting bolt (5) in or out to move the wheel assembly.

NOTE: The tool is available through a Kubota dealer.

Set the wheel to the desired position on the shaft. Remove the pusher bolts and replace them in the outer holes (6).

Tighten the six wedge retaining bolts in increments of 68 N·m (50 ft-lb) until a final torque of 391 N·m (290 ft-lb) is achieved.



NOTICE

Tighten the wedges evenly.

Repeat the procedure on the other wheel, ensuring that both rear wheels are the same distance from the ends of the axle shafts.

NOTE: Check the torque of all six wedge retaining bolts on each wheel after driving the tractor for 200 m (218.72 yd), after 1 hour and 10 hours of operation and thereafter at the 50-hour service intervals.

Adjusting Rear Wheels



WARNING



Tractor wheels are very heavy. Handle with care and make sure that they cannot fall and cause injury when stored.

NOTE: It may be necessary to interchange the left- and right-hand wheel assemblies when changing from one track width setting to another. If so, be sure that the V of the tire tread remains pointing in the direction of forward travel.

Rear wheel track adjustment is effected by changing the position of the disc and/or wheel rim, relative to the rear axle.

In each position, a range of track settings may be achieved by moving the wheel assemblies in or out on the axle shafts.


Follow all steps outlined in Rear Wheel Track Adjustment to change wheel position.

Adjusting Pressed Steel Wheel

Remove the disc to hub bolts (1) after the rear axle is jacked up and blocked. Use a suitable lifting device to remove the wheel and store the wheel and tire where it won't fall over. Repeat the procedure on the opposite wheel and install where the first wheel was removed.

Torque the disc to hub bolts to 407 N·m (300 ft-lb) in 68 N·m (50 ft-lb) increments using a diagonal pattern.

NOTE: Check bolt torque after driving the tractor for 200 m (218.72 yd), after 1 hour and 10 hours of operation and thereafter at the 50-hour service intervals.



Adjusting Cast Center Wheel



WARNING



Never operate the tractor with a loose wheel or rim. Always tighten the bolts to the specified torque and check them frequently.


Remove the disc to rim attaching hardware (1) after the rear axle is jacked up and blocked. Remove the wheel using a suitable lifting device and store where it won't fall. Repeat this procedure on the opposite rim and install on the first disc. Remove wheel weights first, then position discs as required if the discs (2) are to be switched.

Reinstall the rim and weights and tighten all bolts and nuts.

Repeat the procedure on the other wheel.

Tighten the rim to disc retaining nuts uniformly in an alternate pattern, 68 N·m (50 ft-lb) at a time, until a torque of 597 N·m (440 ft-lb) for Grade 8 bolts is obtained.

NOTE: Check hardware torque after driving the tractor for 200 m (218.72 yd), after 1 hour and 10 hours operation and thereafter at the 50-hour service intervals.



Dual Rear Wheels



WARNING



Tractor wheels are very heavy. Handle with care and ensure, when stored, that they cannot fall and cause injury.

NOTE: Dual rear wheels may only be installed on tractors with 2336 mm (92 in) or 3048 mm (120 in) rear axles.

The outer wheel track spacing can be adjusted to a maximum of 3251 mm (128 in) and the inner wheel to a minimum of 1524 mm (60 in). Position the wheels on the axle to achieve the desired track spacing. Refer to Outer Wheels and Inner Wheels in this section.

Dual rear wheels may be installed on tractors equipped with the 2336 mm (92 in) or 3048 mm (120 in) axle.

View A shows inner small hub pressed steel dual wheel configuration.

View B shows inner large hub cast hub dual wheel configuration.

Outer Wheels

The outer wheels (6) are pressed steel wheels. They are bolted to extension hubs (7) that are clamped to the axle shafts using wedges (8).

The hub to wedge attaching hardware can be installed in either of two positions to make removal easier depending on wheel spacing.

Option 1



Install six 76 mm (3.0 in) long wedge-to-hub bolts (9) from the wedge side as shown.

Torque bolts to 391 N·m (290 ft-lb).

Option 2

Install four 178 mm (7.0 in) long wedge-to-hub bolts (10) from the hub side as shown.

Torque bolts to 391 N·m (290 ft-lb).



NOTICE

These 178 mm (7.0 in) long bolts are included in the optional dual wheel kit available from a Kubota dealer. Do not use the standard (shorter) wedge bolts.

Tire Clearance


A minimum clearance of 102 mm (4.0 in.) must be maintained between the sidewall of the tires measured at the closest point (1). Make sure the tractor is properly ballasted and the implement attached to accurately measure the tire clearance.



WARNING



Make sure it is securely supported before removing a wheel.



Wheel Removal/Installation

Proceed as follows to remove the outer wheel:

- Block the front wheels, front and rear, then jack up and support the rear axle.
- Remove the 10 wheel-disc-to-hub bolts from the wheel and lower the wheel to the ground using a suitable lifting device. Repeat on the other wheel.

When reinstalling the outer wheels, torque the disc to hub bolts in an alternate pattern to 800 N·m (590 ft·lb).

Inner Wheels

The manual adjust inner wheels can be adjusted in the same way as manual adjust single wheels. However, limited track settings may be achieved due to interference between inner and outer tires or between the inner tires and the fenders.

Before adjust the inner wheels remove the outer wheels as described under Outer Wheels.


Follow the instructions under Rear Wheels Track Adjustment earlier in the section to adjust the track width of the inner wheels.

NOTE: Drive the tractor for 200 m (218.72 yd) then check the wheel hardware torque. Check the wheel hardware torque daily for the next 50 hours of operation and then at each 50-hour service interval.

Adjusting Front Fenders (Suspended Axle)

Suspended axles are equipped with dynamic front fenders (1). The spacing (height, pitch, fender swivel stop and distance from side of tractor) is specific to the size of tire and fender.

- The following pages explain how to adjust the height (2), pitch (3), distance from the side of the tractor (4) and fender swivel stop length (5).
- Match your front tire size to the corresponding spacing position listed in Table 3-30 on page 3-109.



Adjust Fender Height and Pitch

- Follow the pitch and height specifications for your size of tire if available (see Table 3-30 on page 3-109).
- Remove the 2 nuts (1, Figure 1) and bolts (2) and lock washers securing the support arm (3) to the bracket (4).
- Adjust the height and pitch of the support fender. Secure the support arm (3, Figure 2) to the bracket (4) with a bolt (2) in one of the slotted holes (5) and in one of the 3 top holes (6).
- Secure bolts with lock washers and nuts. Tighten nuts.





Figure 2: Showing the bolts (1) nuts (2) securing the support arm (3) to the bracket (4).

Figure 1: Showing the bolts (1) nuts (2) securing the support arm (3) to the bracket (4).



Adjust the Distance between the Fender and the Side of the Tractor

- Follow the distance specification for your size of tire if available (see Table 3-30 on page 3-109). Distances are marked by distance location numbers 1–5 etched into the swivel support (1). Figure 1 shows the first hole (X) in the bracket (2) set to distance location 4.
- Remove the 2 nuts and bolts (3, Figure 1) on the swivel support. Position one of the holes (X or Y) in the bracket over one of the distance location numbers.
- Secure the bracket to the swivel support with bolts and nuts. Tighten nuts.





Figure 1: First hole (X) in the bracket (2) set to distance location 4.

Figure 2: Showing the bracket (2) secured to the fender swivel support (1).




Fender Spacing Specifications

Match your front tire size to the corresponding spacing position listed below.

Tire Size	FENDER	
	Fender Size	Spacing Position for Single Tires
Front (380/80R38)_ Rear (380/90R54)	480 mm	A
Front (380/80R38)_ Rear (480/80R50)	480 mm	A
Front (380/80R38)_ Rear (520/85R46)	480 mm	A
Front (380/85R34)_ Rear (380/90R50)	480 mm	A
Front (380/85R34)_ Rear (480/80R46)_R1W	480 mm	A
Front (380/85R34)_ Rear (480/80R46)_R1	480 mm	A


Spacing Position A (480 mm Fender, Single Wheels)

- For correct height and pitch: Install bolts (1) to the bracket holes as shown below. Install lock washers onto bolts.
- For correct distance: Move the first bracket hole (X) to location 4 and secure with bolts (2) as shown below.
- Tighten all nuts.




Spacing Position B (480 mm Fender, Single Wheels)

- For correct height and pitch: Install bolts (1) to the bracket holes as shown below. Install lock washers onto bolts.
- For correct distance: Move the first bracket hole (X) to location 4 and secure with bolts (2) as shown below.
- Tighten all nuts.




Spacing Position C (540 mm Fender, Single Wheels)

- For correct height and pitch: Install bolts (1) to the bracket holes as shown below. Install lock washers onto bolts.
- For correct distance: Install bolts (2) to the top slotted holes as shown. Align these slotted holes with location 3. The second bracket hole (X) will be offset of location 3 as shown.
- Tighten all nuts.




Spacing Position D (620 mm Fender, Single Wheels)


- For correct height and pitch: Install bolts (1) to the bracket holes as shown below. Install lock washers onto bolts.
- For correct distance: Move the **second bracket hole (X)** to location 3 and secure with bolts (2) as shown below.
- Tighten all nuts.



Spacing Position E (620 mm Fender, Single Wheels)

- For correct height and pitch: Install bolts (1) to the bracket holes as shown below. Install lock washers onto bolts.
- For correct distance: Move the second bracket hole (X) to location 3 and secure with bolts (2) as shown below.
- Tighten all nuts.





1. Front weight pack
2. Rear wheel weight discs

Ballasting and Tires

Maximum tractor performance is dependent upon proper ballasting and tire selection.

Selecting the proper size and type of front and rear tires is also important in achieving maximum tractor efficiency. Various tire sizes and types are available for the tractor. A KUBOTA dealer can assist with this subject.

The tires selected for the tractor must be able to support the weight of the tractor and equipment. The tires must also be able to provide adequate traction to utilize the tractor horsepower and turn it into useful drawbar horsepower.

You will have to adjust the ballast, tire pressure and tractor weight split between the front and rear axles for various loads and conditions to achieve the best ride and performance.

Ballast

Ballast is mass that is added to the tractor chassis or wheels to increase the total weight and to balance the weight distribution.

Total Weight

The total weight is the combined weight of the tractor and any load added at the hitch.

Static Weight Distribution

Static weight distribution is the percentage of the total weight under the front and the rear tires when the tractor is not moving.

The tractor is designed to have 60% of the weight under the rear tires and 40% under the front tires.

NOTE: Ballasting is a matter of adjusting all of the factors for best tractor performance in the field.

Tire and Ballast Factors

NOTE: The information and practices in these notes must be followed for proper operation of the tractor and best performance.

Tire specifications: Be aware of the tire manufacturer’s specifications and follow the manufacturer’s guide for use of the tires. Do not exceed the maximum load rating of the tires.

Tire inflation: Ensure that tires are properly inflated at all times. Do not over inflate tires. Do not operate the tractor on under inflated tires or tires that do not hold pressure.

Tire condition: Tires must be in good condition to achieve the desired performance from the tractor.

Wheel spacing: Ensure that tires and rims are properly installed to allow for tire deflection and steering limitations.

Tractor power: The rated tractor power (PTO horsepower) is provided in the tractor specifications.

Allowable amount of ballast: Maximum tractor weight is a range from 54 to 64 kg (120 to 140 lb) per PTO hp.

Maximum weight: The maximum loaded weight of the tractor must not be exceeded.

Tractor front axle: These weights are provided in the tables found in this section.

Type of implement: The type of implement contributes to the load on the tractor and the balance of weight.

Type of operation: The type of operation being performed affects the balance of the tractor and the loads on the tires.

Type of soil and terrain: The type of soil being worked and the terrain affect the loads on the tractor.

Travel speed: Travel speed must be adjusted for tractors that carry more weight and/or when pulling loads. Use only safe and correct operating speeds. Higher speeds mean reduced drag. Follow the recommendations for ground speed.



CAUTION



Adjust travel speed for increased braking distances and safe cornering. Road speeds must be reduced.

Not Enough Ballast	Too Much Ballast
Too much wheel spin	Soil compaction
Poor handling and lack of control	Waste of fuel
Tire wear	Extreme mechanical wear
Waste of fuel	Possible engine damage
Reduced productivity and efficiency	Reduced productivity
Possibly unsafe	Possibly unsafe

NOTE: Always maintain the proper air pressure in the tire to carry the load. Do not over inflate radial or bias ply tires. Radial tires will work with lower air pressures. Radial tires will show up to 20% sidewall deflection or bulge when properly inflated.

NOTE: The force that enables the tires to drive the tractor must be transmitted through the tire sidewalls. The tires work best when all the tires on a given axle are working at the same rate. Think of them like a shock absorber; they must respond the same way to share the load equally.

Ballast Benefits and Limitations



WARNING



Never operate the tractor or equipment outside the specified safe limits for slopes and inclines. Read your operator's manuals or check with the manufacturer for specifications.

Ballast Limitation: Tractors have limitations to the loads they can pull. Using too much ballast will not compensate for implements that are too large or too heavy for the tractor.

Mechanical Front Wheel Drive: The MFWD to the front wheels is important for efficient operation of the tractor and depends on proper weight distribution. Overloading the front axle or improper balancing of the tractor may damage the front steering and drive components.

NOTE: Intentionally exceeding recommended ballast limits may damage the drive line and structure of the tractor. This damage will not be covered by your warranty.

Performance and Productivity: A properly set up tractor and equipment will use less fuel and cover more ground in the time available.

Pulling lighter loads at increased ground speed is more efficient than loading a tractor to the maximum.

Steering and Wheel Hop: The front wheels must be in contact with the ground at all times. Proper weight bias keeps the wheels in contact with the ground and provides the right amount of pressure without bounce and with normal steering response.

Tractor Horsepower: Horsepower limits the amount of ballast that can be used. Ratings for the tractor are provided in the specifications. The standard for calculating ballast limitations is to use the specified PTO horsepower rating.

NOTE: PTO horsepower can be estimated as 80% of the rated horsepower.

The engine must be operated in the proper power/rpm range.

The specified weight per horsepower is given as 54 to 64 kg (120 to 140 lb) using the total combined weight of the tractor and ballast added.

Tractor Weight: The base weight of the tractor limits the amount of weight that can be added.

Specified weights for the tractor are estimates based on the design specification and a basic set of options. The actual weight of any tractor is more closely represented by the shipping weight documentation.

Note that the shipping weight may include ballast already installed. The best way to determine tractor weight is to use truck weigh scales or get axle weights from a suitable set of scales or load cells. Make note of any ballast installed at the time of weighing.

Soil Conditions and Terrain: Variable soil conditions such as moisture or hardness, compaction or looseness and presence of stones, affect the ability of the tractor to maintain a constant ground speed and wheel slip.

It is recommended that the machine ballast be set up for the typical or average field conditions and adjusted only as required.

It may be necessary to adjust the ballast for the worst case or most difficult situation when terrain is variable, such as inclines, slopes, depressions and contours.

NOTE: Do not exceed ballast and tractor weight limits.

Selecting Ballast

When tractor horsepower loads vary, the optimum weight of the tractor will change. This means that ballast may have to be added or removed to maintain the best tractor performance. Proper ballast will greatly improve tractor operation and ride.

NOTE: Using these procedures will result in radial ply tires and bias-ply tires having different ballast.

NOTE: Radial tires require less overall weight to achieve the same traction as bias-ply tires. Proper ballasting of radial tires is commonly achieved with cast iron weights alone. Bias-ply tires may require both cast iron weights and liquid ballast in the tires.

NOTE: Liquid ballast is not recommended for radial tires.

Always treat all the tires on a tractor axle equally when selecting ballast and tire pressure.

The amount of ballast required is affected by:

- Shipping weight of tractor
- Soil and traction conditions
- Type of implement: fully-mounted or semi-mounted or trailed type
- Working speed
- Tractor horsepower load
- Tires: type, size and number of tires
- Tire pressure.

General Weight-Split Guidelines

Maintaining stability and grip is vital to safe and efficient operation. The type of equipment used affects the weight-split calculations.

The target 60% rear 40% front weight split is a starting point for general use; adjust the split for specific applications and equipment loads.

Increased weight on the drawbar removes downward pressure at the front axle and can be compensated by added front weight.

Towed Draft Implements

Equipment that places small vertical forces on the tractor drawbar, discs, cultivators, chisel plows, etc.:

- Reduce front axle load to 35% of the total weight to control traction and rear wheel hop.

Trailers and Towed Tanks

Implements that place high vertical loads on the tractor drawbar:

- Increase the front axle load to a maximum of 55% of the total weight to maintain stability and steering control.

Integral and Semi-integral Implements

Rollover plows and large depth controlled implements place large vertical loads on the tractor at the 3-pt hitch:

- Increase the front axle load to a maximum of 55% of the total weight to maintain stability and steering control.


Adapting Ballast to Work Load and Ground Speed

Do not use more ballast than needed. Remove excess ballast when it is not required.


Do not add excessive weight to the tractor to pull heavy loads. Reduce the load because pulling a lighter load at a higher ground speed is more efficient and easier on the tractor.

The recommendations in this manual are based on a 8 to 10 kph (5 to 6 mph) ground speed.

NOTE: Avoid operating in a gear that results in laboring the engine at ground speeds below 8 kph (5 mph). Keep the engine in the operating power rpm range. Reduce the load as required to achieve recommended ground speeds.



Ballasting Decisions



Use this chart as a guide and follow the instructions that are provided in this section of the manual to determine how much ballast to use.

NOTE: For every adjustment in weight and load there is a change in bias and traction of the tractor. Ballasting is about finding the best compromise to maintain peak performance and efficiency.

NOTE: Do not over ballast or under ballast the tractor. Try to keep the tractor set up close to what works for the most common conditions and applications. Ballasting is always a compromise of choices and results.

Checking Wheel Slippage

A good way to monitor ballasting requirements is to check the drive wheel slippage. Keep slippage to 8 - 15% under normal field conditions.

More weight may be required if the drive wheels slip excessively. However, remember that excessive load and/or poor traction conditions will also cause excessive wheel slip.

Always check slippage several times and average the results wheel slippage will vary as field conditions change. Remove weight if slippage is less than 8%.

Automatic Wheel Slip Monitor

Slippage is measured automatically when the optional ground tracking radar is installed.

Manual Wheel Slip Measurement

Wheel slippage can also be measured manually.

1. Move the tractor and the equipment to the field where the work will be done. Disconnect the equipment and drive the tractor forward for 30 m (100 ft). Mark one rear tire on the sidewall where the tire meets the ground and place a stake in the ground as the start point for the test.
2. Drive the tractor forward until the tire completes 10 full revolutions and place a stake at this location to mark the end point of the test run.
3. Drive the tractor back and attach the equipment.
4. Engage the equipment to working depth and drive forward to the start point. Re-mark the sidewall at the stake location then proceed.
5. Drive back over the course again at working speed, with implement fully engaged. Count tire revolutions between the same two marks. This is N2.
6. Adjust the ballast or load for correct wheel slip.

Table 3-32: Wheel Slippage Chart

Wheel Revolutions from Step 5	Approximate % Slip	Result
Less Than 10 - 3/4	Too low	Remove Ballast
10 - 3/4	8	Proper Ballast
11	10	
11 - 1/2	15	Add Ballast
More Than 11 - 1/2	Too High	

$$(N2/10) \times 100\% = \text{Wheel Slip}$$

NOTICE

Do not exceed the tractor gross vehicle weight (GVW) shown below. This can cause an overload condition that may void the warranty and may exceed the load rating of the tires and ROPS structure.

Ballast Limitations

Ballast is limited by the tire capacity or tractor capacity. Do not exceed the recommended carrying capacity. If a greater amount of weight is needed for traction, use either a larger single tire or duals.

Ballast can be added by bolting on cast iron weight or by adding liquid calcium chloride in the tires. Bolt-on cast iron weight is recommended because it can easily be removed when not needed.

IMPORTANT: The GVW is:

- For M8-181 and M8-201 = 10929 kg (24094 lb)

IMPORTANT: Do not exceed tire load limits. Refer to the tire load charts in Section 5: Lubrication and Maintenance or refer to the manufacturer's specifications.

Estimating Ballast Requirements

It is possible to estimate the tractor's operating weight and to calculate the amount of front and rear ballast required. These calculations are general starting points.

Contact a KUBOTA dealer or local tire distributor for more information.

Points to Remember

Operate the tractor in a weight range of 54 to 64 kg (120 to 140 lb) per PTO horsepower to efficiently develop drawbar horsepower.

Ballast tractors with MFWD to achieve 60% rear and 40% front weight distribution with towed high draft implements and 3-pt hitch mounted implement.

NOTE: All weights provided from KUBOTA are approximations and the calculations described provide results that are within an acceptable margin of error.

These results can be used to establish a baseline for further adjustment.

Table 3-33: Typical Shipping Weights Without Cast Ballast for KUBOTA M8-181 and M8-201 Tractors

Model	Total Weight	Rear	Front
M8-181 and M8-201	10 890 kg (23 950 lb)	6 316 kg (13 891 lb)	4574 kg (10 059 lb)
NOTE: Includes weight of fuel with tanks filled (approximately 318 kg (700 lb)).			

Example 1

M8-181 and M8-201, 200 PTO hp - Desired 60%/40% weight split

		Total Maximum	Rear 60%	Front 40%
208 PTO hp x	60 kg (130 lb.) per hp =	12480 kg (27513 lb)	7488 kg (16508 lb)	4992 kg (11005 lb)
Shipping weight in kg (lb)		10890 kg (23 950 lb)	6534 kg (14404 lb)	4356 kg (9603 lb)
Weight to be added in kg (lb)		1 590 kg (3 505 lb)	945 kg (2083 lb)	636 kg (1402 lb)

NOTE: All weights are approximations.

The rear weight needed can be accomplished by adding a set of duals and hubs which weigh approximately 600 kg (1320 lb) plus two 539 kg (1188 lb) weights to the rear wheels. And also 10 x 39 kg (86 lb) weights.

The front weight can be added by using 20 of the 30 kg (66 lb) plates = 630 kg (1388 lb)

Weighing the Tractor

The most accurate way to determine the weight of the tractor is to have it weighed using suitable scales or equipment.

Obtain the front and rear wheel loads and use those figures in the calculations as actual weights.

Commercial truck scales or loading facilities may offer access to their scales for a fee.

There are also portable load cells that may be purchased or leased and may be used by some equipment service providers in your area.

When weighing the tractor, the preferred method is to obtain the total weight on both front and rear axles.

If dual wheels are used, place blocks to drive the inner tires onto. This removes the load from the other tires.

There may be a record of bill of lading with the delivery weight if the tractor was delivered by truck to the KUBOTA dealer. The charts earlier in this section give the load carrying capacity per tire.

Calculating Tire and Axle Loads

NOTE: Include the weight of fully raised three-point hitch implements when calculating rear axle load when operating at road speeds for an extended period.

NOTICE

Do not overload tires. Reduce the load, install higher rated ply tires or reduce road speed if maximum tractor weight exceeds the load rating of the tire as listed in the tire chart.

NOTE: Example Calculation for Tire Load:

Starting with a Model M8-201 with rear axle weights and dual wheels.

- Rear axle shipping weight = 6 316 kg (13 891 lb)
- Plus rear axle weights 539 kg (1 188 lb)
- Plus dual wheels 600 kg (1 320 lb)
- Plus 3-pt hitch load 2 727 kg (6 000 lb)
- Total rear axle load without additional ballast = 10 051 kg (22 158 lb)
- Total rear axle load supported by 4 tires = 10 495 kg (23 137 lb)
- Therefore, load supported by each rear tire with 3-pt hitch fully raised = 2 512 kg (5 538 lb).

Rear Tire Weighting

NOTE: Install cast iron weight first. Use liquid ballast only as required.



CAUTION



Installing liquid ballast requires special equipment and training. Have liquid ballast added by a KUBOTA dealer or a qualified tire specialist.

NOTICE

With radial tires never fill past the 40% to 50% range. Reduced air volume limits the ability of the tire to carry loads and shocks resulting in tire damage if this rule is exceeded. Bias ply tires can be filled to 75%. Contact a KUBOTA dealer.

NOTE: Do not use any other liquids than a calcium chloride and water solution to ballast tires. Other types of liquids pose hazards and may damage the tires. Do not use alcohol or ethylene glycol.

The following chart shows how much ballast can be held at 40% to 50% full.

IMPORTANT: Maximum recommended vehicle weight might be exceeded if tires are filled over 50%. Never fill radial tires past 50%.

NOTE: Sloshing may be felt and heard in liquid ballast tires. This is normal.


NOTE: Check manufacturing manual for tire ballast information.

Rear Wheel Cast Iron Weights

Cast iron weights (1) are available in 39 kg (86 lb) sets. These weights will be installed on the axles either inside or outside of the wheels.

The following table lists the maximum number and location of rear wheel weights:

Model	240 kg (450 lb) Weight	
	Inside	Outside
M8-181 and M8-201	3	2



Installing Cast Iron Rear Wheel Weights



CAUTION



Wheel weights are heavy and require appropriate lifting equipment or have the job done by a KUBOTA dealer.


The wheel must be removed to install weights (1) on the inside of a wheel. Refer to Rear Wheel Track Adjustment Section for wheel removal information.

Attach the first weight to the wheel disc and tighten the attaching bolts to 258 N·m (190 ft-lb).

NOTE: Check the torque of all attaching bolts on each wheel after driving the tractor for 200 m (218.72 yd) after 1 hour and 10 hours operation and thereafter at the 50-hour service intervals.

Tighten attaching bolts securely to 258 N·m (190 ft-lb). Retighten every two hours of service until bolt torque stabilizes. Check tightness every 250 hours thereafter.

Check to make sure the weights are centered. Excessive runout can cause an unbalanced condition when operating at high speed.



Ballasting Front End for Transport



CAUTION



Additional front ballast may be needed when transporting large 3-pt hitch mounted equipment.

The 40% to 60% front-to-rear split is a baseline for proper traction and control under field conditions.

When pulling an implement on the road for transport the vehicle speeds will be higher than in field operations. With higher speed there is less need for rear ballast and the front drive will not be engaged.



Implements that place downward force on the hitch when being transported require added front bias.

Additional front bias is necessary when 3-pt hitch attachments are raised for transport. Add front-end ballast when it is needed for stability and steering control.

The front weight bias can be increased to a maximum of 55% of the total weight, if the tractor and tire load ratings are not exceeded.

NOTICE

Do not exceed axle weight rating.



DANGER

Never allow the tractor to operate with the front wheels off the ground.



Tractor front-end ballast may not always maintain satisfactory stability if the tractor is operated at high speed on rough or hilly terrain. Reduce speed and exercise caution under these conditions.

Determining Maximum Front Ballast

NOTICE

Do not overload front tires. Reduce ballast or install heavier tires if maximum weight shown in the tire chart is below ballasted weight.

Use adequate front weight as required for the operating condition. Make sure MFWD tractors have adequate ballast to properly load front wheels. This is especially important when pulling heavy loads. Remove ballast when it is no longer needed.

The tire inflation chart in Section 3 shows the load carrying capacity for the front tires.

NOTE:

- *Do not exceed total tractor weight limit*
- *Do not exceed front axle weight limit*
- *Do not exceed tire load limit.*

Front Weights – Cast Iron

Front weights are available as follows:

Cast steel plates weigh 30 kg (66 lb) each.

Weight kits are available as packages of 20 weights.

Weights are available from a KUBOTA dealer.

The following table lists the maximum recommended front weights by model number:

Model	20 X 30 kg (66 lb) Weights
M8-181 and M8-201	600 kg (1 320 lb)

Adjust for Type of Load

Determine the type of load the pulled equipment places on the hitch.

- High vertical loads on the tractor drawbar from trailers and towed tanks.
- Large vertical loads on the tractor at the 3-pt hitch from rollover plows and other large depth controlled implement.
 - Front axle bias may be adjusted to 55% (maximum) of the total tractor weight including the hitch load.
- Small vertical forces on the tractor drawbar from towed draft implements such as discs, cultivators, chisel plows, etc.
 - Front axle bias may be adjusted to 35% (minimum) of the total tractor weight including the hitch load.

Installing Front Weights



WARNING



The tractor must not be operated unless both the tie bolts and attaching bolts are in position with the bolts tightened as specified. Recheck the bolt torques after one, eight and 50 hours of operation if the bolts have been disturbed for any reason.



CAUTION



Optional front weights are heavy. Use appropriate lifting equipment or have the job done by a KUBOTA dealer.

NOTICE


Retighten and check the torque of attaching hardware after each one hour of use until the first eight hours of use or until the torque is stable.

Observe the regular 50-hour service intervals.

Install the front weights on the weight bracket using a suitable lifting device.

To add or remove individual weights:

- Remove the flange nut from one end of the tie rod (1) and pull the rod out of the assembled weight pack.
- Loosen the mounting bolts (2) holding the bracket clamps.
- Add or remove individual weight plates as needed, then reinstall the tie rod and flange nuts. Make sure the weights are centered on the mounting bracket.
- Install the tie rod (1) so that the ends are even then install and tighten the flange nuts to 550 N·m (406 ft-lb) minimum.



- Tighten the mounting bolts (2) at the bracket clamps to 417 N·m (308 ft-lb) minimum.
- The complete weight assembly can be removed after both attaching bolts (2) are removed. Use a suitable lifting device to lift the assembly.

NOTICE

Total package weight is 600 kg (1 320 lb)

Front Tires - Liquid Weight



WARNING



Improper use of liquid ballast can lead to unsafe operating conditions and mechanical damage to the tractor.



CAUTION



Installing liquid weight requires special equipment and training. Contact a KUBOTA dealer.

NOTICE

With radial tires never fill any tire up to more than 40% to 50%. More liquid ballast solution will leave too little air space to absorb shocks. Damage to the tire could occur. This occurs due to the lower inflation pressures that are used with radial tires. Bias ply tires can be filled to 75%.

NOTICE

If you are considering the use of liquid ballast, first check with the tire manufacturer to determine whether use of liquid ballast is either approved or recommended. Always follow the manufacturer's recommendations.

Table 3-36: Liquid Tire Ballast

Tire Size	Water L (gal)	CaCl ₂ kg (lb)	Total Wt. kg (lb)
Front (380/80R38)_ Rear (380/90R54)	77 (20)	42 (93)	121 (267)
Front (380/80R38)_ Rear (480/80R50)	88 (23)	50 (110)	139 (307)
Front (380/80R38)_ Rear (520/85R46)	127 (33)	76 (167)	200 (440)
Front (380/85R34)_ Rear (380/90R50)	197 (52)	118 (260)	315 (694)
Front (380/85R34)_ Rear (480/80R46)_R1W	242 (64)	145 (320)	387 (854)
Front (380/85R34)_Rear (480/80R46)_R1	63 (43)	98 (215)	261 (574)

NOTE: The above weights are based on 75% fill. Fill radial tires to no more than 40% to 50%. Calculate weight as required.

A solution of water and calcium chloride provides economical ballast and, if used properly, it will not damage tires tubes or rims. Some tire manufacturers do not approve the use of liquid ballast.

If an operator of the tractor decides to use liquid ballast, be aware of the risks and limitations and follow the guidelines provided:

- The use of alcohol as liquid ballast is not recommended.
- Liquid ballast is difficult to add and to remove
- Liquid ballast results in poor tire performance
- Liquid ballast in tires increases ground compaction
- Improper use of liquid ballast can lead to over loading tires and tractor.

Tires

Check the tire air pressure and recheck every 50 hours or weekly.

Inspect for damaged tread and side walls when checking tire pressure.



WARNING

Inflating or servicing tires can be dangerous. Use trained personnel to service or install tires whenever possible. Follow the safety precautions below to avoid the possibility of serious or fatal injury:

Tractor wheels are very heavy. Handle with care and make sure that they cannot topple and cause injury when stored.

Never attempt tire repairs on a public road or highway.

Ensure the jack is placed on a firm, level surface.

Make sure the jack has adequate capacity to lift your tractor.

Use jack stands or other suitable blocking to support the tractor while repairing tires.

Do not put any part of your body under the tractor or start the engine while the tractor is on the jack.

Never hit a tire or rim with a hammer.

Make sure the rim is clean and free of rust or damage. Do not weld, braze, otherwise repair or use a damaged rim.

Do not inflate a tire unless the rim is mounted on the tractor or is secured so that it will not move if the tire or rim should suddenly fail.

When fitting a new or repaired tire, use a clip-on valve adaptor with a remote gauge that allows the operator to stand clear of the tire while inflating it. Use a safety cage, if available.

Tire air pressure affects the amount of weight that a tire may carry. Locate the tire size for your tractor in the Tire Pressure and Permissible Loads tables in Section 3. Do not exceed the load for the pressures listed. Do not over or under inflate the tires.

- Do not inflate a steering tire above the manufacturer's maximum pressure shown on the tire or beyond the maximum shown in the Tire Pressure and Permissible Loads tables in Section 5 if the tire is not marked.
- Never inflate a traction tire (front tire on a four-wheel drive tractor or any rear tire) over 241 kPa (35 psi). Deflate the tire, relubricate the bead with a soap/water solution and reinflate if the bead does not seat on the rim by the time this pressure is reached,. Do not use oil or grease. Inflation beyond 241 kPa (35 psi) with unseated beads may break the bead or rim with explosive force sufficient to cause a serious injury.
- Adjust inflation pressure to the recommended operating pressure after seating the beads.
- Do not re-inflate a tire that has been run flat or seriously under inflated until it has been inspected for damage by a qualified person.
- Torque wheel hardware after driving the tractor for 200 m after one hour and 10 hours operation and thereafter at the 50-hour service intervals.




3-pt Hitch



WARNING

- Never stand directly behind the tractor, between the lower links or on or near the implement or 3-pt hitch.
- Never extend arms, legs, any part of the body or any object into the area near the linkage point of the implement while operating the external raise/lower control switch.
- Never have an assistant working the opposite set of controls. When moving to the opposite set of controls, move around the tractor or implement.
- Do not cross between the implement and tractor.



The 3-pt hitch (1) is classified as a Category 3 Implement attachment. It is an electro-hydraulic system that has an automatic position control feature to maintain implement depth as determined by the operator. The 3-pt hitch is designed to accept Category II, III, III-N and 4N implements.

The 3-pt hitch consists of two lower links (1) to lift and lower the implement. The manually adjusted top link (2) is designated as a third mounting point.


The hitch is adjusted using the control panel on the operator console (see “3-pt Hitch Control System (Rear)” on page 3-131) or the external raise/lower switches (see “External raise/ lower switches” on page 3-139) located on the rear fender.

3-pt Hitch Overview

Use the diagram below to locate the parts of the 3-pt hitch that are mentioned throughout the instructions.

Table 3-37: 3-pt Hitch Parts Overview



1	Left and right lift rods
2	Top link
3	Top link transport hanger
4	Lift rod adjusting blocks
5	Lower links
6	Sway blocks




3-pt Hitch Control System (Rear)

The 3-pt hitch controls is located on the EZ-Command Center (1) and Operator Console (2).

- Rear 3PTH Float mode: Press the fast lower button twice to enter float.
- 3-pt hitch raise/lower switch (3) (rear 3-pt hitch only)
- Depth control dial (hydraulic dial) (4)
- 3-pt hitch lock button (5)
- External Raise/ Lower Switches (6) (located on each rear fender) (rear 3-pt hitch only).
- The rear 3-pt will only drop or raise to the height set in the dials or on the monitor. The lower limit can only be set by the dial and the upper limit can only be set on the monitor.
- The speed at which the 3-pt will go down is controlled by the 3-pt speed dial or the 3-pt lower image with the rabbit in the monitor.
- If front 3-pt is equipped there is a hydraulic couplers in the front for hydraulic operations. The front hydraulic valve/couplers are controlled by the #5 hydraulic lever (8), the #5 hydraulic lever is located on the MFH and is the blue lever. Hydraulic coupler is now #5 hydraulic lever which is on the loader joystick left and right. Left to extend and right to retract all the way to activate float.
- If front 3-pt is equipped, the front 3PTH is lifted and lowered by pressing and holding the 4th function button (9) on the joystick (10) and pushing the joystick forward to lower and back to raise. The loader joystick must be unlocked and the loader mode selected to use the front 3PTH. Front 3PTH is in mechanical float. See “3-pt Hitch” on page 3-129
- Front 3PTH has no indicators on height or control to drop speed. It only has an up and down control.






3-pt Hitch Settings (Rear) Display Screen

The menu below displays the 3-pt hitch settings with the optional radar installed and slip control enabled.

Ref	Description
1	3-point hitch lock indicator
2	3-point hitch status indicator
3	Ride control indicator
4	Draft control indicator
5	Wheel slip control indicator
6	3-point lock switch
7	Ride control switch
8	Draft control switch
9	Wheel slip control switch

Ref	Description
10	Positive switch
11	Minus switch
12	Wheel slip indicator and set point
13	Draft control setting
14	3-point hitch drop speed control
15	Lift arm bottom limit set point
16	Lift arm current position
17	Lift arm top limit control



Switching between 3-point hitch lock and unlock

Touch the left half of the 3-point hitch lock switch (6) and the 3-point hitch gets locked. A touch on the right half unlocks the 3-point hitch. While it is locked, the indicator (1) lights up and stays on.

Adjusting the lift arm top limit control (17)

Touch the (+) switch (10) or the (-) switch (11) on the right side of the lift arm top limit control (17) to readjust the top limit height.

Raise the percentage to increase the top limit. When it has reached 100%, the top limit setting is cancelled.

Adjusting the lift arm bottom limit control (15)

Using the depth control dial (hydraulic dial), the bottom limit height can be readjusted.

Lower the percentage to decrease the bottom limit. When the draft control switch (8) is ON, the lower link lowering position varies according to the draft sensitivity control (13) setting value.

Displaying the lift arm height (16)

The current lift arm position (height) is automatically displayed with the bar graph and percentage. A higher percentage shows a higher 3-point hitch height.


Adjusting the 3-point hitch lowering speed control (14)

Extend the graph farther to the right (raise the percentage) to increase the lowering speed.

Switching the automatic draft control

Touch the left half of the draft control switch (8) and the automatic draft control gets activated. A touch on the right half deactivates it.

If a “lowering” action is made with the depth control dial (hydraulic dial) or the 3-P. quick lower switch in the automatic draft control mode, the indicator (4) lights up and stays on.



Adjusting the draft sensitivity control (13)

Extend the graph farther to the right (raise the percentage) to increase the draft sensitivity. Depending on the type of job, readjust the draft sensitivity. If the draft sensitivity is set at 0%, the position control works instead.

Setting the ride control

Touch the left half of the ride control switch (7) and the ride control gets activated. A touch on the right half deactivates it.

The ride control unit serves to absorb vibrations and shocks upon the tractor, when the machine is moved equipped with a 3-point-hitched implement.

(The ride control unit activates itself if the 3-P. quick raise switch is pressed to bring the rear hitch up to its top limit and the traveling speed rises above 6 km/h (3.7 mph).)

Setting the wheel slip control (9)


Used together with the optional radar device, the tractor can be constantly kept under the best control. This helps to improve your productivity. (For details, contact your local Kubota Dealer.)

Calibrate 3PT Hitch

The 3PT hitch will be calibrated at the factory or KUBOTA dealership prior to delivery to the operator.

NOTE: A calibration must be done if the position sensor is unplugged for longer than seconds.

1. Press the 3PT hitch unlock button (1) on the operator console to unlock the 3PT hitch. Make sure the indicator icon in the display screens displays that the 3PT hitch is in the stop position .
2. Press and hold the 3PT hitch unlock button for 10 seconds or until it starts to flash.
3. Press the raise (2) or lower button (3) on the EZ-Command Center (4) to start the calibration. Wait until the calibration is complete.
4. If the calibration is successful the 3PT lock button will be illuminated indicating the 3PT hitch is locked. If the calibration is unsuccessful the 3PT hitch lock button will not be illuminated indicating the 3PT hitch is unlocked.



Fender-mounted 3-pt Hitch Switches



DANGER



Do not stand on or near an implement or between an implement and the tractor.

The fender-mounted 3-pt hitch switches (1) are located on the rear fenders below the fender-mounted work lights.

The fender-mounted switches are used to raise and lower the 3-pt hitch.

Refer to External Raise/Lower Switch in Section 3: Tractor Operation for more detailed instructions on using the fender-mounted 3-pt hitch controls.



Enable 3-pt Hitch




WARNING



- Never stand directly behind the tractor, between the lower links or on or near the implement or 3-pt hitch.
- Never extend arms, legs, any part of the body or any object into the area near the linkage point of the implement while operating the external raise/lower control switch.
- Never have an assistant working the opposite set of controls. When moving to the opposite set of controls, move around the tractor or implement.
- Do not cross between the implement and tractor.

The 3-pt hitch is locked in place until it is enabled using the EZ-Command Center. The 3-pt switch indicator will stay lit when it is enabled. While locked, the controls and the manual control lever will not function. If any buttons are pressed or the lever is moved, the display panel will flash an indicator.

- Press the 3-point hitch lock button (1) to unlock, the lock and unlock status switch and the switch indicator goes on while the lock status is on.
- Before traveling on public roads, be sure to get the 3-point hitch locked to avoid accidental drop of the implement.
- If traveling with the ride control on, unlock the 3-point hitch lock button.



External raise/ lower switches



WARNING



- Never stand directly behind the tractor, between the lower links or on or near the implement or 3-pt hitch.
- Never extend arms, legs, any part of the body or any object into the area near the linkage point of the implement while operating the external raise/lower control switch.
- Never have an assistant working the opposite set of controls. When moving to the opposite set of controls, move around the tractor or implement.
- Do not cross between the implement and tractor.



CAUTION

Before leaving the tractor to operate the external raise/lower switch carry out the following procedures:



- Apply the parking brake.
- Shift the transmission into neutral.
- Disengage the PTO.
- Move the hand throttle lever to the low idle position (fully rearward).


The external raise/ lower switches (1) are located on each rear fender. It can be used to manually raise and lower the hitch at a slow, controlled rate.

NOTE: The external raise/ lower switches will not operate if the tractor is moving.

Before using the external raise/lower switch, make sure no person or object is in the area of the 3-pt hitch or the implement.

- Push and hold the upper part (2) of the switch to raise the hitch. Release when the desired height is reached.
- Push and hold the lower part (3) of the switch to lower the hitch. Release when the desired height is reached.


The lower links should align with the implement before attempting to attach the implement to the 3-pt hitch.



Position/Mix Draft Mode Select

Select the position control or the draft control depending on the types of work. Choose the draft control for jobs requiring traction such as plowing and sub-soiling.

Position control mode in use	Touch the right half of the draft control switch (1) and the position control mode is selected and the draft control (2) indicator goes off.
Mix draft control mode in use	Touch the left half of the draft control switch (3) and the mix draft control mode is selected and the draft control indicator (4) lights up. Extend the draft sensitivity adjustment (5) graph farther to the right to increase the percentage of work done in draft control versus that in position control.



Depth Control Dial (Hydraulic Dial)

1. The depth control dial (hydraulic dial) (1) is used to adjust the implement height (plowing depth).



For details, refer to the descriptions of the following position, mix draft and flow controls.

2. For traveling on public roads, keep the implement raised with the depth control dial.
3. When the dial is preset for the implement to get to the lower limit, the 3-Pth. quick raise/lower switch can be used to raise and lower the implement.

Position Control Mode

1. This will control the working depth of the 3-point hitch mounted implement regardless of the amount of pull required.

- Down (2)
- Up (3)



Mix Draft Control Mode

The mix draft control mode (1) will control the pull of the 3-point implement. As the load on the 3-point hitch changes due to various soil conditions, the draft control system automatically responds to these changes by either raising or lowering the implement slightly to maintain a constant pull.


Set the implement pull with the depth control dial (hydraulic dial).

1. For traveling on public roads, keep the implement raised with the dial.
2. When the dial is preset for the implement to get to the lower limit, the 3-P. quick raise/lower switch can be used to raise and lower the implement.



Position Control Mode

1. This will control the working depth of the 3-point hitch mounted implement regardless of the amount of pull required.
 - Down (2)
 - Shallow (3)
 - Up (4)



Draft sensitivity adjustment switch

During work in the draft mode, readjust the sensitivity with switch according to the plowing depth, the type of soil and other factors. Refer to Table 3-41.

Draft sensitivity adjustment switch	Retract the bar graph leftward with the (-) switch.	Extend the bar graph rightward with the (+) switch.
Plowing depth	Shallow	Deep
Type of soil	Light	Heavy
Field (ruggedness)	Little	Much
(Sensitivity)	(Low)	(High)

Float Control

Press the fast lower button on the MFH twice to enter float mode.

Lift Arm Top Limit Adjustment

Set for work in which a 3-point hitch top limit is required.

- Using the (+) and (-) switches, the setting can be changed. (The setting is variable in the 30-100% range.) Slide the slider to the right (increasing the value) to raise the top limit of the 3-point hitch.
- When the setting has reached 100%, the top limit control is turned off.

For the setting procedure, refer to “3-pt Hitch Settings (Rear) Display Screen” on page 3-132.

Adjust Lift Rods



WARNING

Before the lift rod is disconnected from the lower link:




- Lower attached equipment to the ground and make sure it is properly supported
- Make sure the hydraulic control lever is fully down
- Stop the engine
- Remove the lift rod securing pin.

1. To adjust the lift rods (1), raise the adjusting block (2) and rotate it to lengthen or shorten the lift rod assembly.
2. Slide the adjusting block down to engage the locking boss (3) on the lift rod end to prevent rotation of the adjusting block.
3. For most implements, adjust both lift rods so the centers of the lower link balls are 254 mm (10 in) above the ground when the hitch is fully lowered.
4. Adjust the lift rods to level the equipment in the operating position.

Adjust Top Link

5. Raise the handle/locking latch (4) and then turn the sleeve (5) to adjust the top link (6).
6. Push the handle/locking latch down to engage the locking tab in the end of the top link assembly to prevent further rotation of the sleeve.
7. Adjust the top link to 724 mm (28.5 in) measured between the center of the attaching points for most equipment. Readjust to level the equipment as required.
8. Remove and store the top link or use the transport hanger to lock it in a vertical position when not in use.



Sway Blocks


The sway blocks (1) control lower link side movement to prevent the equipment swaying from side to side in both the transporting and operating positions. This is especially important when operating on slopes near fences, walls or ditches.

The sway blocks can be mounted in a rigid or sway position.

Rigid Position

To prevent side movement of the equipment in both the operating and transporting positions, rotate the sway blocks (1) to the forward position and use the pins (2) and the clips (3) to secure in the forward hole (rigid position).

NOTE: Install the pin with the clip on the inside of the drawbar support.




Swing Position

To allow side movement of the equipment in the operating position but remain rigid in the transporting position, rotate the sway blocks (4) rearward and secure them. Install pins (5) and clips (6) in the rear hole (swing position).

NOTE: Install the pin with the clip on the inside of the drawbar support.

NOTE: When setting the sway blocks to permit side-to-side movement, make sure the rear tires cannot contact the sway blocks, lower links or implement.




Guide Blocks, Spacers and Shims

The guide blocks and spacers can be positioned so the 3-pt hitch will accept category II, category III or category III-N implements.

Category II or Category III Position

Install the guide blocks (7) on the inside of the lower links. Add shims (8) if required.




Category III Position

Position the guide blocks (1) and spacer (2) on the inside of the lower links. Add shims (3) if required.

Shims are available to adjust the amount of lateral movement between the sway blocks and the lower links when the hitch is in the raised (transport) position or when the sway blocks are in the rigid position.

Make the adjustment with the sway blocks in the rigid position by placing an equal number of shims on each lower link. Install the shims so the linkage can be fully raised and lowered without binding with an implement attached.




Linkage Category Conversion

Tractors are equipped with category III linkage. To convert from category III to category II, insert bushings into the top link and lower link implement connections. Reposition the guide blocks and spacers as described previously.


Hook-end Hitch

The hook-end hitch has 2 lower links (4) and one adjustable top link (5). The 3 links have open claw ends to permit fast coupling and uncoupling of implements. The claws have self-locking latches to connect the implement securely to the tractor's hitch.



Stabilizers keep the 2 lower links at the width setting required for the implement.

Ball bushings are supplied with the tractor. Install these ball bushings on the implement's lower hitch pins (6) and upper hitch pin (7).



Stabilizers

Stabilizers may be fitted in place of the sway blocks.



WARNING




Do not operate steerable equipment unless the stabilizers are installed and correctly adjusted to prevent excessive lateral movement.

The stabilizers will control the sway of the lower links and attached equipment when in work or when being transported. This is especially important when operating on slopes or near fences, walls or ditches and with certain implements.

An externally threaded rod (1) is attached to the lower links. The threaded rod engages with the screwed thread in the tube assembly. The overall length of the assembly is determined by screwing the rod in or out, as required.

An adjustable chain (2) is attached at one end of the rear cab and the other end via spring to a hinged cover (3). A lug (4) engages a notch in the cover.




Adjusting the Stabilizers

The implement should be attached to the 3-point linkage with the cover (1) on both stabilizers raised to allow the stabilizers to telescope freely.

Lift the locking/adjusting lever (2) over the peg (3) so that the lever is at a right angle to the stabilizer. Turn the lever to screw the threaded section (4) in and out of the stabilizer. When the length is satisfactory, align the notch in the cover with the lug on the stabilizer and lower the lever back down over the peg and close the cover.


The chain should then be adjusted by placing the appropriate link over the attaching hook to lift the cover on the stabilizer when the implement is lowered into work.



IMPORTANT: When setting the stabilizer length to provide sway, make sure that there is no possibility of the rear tires fouling the stabilizers.

Implement Hook-up

1. Use the stabilizer or sway blocks to set the lower links of the 3-pt hitch the correct distance apart to align with the 2 lower ball bushings installed on the implement.
2. Drop the 3-pt hitch to the lowest position, make sure the self-locking latches are closed and raise the top link. Reverse the tractor until the lower link claw couplers (1) are under the implement hitch pins. The large claw openings and the guide cones on the implement ball bushings make it easy to align the tractor to the implement.
3. Use the hydraulic control to raise the 3-pt hitch and listen for the sound when the self-locking latches connect to the implement ball bushings.
4. Lower the top link claw (2) onto the upper implement ball bushing and press down until the latch connects.
5. Rotate the sleeve on the top link to adjust the length of the top link to the initial 724 mm (28.5 in) setting.
6. Remove or retract the implement supports.
7. Attach remote equipment as required.
8. Check these items before proceeding:
 - Make sure there is no interference with tractor components.
 - Drop the hitch to the lowest position and make sure the top link does not contact the PTO guard.
 - Use the lift control lever to carefully raise the 3-pt hitch and check for clearances with the implement in the raised position.
 - Perform a series of left and right hand turns to check the swing clearance with the tractor and implement combination.



NOTICE

- Make sure that the PTO driveline will not over-extend and disengage, bottom out or be at an excessive angle before operating PTO driven equipment.
- Make sure that the driveline shield does not contact the PTO guard or drawbar. See PTO Operation for more information.
- Make sure there is adequate clearance between the implement and the tractor when attaching mounted or semi-mounted equipment to the 3-pt hitch or when attaching trailed equipment to the drawbar or hitch.
- If the tractor is equipped with an UltraSteer front axle, adjust the steering stops, sway blocks or stabilizers to make sure that semi-mounted or trailed equipment will not interfere with the tractor's rear tires.

Hydraulic Trailer Brake Coupling



WARNING


Always lock the service brake pedals together before hitching a trailer with hydraulic brakes to the tractor. With the service brake pedals locked together apply the parking brake, stop the engine and immediately block the wheels.



When parking a tractor/trailer combination apply the tractor and trailer parking brakes with the engine running. Hydraulic pressure cannot be applied to the trailer braking system with the tractor engine off.

Connect hydraulic trailer brakes to the quick-release coupling (1) at the rear of the tractor. The coupling (1) conforms with ISO 5676. When the trailer brake hose is connected to the quick-release coupling the trailer brakes will be automatically applied when the service brakes are used to stop the tractor.

NOTE: Always keep the dust-cap in place on the quick-release coupling for hydraulic trailer brakes when not in use. It is a legal requirement in some countries that the trailer brakes may only be connected to the tractor coupling by means of a compatible female coupling.



Towing Attachments and Drawbar Operation

NOTICE

Refer to the data plate of attachments, as well as the D-value (theoretical horizontal force between tractor and trailer) and permissible S-value (maximum vertical load) of the hitch coupling frame. If different, only the lowest value of each is allowed. See Figure 1 for a sample data plate.

Efficient drawbar operation is critical to optimum tractor performance. Drawbars are designed to produce maximum traction for the wheelbase, tire size, weight distribution and ballast of the tractor and are integral to overall tractor performance.



DANGER



Drawbar height and length are fixed and must not be altered. Altering the height or length of the drawbar will change tractor characteristics and will result in death or serious injury to the operator and/or bystanders.



DANGER



Never allow the tractor to operate with the front wheels off the ground.

Tractor front-end ballast may not always maintain satisfactory stability if the tractor is operated at high speed on rough or hilly terrain. Reduce speed and exercise caution under these conditions.

Swinging Drawbar



WARNING



Always secure the drawbar to prevent swinging when transporting the tractor or when operating any equipment except ground engaging equipment.


The swinging drawbar (1) is compatible with the coupling frame.

Two swing limiter pins (2) secure the drawbar in the fixed position.

Fasten the drawbar in position using the swing limiter pins when pulling equipment which requires accurate positioning and when transporting equipment.

Allow the drawbar to swing when pulling ground engaging equipment which does not require accurate positioning. This will make steering and turning easier.

See the following pages for details on adjusting the length and height of this drawbar and for attaching a trailer.



Automatic Hitch Pin




WARNING

Never allow anyone to stand between the tractor and implement while backing the tractor to the implement. Always bring the tractor to a complete stop and engage the parking brake before allowing anyone behind the tractor to hitch the implement.



WARNING

Always secure the drawbar to prevent swinging when transporting equipment or when operating any equipment except ground engaging equipment.



The drawbar is equipped with a hitch pin that will automatically drop in place when hitching up to implements.

To operate:

Place the hitch pin (1) in the raised position.

Retaining ring (2) fits in the upper notch (3) of the clevis to hold the hitch pin in the raise position.

Release strap (4) must be positioned in front of the retaining ring as shown. The drawbar is now prepared to hitch to the implement.

The implement hitch will contact the release strap (4) when aligning the drawbar when backing the tractor to attach the implement. As the release strap is pushed forward it dislodges the retaining ring (2).

The hitch pin (1) will drop as the retaining ring slides down the incline on the front of the clevis. The implement is now attached to the tractor without requiring the operator to leave the cab of the tractor or the help of a second operator.


The retaining ring (2) locks into the lower notch (3) of the clevis after the hitch pin (1) drops into place. Notch (3) holds the retaining ring in the lower position preventing the hitch pin from inadvertently unhitching.

To manually unhitch the implement:

1. Pivot the retaining ring (2) up away from notch (3).
2. Pull the hitch pin from the clevis.

NOTICE

Always install a safety retaining pin in the hitch pin (4) to secure the hitch pin and prevent any accidental unhitching of the implement.




Drawbar Length Adjustment

Model M8-181 and M8-201(equipped with 2-speed PTO)

This model has a straight drawbar (A). The drawbar is not height adjustable but has 3 length adjustments. Refer to the tables below.

Drawbar Length

Three holes are provided at the front of the drawbar for adjusting length. The front locating pin may be inserted in any of the 3 holes to vary the PTO shaft to hitch point distance.



NOTICE

The clevis and hitch pin retainer must be moved to the top when the drawbar is inverted.

Always use the close-coupled position for equipment exerting high downward forces, such as 2-wheeled trailers, etc.

Use the PTO Type 1 for 540 rpm PTO equipment, the PTO Type 2 for 1000 PTO operation with 21-spline 35 mm (1.375 in) shaft and the PTO Type 3 for 1000 rpm operation with the 20-spline 45 mm (1.75 in) shaft.

NOTE: Refer to "ANSI/ASABE AD6489-3:2004 JUL2017".

Table 3-42: Standard Duty Drawbar Length Adjustment

PTO Type	Distance from Hitch Point to PTO Shaft		
	Short	Regular	Extended
1 (540 rpm)	240–260 mm (approx. 10 in)	340–360 mm (approx. 14 in)	N/A
2 (1000 rpm)	240–260 mm (approx. 10 in)	390–410 mm (approx. 16 in)	N/A
3 (1000 rpm)	340–360 mm (approx. 14 in)	490–510 mm (approx. 20 in)	640–660 mm (approx. 26 in)

Table 3-43: Heavy Duty Drawbar Length Adjustment

PTO Type	Distance from Hitch Point to PTO Shaft	
	Short	Regular
1 (540 rpm)	240–260 mm (approx. 10 in)	340–360 mm (approx. 14 in)
2 (1000 rpm)	240–260 mm (approx. 10 in)	390–410 mm (approx. 16 in)
3 (1000 rpm)	340–360 mm (approx. 14 in)	490–510 mm (approx. 20 in)

Adjusting Drawbar Length



WARNING



Always secure the drawbar to prevent swinging when transporting equipment or when operating any equipment except ground engaging equipment.


NOTICE

Make sure that the total weight on the rear axle does not exceed the maximum rear axle loading or the rear tire load capacity, whichever is the lower when supporting equipment on the drawbar. See Tire Load and Inflation tables in this section.

NOTE: The drawbar is shipped in the shortest position. Reposition as required by the attachment.

To change the drawbar length:

1. Remove the 2 bolts (1) that retain the front pin (2).
2. Adjust the drawbar length as required and re-install pin and bolts. Torque bolts to 60 N·m (44 ft-lb).



Towing Operations



WARNING



Always be aware of and observe vehicle operation regulations and statute. Know the operating limits of the tractor.

The operation of tractors as tow vehicles for agricultural trailers and equipment creates additional responsibilities for the operator and for anyone in the area of operation. Additional loading increases strain on equipment and risks of accidents. For this reason it is highly recommended that additional precautionary measures be taken.

- Adjust/reduce speed to allow for the nature of the towed equipment.
 - Never exceed the recommended capacities of the tractor for GVW (gross vehicle weight) and towing.
 - When highway towing always lock the drawbar in the center position for best stability.
 - Use all safety restraints provided including pin retainers and safety chains.
 - Use safety warning equipment as required by law.
-

Safety Chain


Use a safety chain (2) with tensile strength equal to or greater than the gross weight of the implement to be towed by the tractor when towing implements (1) on the highway. This will control the implement in the event the drawbar (3) and implement disconnect.

A chain guide (4) is provided to support the chain.

Make a trial run by driving the tractor to the right and to the left for a short distance to check the safety chain adjustment after attaching the safety chain. Readjust to eliminate a tight or loose chain if necessary.

Check the implement operator's manual for implement weight and attaching hardware specifications.

Safety chains, attaching hardware and chain guide are available from a Kubota dealer.



Attaching and Detaching Trailed Equipment

NOTICE

Regulations in some areas require brakes on towed equipment when operating on public highways. Ensure you comply with legal requirements before traveling on public highways.

To attach the tractor to trailed equipment and implements:

1. Make sure implement is at the drawbar height.
2. Slowly inch rearwards to allow the drawbar and implement hitch to intersect (steering sharply left and right will aid in hitch alignment).
3. Set parking brake and stop engine.
4. Insert hitch pin and make sure the retainer is in the latched position.

NOTE: For implements that require hitch extensions or interfere with the tractor clevis, remove and store the clevis and hitch pin.

Always use a safety chain installed between the tractor and implement hitch when transporting equipment on public highways.

North American standards recommend the following precautions for towing equipment not equipped with brakes:

- Do not tow equipment weighing more than twice the tractor weight.
- Do not exceed 16 km/h (10 mph) if towed equipment weighs more than the tractor.
- Do not exceed 32 km/h (20 mph) while towing equipment that weighs less than the tractor.

When detaching equipment:

- Support the equipment to prevent uncontrolled dropping.
 - Block the equipment wheels to prevent unwanted rolling.
 - Make sure that all power sources on the tractor and on the equipment are turned off.
 - Detach all electrical and hydraulic connections between the tractor and the equipment. Use proper care in safe handling of hydraulic connections. Refer to Hydraulic Operations in Section 4.
 - Remove the coupling pins and safety chains and then pull the tractor away from the equipment.
-

Power Take-off (PTO) (Front and Rear)



DANGER



Before operating the PTO always make sure that all safety shields and guards are in place. These safety shields are designed for the protection of the operator and bystanders.

NOTICE

Excessive clutch slippage can cause premature clutch failure. Do not attempt to unplug a jammed implement by repeatedly engaging and disengaging the PTO clutch.



WARNING



The PTO lever release locks are to be lifted to move the lever forward or backward and released immediately after this movement. Failure to release can cause the over-travel of the lever past the end of travel detent.

The independent power take-off (PTO) transfers engine power directly to mounted or trailed equipment. “Independent” means that the PTO may be engaged, operated and disengaged with the tractor stopped or while moving.

The PTO drive is a wet disc type clutch with an integral brake, controlled by a solenoid operated valve.

When engaged the PTO warning light on the side operator console will appear. Refer to Engine Warning Lights in Section 2 for more information.

Rear PTO shafts can be interchanged from 1000 RPM shaft to 540 RPM shaft by removing the 8 hex bolts. Removing the shaft currently installed and install the new shaft of the desired speed and reinstall the 8 hex bolts.

The rear PTO can also be set into econo mode or normal mode for both the 1000 RPM shaft and the 540 RPM shaft with the 2 levers at the back right of cab. ECONO mode allows you to turn the PTO shaft at its max speed so 540 RPM or 1000 RPM shaft but at a much lower engine speed and load to save on fuel and increase efficiency for lighter jobs that don't require as much engine power

Rear PTO is equipped with an auto PTO feature which will allow you to have the PTO automatically turn off or on based on the height of the 3pt hitch. There are 2 settings in the monitor, one will allow to set the raise height at which the PTO will turn off, the other is to set the lower height at which the PTO will turn back on.

NOTE: The PTO will automatically disengage when the engine is stopped.

NOTE: The PTO will only engage with the operator in the seat and will disengage if the operator leaves the seat.

PTO Requirements

The implement PTO drive shaft must have one of the 3 drive shafts.

- 21 spline 1000
- 20 spline 1000
- 6 spline 540

NOTE: Do not use adapters for smaller or larger yokes.

Rear Power Take-off (PTO)

NOTICE

The PTO will only engage with the operator in the seat and will disengage if the operator leaves the seat.

Non-Stationary mode:

If the operator is to leave the seat there is a 10 second delay before the PTO will shut off. A beep will start right after the operator leaves the seat and if the park brake is not engaged.

Stationary mode:

- Allows the operator to Enable the rear PTO without being in the seat.
- Rear PTO safety override is available through the EIC under the configurations menu.
- Rear PTO safety override default state is OFF. Every time the tractor is started, the rear PTO armrest switch is switched to OFF position or the PTO fender switch is used. The rear PTO safety override will automatically change to OFF (disabled).

The following conditions must be met:

- Safety override Enabled
- Park brake is On
- Transmission is in the Neutral position
- Speed of tractor is at 0.0 mph/kph

NOTE: If any one of these conditions are not met, the rear PTO will not turn but the safety override will remain On (Enabled).

With the 540 shaft is installed:

- 540 NORM is selected, normal operation occurs with no limitations or restrictions.
- 540 ECO is selected, PTO rpm will be limited to MAX 670 RPM. As soon as MAX RPM is reached, the engine speed will stay around 1950 rpm.
- 1000 NORM is selected, the PTO will disengage when it reaches 670 RPM. The PTO switch will need to be turned OFF before the PTO will re-engage and Error code 5151 will appear on the monitor screen.
- 1000 ECO is selected and 540 shaft is installed, the PTO will disengage when it reaches 670 RPM. The PTO switch will need to be turned OFF before the PTO will re-engage and Error code 5151 will appear on the monitor screen.

With the 1000 shaft is installed:

- 1000 NORM is selected, normal operations occur with no limitations or restrictions.
 - 1000 ECO is selected, PTO rpm will be limited to MAX 1170 RPM. As soon as MAX RPM is reached, the engine speed will stay around 1950 rpm.
 - 540 NORM is selected, the PTO shaft will not reach operating speed. The PTO will continue to spin but at reduced RPM. No error code will appear.
-

PTO Controls



WARNING




The PTO lever release locks are to be lifted to move the lever forward or backward and released immediately after this movement. Failure to release can cause the over-travel of the lever past the end of travel detent.

Push the rear PTO switch (1) or front PTO switch (2) (if equipped) on the operator console (3) to engage the Power-Take Off (PTO).

Use the PTO lever (4) 540 or 1 000 speed. Use the PTO lever (5) to select ECO or NORM mode.

Pull up the switch knob and tilt it forward and the PTO clutch comes ON (engage).

Tilt the switch knob backward and the PTO clutch comes OFF (disengage).



Engaging the PTO

1. Understand the safe operation of the PTO. Read PTO Safety in Section 1.
2. Attach the equipment as described in Attaching Equipment to the PTO Shaft with the engine stopped.
3. Start the engine with the PTO disengaged.
4. Select the appropriate gear (ECO or NORM, 540 or 1000).
5. Pull up the switch knob (1) and tilt it forward (A) and the PTO clutch comes ON (engage).
6. Operate the PTO at lower rpm to make sure the equipment is free of obstructions.
7. Gradually bring the engine up to operating speed. Operate the engine at 1900 rpm for 1000 rpm PTO equipment and 1880 rpm for 540 rpm equipment. Make sure the equipment is operating properly.

NOTE: *The independent PTO is controlled only by the PTO control switch. The operation of the inching pedal does not affect the PTO operation.*

Disengaging the PTO

Reduce engine speed to 1 000 rpm and then tilt the switch knob backward (B) and the PTO clutch comes OFF (disengage).


NOTICE

Tilt the knob back in emergency or push the PTO emergency shut off button on the rear fenders.

NOTICE

The PTO has a non-critical overspeed alert. The PTO ON light will flash and a one second audible alarm will occur during these conditions:

- The speed of a 540 rpm PTO is more than 630 rpm.
- The speed of a 1000 rpm PTO is more than 1152 rpm.




NOTICE

Always disengage the PTO before making sharp turns and before raising mounted equipment to its fully raised position. Stop the tractor and wait for the equipment to clear itself if PTO equipment becomes plugged. Immediately disengage the PTO by tilting the switch knob backward and then stop the engine if the equipment does not clear itself or if the PTO clutch slips. Wait until the PTO stops before exiting the tractor or working on the equipment.

NOTICE

There is a PTO lockout feature that causes the PTO clutch to disengage when the tractor is shut off.




Engaging the PTO with PTO Gear Shift Lever



WARNING



Be sure to observe the PTO shaft speed prescribed for the individual implements. It is extremely dangerous to run an implement at high speed that is meant to be operated at low speed. Use only when this higher rpm is specifically recommended by the implement manufacturer.



Choose from the following 4 PTO operating modes according to the type of implement or the workload.

Set the mode selector lever (1) to the NORM (normal) mode for general work and the ECO (economy) mode for light-duty work only.

In ECO mode, the engine runs at low speed for energy saving operation. Using the 540 OR 1000 rpm PTO gear shift lever (2), select a speed to suit the implement in use.

Handling the levers


1. Before handling both the levers, set the PTO clutch control switch to the OFF (disengage) position.
2. To shift, lift the lever lock up to release from detent and move the lever slightly in the desired direction to ensure it is out of detent lock. Release the lever so the detent lock can re-engage automatically. Move the lever to the desired position and allow it to automatically lock into detent.
3. Must pull the lever lock up to move out detent to be able to move back to neutral.

Table 3-44: PTO with Gear Shift Levers


PTO operating mode selector lever	PTO gear shift lever	
Normal (PTO/Engine speed)	540/2005	1000/1995
Economy (PTO/Engine Speed)	540E/1608	1000E/1600

Enabling/Disabling Stationary PTO



1. Press the left button (1) on the EIC to access the main menu.



2. Use the left button (1) scroll till CONFIG (2) is highlighted. Press the right button (3) to access the menu.




3. Use the left button (1) scroll till OVERRIDE (4) is highlighted. Press the right button (3) to access the menu the PTO override (5).



4. Use the left button (1) scroll till PTO (2) is highlighted. Press the right button (3) to ENABLE the rear PTO safety override.

NOTE: A STAR next to PTO will appear when the safety override is enabled.

5. To disable the rear PTO safety override. Key the tractor OFF or perform steps 1 thru 4 so that the STAR is no longer next to PTO.



Front PTO Operation



WARNING

Disengage PTO, stop engine and allow all rotating components to come to a complete stop before connecting, disconnecting, adjusting or cleaning any PTO driven equipment.



Remove front PTO when not in use.

Non-Stationary mode:

If the operator is to leave the seat there is a 10 second delay before the PTO will shut off. A beep will start right after the operator leaves the seat and if the park brake is not engaged.

Stationary mode:

Not provided or applicable.

The front PTO and rear PTO are independent and both PTOs can be operated together or individually.



Front PTO Clutch Control Switch

The PTO clutch control switch engages or disengages the PTO clutch which gives the PTO independent control.

Pull up the switch knob and tilt it forward and the PTO clutch comes ON (engage).




Tilt the switch knob backward and the PTO clutch comes OFF (disengage).

IMPORTANT: To avoid shock loads to the PTO, reduce engine speed when engaging the PTO, then open the throttle to the recommended speed.

NOTE: If the PTO system is engaged and you stand up from the seat, the warning buzzer will whistle for about 10 seconds after standing up. This is because the tractor is equipped with Operator Presence Control System. PTO turns off at this point in time if operator leaves seat.

NOTICE

Tilt the knob back in emergency or push the PTO emergency shut off button (1) on the rear fenders.



PTO Options

The model M8-181 and M8-201 tractors are equipped with a standard 34.9 mm (1.375 in) 6-spline 540 rpm shaft for PTO operation.

An optional 20-spline 44.5 mm (1.75 in) output shaft is available for the 1 000 rpm operation. The alternative 20-spline shaft may be purchased from a Kubota dealer.

An optional 34.9 mm (1.375 in) output shaft is available for 1 000 rpm operation. The alternative 21-spline shaft may be purchased from a Kubota dealer.

Contact a Kubota dealer for more information on options.

NOTE: The 6-spline shaft is used to operate equipment having a power requirement up to (65 hp). Couple equipment having a higher power requirement to the 21-spline shaft.

NOTICE

Use the 35 mm (1.375 in) 540 rpm PTO shaft (Type 1) only on implements requiring less than 65 kW (87 PTO horsepower).

Use the 35 mm (1.375 in) 1000 rpm PTO shaft (Type 2) only on implements requiring less than 130 kW (174 PTO horsepower).

Use the 45 mm (1.750 in) 1000 rpm PTO shaft (Type 3) if heavier loads are expected.

PTO Master Shield



WARNING



- Never stand on the PTO master shield or use the master shield as a step during PTO operation.
- Install the PTO shaft cover (3) provided whenever the tractor PTO is not in use. The PTO shaft cover is threaded into the housing.



WARNING




Never remove or alter the PTO master shield at any time to assist in attaching any type of implement.

The PTO master shield (1) is adjustable to three positions by placing the prop rod (2) in positions A, B or C.

Position A: Shield is level; use this position during normal PTO operation.

Position B: Shield is tilted upward; only use this position while attaching implement PTO shaft to the tractor. Lower the shield to position A after the shaft is attached.

Position C: Shield is tilted downward; use this position to provide clearance for the top link when non-PTO implements are attached.




Changing the PTO Output Shaft



WARNING

Before changing the PTO shaft:

- Engage the parking brake and park the tractor so the rear end is approximately 10 cm (4 in) higher than the front end.



- Apply the parking brake
- Move the gear shift lever to Neutral
- Disengage the PTO by pushing the PTO selector knob down
- Stop the engine
- Make sure the PTO shaft has stopped turning.




CAUTION



Make sure the rear axle oil is at or below the fill mark before removing the retainer to prevent oil loss.



WARNING




Never remove or alter the PTO master shield at any time to assist in attaching any type of implement.

NOTICE

Never operate the tractor with the PTO shaft removed.

To change the PTO stub shaft perform the following:

1. Remove the PTO shaft cover (1).
2. Remove the 8 retaining bolts (2).
3. Remove PTO stub shaft (3) from mounting face (4).
4. Install desire stub shaft onto mounting face.
5. Install the 8 retaining bolts and torque to 115 N·m (85 ft-lb).
6. Install the PTO shaft cover.



Attaching Equipment to the PTO Shaft

Mount or hitch the equipment to the tractor as outlined in either 3-pt Hitch Linkage in Section 4 or Towing Operations earlier in this section.

1. With the engine stopped, all equipment lowered and the PTO stopped, pull the PTO shaft cover as previously described.
2. Attach the equipment driveshaft to the tractor PTO shaft. Ensure that the equipment driveshaft coupler lock pin (1) engages the PTO shaft lock groove. Pin the coupler to the shaft if the coupler does not have a lock.
3. Mounted equipment only: Raise and lower the linkage and check for interference. Ensure the PTO shaft is not binding in the fully raised position. Set the height limit control knob on the right hand console to limit raising height if necessary. Also study the instructions in 3-Pt Hitch Controls in Section 4.
4. Trailing equipment only: Ensure that the drawbar is fixed in the center position and that the drawbar is set at the correct length for the PTO speed selected. Refer to Towing Operations earlier in this section.
5. Position the PTO master shield, as previously described, in the proper position before operating the PTO.
6. Check that the PTO driveline is not overextended, bottomed out or at an excessive angle and that the driveline shield does not contact the PTO guard or drawbar.

NOTICE



Check to make sure the driveline will not bottom out or become disengaged before operating PTO driven equipment. Use the following to determine PTO shaft engagement.



WARNING



Use of the PTO shaft adapters is not recommended due to risk of overspeeding the implement and also compromising the effectiveness of the PTO shield.



PTO Operation



WARNING

Whenever operating PTO equipment observe the following safety precautions:

- Follow the equipment operator's manual instructions.
- Do not wear loose clothing when operating PTO equipment.
- Stop the engine and wait until the PTO shaft and equipment stops before getting off the tractor and working on the equipment when operating PTO-driven equipment.
- Do not clean or adjust PTO driven equipment while the tractor engine is running.
- Make sure that the PTO master shield is installed.
- Always apply the tractor parking brake and block the rear wheels front and back when operating stationary PTO equipment.
- Do not work under any equipment which is supported only by the hydraulic lift or remote cylinder. Always use suitable blocking or supports.
- Always replace the PTO shaft cover when the PTO is not being used.




NOTE: *The PTO operation will shut off if operator leaves the seat.*

NOTE: *The PTO brake will remain applied as long as the engine is running and the PTO is off. The brake will release so the PTO shaft can be turned by hand when attaching equipment when the engine is shut off.*


PTO EIC Configuration

The PTO configurations (1) located in the EIC screen (2) allows the operator changes to the engagement characteristics of the PTO based on the size of implement load and type of soil.




Light Configuration (3):

- Is meant for light PTO implement loads or light soil conditions where a harsh engagement of the PTO is not required. The application pressure is lowered during the filling phase for a smoother engagement.




Medium Configuration (1):

- Is meant for normal PTO implement loads or normal soil conditions where an engagement of the PTO clutch will avoid clutch slippage. The application pressure is higher than the light pressure during the filling phase which provides a bit harsher engagement.



Heavy Configuration (2):

- Is meant for heavy PTO implement loads or heavy soil conditions where a harsh engagement of the PTO clutch is needed to avoid clutch slippage. The application pressure is high during the filling phase providing the harsh engagement.




PTO icon Settings

The following are icons of the PTO settings on the K-Monitor.

Table 3-45: PTO Setting Icons	
Icon	Description
1	Front PTO indicator
2	Front PTO rpm
3	Rear PTO indicator
4	Rear PTO rpm
5	Height at which the PTO turns on when the implement is lowered
6	Auto PTO switch

Table 3-45: PTO Setting Icons	
Icon	Description
7	(+) switch
8	(-) switch
9	Height at which the PTO turns off when the implement is raised
10	Current lift arm height
11	Auto PTO indicator



PTO Settings

Automatic ON/OFF setting of PTO shaft revolutions, which is interlocked with the lifting height of the rear 3-point-hitched implement, can be made.

Setting the 3-point-hitch-interlocked PTO function

- Start the engine and start PTO rotation.
- Touch the left half of the Auto PTO switch (1) and the 3-point-hitch-interlocked PTO function is enabled. A touch on the right half (2) disables this function. While the 3-point-hitch-interlocked PTO function is on, the indicator (2) lights up and stays on.

Setting the height at which the PTO restarts turning when the implement is lowered


- Touch the (+) switch (3) or (-) switch (4) on the right side to readjust the height at which the PTO shaft restarts turning. Raise the percentage to raise the height at which turning restarts.

Setting the height at which the PTO stops turning when the implement is raised

- Touch the (+) switch (3) or (-) switch (4) on the left bottom to readjust the height for the PTO shaft to stop turning. Lower the percentage to lower the height at which turning stops.

Displaying the PTO rpm

- Engage the PTO switch at ON (engage), the front PTO rpm (5) as well as the rear PTO rpm (6) are displayed.



Rear PTO Operation

The rear PTO has 4 modes:

- Normal
- ECO
- 1 000 RPM
- 540 RPM.

There are 2 PTO sensors:

- Shaft speed
- Shaft detection sensor

To operate the rear PTO:

1. The operator must select either Normal or ECO mode.
2. Push or pull the lever (1) to either Normal or ECO mode depending on the application.

Normal mode:

- The rear PTO runs at its normal operating speed at a higher engine RPM. For the shafts to reach full operating speed, the engine's RPM must be around 1 800 - 2 000 RPM. This mode is used for most PTO work.

ECO mode:


- The rear PTO must operate at a reduced engine RPM speed.
- The PTO has reached full operating speed at a much lower engine RPM to increase fuel savings but less PTO power. This mode is suited for light duty applications.

3. Once normal or ECO has been selected, the operator must select either 540 or 1 000 RPM.

NOTE: Make sure to check which shaft is installed on the tractor. 540 (6 spline shaft) or 1 000 (21 spline small shaft or 20 spline big shaft).


NOTE: An alarm will sound and the PTO will stop if the operator leaves the seat.

4. If the PTO is activated and 1 000 shaft lever is selected but the 540 shaft is installed. The shaft detection sensor will read an over speed and shut the PTO down when the speed reaches above 650 PTO rpm.
5. The PTO will shut down if a 540 shaft and ECO mode is selected and the PTO shaft goes above 650 RPM.



6. The PTO will shut down if a 1 000 shaft and ECO mode is selected and the PTO shaft goes above 1 150 RPM.
 7. To switch between ECO and Normal mode, the PTO must be turned off to avoid grinding the gears. There is no sensor to stop from switching between ECO and Normal Mode while the PTO is running.
 8. To switch between 540 and 1 000, the PTO must be turned off to avoid grinding the gears and there is no sensor to stop from switching between 540 and 1 000 while the PTO is running.
-

Auto PTO Operation



1. The rear-PTO can be preset to turn itself on and off, being interlocked with the lifting height of 3-point hitch mounted implement.
2. Touch the left half of the auto PTO switch (1) and the setting is enabled. By touching the right half (2) of the switch and the setting is disabled.
3. While the auto PTO switch is on, the indicator (2) lights up.
4. Use the switches (3 and 4) to readjust the height for turning on the PTO in lowering the implement and the height for turning it off in raising the implement.

NOTE: If operation leaves the seat or PTO switch is turned off, the Auto PTO switch will turn off as and has to be re-engaged.

Rear PTO Calibration (TMT20)

Contact a Kubota dealer for assistance.

Diesel Particulate Filter Regeneration

The model M8-181 and M8-201 tractors are equipped with technology that meets the following standards:

- North American Tier 4F S5 clean emissions standards;
- Environmental Protection Agency (EPA) regulations which took effect in North America in January 2011;
- European Union Stage IIIB regulations; and
- Japanese Ministry of Land, Infrastructure and Transportation (JMLIT)/Japan Ministry of the Environment (JMOE) regulations expected to commence in 2013.

These standards regulate diesel sulfur emissions to 15 ppm for off-highway applications.

Regeneration process

Regeneration is the process of cleaning the particulate filter by using high exhaust to burn off the particulates. Regeneration is not required under normal loads. When regeneration is required, the process will commence automatically. No action on the part of the operator is required. This section is intended to help the operator become familiar with the basic technology behind the process.


The DPF uses a catalytic reaction to continuously burn up the carbon particles. This reaction occurs during normal tractor operations.

Carbon builds up in the DPF during operation. Running in cold weather or with low loads increases the amount of carbon building up. When this quantity reaches a critical number, the system momentarily injects a small amount of diesel fuel into the DPF in order to burn off this excess residue.

DPF Regeneration Overview

- The internal composition of the DPF reduces exhaust noise.
- Regeneration is used in conjunction with the Variable Geometry Turbo system to tune engine performance and reduce fuel consumption.
- With DPF regeneration full engine performance can be realized even after startup in cold temperatures.

For more information on DPF regeneration, consult the Cummins engine owner's manual for the engine on the tractor.



Aftertreatment System Operation

The tractor is equipped with a Tier 4 final aftertreatment system. This system ensures that exhaust is nearly free of harmful emissions by injecting diesel exhaust fluid (DEF) into the exhaust stream and by burning off any soot trapped in the diesel particulate filter (DPF). The burning off of soot trapped in the filter is referred to as DPF regeneration.

In most cases the aftertreatment system operates automatically. As the operator, your basic responsibilities are:

- Making sure there is enough diesel exhaust fluid (DEF) in the DEF tank.
- Knowing how to respond to the aftertreatment indicator lights as they appear on electronic instrument cluster (EIC). There are separate sets of indicator lights for DPF and DEF warnings.
- Knowing how to force the system to perform a regeneration.
- Knowing how to inhibit (stop) the aftertreatment system from performing regeneration.
- Knowing how to re-enable the aftertreatment system after it has been inhibited.

Summary of everything you need to know about operating the aftertreatment system:

- Keep regeneration enabled when regeneration does not pose a safety hazard. Under normal working conditions this will allow the aftertreatment system to automatically clean the DPF filter.
 - Only inhibit regeneration when regeneration would cause a safety hazard. For example, inhibit regeneration when the tractor is in a shed or near material that can catch fire.
- Watch the electronic instrument cluster for aftertreatment indicator lamps. Respond to them immediately.
- Top-up the diesel exhaust fluid (DEF) tank every time you fill up the fuel tank. Never mix DEF with diesel. Always use clean DEF. Do not allow any contamination to the DEF tank or sensor. Even one or two drops of diesel fuel can affect the DEF sensor system.

- Wait for the Power-off Indicator (POI) lamp to shut-off before turning the battery shut-off switch to OFF. Aftertreatment system does not purge the DEF lines.

NOTE: It does not take 5 minutes for the Power-off Indicator (POI) to turn off.

- Have the aftertreatment system maintained at the correct service intervals.
-

Selective Catalytic Reduction (SCR)

NOTICE

Do not tamper, modify or remove any component of the SCR system. Do not use DEF that does not meet the specifications provided or to operate the vehicle with no DEF.

The SCR system is used to decrease the mono-nitrogen oxides (NOx) emissions from the vehicle tailpipe. The system is composed of several main components:

1. Aftertreatment diesel exhaust fluid (DEF) dosing unit
2. Aftertreatment DEF dosing valve
3. Aftertreatment SCR catalyst
4. Aftertreatment DEF tank and header assembly

The model M8-181 and M8-201 tractors are equipped with the SCR system. It is used to decrease the mono-nitrogen oxides (NOx) emissions from the vehicle tailpipe. The system is composed of several main components:

Diesel Exhaust Fluid (DEF)

DEF is required for an engine equipped with a SCR system. DEF is a fluid that is sprayed into the exhaust gas prior to the aftertreatment SCR catalyst. The DEF vaporizes and decomposes to form carbon dioxide and ammonia. The ammonia reacts with the NOx emissions over the aftertreatment SCR catalyst to form nitrogen and water.

Selective Catalytic Reduction (SCR)

The SCR system consists of a SCR catalyst, AMOX and the Diesel Exhaust Fluid Tank. This system uses a small amount of Diesel Exhaust Fluid (DEF) to convert NOx emissions in the exhaust into nitrogen and water.

Ammonia Oxidation Catalyst (AMOX)

In order to ensure sufficient NOx reduction, a small amount of excess Diesel Exhaust Fluid (DEF) is injected into the exhaust stream. This excess DEF may pass through the Selective Catalytic Reduction (SCR) catalyst as ammonia. To prevent excess ammonia from entering the atmosphere, the exhaust gas flows through an Ammonia Oxidation Catalyst (AMOX) where the ammonia reacts with oxygen in the presence of this catalyst to form nitrogen and water.

Diesel Exhaust Fluid Tank

The Diesel Exhaust Fluid Tank is responsible for storing, controlling and supplying the appropriate quantity of Diesel Exhaust Fluid from the DEF tank to the DEF injector. The Diesel Exhaust fluid is used by the SCR system to reduce NOx emissions in the exhaust.

NOTICE

Cummins Inc. supplies the aftertreatment DEF dosing unit, aftertreatment DEF dosing valve and the aftertreatment SCR catalyst. The vehicle manufacturer supplies the DEF tank, the DEF lines, the DEF tank temperature and level sensor, the DEF quality sensor and all wiring between the components, unless labeled with a Cummins® part number.

If the aftertreatment DEF components do not have a Cummins® part number, see equipment manufacturer service information.

Diesel Exhaust Fluid

- Slight ammonia smell
- Colorless
- Non-toxic and non-polluting
- Non-flammable
- Naturally occurring and is biodegradable.

The aftertreatment DEF dosing valve is coolant cooled and sprays DEF into the exhaust.

The engine control module controls the amount of DEF sprayed into the exhaust. It also controls the DEF tank heater and DEF line heaters.

The aftertreatment SCR catalyst uses DEF to reduce the NOx emissions by converting the engine out NOx into nitrogen and water. The aftertreatment SCR catalyst itself requires no maintenance.

A vehicle with SCR will be equipped with an additional lamp on the dashboard, the aftertreatment DEF lamp. This lamp, along with the check engine lamp and stop engine lamp, alert the operator to the level of DEF in the tank. As the DEF tank level approaches empty, the aftertreatment DEF lamp will illuminate and engine power will be reduced. Attempting to operate the vehicle with no DEF in the tank will result in the vehicle speed being limited to 8 km/h (5 mph).

DEF is sprayed into the exhaust when the temperature in the aftertreatment SCR catalyst reaches approximately 250 °C (482 °F). The amount of DEF consumed will differ from vehicle to vehicle, as DEF consumption depends on engine speed and load.

The aftertreatment DEF dosing unit pumps DEF from the DEF tank to the aftertreatment DEF dosing valve. The aftertreatment DEF dosing unit and header unit is electrically heated and contains a filters that are maintenance items.

NOTE: See Section 5: Lubrication and Maintenance Schedule for changing Diesel Exhaust Fluid (DEF) In-tank filter.

Even though DEF freezes at approximately -12°C (11°F), the SCR system is designed to be frozen and thawed. The DEF tank is heated by engine coolant and the DEF lines and aftertreatment DEF dosing unit are electrically heated. No operator interaction is needed when operating in cold temperatures; heating and thawing are controlled automatically by the engine control module (ECM).

After turning the keyswitch OFF on a vehicle with SCR, a pumping sound may be heard from underneath the vehicle. This sound is the aftertreatment DEF dosing unit purging any unused DEF from the system and returning it to the tank. This is normal system operation. The purge process takes approximately 100 seconds to complete.

Under certain conditions (cold or very dry), water condensation, in the form of water vapor, can be seen coming from the vehicle tailpipe. This is normal operation and will clear within a few minutes of normal vehicle operation.

NOTICE


Do not disconnect the vehicle batteries during this process to avoid system damage.

For more information on DEF, consult the Cummins' engine owner's manual for the engine on the tractor.


Modes of Regeneration

The following configurations allow the operator to set the regeneration mode to either inhibit or forced the regeneration cycle or allow the automatic regeneration of the DPF.


- **Automatic:** The Electronic Control Module (ECM) uses multiple inputs from the engine and the machine to determine the best time to perform an automatic regeneration. Automatic regenerations can take place throughout the operating cycle of the engine. The regeneration active indicator will be illuminated when a regeneration is being performed. Interruptions of the regeneration are acceptable. If a regeneration is in progress and needs to be stopped, it is permissible to use Inhibit the regeneration through the EIC.




- **Inhibit:** The inhibit regeneration is used to stop a DPF regen cycle if the cycle is happening at an inopportune moment. Automatic and Manual regeneration modes are disabled. You must re-enable automatic or manual regen modes through the EIC.



- **Forced:** The forced regeneration is used to perform a manual DPF regen cycle if the the filter has become too plugged and the automatic regen has not taken place. It is recommended that a force regen is done outside due to the high exhaust temperatures and gases that are produced during the regen cycle.



- **Automatic:** The automatic regeneration allows the ECM to perform a DPF regen whenever conditions are met. Automatic regen does not affect the machine's operation or performance. The only indication of an automatic regen cycle is a warning light indicating the exhaust temperature is higher than normal.



Regeneration Triggers

The engine management software controls the response of the engine. The tier 4 final system has several parameters may now cause the regeneration system to operate. A regeneration may be required for the following reasons:

- **Soot:** The DPF will collect soot production by the engine. An automatic regeneration will become active to reduce soot level.
- **Start-Up Regeneration:** A start-up regeneration is initiated by the ECM after a cold engine start. This regeneration is performed to heat the system to a required temperature for Diesel Exhaust Fluid (DEF) dosing to begin.
- **SCR Maintenance:** A regeneration is performed to maintain the SCR system.

NOTE: For forced regeneration, ECM must request a regen meaning DPF lamp on. The tractor must be at idle with park brake on.

NOTE: Do not touch the throttle during operation or regen will be aborted.

NOTE: The tractor will go from idle to 1 000 rpm on its own.

What is Diesel Particulate Filter Regeneration?



DANGER



Never park the tractor under any material or surface that can combust. The regeneration process will cause high exhaust temperatures, which can cause fires.

What is Diesel Exhaust Fluid?

Diesel exhaust fluid (DEF) is a solution of about 1/3 urea 2/3 water that is injected into exhaust system to convert the emissions into harmless nitrogen and water.

To maintain clean emissions, the diesel particulate filter (DPF) traps soot and ash. The aftertreatment system uses hot exhaust to clean the diesel particulate filter of soot. This a process is called diesel particulate filter (DPF) regeneration.

Indicator lamps on the EIC (see next page) will show the status and activity of DPF process.

Passive Regeneration

Operating conditions such as **high engine loads during normal operation** make the exhaust hot enough to clean the diesel particulate filter. This type of DPF regeneration is called **passive regeneration**.

If the exhaust is not hot enough to clean the filter, the after treatment system will automatically increase the exhaust temperature by injecting fuel into the exhaust system. This type of DPF regeneration is called active (or automatic) regeneration.

Passive regeneration will occur automatically until you manually inhibit regeneration.

Inhibited and Forced Regeneration

You can stop the after treatment from automatically cleaning the filter. This is called **inhibiting DPF regeneration**. You would only inhibit the automatic system when high exhaust temperatures create a safety hazard. For example, if the tractor is in a shed and is surrounded by combustible materials.

You can only inhibit DPF regeneration and operate the tractor for a limited time before soot builds up in the filter. If the filter is not cleaned in time, the engine will eventually derate to idle speed, forcing you to manually start the cleaning process or else risk damaging the system. Manually starting the filter cleaning process is called **forced regeneration**.

Refer to page 3-197 for instructions on inhibiting, forcing and re-enabling regeneration through the EIC.

Aftertreatment Indicator Lamp Identification: Exhaust System Cleaning

Table 3-46 identifies warning lamps associated with the exhaust system cleaning and any action required from the operator.

Indicator Lamps	 Solid	 Solid  Solid	 Solid  Solid	 Solid  Solid	 Flashing  Solid
Indicator Meaning	Cleaning request active: Allows automatic regen to take place or perform forced regen if automatic was inhibited.	Filter regeneration is recommended. Cleaning Requested Cleaning Inhibit Switch Active:	Forced regeneration required. Engine will derate. Cleaning Request Active:	Forced regeneration required. Engine will shut down. Cleaning Request Active:	Cleaning request active: Cleaning initiated.
Required Action	Filter regeneration is recommended. Cleaning requested: <ul style="list-style-type: none"> • Provide Cleaning Opportunity. • Alter Duty Cycle • Perform start cleaning. 	When Safe, Deactivate Cleaning Inhibit Switch. Perform Regeneration.	Requires cleaning. <ul style="list-style-type: none"> • Perform start cleaning. • Cummins Fault Codes: FC3714 & FC4863 will be displayed 	Requires cleaning. <ul style="list-style-type: none"> • Perform start cleaning. 	<ul style="list-style-type: none"> • Response: Wait for cleaning to complete.

Aftertreatment Indicator Lamp Identification: High Exhaust Temperature (HEST) Lamp:

Table 3-47 identifies warning lamps associated with the High Exhaust Temperature (HEST) Lamp and any action required from the operator.

Overview

The High Exhaust System Temperature (HEST) Lamp will illuminate during exhaust system cleaning. In addition, the HEST Lamp will also illuminate if the exhaust temperature exceeds the calibrated temperature threshold.

Operation

When an exhaust system cleaning event is initiated or the exhaust temperature exceeds the calibrated value, the HEST Lamp will illuminate in a SOLID ON state. The HEST Lamp stays ON during the entire exhaust system cleaning. The HEST Lamp will then turn OFF when the temperature falls below the second calibrated temperature.

Indicator Lamps	Solid 	Flashing 
Indicator Meaning	Exhaust gas and part are extremely hot:	Exhaust gas and part are extremely hot. Regeneration is in progress.
Required Action	When stationary, keep tractor away from people, combustible material and vapors.	

Aftertreatment Indicator Lamp Identification: Exhaust System Cleaning Disable (Inhibit) Lamp

Table 3-48 identifies warning lamps associated with the Exhaust System Cleaning Disable (Inhibit) Lamp and any action required from the operator.

Table 3-48: Exhaust System Cleaning Disable (Inhibit) Lamp	
Indicator Lamps	<p style="text-align: center;">Solid</p> <div style="text-align: right;">  </div>
Indicator Meaning	<p>The Exhaust System Cleaning Disable (inhibit) Lamp indicates that the Exhaust System Cleaning Disable (Inhibit) Switch is active, therefore automatic and manual (non-mission) exhaust system cleaning cannot occur.</p>
Required Action	<ul style="list-style-type: none"> • Regeneration Inhibited: Automatic and Manual regeneration is disabled and cannot be performed.

Aftertreatment Indicator Lamp Identification: Diesel Exhaust Fluid (DEF)

Table 3-49 identifies warning lamps associated with the Diesel Exhaust Fluid (DEF) lamps and any action required from the operator.

Indicator Lamps	Warning Level	Warning Level	Warning Level	Warning Level
	Warning 1	Level 1	Level 2	Level 3
<p>3</p> <p>2</p> <p>1</p>	<p>Solid</p> 	<p>Solid</p> 	<p>Flashing</p> 	<p>Solid</p>  <p>Solid</p>  <p>Solid</p> 
Indicator Meaning	DEF level is low. Illuminates at 10% of tank level to 2.5%.	DEF level is critically low. If you do not add DEF immediately, 25% reduction in torque and engine speed will be reduced. Illuminates at 2.5% tank level to 0%.	DEF tank is empty. The warning runs for 30 minutes before final inducement, following the depletion of the DEF tank. There will be a 50% reduction in torque and engine speed will be reduced. Illuminates at 0% tank level. <ul style="list-style-type: none"> • Cummins Fault Codes: FC1673 & FC3547 	DEF tank has been empty for at least 30 minutes. The machine will be locked at idle and torque will be reduced. Illuminates at 30 minutes after tank level is at 0%. <ul style="list-style-type: none"> • Cummins Fault codes: FC1673, FC3547, & FC3712
Required Action	Fill DEF tank with DEF	Fill DEF tank with DEF immediately. Engine power will be restored once the DEF tank is filled.	Fill DEF tank with DEF immediately. Engine power will be restored once the DEF tank is filled.	Stop the tractor once it is safe to do so. Refill the DEF tank. Engine power will be restored once the DEF tank is filled.
<p>NOTE: If adding DEF to the DEF tank does not turn the indicator lamps off or restore engine power, contact a Cummins authorized repair location.</p>				

Aftertreatment Indicator Lamp Identification: Diesel Exhaust Fluid (DEF) Quality Operation

Table 3-50 identifies warning lamps associated with the quality of operation for the Diesel Exhaust Fluid (DEF) and any action required from the operator.

DEF Quality Operation

The DEF Lamp in conjunction with the Amber light warning, Red light warning and Fault codes are used to determine the level of inducement due to poor quality DEF. Below are the stages that will be triggered when poor quality DEF is detected.

Table 3-50: Aftertreatment Warning Lamps for the Diesel Exhaust Fluid (DEF) Level					
Indicator Lamps					
3					Solid 
2	Solid 	Solid 	Solid 	Solid 	Solid 
1	Solid 	Solid 	Solid 	Flashing 	Flashing 
Warning Level	Warning 1	Warning 2	Primary Inducement (Initial)	Secondary Inducement	Final Inducement
Indicator Meaning	DEF quality is poor. Appears within 30 minutes after the engine has been started. No limitations. DEF quality MUST be checked and corrected to prevent farther limitations. The DEF lamp is SOLID, Amber light warning is SOLID.	DEF quality is poor. Appears within 60 to 120 minutes after warning 1. No limitations. DEF quality issue MUST be checked and corrected to prevent farther limitations. The DEF lamp is SOLID, Amber light warning is SOLID.	Primary warning that DEF quality is poor. Appears 30 minutes after warning 2. A 25% reduction in torque and engine speed will be reduced. DEF quality MUST be checked and corrected to prevent farther limitations. The DEF lamp is SOLID, Amber light warning is SOLID. • Cummins Fault codes: FC3714	Secondary warning that DEF quality is poor. Appears 75 minutes after the primary inducement. A 50% reduction in torque and engine speed will be reduced. DEF quality MUST be checked and corrected to prevent farther limitations. The DEF lamp will FLASH, Amber light warning is SOLID. • Cummins Fault codes: FC3714	Final warning that DEF quality is poor. Appears 15 mins after the secondary inducement. 3 to 4 hours after warning 1 or fault detection is displayed before the final inducement is activated. The machine will be locked at idle and torque will be reduced. DEF quality issue MUST be corrected to gain engine speed and torque. The DEF lamp will FLASH, Amber light warning is SOLID, and Red STOP warning is SOLID. • Cummins Fault codes: FC3712
Required Action	Check DEF quality. Replace bad DEF with new good DEF and replace faulty component/sensor.	Check DEF quality. Replace bad DEF with new good DEF and replace faulty component/sensor.	Check DEF quality. Replace bad DEF with new good DEF and replace faulty component/sensor.	Check DEF quality. Replace bad DEF with new good DEF and replace faulty component/sensor.	Check DEF quality. Replace bad DEF with new good DEF and replace faulty component/sensor.
NOTE: Filling the DEF tank will not resolve the issue. Contact a Cummins authorized repair location.					

Aftertreatment Indicator Lamp Identification: Diesel Exhaust Fluid (DEF)/SCR Malfunction Operation

Table 3-51 identifies warning lamps associated with the malfunction operation for the Diesel Exhaust Fluid (DEF)/Selective Catalyst Reduction (SCR) and any action required from the operator.

DEF/SCR Tampering or Malfunction Operation

The DEF Lamp in conjunction with the Amber light warning, Red light warning and Fault codes are used to determine the level of inducement due

to tampering or malfunction of a component or components of the DEF/SCR system. Below are the stages that will be triggered when tampering or a malfunction is detected.

Indicator Lamps					
3					Solid 
2	Solid 	Solid 	Solid 	Solid 	Solid 
1	Solid 	Solid 	Solid 	Flashing 	Flashing 
Warning Level	Warning 1	Warning 2	Primary Inducement (Initial)	Secondary Inducement	Final Inducement
Indicator Meaning	First warning that a component has been tampered with or malfunctioned. Appears within 1 hour after the engine has been started. No limitations. Diesel Exhaust Fluid Lamp is SOLID, Amber light warning is SOLID.	Second warning that a component has been tampered with or malfunctioned. Appears 60 to 120 mins after warning 1. No limitations. The Diesel Exhaust Fluid Lamp is SOLID, Amber light warning is SOLID.	<ul style="list-style-type: none"> Primary warning that a component has been tampered with or malfunctioned. Appears 30 mins after warning 2. A 25% reduction in torque and engine speed will be reduced. The Diesel Exhaust Fluid Lamp is SOLID, Amber light warning is SOLID. Cummins Fault codes: FC3714 	Secondary warning that a component has been tampered with or malfunctioned. Appears 75 mins after the primary inducement. There will be a 50% reduction in torque and engine speed will be reduced. The Diesel Exhaust Fluid Lamp will FLASH, Amber light warning is SOLID. <ul style="list-style-type: none"> Cummins Fault codes: FC3714 	Final warning that a component has been tampered with or malfunctioned. Appears 15 mins after the secondary inducement. There is 3 to 4 hours after warning 1 or fault detection is displayed before the final inducement is activated. The machine will be locked at idle and torque will be reduced. The Diesel Exhaust Fluid Lamp will FLASH, Amber light warning is SOLID, and Red STOP warning is SOLID. <ul style="list-style-type: none"> Cummins Fault codes: FC3712
Required Action	DEF/SCR MUST be checked for failed/tampered components and corrected to prevent farther limitations.	DEF/SCR MUST be checked for failed/tampered components and corrected to prevent farther limitations.	DEF/SCR MUST be checked for failed/tampered components and corrected to prevent farther limitations.	DEF/SCR MUST be checked for failed/tampered components and corrected to prevent farther limitations.	DEF/SCR system failure MUST be corrected to gain engine speed and torque back.
NOTE: If adding DEF to the DEF tank does not turn the indicator lamps off or restore engine power, contact a Cummins authorized repair location.					

DEF/SCR System Override

When a DEF/SCR system fault is detected whether it is a DEF level, DEF quality, or tampering/malfunction issue the system can be overridden. If system is overridden the inducement will go back to the primary inducement and limitations. You will then have 30 minutes before final inducement is reached again. During the 30 minutes of the override you will go through the both the primary and secondary limitations. You can perform an override 3 times before the system will lock in the final inducement stage and the issue must be fixed to gain torque and engine speed back. Inducement override cannot be done if final inducement is reached. Inducement override can ONLY be done in the primary or secondary inducement stages. The SCR system override is done through the EIC (dash display).

Final Inducement Overview/Summary

Final inducement is requested by ECM 3 to 4 hours after warning 1 or fault detection for DEF quality and Tampering/Malfunction. For DEF level final inducement is requested 30 minutes after the DEF level gage reads ZERO. When final inducement is requested engine speed is LOCKED to idle, the engine STOP lamp will be ON for two minutes to warn the operator after which engine speed will gradually ramp down to idle speed, engine STOP light remains ON. Once in final inducement engine power will not be restored until the fault condition is resolved. As soon as final inducement is requested inducement override switch functionality is disabled as soon as the STOP lamp is turned ON and derates are applied. After the fault condition has been resolved and the engine is running the ECM shall wait for operator activity to be detected after which the STOP lamp is turned OFF immediately and engine speed is ramped up slowly to commanded engine speed. The Amber light warning is turned OFF within 10 minutes of the engine running after the fault condition is resolved.

PM Warning Level and Required Procedures

During Auto Regeneration Mode when the PM level has built up in the DPF, the regeneration cycle will begin automatically. If the regeneration cycle is interrupted or the regeneration conditions are not satisfied, the buzzer starts sounding and the indicator display changes in response to the PM level in order to prompt the operator to perform the required procedure listed below.

NOTE: Once the regeneration level has been reached, immediately perform the required procedure for regeneration. Interrupting the regeneration cycle or continued operation by ignoring the warning signs may cause DPF and engine damage.



	DPF system status		Required Procedure
PM warning level: 1 Buzzer: Not sounding		The regeneration indicator starts flashing	A specific amount of PM has accumulated in the DPF muffler. Continue to work the tractor to raise the DPF temperature. Continue the work and increase the engine rpm until the indicator turns "OFF". The regeneration cycle begins and continues until cycle is complete then the indicator will turn "OFF".
		The RPM increase indicator starts flashing.	
		The regeneration indicator will stop flashing and remain "ON" constantly.	
PM warning level: 2-1 Buzzer: Sounding every 5 seconds	If the regeneration cycle was interrupted or conditions are not satisfied for regeneration then DPF system is now in Level 2.		
PM warning level: 2-2 Buzzer: Sounding every 3 seconds		The regeneration indicator starts flashing.	Start the regeneration, referring to PM warning level: 1 above. Now the parked regeneration indicator starts flashing and the parked regeneration can also be started. If the regeneration conditions are not met, perform the parked regeneration. For the procedure, refer to Operating Procedure for Parked Regeneration.
		The RPM increase indicator starts flashing	
		The parked regeneration indicator starts flashing.	

Table 3-54: Auto Regeneration Mode		
	DPF system status	Required Procedure
PM warning level: 3 Buzzer: Sounding every 1 second Engine output: 50%	 <p>The engine warning indicator starts flashing.</p>	<p>If the regeneration fails in the warning level 2:</p> <p>Immediately discontinue working the tractor and begin the parked regeneration cycle process. For the procedure, refer to Operating Procedure for Parked Regeneration. At this PM warning level, the Auto Regeneration Mode does not function. If the tractor is operated further, the regeneration cycle will be disabled.</p>
	 <p>The parked regeneration indicator starts flashing.</p>	
PM warning level: 4 Buzzer: Sounding every 1 second Engine output: 50%	<p>If the parked regeneration is interrupted or the tractor is continuously operated in the warning level 3:</p>	
PM warning level: 5 Buzzer: Sounding every 3 seconds	 <p>The engine warning indicator remains constantly "ON".</p>	<p>Immediately move the tractor to a safe place and park it there and turn the engine "OFF". Contact your local Kubota Dealer. At this level, never continue to operate the tractor otherwise damage will result to the DPF and engine.</p>

Introduction to Inhibiting, Forcing and Re-enabling DPF Regeneration

By default, the aftertreatment system is enabled and will burn off soot in the diesel particulate filter automatically. While the aftertreatment system is enabled you have the option to inhibit (stop) the regeneration process or to force a regeneration.

See the following pages for instructions.



Inhibiting DPF Regeneration



WARNING



Do not inhibit regeneration more than twice without performing the regeneration process. If the inhibit function is used a third time the Engine Control Module (ECM) will force the engine to shut down and generate a red engine alarm on the display panel. The engine cannot be restarted without the ECM being reprogrammed by an authorized Cummins technician.

Do not inhibit the automatic DPF regeneration process unless regeneration poses a safety hazard. For example, if the high exhaust temperatures might ignite nearby combustible materials, then inhibit the aftertreatment system and drive to a location where it is safe to re-enable the automatic aftertreatment system.

NOTE: Make sure it is safe to postpone the regeneration and necessary to finish working without further interruption before inhibiting regeneration.


NOTE: DPF regeneration must be performed at the earliest possible time and cannot be postponed indefinitely.

The INHIBIT Mode (1) is available if the aftertreatment system is enabled.

To inhibit DPF regeneration:

1. Press the Scroll button (2) on the EIC dash until the INHIBIT is highlighted.
2. Press the Select button (3).
3. The aftertreatment system is now temporarily stopped.
4. Re-enable the aftertreatment system. See next page.

To return to the top screen at any time, use the Scroll button to select Back (4).



Forcing DPF Regeneration



WARNING



Make sure the exhaust pipe is not directed at any surface or material that can combust due to exposure to high exhaust temperature.


A forced regeneration is also referred to a “parked” or a “manual” regeneration.

The Forced Regeneration Mode (1) is available if the aftertreatment system is enabled and the DPF Lamp will be on and tractor at idle. The tractor will go to 1 000 rpm meaning and the throttle can not be touched or it will jump out of regen.

To force a DPF regeneration:

1. Engage the parking brake. Make sure the engine is running.
2. If the aftertreatment system was inhibited, re-enable automatic mode.
3. Press the Scroll button (2) on the EIC dash until FORCED is highlighted.
4. Press the Select button (3). The aftertreatment system will now burn off soot in the diesel particulate filter. Once a forced regeneration is complete, the DPF system will return to automatic (enabled) mode.

To return to the top screen at any time, use the Scroll button to select Back (4).



NOTE: To perform forced regen. Clean request must be active (DPF lamp on), park brake on and tractor at idle.

NOTE: If throttle is touched, forced regen will be aborted.

Auto Regeneration Mode



WARNING



Make sure the exhaust pipe is not directed at any surface or material that can combust due to exposure to high exhaust temperature.

The Auto Regeneration Mode (1) is available if the aftertreatment system is enabled.

To automatic a DPF regeneration:

1. Engage the parking brake. Make sure the engine is running.


NOTE: (Make sure that the DPF INHIBIT switch lamp is  "OFF".)

NOTE: Switch lamp OFF: Auto Regeneration Mode activated.

NOTE: Switch lamp ON: Regeneration Inhibit Mode activated.

2. If the aftertreatment system was inhibited, re-enable automatic mode.
3. Press the Scroll button (2) on the EIC dash until Auto Regeneration is highlighted.
4. Press the Select button (3).
5. When the regeneration indicator  starts flashing: A specific amount of PM has built up in the DPF.
6. Continue to operate the tractor and the regeneration process will begin automatically, make sure the working place is in a safe area as DPF and exhaust temperature will rise.

To return to the top screen at any time, use the Scroll button to select Back (4).



NOTE: If the Auto Regeneration Mode is selected, DPF regeneration may not begin because system requirements have not been satisfied.

Headland Management System

The purpose of the Headland Management System (HMS) is to reduce the number of actions performed by the operator while turning the vehicle at the end of the field. This is accomplished by recording the actions performed during the first turn and then replaying those actions during subsequent turns.

The HMS system has 2 main functions: recording and playback. In recording mode, eligible operator commands are stored in HMS memory. During playback, the stored commands are read from HMS memory and executed exactly as if they had been performed by the operator. The operator always has full control over the vehicle. New commands issued by the operator during playback will override the commands issued by the HMS.

Every sequence of commands stored in HMS memory is split into 2 stages: exit and enter. This 2-stage approach allows the operator to perform turns with different lengths or at varying speeds.

The recording process begins when the operator selects a sequence (A) and ends when the operator saves the recording (F). The exit stage occurs between (B) and (C), the enter stage occurs between (D) and (E).

Operating Restrictions


The HMS is designed only for operation in the field while the operator has control of the tractor. Several built-in restrictions in place prevent misuse of the HMS. Recording or playback will stop if any of these conditions are not met:

- The operator must be in the seat.
- The engine must be running at 900 rpm or higher and the tractor must be traveling at 0.5 – 10.0 km/h (0.6 – 6.2 mph).
- The parking brake and service brake must not be engaged.
- The transmission shift lever must be in forward.

NOTE: Engaging the inching pedal terminates the HMS system.

- Transmission auto shift mode must not be engaged.

The operator can also stop playback or override a command at any time by pressing the trigger button or any of the sequence buttons.



Preprogram Operating Procedure sample

1. Press the field-out button (1) when you reach the headland, the steps (A) thru (D) are carried on in sequence.
2. After swiveling the machine, press the field-in button (2) the steps (E) thru (H) are carried on in sequence.





Table 3-55: Headland Operating Example

Field out	
A	Implement (UP)
B	PTO (OFF)
C	Differential lock (OFF)
D	4WD (OFF)
E	4WD (ON)
F	Differential lock (ON)
G	PTO (ON)
H	Implement (DOWN)


- (I) - Field In
- (J) - Field Out



Headland Management System Display Icons

The following icons are displayed on the monitor when HMS is enabled. Refer to Headland Management System on "Headland Management System" on page 3-201.

Icon	
1	Headland Management System lock indicator
2	Program code display indicator
3	Headland Management System lock/unlock switch
4	Program select switch



Headland Management System Settings

Before recording this program, read Table 3-57 below to confirm programmable actions.


Table 3-57: Recordable Program				
Type of work	Program select switch	Program	Indicator	
A	Code: I	Field out	Indicator "I" lights up	 is displayed and indicates recording
	Code: II	Field in	Indicator "II" lights up	 is displayed and indicates recording
B	Code: I	Field out	Indicator "I" lights up	 is displayed and indicates recording
	Code: II	Field in	Indicator "II" lights up	 is displayed and indicates recording

Preparations for recording the program

The program consists of 2 different types of operation, "Field in" and "Field out". The recorded entries can be overwritten any number of times.

1. Touch the right half of the Headland Management System lock/unlock switch (3) to unlock the program. A touch on the left half gets the program locked. When the program is unlocked, the Headland Management System lock indicator (1) goes off.
2. Using the program select switch (4), choose the program code "I". Every time the select switch is touched, the program code alternates among "I, II, "I" and "II" in that order.


The program code display indicator (2) lights up interlocked with the select switch (4).



Headland Management System Recording Icons


The following icons are displayed on the monitor when HMS is in recording mode. See Table 3-58.

Icon	
1	Headland Management System lock/unlock switch
2	Program select switch
3	Record switch
4	Indicator
5	Headland Management System lock indicator
6	Program codes " indicator
7	Subcategory icon
8	Pre-program lead time
9	Pre-program travel distance



Recording Program

1. Make sure the Headland Management System lock indicator (1) is off.
2. Using the program select switch (2), be sure that the program code "I" (Field out) is selected.
3. Touch the left half of the automatic record switch (3) and the indicator (4) of this switch lights up to show that the program is ready to be recorded.
 - Carry out actual work in accordance with the field-out operation procedure to record in the program.
4. In the monitor's LCD screen, the subcategory icons (5) get displayed one by one according to the program recording order.
 - If the tractor stops and the procedure is still used, the interrupt duration is recorded as lead time (6). If the tractor travels and the procedure is continued, the distance (7) is recorded.
5. With the field-out operating procedure completed, touch the right half of the record switch (3) to end the recording procedure.
 - Now the field-out operating procedure has been recorded.
6. Using the program select switch (2), choose the program code "II" (Field in).
7. Record the field-in operating procedure.
 - Now the recording for both the program codes "I" and "II" is completed.




HMS Delete Program Icons

The following icons are displayed on the monitor.
See Table 3-59.


Table 3-59: Delete Program Icons	
Icon	
1	Headland Management System lock/unlock switch
2	Program select switch
3	Delete switch
4	Edit switch
5	Scroll switch (DOWN)

Table 3-59: Delete Program Icons	
Icon	
6	Scroll switch (UP)
7	Record switch
8	Headland Management System lock indicator
9	Program code indicator
10	Subcategory icon



Deleting Program

1. Make sure the Headland Management System lock indicator (1) is off.
2. Using the program select switch (2), choose the program code to delete.
3. To delete the entire program, touch the delete switch (3). (The deleting can also be done by turning on the record switch (4) first and then immediately turning it off.)
4. To delete part of a program:
 - Select the program you want to delete a step from by using the program select button (2).
 - Select the step you wish to delete by using the scroll up and down switches (5 and 6).
 - Press edit button (8) to access step editing.
 - While in step editing, press the delete button located on the right side of screen. See page 3-214 for image button (6).




HMS Modifying Program Icons

The following icons are displayed on the monitor.
See Table 3-60.

Icon	
1	Headland Management System lock/unlock switch
2	Program select switch
3	Delete switch
4	Edit switch

Icon	
5	Scroll switch (DOWN)
6	Scroll switch (UP)
7	Record switch
8	Headland Management System lock indicator
9	Program code indicator
10	Subcategory icon




HMS Modifying PTO to Differential Lock Program Icons

The following icons are displayed on the monitor. See Table 3-61.

Table 3-61: Modifying PTO to Differential Lock Program Icons

Icon	
1	PTO-related main category icon
2	Subcategory icon
3	Save switch
4	Cancel switch
5	Distance/time select switch
6	Delete switch
7	Lead time icon (Timer)




HMS Modifying Program

Example: Modifying the lead time for the PTO shaft to stop from the current 2-second entry to a 5-second entry.

1. Make sure the Headland Management System lock indicator (1) is off.
2. Using the program select switch (2), choose the program code to modify.
3. Using the scroll switch (3 or 4) to select the PTO-related subcategory icon (5) to modify. Then touch the edit switch (6).

 - Now the following editing screen appears.



4. On the editing screen, the PTO-related main category icon (1) and subcategory icon (2), selected in the above step 3, are automatically displayed. Refer to


- Make sure the lead time icon (timer) (3) is on. Then touch this icon.

5. Enter a new lead time (5 seconds in this example) and save the entry using the Numeric Keypad.

NOTE: To change the lead time to the pre-program distance, touch the distance/time select switch (4). The lead time icon (3) changes to the distance icon. The steps hereafter are the same as for the lead time setting.

6. Touch the save switch (5).


- The "Change settings. Are you sure?" message appears.
- If "YES" is selected, the program will be modified and the previous screen will show up again.



HMS Modifying PTO to Differential Lock Program Icons

The following icons are displayed on the monitor. See Table 3-62.


Icon	
1	PTO-related main category icon
2	Main category scroll switch
3	Save switch
4	Cancel switch
5	Subcategory icon
6	Subcategory scroll switch
7	Pre-program distance icon
8	Distance/time select switch




HMS Modifying Differential program to PTO program

Example: Switching between the PTO program and differential lock program

1. Make sure the Headland Management System lock indicator (1) is off.
 2. Using the program select switch (2), choose the program code to modify.
 3. Using the scroll switch (3 or 4) to select the PTO-related subcategory icon (5) to modify. Then touch the edit switch (6).
- Now the following editing screen appears



4. On the editing screen, the PTO-related main category icon (1) and subcategory icon (2), selected in the above step 3, are automatically displayed
 - If “YES” is selected, the program will be modified and the previous screen will show up again.
5. Using the main category scroll switch (2), select the differential lock icon.
 - The subcategory icon (3) also changes itself to the differential lock icon.
6. Using the subcategory scroll switch (4), select the differential lock OFF icon.
 - (If the lead time icon stays on, change it to the pre- program distance icon with the distance/ time select switch (6).)
7. Make sure the pre-program distance icon (5) is on. Then touch this icon.
 - (If the lead time icon stays on, change it to the pre- program distance icon with the distance/ time select switch (6).)
8. Using the appearing "NUMERIC KEYPAD", enter a new distance, for example 3.0 m (10 ft) and save the entry.
9. Touch the save switch (7).
 - The "Change settings. Are you sure?" message appears.
10. To select the differential lock subcategory icon touch the edit switch (5). And use the scroll switch (3 or 4).
11. The editing screen shows up. Now change the differential lock program to the PTO program.



Loader Introduction



WARNING



Careless or incorrect use of the loader/implement may result in serious injury or fatality for the driver or others. Observe the safety instructions.

The information provides the commissioning, operation and maintenance of agricultural loaders. Visit a Kubota dealer for additional information.

Read and apply the information to use the machine in a safe manner in combination with short stoppages.

Read the information thoroughly before starting the machine.

IMPORTANT: *The loader and loader subframe combination is designed for a specific tractor model. Contact your dealer for the correct combination for a specific tractor model. Do not install incorrect combinations.*

Loader Identification

NOTE: Loader identification data shall be supplied to the dealer when requesting parts or service. This data is also needed to identify the equipment if it is ever stolen.

Each loader has an identification plate (1) with an identification number. The plate is located on the inside of the left arm.

1. The plate specifies:
 - Product: Machine name
 - Type: Type/model
 - Made by: Complete address of manufacturer and country of manufacture.
 - Ref. No.: Reference number for loader
 - Serial No.: Serial number for loader
 - Date: Date of manufacture
 - Weight: Loader weight without implements, according to the factory delivery specification.

The type , serial number and date of manufacture must always be quoted during service questions or when spare parts are needed.

Cylinders, valves, control cables and hoses are equipped with machine signs or punched/printed order numbers.

Description And Definitions

Not all accessories fit all loaders. Please contact your dealer for information on compatibility with your loader.

Not all accessories are available on all markets.

Description

The front loader is adjusted to:

- The equipment installed on wheel-bound agricultural and forestry tractors.
- The equipment can handle various certified implements for lifting, carrying, cutting, scraping, grading, sweeping and plowing.



WARNING

Risk of crushing, pinching, tipping. In the event that one of the loader's hoses ruptures, the loader/ implement/load can fall down in an uncontrolled manner. If a pipe ruptures, correct the problem immediately according to section.




When replacing parts, only use original spare parts in order to restore the machine to its original design. Clear the land according to applicable requirements/legislation for the country or area where you are located.

IMPORTANT: *Faults in the power supply to the loader's electrical and/or hydraulic systems may mean that certain functions cannot be activated. For example: Raising the loader, opening the implement, third and fourth hydraulic functions etc.*

Loader Operating Status Icons

The following chart below is a list of loader operating icons.

- Boom neutral (1)
- Boom raising (2)
- Boom lowering (3)
- Boom floating (4)
- Bucket neutral (5)
- Bucket dumping (6)
- Bucket rollback (7)
- 3rd function neutral (8)
- 3rd function retract (9)
- 3rd function extend (10)



Setting the Loader Control Valve


In the figure below, the settings of the loader control valve (if equipped) (1) can be checked.

- To modify any of the settings, touch the “graph” of the loader control valve. The “detailed settings of loader control valve” screen will appear.

How to use the screen

- The preset oil flow rate (2) is displayed.
- The loader operating status (3) is indicated with the icon shown.

- Lever lock indicator (4)
- Accumulator indicator (5)
- Discharge rate from raising (6)
- Discharge rate from lowering (7)
- Discharge rate from dumping (8)
- Discharge rate from rollback (9)
- Discharge rate from 3rd function (retract) (10)
- Discharge rate from 3rd function (extend) (11)




Detailed Settings of Loader Speed

Each of the action can be individually preset in detail but only one can be set for priority flow.

1. To set accumulator, touch the switch (1).
2. Touch the switch (2), and the previous screen reappears.

Setting the oil flow rate

3. To adjust the oil flow rate for the loader, use the “Plus (+)” switch (3) and the “Minus (-)” switch (4).
4. Raise the percentage to increase the oil flow rate.



Valve Lock





WARNING



Do not utilize the valve lock for machine maintenance or repair. The valve lock is to prevent accidental actuation when implement is not in use or during transport.

The control valve is equipped with a valve lock feature. The control valve is locked in the neutral position. The lock is not intended and will not prevent a leak down of the implement during the period of storage.

- Lighting (locked) (1)
- Off (Unlock) (1)
- Selection button for remote control valve and loader (2)
- Lever lock button (3)
- Loader mode indicator (4)
- Remote control valve mode indicator (5)



Tractor Towing



WARNING



When using a chain, attach the chain with the hook open side facing up. If the hook slips, it will drop down instead of flying up.



CAUTION



Do not tow the tractor at a speed of more than 8 km/h (5 mph). Steering is much slower and the steering wheel is hard to turn when the engine is not running.

NOTICE

Only tow the tractor a short distance, such as out of a building. Do not tow it down roadways or as a method of transport.

NOTICE

Haul the tractor with all four wheels on a flatbed trailer or truck for transport purposes.

Use a chain or cable of sufficient capacity and length if towing the tractor is necessary. Tow the tractor from the rear using the drawbar or 3-pt hitch only. Have an operator steer and brake the tractor.

Observe the following to avoid damage to the transmission or other components that turn but are not lubricated during towing:

- Only tow a short distance.
- Keep speed below 8 km/h (5 mph).
- Run the engine to provide lubrication, power steering and power brakes if possible.

NOTE: Mechanical front wheel drive (MFWD) will be engaged if the engine is not running, regardless of the position of the MFWD activation switch.

Freeing a Mired Tractor



CAUTION



Attempting to free a mired machine can involve safety hazards such as the mired tractor tipping rearward, the towing tractor overturning and the tow cable or tow bar failing and recoiling from a stretched condition.

NOTICE

Always use a low gear and avoid high engine rpm when attempting to free a mired tractor. Also, place the MFWD and differential in the lock mode.

Back tractor out if mired down in mud. If an implement is attached, unhitch the implement and move it away from the mired tractor area. Dig mud from behind the rear wheels. Place heavy boards behind the wheels to provide a solid base and try to back the tractor out slowly.

Pull rearward with another tractor if tractor cannot be freed under its own power.

NOTICE

The drawbar at the rear of the tractor is the correct point to connect a tow cable. Connect the tow cable to the drawbar of the mired tractor and pull rearward.

Connection of the tow cable to a different point can cause damage to the tractor or its frame.

Do not use a tow cable to attach two tractors together to try to pull a load that is more than the capacity of one tractor.

Inspect the tow cable and the drawbar pin for wear before use. Replace if necessary.

Remove all front weights from the mired tractor prior to pulling.

Jacking Points




CAUTION



Always jack on a stable flat surface, ideally a concrete floor. Block all tractor wheels when jacking and use only approved safety stands.

- Secure the tractor on firm and levelled ground only.
- Secure using suitable jack stands. Jack stands are available from a Kubota dealer.
- To jack up the vehicle from the rear, apply vehicle jacks at points (A).
- To jack up the vehicle from the front, apply vehicle jacks at points (B).




Transporting the Tractor

NOTICE

Do not chain around the four-wheel drive shaft, steering cylinders, front wheel drive axle or other components that could be damaged by contacting the chain or by heavy loading

Haul the tractor with all four wheels on a flatbed trailer or truck.

- Securely chain the tractor to the transporter
- Use wheel blocks to prevent rolling movement
- Use the tie down brackets (1) provided on the front axle of the tractor
- Use the drawbar or drawbar cage for a rear tie-down point.



This Page Is Intentionally Left Blank.

Section 4: Hydraulic Operation – Contents

Hydraulic System Overview	.4-2
Standard Flow and High Flow Pump System	.4-2
Standard Flow Pump System Overview	.4-3
Low-pressure Hydraulic System	.4-3
Implement Hydraulics	.4-3
Steering/Brake Systems – With Trailer Brake	.4-3
Steering/Brake Systems – Less Trailer Brake	.4-3
Hydraulic Oil Filters	.4-4
Transmission Oil Level	.4-4
Steering System Overview	.4-5
Brake System Overview	.4-6
Four Wheel Drive Brakes	.4-6
Hydraulic Brake System	.4-7
Remote Valve Controls	.4-8
Connecting and Adjusting Couplers	.4-9
Connecting Single-acting Cylinders	4-10
Connecting Double-acting Cylinders	4-10
Connecting and Operating Continuous Flow Hydraulic Equipment Operation	4-11
Hydraulic Motor Application	4-12
Operating the Hydraulic System	.4-13
Remote Control Valve Switch	4-14
Operation of remote valves 1 and 2	4-14
Securing the priority flow	4-14
Operation of remote valves 3 to 5	4-15
Joystick for Remote Control Valve and Loader	4-15
Setting of Remote Control Valves	4-16
Locking and unlocking all the remote control valves	4-16
Locking and unlocking each of the remote control valves	4-16
Remote Valve Settings	4-17
Hydraulic Remote Control Valves Icons	4-19
Detailed Settings of Remote Control Valves	4-20
Setting the oil flow rate and timer	4-20
Operate the Hydraulic System Step 3 of 3: Operate the Hydraulic Levers	4-21
Drivability Icon Settings	4-24
Differential Lock Setting	4-25
Front Wheel Drive Setting	4-26
Front Suspension Setting	4-27

Hydraulic System Overview

KUBOTA M8 tractors are equipped with 117 lpm (31 gpm) standard pump or 159 lpm (42 gpm) high flow pump hydraulic system. Both consist of low and high pressure circuits that get their oil from either the transmission and rear axle housing reservoir oil or the right side hydraulic tank.

The low-pressure hydraulic circuit delivers hydraulic oil from the rear axle sump to the transmission hydraulics, brake system and external line. The external line supplies hydraulic pressure to the PTO clutch, PTO Brake, MFWD clutch and differential lock.

Standard Flow and High Flow Pump System

The 118 lpm (31 gpm) standard flow pump and The 166 lpm (44 gpm) high flow pump system supplies oil to the rear implement valve, front and rear 3PT and front end loader (if equipped). Both the standard and high flow pumps receive oil from a separate hydraulic tank.

The hydraulic pumps are mounted to a drive housing that is driven off the PTO through shaft

NOTE: Liter to gallon conversions are given in U.S. gallons. One U.S. gal \approx 3.8 L.



WARNING



During normal operation, the tractor may pressurize hydraulic fluid to extreme levels. Escaping fluids under high pressure can penetrate the skin and cause serious and life threatening injury.

- Never use your hands to check for fluid leaks. Use a piece of cardboard or paper to search for any suspected leaks.
 - Always shut off the engine and relieve any residual pressure before connecting or disconnecting any hoses.
 - Get immediate medical attention if any fuel, oil or hydraulic fluid penetrates your skin.
-

Standard Flow Pump System Overview

This section opposite provides an overview of the tractors that are equipped with a standard flow, hydraulic system.

Low-pressure Hydraulic System

The hydraulic system is split into 2 sections: the implement hydraulic system and the steering/brake systems. The implement hydraulic system is a high-pressure system that powers the implement valve, suspension systems, 3PT hitch systems, and the front end loader. The steering/brake system powers the steering (including autosteer), the service brakes, and the trailer brakes.

Implement Hydraulics

Flow for the implement hydraulics is provided by the main piston pump. The pump drive is connected directly to the engine output, via the transmission. The pump draws oil directly from the hydraulic reservoir, and outputs flow to the implement valve. The optional features (Cab/Axle suspensions, front end loader, front 3PT hitch) have their supplies teed in directly at the pump outlet.

The implement valve and all optional features provide load sense signals to the piston pump via the load sense manifold. This manifold acts as a multi-way shuttle valve to output the highest load sense signal to the piston pump. It also leaves the load sense path open to the implement valve, as the implement valve acts as the drain for trapped load sense pressure.

The returns from the implement valve and all other optional features are returned to the cooler bypass manifold. From this manifold, flow is directed to the hydraulic cooler. Cool oil returns to this manifold from the cooler, goes through the return filter and back to the reservoir.

Steering/Brake Systems – With Trailer Brake

Oil for the steering and brake system is supplied by the transmission. The service brake supply is provided by the transmission clutch supply circuit, and the steering and trailer brake are supplied by the dedicated steering pump.

The steering pump provides oil to the priority/charge manifold via the high pressure steering filter at the pump outlet. In this priority valve, priority is given to the steering system. The priority cartridge works to maintain a pressure 160 psi higher than the steering load sense at the steering valve inlet. Extra flow from the priority valve, when not required

by the steering valve, is directed to charge the accumulator that is used to provide oil to the trailer brake valve. The accumulator will charge up to 2150 psi, at which point extra flow from the priority valve will be provided and open directly back to the tank. When accumulator pressure drops to 1700 psi, the accumulator will be recharged.

The priority valve also contains a pump outlet relief valve, set to 2300 psi, to protect the pump from over-pressure situations. It also contains a 2000 psi load sense relief, which limits load sense pressure from the steering valve to 2000 psi, resulting in a maximum steering valve inlet pressure of 2160 psi.

The service brake valve has a 290 psi boost signal provided by the transmission, via a check valve and an accumulator. The check valve and the accumulator serve to maintain a supply of boosted oil to the brake valve in the event of a loss of transmission pressure.

Steering/Brake Systems – Less Trailer Brake

Oil for the steering and brake system is supplied by the transmission. The service brake supply is provided by the transmission clutch supply circuit, and the steering system is supplied by a dedicated steering pump.

The steering pump provides oil directly to the steering valve, via the high pressure steering filter at the pump outlet. The steering valve is an open center design, so any unused steering input flow is directed back to the transmission reservoir.

The steering valve includes a 2300 psi relief valve, which will protect the steering pump and valve from over-pressure situations, such as when the steering is dead-headed.

The service brake valve has a 290 psi boost signal provided by the transmission via a check valve and an accumulator. The check valve and the accumulator maintain a supply of boosted oil to the brake valve in the event of a loss of transmission pressure.


Hydraulic Oil Filters

The transmission oil filter (1) is located on the right side of the range gear part of the transmission near the bottom and receives oil from the gear transmission pump then passes it to the transmission hydraulic block.

The hydraulic system oil filter (2) is located to the front of the bracket and receives oil from the gear charge section pump then passes the oil to the intakes of the piston pumps.

The transmission filter has a 9 bar (131 psi) and the hydraulic filter by-pass has a 6 bar (85 psi) (high and standard flow) on pump has to prevent oil starvation in the case of filter blockage. The bypass valves are fitted with sensor switches that send a signal to the EIC when the filter bypass is activated and the system warning lights are illuminated.


Refer to Replace the Transmission and Hydraulic Oil Filters in Section 5: Lubrication and Maintenance for more information.



Transmission Oil Level

The transmission and rear axle are a common reservoir.

The fill tube on the transmission (3) is located at the right rear of the tractor.



The sight glass (4) indicating oil level in the rear axle and transmission is located beside the PTO stub shaft cover.

Refer to Change the Hydraulic Oil in Section 5: Lubrication and Maintenance for more information.



Steering System Overview

M8 tractors have a hydraulically powered steering system. This system is composed of a steering control valve mounted at the front of the cab on the outer side of the main console pedestal housing and mechanically connected to the steering column inside the cab and a steering cylinder located at the front of the tractor.

The steering system oil pressure is provided from the pump farthest from the drive of the tandem gear pump stack and travels through the steering oil filter. The pressurized oil from filter enters the steering control valve and proportioned and directed to the left or right side of the double acting steering cylinder based on the position and movement of the steering column.

Brake System Overview

M8 tractors are equipped with hydraulic-assisted power brakes. The brake system consists of the following components:

- Brake accumulator
- Brake pedals
- Power brake actuator valve
- Hydraulic lines
- Rear-axle brake assemblies

NOTE: The hydraulic assist only functions with the engine running. With the engine off the brakes will still function but greater pedal effort will be required. Use both the parking (emergency) brake and the service brake pedals if the engine is not running.

The service brake pedals operate the brake valves to apply direct hydraulic pressure to the rear axle brakes. The use of hydraulic boosters in the power brake valve assembly ensures only light pedal effort is required to operate the brakes.

A brake accumulator, mounted on the top of the transmission maintains a minimum pressure of 1207 kPa (175 psi) to the brake circuit.

The brake system consists of separate left and right wheel brake circuits operated by the left and right service brake pedals (2). Each service brake pedal operates a master cylinder and hydraulic booster in the power brake valve (3), allowing the left and right brake circuits to operate independently to assist with turning in tight spaces or to work in tandem for maximum braking effect.

The system balances the pressure to the left and right rear axle brake assemblies to compensate for uneven brake wear with the service brake pedals connected together.

Four Wheel Drive Brakes


M8 tractors are classified as Front Wheel Assist vehicles.

The front wheel assist is automatically activated so that both front and rear wheels assist in braking when the service brake pedals are applied.

NOTE: MFWD automatically engages when the parking brake is applied with the engine running regardless of the MFWD switch position. MFWD also automatically engages to assist in braking when both service brake pedals are applied.



WARNING



- Never leave the operator's seat without first bringing the tractor to a complete stop and applying the parking brake.
- Do not use the tractor if either the service brakes or the parking brake do not function properly.
- Do not use the transmission to keep the tractor stationary when parked. Always use the parking brake.
- Apply the parking brake whenever the tractor is not in operation.




WARNING



Always lock the service brake pedals together when traveling on the highway or when a hydraulically braked trailer is attached. Do not use the brakes to assist in high speed turns.

Hydraulic Brake System



The hydraulic service brake operates in conjunction with the transmission circuit within the tractor hydraulic system.

A fixed displacement gear pump draws oil from the reserve and provides flow to both brake circuit and a transmission circuit.

The gear pump provides flow to the transmission where the pressure is limited by the transmission control relief valve. The oil then flows unimpeded through the transmission valve and on into a junction where it tees between the service brake valve, an accumulator and a low pressure switch. If the pressure in this circuit falls below 15 bar (217 psi), the low pressure switch will open and turn on a warning light on the dash.


When the foot brake pedal is depressed, oil is forced from the valve to the rear service brakes (6) via the right and left brake lines. Pressure in the valve is also used to assist pedal effort.

Remote Valve Controls

The external hydraulic power can be taken out of up to 5 segments. Depending on different-destination models and mounted options, however, the number of ports varies. In this manual, the 5-segment system is taken as an example.

Carefully check the relation between each valve and control switch before connecting the hydraulic hoses.

- Remote control valve switch 1 (1)
- Remote control valve switch 2 (2)
- Remote control valve switch 3 (3)
- Remote control valve switch 4 (4)
- Remote control valve switch 5 (5)
- If Loader is installed - Remote control valve switch (5)/Loader joystick.



Connecting and Adjusting Couplers



WARNING



- Always shut down the engine and relieve any residual pressure before connecting or disconnecting any hoses.
- Get immediate medical attention if any fuel, oil or hydraulic fluid penetrates your skin.

Each control valve has a pair of self-sealing, quick couplers to facilitate remote cylinder connection. These couplers also permit the disconnection of coupled hoses from an implement in an event that the implement accidentally becomes detached from the tractor drawbar.

The couplers will accept standard 12.7 mm (0.5 in) SAE or ISO tips. The couplers can be connected or disconnected under pressure. Disconnect pressure is proportional to system pressure. Increased system pressure will require increased force to disconnect the couplers.


To connect a remote cylinder hose:

1. Open the coupler dust cover (1).
2. Clean, then insert the tip making sure the tip is correctly seated.

Activate the remote valve to supply hydraulic pressure which will complete the hydraulic coupling of the tractor and implement.

Move the applicable control switch to the float position with the engine running to relieve pressure of coupled hoses from an implement to the tractor valve. Use the implement locks to support the equipment when pressure is relieved from the cylinder(s) when applicable.

Shut the engine off with the control lever still in float. After the engine is shut down return the control lever to the neutral position. The couplers can now be connected or disconnected with minimal pressure and effort.



Connecting Single-acting Cylinders



WARNING



- Always shut down the engine and relieve any residual pressure before connecting or disconnecting any hoses.
- Get immediate medical attention if any fuel, oil or hydraulic fluid penetrates your skin.

Connect the hose from a single-acting cylinder to the extend coupler (1) on the lower side of desired remote control valve.

Pull the control lever back to the extend position to extend a single-acting cylinder.

Manually return the lever to the neutral position to stop the cylinder before it is fully extended.


Move the lever fully forward to the float position to retract a single-acting cylinder.

NOTE: Always use the float position to lower a single-acting cylinder. The retract position is for double-acting cylinders only.

Connecting Double-acting Cylinders

Connect the feed hose from a double-acting cylinder to the extend coupler (1) on the lower side of the desired remote control valve and the return hose to the retract coupler on the top side of the valve (2). Pull the control lever back to the extend position to extend a double-acting cylinder.

Push the control lever forward past neutral to the retract position to retract a double-acting cylinder. Further forward movement of the lever will select float which will allow the cylinder to extend or retract freely. This feature is very helpful when carrying out work with equipment such as scraper blades and loaders.



Connecting and Operating Continuous Flow Hydraulic Equipment Operation

Connect continuous flow hydraulic equipment (e.g., hydraulic motors) with the pressure hose connected to the retract coupler (1) and the return hose connected to the low pressure return circuit (2).


Use the flow control to regulate the motor speed. Adjust the flow of the connected remote control valve to regulate the orbit motor speed.

The motor will be stationary when in the remote control valve lever fully forward in the float position. The hydraulic motor will operate if the lever is pulled back to the retract position. Move the lever from the retract position to the float position to stop the motor. In the float position, the motor will be able to stop slowly preventing damage from occurring.

NOTE: The remote control valve lever must not be moved rearward to the neutral or extend positions as damage to the equipment may result when operating continuous flow equipment.

Observe the following to further protect the tractor and equipment.

- Do not open any by-pass valve in the equipment or motor. Use the flow control to regulate the rate of flow or speed of the motor.
- Do not hold the remote control valve lever to operate the equipment.
- Operate continuous flow equipment at the highest flow setting (by use of the flow control) and lowest engine speed that will give the required machine performance and speed to ensure optimum hydraulic oil cooling.



Hydraulic Motor Application

NOTE: The hydraulic remote valves on the tractor provide an open center supply and return.

1. Use hydraulic motors designed for open center or pressure/flow load compensating hydraulic systems only. Do not use a hydraulic motor designed for closed center hydraulic systems unless it is adapted for use by removing the inlet restrictor.
 2. Rating: Hydraulic motors up to 76 L/min (20 gpm) at 15513 kPa (2250 psi) can be used.
 3. Make sure the hydraulic motor does not have restrictors in the ports or fittings.
 4. Hydraulic motors less than 38 L/min (10 gpm) may be equipped with 12.7 mm (0.5 in) ID hoses and standard (ASAE/SAE/ISO) couplers.
 5. Connect hydraulic motors greater than 38 Lpm (10 gpm) with 19 mm (0.75 in) hoses and standard (ASAE/SAE/ISO) couplers to prevent excessive restriction and heat generation.
 6. It is recommended that the low pressure return line kit be installed. The use of the low-pressure return circuit will reduce back pressure in the remote hydraulic return line which will result in more efficient hydraulic motor operation. The low pressure return circuit can also be used in applications where low return oil pressure is desired to improve implement operation such as with orbit motor case drain lines or implement mounted hydraulic control valves.
-

Operating the Hydraulic System



WARNING



Make sure all bystanders are clear of the tractor before operating electro-hydraulic remote (EHR) valves.

Before traveling on public roads, be sure to set the remote control valve lock button (1) to avoid accidentally dropping the implement. The indicator stays on while in the lock status.

Use the display monitor (1) to set the hydraulic flow rate (hydraulic pressure) to and operation mode of, the implement valve.

Use the hydraulic levers to control the movement of the implement.

This section begins by detailing the operational relationship between the hydraulic levers, display monitor, remote couplers. Instructions are then provided as follows:

- Step 1 of 3: Activate the hydraulic levers.
- Step 2 of 3: Adjust the hydraulic flow rate limit and operation mode of each valve section using the display monitor.
- Step 3 of 3: Operate the hydraulic levers.




Remote Control Valve Switch

The remote control valve switches (1) direct pressurized oil flow to the implement hydraulic system.

Operation of remote valves 1 and 2


Each switch can be set at 4 positions. If the switch is held at the FLOAT or DETENT position, the switch is held at that position.



Securing the priority flow

Oil is preferentially fed from the hydraulic pump to a specified remote control valve.


Once the priority flow is ensured, the indicator (2) lights up.



Operation of remote valves 3 to 5

Each remote valves switch (1) can be set to 4 positions.

- (A) Extend
- (B) Retract
- (C) Float
- (N) Neutral
- (D) Detent



Joystick for Remote Control Valve and Loader

Using the joystick, the loader and the hydraulic remote control valves (5th) can be operated.


Each time you press the selection button (2), the remote control and the loader mode switch and the respective indicator lights up.

If no such operation is needed, lock the joystick with its lock button (3).

- (A) Extend
- (B) Retract
- (C) Float
- (N) Neutral

NOTE: Moving the joystick diagonally provides flow for two valves simultaneously in the different combinations illustrated.

NOTE: If the front loader valve is not installed, the loader mode indicator (4) and remote control valve mode indicator (5) are blinking. When the valve is installed, the indicator blinking is stopped.



Setting of Remote Control Valves

All the remote control valves can be preset in detail and their settings can be confirmed.

For the setting procedure, refer to “Remote Valve Settings” on page 4-17.


Locking and unlocking all the remote control valves

Touch the left half of the switch (1) and all the remote control valves are locked and cannot be used for raising and lowering. Touch the right half of the switch and the valves are unlocked.

While the remote control valves are locked, the indicator (2) lights up.

Locking and unlocking each of the remote control valves

Touch any of the remote control valves lock/unlock switches (3) and the relevant remote control valve can be locked and unlocked. (The figure below shows that the 3rd segment is being locked.)



Remote Valve Settings

The hydraulic valves can be locked out using the lock out button (1). This will prevent any accidental hitting of the switch causing the hydraulic valve to move

In the figure below, the settings of all the remote control valves can be checked.

1. To modify any of the settings, touch the relevant valve. The “detailed settings of the selected remote control valve” screen appears.
2. Touch the left half of the lock out button (1) and all the remote control valves are collectively locked and the implement cannot be raised and lowered. In locked status, the indicator (2) also lights up.
3. Press the right half of the lock out button (1) and it unlocks all the valves.

Icon	Description
	The priority flow from the hydraulic pump is set for the first remote control valve.
	The automatic shut off timer of the second remote control valve is set at ON.
	The preset oil flow rate to each implement (remote control cylinder) is displayed. (The third remote control cylinder remains locked, which means that no oil is flowing.)
	The automatic shut off timer (time) of remote control is displayed.
	Valve action status indicator: The oil flow to the implement (remote control cylinder) is indicated with the icon shown below.





Table 4-2: Valve Action Status Indicator	
Icon	Description
	Remote Cylinder - Retract
	Remote Cylinder - Extend

Table 4-2: Valve Action Status Indicator	
Icon	Description
	Remote Cylinder - Float
	Remote Cylinder - Lock
	Remote Cylinder - Lock


- Individual remote control valve lock/ unlock switch (8)
- Valve operating time (9)
- Discharge rate from cylinder (retract) port (10)
- Discharge rate from cylinder (extend) port (11)
- Priority valve indicator (12)
- Timer mode indicator (13)

Hydraulic Remote Control Valves Icons

The following icons represents the individually preset of the selected remote control valve.

Icon	Description
1	Remote control valve operating status indicator
2	Priority flow status indicator
3	Automatic shut off timer indicator
4	Remote Control Valve Number
5	Previous screen resume switch
6	Remote control valve lock/unlock switch

Icon	Description
7	Priority flow status on/off switch
8	Automatic shut off timer on/off switch
9	(+) switch
10	(-) switch
11	Automatic shut off timer control
12	Discharge rate from cylinder (retract) port control
13	Discharge rate from cylinder (extend) port control



Detailed Settings of Remote Control Valves

Each of the valves can be individually preset in detail, but only one can be set for priority flow.

1. Display the valve number (1) to be set in detail.
2. To ensure the priority flow for the valve 1, touch the left half of the priority flow status on/off switch (2). A touch on the right half clears this setting. Once the priority flow is ensured, the indicator (2) lights up and stays on.
3. To set the automatic shut off timer, touch the left half of the automatic shut off timer on/off switch (3). A touch on the right half clears this setting. Once the timer is ensured, the indicator (4) lights up and stays on.
4. To lock the remote control valve, touch the left half of the remote control valve lock/unlock switch (5). A touch on the right half clears this setting.
5. Touch the switch (6) and the previous screen reappears.

Setting the oil flow rate and timer

To adjust the oil flow rate for the implement (remote control cylinder), use the (+) switch (7) and the (-) switch (8).


Raise the percentage to increase the oil flow rate.

The timer may be preset up to 60 seconds.

If the timer is set to (∞), the remote control valve will go into continuous operation.






NOTE: When you have moved the remote control valve switch or lever to the “raise” or “lower” position and then released your hand from the switch or lever, the timer gets activated. When the set time is over, the oil flow to the implement is interrupted. After this stage, the timer can be set only with the switch or lever.

If during an action the switch or lever is moved in the reverse direction, the timer setting is cancelled.



Operate the Hydraulic System Step 3 of 3: Operate the Hydraulic Levers

Each operation mode (continuous, manual and timed) changes the behavior of the hydraulic levers. See Table 4-4 for an overview of the lever positions and operation modes. See the following pages for details.

Table 4-4: Hydraulic Lever Operation Quick Reference				
Float Position	Retract Position	Neutral Position	Extend Position	
				
Symbol: 	Symbol: 	Symbol: N	Symbol: 	Symbol: 
<p>Float: De-pressurizes the hydraulic system connected to the valve section.</p> <p>Float will permit the cylinder to extend or retract allowing equipment such as scraper blades to “float” or follow the ground contour.</p> <p>The “float” position is also used for retracting a single-acting cylinder and for the OFF position for hydraulic motors.</p> <p>To place the valve section in float mode, push the lever all the way forward until it locks into place.</p>	<p>Retract: Places the valve section in retract mode. Use this mode to retract double-acting cylinders or to supply continuous flow to a hydraulic motor. Do not use to retract single-acting cylinders.</p> <p>Manual Mode: Use this mode to manually adjust the flow. Push the lever forward (but not all the way into detent) to supply flow. Release the lever to stop the flow.</p> <p>Timed Detent Mode: Allows the operator to engage a timed detent, which is a set time between when the control levers are activated and when they will automatically return to neutral. Program the detent before use. To start timed retract mode, push the lever forward until it clicks into the detent and release to neutral.</p> <p>Continuous Mode: Use this mode to supply continuous flow to a hydraulic motor. Set the time mode to infinity. There is no lock to get retract into continuous flow.</p>	<p>Neutral: There is no hydraulic flow in or out of the valve section.</p>	<p>Extend: Places the valve section in extend mode. Use this mode to extend single or double-acting cylinders. Do not use the extend position to start a hydraulic motor.</p> <p>Manual Mode: Use this mode to manually adjust hydraulic flow. Pull the lever back to supply hydraulic flow. Release the lever to stop the flow.</p> <p>Timed Detent Mode: Allows the operator to engage a timed detent, which is a set time between when the control levers are activated and when they will automatically return to neutral. Program the detent before use. To start timed extend mode, pull the lever back until it clicks into the detent and release to neutral.</p>	<p>Detent Mode: Set the switch to the “DETENT” position, and it is held at this position unless it is returned to the “NEUTRAL” position. This function is useful for implements that need constant oil feed.</p> <p>Continuous Mode: Do not use the extend position to start a hydraulic motor.</p>

Float Mode

Float mode de-pressurizes the hydraulic system connected to the valve section.


Float will permit the cylinder to extend or retract allowing equipment such as scraper blades to “float” or follow the ground contour.

The “float” position is also used for retracting a single-acting cylinder and is the OFF position for hydraulic motors.

IMPORTANT: Do not hold the lever in the fully extend or retracted position after a remote cylinder has reached the end of its stroke. Doing so will overheat the oil and may lead to failure of hydraulic pump driveline components.

To engage float mode, push the hydraulic lever forward until it locks into position (1).

To disengage float mode, pull the lever back to the neutral position (2).




Lever locked into the float position.

Neutral Mode

If the valve section is in neutral mode then there is no hydraulic flow in or out of the valve section.

- In manual mode, releasing the lever to the neutral position (2) will cause the valve section to enter neutral mode.
- In timed detent mode, the valve section will enter neutral mode if the lever is in the neutral position (2) once the timed detent is complete.
- To correctly place the valve section in neutral mode during continuous flow mode, the operator must first push the lever to the float position (1) and allow the motor to stop before pulling the lever to the neutral position (2).



Lever at the neutral position.

Continuous Flow Mode

NOTICE

Only use continuous flow mode to operate hydraulic motors. Always use the retract position to operate hydraulic motors. Never use the extend position to operate hydraulic motors.




Do not operate the motor by manually holding the hydraulic levers in place or using timed detent mode. If the detent is not working in continuous mode, check the equipment for proper adjustment or contact a dealer for assistance in adapting the equipment to suit the tractor.

Do not use continuous flow mode to operate remote cylinders. When the cylinder has reached the end of its stroke the control lever will not return to neutral and the hydraulic system relief valve will be activated. This will overheat the oil and may lead to failure of the hydraulic and driveline components.

- Use the tractor implement valve flow control (K-monitor) to regulate the motor speed. Do not adjust the flow rate by opening any by-pass valve attached to the equipment or motor.
- If the hydraulic motor is going to be under heavy load, set a low flow rate before startup. Gradually increase the flow once the motor is working. For optimum hydraulic oil cooling, operate continuous flow equipment at the highest flow setting.
- If the flow control is open too far, the 3-pt hitch and other remote valves may slow down or stop. This will ensure that the hydraulic system will only supply the oil demanded by the motor and the pump will not be providing excessive oil flow.

NOTE: Connect the hoses to the remote couplers properly before proceeding.

To supply continuous flow, set time detent to infinity on the remote valve, activate timed detent mode (1) and release to neutral (2). Gradually pushing the lever forward before clicking into the retract will steadily increase the load on the hydraulic motor before continuous flow mode is engaged.



To stop continuous flow mode:

Gradually push the lever forward until it is in the retract position.

1. Push the lever forward into the float position (3).
2. Allow the motor to slow down.
3. To stop the motor, pull the lever back to the neutral position (2).


NOTE: Do not stop continuous flow by nudging the lever past neutral (in either direction) as this will stop the flow abruptly and damage the motor.

Drivability Icon Settings

The following icons are settings for differential lock, front wheel drive and front suspension settings.

Table 4-5: Drivability Setting Icons	
Icon	Description
1	Differential lock indicator
2	Auto differential lock indicator
3	4WD indicator
4	Auto 4WD indicator
5	Front suspension (active) indicator
6	Cab suspension indicator

Table 4-5: Drivability Setting Icons	
Icon	Description
7	Differential lock switch
8	Auto differential lock switch
9	4WD switch
10	Auto 4WD switch
11	Front suspension (block) switch
12	Cab suspension (block) switch




Differential Lock Setting

1. Touch the left half of the differential lock switch (1) and the differential of the full-time front and rear wheels gets locked. The indicator (2) lights up and stays on.
2. Turn off the differential lock switch (1) and the differential gets unlocked and the indicator (2) goes off.
3. Touch the left half of the auto differential lock switch (3) and both indicator lights (2) and (4) lights up. Same procedure for disengaging.

Table 4-6: Automatic Differential Lock Operating conditions

Traveling Speed	4-wheel differential lock
0 to 10 km/h (6 mph)	OFF at 15 ° (Auto only)
10 (6 mph) to 15 kph (9 mph)	OFF at 10 ° (Auto only)
15 km/h (9 mph) and above	OFF (Manual and Auto)




Front Wheel Drive Setting

1. Touch the left half of the 4WD switch (1) and the front and rear wheels are driven. The indicator (2) lights up and stays on.
2. Turn off the 4WD switch (1) and the front-wheel drive is disabled and the indicator (2) goes off.
3. Touch the left half of the Auto 4WD switch (3) and the automatic 4WD and both indicator lights (2) and (4) lights up. Same procedure for disengaging.


Table 4-7: Automatic Front Wheel Drive Operating Condition

Traveling Speed	4-wheel differential lock
0 to 10 km/h (6 mph)	OFF at 18 ° (Auto only)
10 (6 mph) to 20 kph (12 mph)	OFF at 13 ° (Auto only)
20 km/h (12 mph) and above	OFF (Manual and Auto)



Front Suspension Setting

1. The front suspension has the “Block” or “Active” modes.
2. Active mode is like auto mode, when the block switch (1) is pressed to the right and is turned off, the suspension is now in active mode and the indicator light (2) will turn on.
3. Press the block switch (1) to the left and the suspension is now blocked and the indicator light (2) will turn off. The axle will now act like a rigid axle.



This Page Is Intentionally Left Blank.

Section 5: Lubrication and Maintenance – Contents

Introduction	.5-4
Daily Service	.5-5
First 50-hour Service	.5-5
Check and Tighten Wheel Torques	.5-6
Reinstall wheels	.5-6
Break-in Precautions	.5-7
Preventing System Contamination	.5-7
Flexible Maintenance Intervals	.5-7
Lubrication and Maintenance Chart	.5-7
Engine Oil	.5-8
Fuel Requirements	.5-8
Fueling the Tractor	.5-9
Overfuel protection	5-10
Adding Diesel Exhaust Fluid (DEF)	5-11
Coolant Mixture and Additives	5-13
Inspection Access	5-14
Cooler Package Access	5-14
Battery Box	5-15
Battery Shut-off Switch	5-15
Engine area Cowlings	5-16
Fuse Panel	5-17
Removing the Drive Shaft Shield	5-18
PTO Shield	5-19
Lubrication and Maintenance Schedule	5-20
Every 10 Hours (daily)	5-23
Check Parking Brake	5-23
Walk Around Inspection	5-24
Check Air Intake Restriction	5-25
Clean Cooling Package	5-26
Check Engine Hoses and Connections	5-27
Engine System Detail 1 of 4: Check Cooling System Hoses	5-28
Engine System Detail 2 of 4: Charge Air Cooler Pipes Inspection	5-29
Engine System Detail 3 of 4: Engine Turbocharger Connections	5-30
Engine System Detail 4 of 4: Exhaust System Connections	5-31
Check Accessory Drive Belt	5-32
Check Air Conditioner Drive Belt	5-33
Check Fuel Filter and Connections	5-33
Engine Oil Level	5-34
Engine Coolant Level	5-35
Check Oil Level for Transmission, and Rear Axle	5-36
Check and Drain the Fuel/Water Separator	5-37
Check Diesel Exhaust Fluid Level	5-38
Check Engine Air Filters	5-40
Check Front Differential Oil and Final Drive Oil Level (Front and Rear)	5-43
Lubricate 3-pt Hitch	5-44
Lubricate Front Axle Grease fittings	5-45
Check Stop Adjustment	5-46
Check the Hydraulic Oil	5-47
Initial 50 Hours	5-48
First 50-hour Service Checklist	5-48

Every 50 Hours	5-49
Clean Alternator	5-50
Check and Clean the Cab Air Filter	5-51
Check Weight Hardware; Front and Rear Wheel Weights	5-52
Check Tire Pressure and Condition	5-54
Lubricate the Front Axle Grease Points	5-57
Lubricate 3-pt Hitch (Front)	5-59
Lubricate Drive Shaft Splines	5-59
Inspect and Tighten Drawbar Components	5-60
Every 100 Hours	5-61
Check Front PTO Gear Box	5-61
Every 250 Hours	5-62
Check the Air Conditioner Dryer and Connections	5-63
Check Condition of Battery	5-65
Drain the Fuel Tanks	5-66
Initial 500 Hours	5-67
Clean Suction Filter	5-67
Change and Fill Oil for Transmission and Rear Axle Final Drives	5-68
Change Transmission Oil Filter	5-69
Change Rear Planetary Oil	5-70
Change Hydraulic Filters (Steering, Charge and Return)	5-71
Change Steering Hydraulic Filter	5-71
Change Hydraulic Oil Return Filter	5-73
Change Hydraulic Charge Filter	5-74
Change the Hydraulic Oil	5-75
Every 500 Hours	5-76
Check Batteries	5-76
Check Battery Connections	5-78
Inspect the Electrical Cables at the Starter	5-79
Change the Engine Oil and Filter	5-80
Replace the Fuel Filters	5-82
Front PTO Oil Change and Filter Clean	5-83
Check the PTO Gearbox Mounting Bolts	5-84
Lubricate the PTO Drive Shaft	5-84
Every 1 000 Hours or 1 Year	5-85
Check the Accessory Drive Belt and Tensioner	5-85
Replace the Cab Air Filter	5-86
Replace the Engine Air Filter	5-87
Inspect the Turbocharger Connections	5-88
Check the Radiator and Heating System Hoses and Connections	5-89
Every 1 000 Hours	5-90
Change Hydraulic Filters (Steering, Charge and Return)	5-91
Change Hydraulic Charge Filter	5-94
Change the Hydraulic Oil	5-95
Clean Suction Filter	5-96
Change and Fill Oil for Transmission and Rear Axle Final Drives	5-97
Change Transmission Oil Filter	5-98
Change Diesel Exhaust Fluid (DEF) In-Tank Filter	5-99
Replace Engine Coolant and Service the Cooling System	5-104
Change the Front Axle Differential Oil	5-107
Change the Front Planetary Hub Oil	5-108

Every 4 500 Hours or Three Years	5-109
Change Diesel Exhaust Fluid (DEF) Dosing Unit Filter	5-109
Every 5 000 Hours or Four Years	5-113
Adjust the Engine Valve Lash	5-113
Every 5 000 Hours	5-114
Clean the Diesel Particulate Filter (DPF)	5-114
As Required	5-115
Windshield Washer Fluid and Wiper Blades	5-116
Check and Adjust the Parking Brake	5-117
Fuse and Relay Replacement	5-118
Lightning Fuse and Relay Panel	5-122
Replace Batteries	5-126
Prepare the Tractor For Storage	5-128
Prepare the Tractor for Use After Storage	5-128
Clean Tractor	5-129

Introduction



DANGER

- Always engage the parking brake fully, place the transmission in neutral, shut the engine off, turn the battery shut-off switch to OFF and block the wheels before performing any maintenance operations.
- Allow the engine to cool before performing maintenance.
- Do not check, lubricate, service or adjust the tractor with the engine running unless otherwise instructed in a specific maintenance operation.
- Read and practice all safety precautions listed in “Precautionary Safety Statements” on page 1-13.



NOTICE

- Park the tractor on level ground and, where applicable, extend all cylinders before checking oil levels.
 - It is strongly recommended to perform all inspections and changes listed in the First 50-hour Service checklist. Owners are urged to consider the operating environment, expected ambient temperature and tractor loads when selecting the types and grades of fluids used in the changes. Contact a KUBOTA dealer for advice on fluid selection.
-

Daily Service

Regular lubrication and maintenance of the tractor is important for optimum performance and a long service life. The following daily procedures will help maintain the tractor at peak performance:

- Check wheel hardware for tightness;
- Check the planetary hub and differential oil level; and
- Check for leaks and loose or damaged parts.

See “Every 10 Hours (daily)” on page 5-27 and “Break-in Precautions” on page 5-7.

First 50-hour Service

The first 50 hours of tractor operation are the most critical for ensuring long and dependable tractor life. The tractor will provide long and dependable service given proper care during the initial 50 hour break-in period and if the recommended service operations are performed and the schedules followed.

Make sure the following steps are carried out during the first 50 hours of operation.

- Review the tractor Pre-delivery Checklist with the KUBOTA dealer and make sure all the items on the list have been inspected and checked off.
- Become familiar with the instructions for operation of the controls.
- Read and understand all safety warnings.
- Check all fluid levels and make sure the systems are filled with the correct fluids suitable for the tractor operating conditions.
- Check the engine, transmission and hydraulic oil levels hourly during the first 10 hours of operation.
- Inspect the tractor for leaks hourly during the first 10 hours of operation.
- Tighten the wheel hardware to the torque values provided in Section 5: Lubrication and Maintenance after the first hour of operation and at the end of each day for the first 50 hours of operation. Also see next page for the following torque sequence.

- Operate the engine at 3/4 load as much as possible during the first 50 hours (3/4 load is approximately one gear lower than would be normally used to pull a matched load).
 - Do not operate the engine at idle speed or full throttle for more than five minutes at a time for the first 50 hours.
 - Check the instruments frequently during operation.
-

Check and Tighten Wheel Torques

Reinstall wheels

- Tighten the wheel nuts in sequence according to Table 5-1.
- Rotate the criss-cross sequence clockwise until all the wheel hub nuts are tightened.
- For wheels mounted to a large hub (A), tighten mounting nuts to 597 N·m (440 ft·lb).
- For wheels mounted to a small hub (B), tighten mounting bolts to 800 N·m (590 ft·lb).





Table 5-1: Torque Sequence for Wheels

1	①
2	②
3	③
4	④
5	⑤
6	⑥
7	⑦
8	⑧
9	⑨
10	⑩
11	⑪
12	⑫
13	Again ①



Break-in Precautions

- Do not operate the engine at more than 3/4 load for the first 24 hours of operation. Hold a full load only for short intervals during the next 24 hours of operation.
- Check the oil level every 8 to 10 hours for the first 100 hours of operation.
- Follow the recommendations outlined in the Cummins owner's manual supplied with the tractor.

Preventing System Contamination

To prevent contamination when changing oils and filters:

- Clean the area around the filler caps, level plugs, drain plugs, dipsticks and filters prior to removal.
- Check that the oil is clean and has not degenerated in storage before connecting remote cylinders.
- Wipe the grease fittings before greasing to prevent the entry of dirt.

Flexible Maintenance Intervals

The intervals listed in the Lubrication and Maintenance Chart in this section are guidelines to be used when operating in normal working conditions. Adjust the intervals for environmental and working conditions. Shorten intervals under adverse (wet, muddy, sandy or extremely dusty) working conditions.

Lubrication and Maintenance Chart

The chart lists the intervals for routine checks, lubrication, service and/or adjustments. Use the chart as a quick reference guide when servicing the tractor.

Engine Oil

KUBOTA and Cummins Inc. recommend the use of a high quality CJ-4 low-ash oil. Additional information on engine oil under extreme conditions (hot or cold weather) can be found in the Cummins Engine Manual provided with the tractor. Contact a KUBOTA dealer for more information.

Fuel Requirements

Select the correct fuel for dependable performance and satisfactory engine life. The tractor is designed to run efficiently on Ultra Low Sulfur Diesel (ULSD) fuel. ULSD fuels must contain 15 ppm or less sulfur content at point of use in North America and Europe.

Contact a KUBOTA dealer for more information and suppliers of ULSD fuels and about cold weather operations.

- Use of fuel with a high sulfur content will damage the engine and after treatment system.
 - Never use blended fuels. Under no circumstances add gasoline, alcohol or blended fuels, such as gasohol or dieselhol, to diesel fuel. These fuel blends are more explosive than pure diesel in an enclosed fuel tank. Do not use these blends.
 - Keep the filler cap area clean and free of debris.
 - Fill the tanks at the end of each day to reduce overnight condensation.
 - Never take the fuel caps off or refuel the tractor with the engine running.
 - Keep control of the fuel nozzle while filling the fuel tanks.
 - Do not fill the tanks to capacity. Allow room for expansion.
 - Wipe up all spilled fuel immediately.
 - Use only internally grounded fuel hoses from storage tanks and pumps to the tractor fuel tank. Check with a fuel hose supplier if in doubt.
 - Make sure the nozzle is in contact with the tractor filler neck before fuel starts flowing and during the entire time fuel is flowing.
-

Fueling the Tractor



DANGER



Always observe safe fuel handling practices when fueling the tractor.

NOTICE


Do not overfill the tanks. Allow room for fuel expansion in changing temperatures. Expanding fuel in overfilled tanks can result in fuel entering engine cylinders and the accompanying hydraulic locks causing damage to the engine.

Model M8-181 and M8-201 tractors are equipped with a fuel tank (1) with a capacity of 330 L (87 gal).


IMPORTANT: Always replace fuel tank caps with genuine KUBOTA caps. Always tighten fuel tank caps securely.

To fuel the tractor:

1. Turn off the engine and allow the tractor to cool before starting refueling procedures.
2. Clean the area around the fuel cap (1) to prevent debris from entering the tank and contaminating the fuel.



3. Turn the fuel cap (1) counterclockwise until loose, then pull upward to remove from the tank. Place the cap in a clean area during refueling to prevent fuel contamination.
4. Check the fuel pump nozzle for damage and make sure the fuel hose is properly grounded. Fully insert the fuel pump nozzle in the fuel tank neck and then start fueling.
5. Wipe up all spilled fuel immediately.
6. Turn the fuel cap clockwise until tightened securely. Lock the fuel cap if required.
7. Store fuel properly. See “Fuel Storage” on page 7-22.

**Table 5-2: Fuel Information**

General Fuel Type	ULSD	ULSK
Final Boiling Point	357 °C (675 °F)	288 °C (550 °F)
Temp Range	-7 °C (20 °F) and above	-7 °C (20 °F) and above
Cetane	40	40
Sulfur Content	15 ppm	15 ppm

Overfuel protection

- 80% fuel level = 1 beep
- 85% fuel level = 2 beep
- 90% fuel level = 3 beep
- 95 % fuel level = 3 seconds beep

Adding Diesel Exhaust Fluid (DEF)



CAUTION


Wear gloves and eye protection when adding diesel exhaust fluid (DEF). DEF is not harmful to handle but will corrode certain metals.



- In case of eye contact: Remove contact lenses. Immediately wash your eyes with a lot of water for at least 15 minutes.
- In case of skin contact: First aid is normally not required. Immediately wash your skin with soap and water. Avoid prolonged contact with DEF.
- If swallowed: Do not give milk or alcoholic beverages. Never give anything by mouth to an unconscious person. If symptoms persist, contact a physician immediately.

Guidelines and Requirements:


- The quality of the diesel exhaust fluid (DEF) must meet ISO 22241-1. Only use commercially grade DEF. Agricultural grade DEF is not acceptable.
- Never add DEF to diesel.
- Top up the (DEF) tank every time you fill up the fuel tank. This is the easiest way to make sure the aftertreatment system always has enough DEF.
- Warning lamps will appear in the tractor when the DEF is low and empty. If you see the low level DEF icon (1) on the EIC fill up the DEF tank immediately. If the DEF level is critically low the engine will lose power. Once the DEF tank is completely empty the engine power will be reduced to idling.



To add diesel exhaust fluid (DEF):

Before using anything to store or dispense DEF, such as containers or funnels, wash these items with distilled water, not tap water. Tap water will contaminate the DEF. If distilled water is not available, rinse the items with tap water first, and then with DEF.

1. The DEF tank is on the left side of the tractor.
2. Clean the area around the DEF cap (1), the cap itself, and any funnels before filling the tank. DEF must not be contaminated.
3. Fill up the tank. Tighten the DEF cap.
4. Clean up any spills immediately. DEF will wreck the paint on the tractor.
5. Store DEF supplies properly. See “DEF Storage” on page 7-19.



Coolant Mixture and Additives

Make sure the coolant and additive level is appropriate for tractor:

- Use a coolant that meets Cummins' Engineering Standards as listed in Table 5-3.
- Use a fully-formulated coolant or a mixture of concentrate and water. Any water used must meet the quality standards as listed in Table 5-4 if mixing concentrate with water.
- Maintain a supplemental additive (SCA) level of 0.6 to 0.8 units per L (2.5 to 3 units per gal). Contact a KUBOTA Dealer for help in obtaining this additive (Type: DCA4).
- Make sure the glycol concentration is appropriate for the climate. See Table 5-5.
- Make sure the coolant is not contaminated. See Table 5-6.

Glycol Concentration (% by volume)	Ethylene Glycol	Propylene Glycol
40 %	-24 °C (-12 °F)	-21 °C (-6 °F)
50 %	-37 °C (-34 °F)	-33 °C (-27 °F)
60 %	-52 °C (-65 °F)	-49 °C (-56 °F)
Arctic climate only: 68 %	-71 °C (-96 °F)	Do not use.

NOTICE

- Failure to maintain DCA4 in the cooling system will cause cooling system corrosion and engine failure.
- It is easier and more economical to test the glycol level using test strips. If the test strips show an improper freezing point, test the glycol level with a refractometer (1) for a more precise reading. Propylene glycol protection levels cannot be checked with the same hydrometer used to check ethylene glycol antifreeze.

Product	Must Meet Engineering Standard
Coolant	Cummins 14603 (use Fleetguard ES Compleat™ or equivalent)
Coolant Filter	Cummins 14315

Contaminant	Allowable Level
Calcium Magnesium (Hardness)	Max 170 ppm as (CaCO ₃ + MgCO ₃)
Chloride	Max 40 ppm as (Cl)
Sulfate	Max 100 ppm as (SO ₄)

Contaminant	Allowable Level	If allowable level is not met
Sulfate (SO ₄)	1500 ppm max	1. Drain coolant. 2. Refill system with fully formulated coolant that meets Cummins Engineering Standard 14603. If mixing water with concentrate, first test the water quality according to Table 5-4. 3. Re-test SCA and glycol levels and adjust if necessary.
Chloride (Cl)	200 ppm max	
PH	7.5 minimum	
Oil or Fuel	No Oil or Fuel	1. Drain, clean and flush coolant system. 2. Replace with fully formulated coolant that meets Cummins Engineering Standard 14603. If mixing water with concentrate, first test the water quality according to Table 5-4. 3. Re-test SCA and glycol levels and adjust if necessary.
Grease, solder bloom, silica gel, rust or scale	Must be free of these contaminants	



Inspection Access



DANGER



Always make sure that safety shields and other protective devices are in place and operational after service and maintenance. Never operate the tractor with missing or damaged safety shields.



WARNING





- Never operate the tractor with the safety shields removed.
- Safety shields, guards and cowlings must not be removed except when access to the guarded areas is required for maintenance. Always replace the safety shields immediately when the service work is complete.

It may be necessary to open or remove various panels and shields in order to complete some maintenance requirements.

Cooler Package Access

The cooler package (1) consists of the engine cooler, the hydraulic oil cooler, the charge air intercooler and the air conditioning (A/C) condenser. To access the the cooler package:

1. Pull the release latch (2) located by the hood (3). The hood will lift open.
2. With the hood open, push the latch (4) on the cooler pack to release the A/C condenser. Pull forward to swing the condenser out providing access to the front of the cooler pack.
3. Make sure the coolers are secure and that the hood is closed and latched before operating the tractor.



Battery Box

The battery box (1) is mounted beside the hydraulic reservoir on the right side of the tractor. The cover for the box is held in place with 2 knobs (one on each side) (2).

The battery box protects the two tractor batteries and the electrical connections.



Battery Shut-off Switch

NOTICE

The battery shut-off switch shall not be used as an emergency engine shut-off switch. Turning the battery shut-off switch to OFF while the engine is running may result in damage to vehicle electronics.

Located above the tool box (not shown), the battery shut off switch (3) provides the control needed to terminate electrical power. This switch can be disengaged and padlocked when the tractor is parked or when there is a need to disconnect the main batteries.

- Turn the battery shut off switch to the OFF position to disconnect battery power.
- Turn the battery shut off switch to the ON position to connect battery power.




Engine area Cowlings

1. Open the hood and locate the 2 latches (1) on the engine guard (2) on both sides of the tractor.
2. Lift and turn the latches to loosen the engine guards.
3. Lift the engine guards to remove it from the engine compartment.
4. Inspect the engine guards for damage. Repair and replace if necessary.

NOTE: Contact a KUBOTA dealer for service and parts advice.





5. Replace the engine guards when the maintenance work is completed.
6. Check the fit and alignment of the engine guards and adjust if necessary. Tighten the mounting screws securely.

IMPORTANT: Make sure the engine guards fits properly and that there is no interference with moving parts.



Fuse Panel




1. Side cover contains fuses and relays, engine and transmission diagnostic connections and is located on the right side of the cab.
2. There are 4 fuse panels:
 - Behind operator's seat (1).
 - Right side bottom of the cab (2).
 - Behind the upper radio and climate control bezel (3).
 - Fuse panels in the engine compartment (4).



Removing the Drive Shaft Shield


The protective shield for the drive shaft is in two pieces. The left and right are attached to the front differential and to each other.

Remove bolts (1) from the shield (2) to service the driveshaft components (3). Remove bolts (4) to remove driveshaft shield.



PTO Shield

The PTO is protected by the shields at the rear of the differential assembly. The adjustable cover (3) for the PTO output shaft must be left in place whenever the PTO is not connected to equipment.



Lubrication and Maintenance Schedule

Routine lubrication and maintenance is vital to ensure the optimum performance and long service life of the tractor. Regular scheduled lubrication and maintenance is recommended every 10 hours and at every 50, 250, 500, 1 000 and 2 000 hours of operation. The Lubrication and Maintenance Chart lists recommended service procedures at hourly intervals in sequential order. Use the chart as a quick reference guide for servicing the tractor. Descriptions of the operations in this section also follow in sequential order.

Table 5-7: Lubrication and Maintenance Chart

	Description	Service Procedures					
		Check	Clean	Lube	Change	Adjust	Drain
Daily Maintenance (every 10 hours)							
1	Inspect/Engage Parking Brake	•					
2	Walk Around Inspection	•					
3	Check and Clean Air Intake Restriction	•	•				
4	Clean Cooler Package <ul style="list-style-type: none"> • A/C Condenser • Radiator • Charge Air Cooler • Hydraulic Oil Cooler • PTO Oil Cooler 		•				
5	Check Engine Hoses and Connections <ul style="list-style-type: none"> • Cooling System Hoses • Air Cooler Pipes • Turbocharger area • Exhaust System Connections 	•					
6	Check and Clean Accessory Drive Belt	•	•				
7	Check and Clean Air Conditioner Belt	•	•				
8	Check Fuel Filter and Connections	•					
9	Check Engine Oil Level	•					
10	Check Engine Coolant Level	•					
11	Check Hydraulic Oil Level <ul style="list-style-type: none"> • Transmission • Rear differential 	•				•	
12	Check and Drain the Fuel/Water Separator	•					•
13	Check Diesel Exhaust Fluid Level	•					
14	Check Engine Air Filters	•					
15	Check Differential Oil and Final Drive Oil Level (Front and Rear)	•					
16	Lubricate 3-Point Hitch	•		•			
17	Lubricate Front Axle Grease fittings	•		•			
18	Check Stop Adjustment	•					
19	Check Hydraulic Oil	•				•	

Continued on next page....

Table 5-7: Lubrication and Maintenance Chart

	Description	Service Procedures					
		Check	Clean	Lube	Change	Adjust	Drain
Initial 50 hours							
-	Perform First 50-hour Service. See Checklist.	•	•	•	•	•	•
Every 50 Hours							
20	Clean Alternator		•				
22	Check and Clean the Cab Air Filter	•	•				
23	Check Weight Hardware; Front and Rear Wheel Weights	•	•			•	
24	Check Front Weight Bolts	•				•	
25	Check Tire Pressure and Condition	•				•	
26	Lubricate Front Axle Grease Points	•	•	•			
27	Lubricate 3-pt Hitch (Front)			•			
28	Lubricate Drive Shaft Splines			•			
29	Inspect and Tighten Drawbar Components	•					
Every 100 Hours							
30	Check the Front PTO Gear Box	•					
Every 250 Hours							
31	Check the Air Conditioner Dryer and Connections	•					
32	Check Condition of Battery	•	•				
33	Check and Drain the Fuel Tanks	•					•
Initial 500 Hours							
34	Clean Suction Filter						
36	Change Oil for Transmission and Rear Final Drives				•		•
37	Change Transmission Oil Filter				•		
38	Change Rear Planetary Oil				•		•
39	Change Hydraulic Filters (Steering, Charge and Return)				•		•
40	Change Hydraulic Oil				•		•
Every 500 Hours							
41	Check Batteries	•					
42	Check Battery Connections	•					
43	Change the Engine Oil and Filter	•					•
44	Replace the Fuel Filters				•		
45	Change the Front Axle Differential Oil	•			•		•
46	Check the PTO Gearbox Mounting Bolts	•					
47	Lubricate the PTO Drive Shaft			•			
Every 1 000 Hours or One Year *							
48	Check the Accessory Drive Belt and Tensioner	•			•		
49	Replace the Cab Air Filter				•		
50	Replace the Engine Air Filter	•			•		
51	Inspect the Turbocharger Connections	•				•	
52	Check the Radiator and Heating System Hoses and Connections	•				•	

Continued on next page....

Table 5-8: Lubrication and Maintenance Chart

	Description	Service Procedures					
		Check	Clean	Lube	Change	Adjust	Drain
Every 1 000 Hours **							
53	Change Hydraulic Filters (Steering, Charge and Return)				•		•
54	Change the Hydraulic Oil				•		•
55	Clean Suction Filter		•				
56	Change Oil for Transmission and Rear Final Drives				•		•
57	Change Transmission Oil Filter				•		
58	Change Diesel Exhaust Fluid (DEF) In-Tank Filter				•		
59	Replace Engine Coolant and Service the Cooling System				•		
60	Change the Front Planetary Hub Oil				•		
61	Clean and Change Front PTO Filter and Oil		•		•		
Every 4500 Hours							
62	Change Diesel Exhaust Fluid (DEF) Dosing Unit Filter	•					•
Every 5 000 Hours or 5 Years ***							
63	Adjust the Engine Valve Lash	•				•	
Every 5 000 Hours ***							
64	Clean the Diesel Particulate Filter (DPF)		•				
As Required							
65	Check Windshield Washer Fluid and Wiper Blades	•				•	
66	Check and Adjust the Parking Brake	•				•	
67	Change Fuse and Relay Replacement	•			•		
68	Replace Batteries	•			•		
69	Prepare the Tractor for Storage	•	•	•			•
70	Prepare the Tractor for Use After Storage	•	•	•	•		
71	Clean Tractor		•				

* Operations performed at 1 000 hours or at year end, whichever comes first.

** Operations performed at 1 000 hours of use, regardless of other scheduled work.

*** Affects engine warranty. Contact a KUBOTA dealer for instructions on 5 000 hour service.

Every 10 Hours (daily)

Carry out daily maintenance every 10 hours of operation under normal operating conditions. Perform this maintenance more frequently when the tractor is operated in severe duty service or during conditions of extreme heat or cold.

A daily maintenance routine reduces equipment issues and helps identify potential problems at an early stage, allowing corrective action to prevent major breakdowns. Daily maintenance protects the owner's investment and helps avoid costly repairs.




DANGER



- Before performing any maintenance operations, always engage the parking brake fully, place the transmission in neutral, shut the engine off, turn the battery shut-off switch to OFF and block the wheels.
- Allow the engine to cool before performing maintenance.
- Do not check, lubricate, service or adjust the tractor with the engine running unless otherwise instructed in a specific maintenance operation.

Check Parking Brake


Make sure that the brakes are in good working order before operating the tractor. Adjust if necessary.



Walk Around Inspection

After applying the parking brake, walk around the tractor carrying out a detailed visual inspection. See “Inspection Access” on page 5-14 for instructions on opening tractor access panels.

- Check the door handle and latch operation.
- Inspect the glass and frame for damage.
- Make sure the hand rails and steps are not loose or damaged.
- Inspect the tires and wheels for proper inflation and signs of damage.
- Inspect the ground or surface under the tractor for signs of fluid leakage.
- Inspect the underside of the tractor for signs of damage or build up of debris.
- Inspect the wheel planetary hubs for signs of oil leakage.
- Inspect the fenders and body panels for damage and make sure they are attached securely.
- Inspect the grille area for damage or build up of debris.
- Make sure the hood latch is secure and will release and latch properly.
- Make sure the exhaust stack is secure and not damaged.
- Inspect the hitch parts for damage or build up of debris.
- Check the area around the tractor for obstacles or potential hazards.
- Make sure that restraints or wheel chocks are removed before moving the tractor.
- Check to see if the tractor and moved and ensure it is safe to proceed with operation if the tractor was parked on an incline or slope.



Check Air Intake Restriction



DANGER

Do not remove safety shields or attempt to work on the tractor when the engine is running.



Pressurized or hot fluids in the lubricating, hydraulic or cooling systems can cause severe injury.

Allow the engine to cool before approaching the exhaust or other hot parts.

Seek medical assistance immediately.


A restriction in the engine air intake may occur .

An intake restriction in the filter will cause the warning and audible alarm on the instrument panel.

NOTE: Normal air filter maintenance is scheduled at 1 000 hours See Operation 36: Replace the Engine Air Filter.

1. Park the tractor in a safe and level location and apply the parking brake:
2. Check for and remove debris and inspect for damage.
3. Open the hood (1). Check for and remove debris from the air intake and inspect for damage
4. Inspect the air intake plenum for damage.


IMPORTANT: Do not operate the tractor if the air intake or filter system is damaged. Contact a KUBOTA dealer for service.



Clean Cooling Package

Never use a pressure washer to clean the cooling package fins. Use compressed air at less than 6.9 bar (100 psi).

1. Park the tractor on a level surface and set the parking brake. Remove the key from the ignition, wait for the power on indicator light to turn off and turn the battery disconnect switch to the OFF position.
2. Open the hood.
3. Push the latch (1) located at the front of the cooling package.
4. Visually inspect the cooler surfaces for signs of leakage or damage. Remove all debris and blow compressed air in both directions through the cooler to clean the cooler fins.
 - A/C Condenser (2)
 - Radiator (3)
 - Charge Air Cooler (4)
 - Transmission Oil Cooler (5)
 - Hydraulic Oil Cooler (6)
 - PTO Oil Cooler (7)
5. Close the hood.



Check Engine Hoses and Connections

NOTICE

Check all engine system hoses and clamps thoroughly after winter. Leaks at engine system connections are more likely to occur after cold weather.

To check the engine hoses and connections:

1. Open the hood.
2. Visually inspect all engine hoses and connections for corrosion, cracks, loose clamps or punctures that can damage the engine.
3. Pay particular attention to the air intake system especially the turbocharger area.

The air intake/exhaust system, aftertreatment, cooling system and turbocharger are detailed on separate pages for clarity.

For detailed overview of these areas, see the next 3 pages.


Engine System Detail 1 of 4: Check Cooling System Hoses

Visually check cooling system hoses and Diesel Exhaust Fluid (DEF) coolant hoses

1. Park the tractor on a level surface and set the parking brake. Remove the key from the ignition and turn the battery disconnect switch to the OFF position. Open the hood.
2. Pay extra attention to the turbocharger area (1).
3. If required, tighten clamps. If the clamp is painted black like the rest of the engine/turbocharger, it is a connection only Cummins can service while the tractor is under warranty. Check these connections for leaks/damage but contact Cummins for service.
4. If required, re-secure parts using the same kind of plastic ties.
5. Check cooling system hose (2).
6. Check upper radiator tube (3) and lower radiator tubes (4).

Table 5-9: Inspections of the Cooling System Hoses

Ref	Description	Torque or Action Required
	Left side and Right side of the engine	
3	Upper radiator hose (4 clamps located on the left side)	5 N·m (65 in·lb)



Engine System Detail 2 of 4: Charge Air Cooler Pipes Inspection

Visually check the air intake and after cooler piping system.

1. Park the tractor on a level surface and set the parking brake. Remove the key from the ignition and turn the battery disconnect switch to the OFF position. Open the hood.
2. Pay extra attention to the turbocharger area.
3. If required, tighten clamps. See Table 5-10. If the clamp is painted black like the rest of the engine/turbocharger, it is a connection only Cummins can service while the tractor is under warranty. Check these connections for leaks/damage but contact Cummins for service.
4. If required, re-secure parts using the same kind of plastic ties.





Table 5-10: Inspections of the Cooling System Hoses		
Ref	Description	Torque or Action Required
	Left side and Right side of the engine	
1	Upper Charge Air Cooler Tube	5 N·m (65 in·lb)
2	Ejector/Aspirator Tube (4 clamps)	Tighten clamps
3	Lower Charge Air Cooler Tube (3 clamps)	5 N·m (65 in·lb)





Engine System Detail 3 of 4: Engine Turbocharger Connections

Check the turbocharger for leaks. Soot at the connections and/or audible whistles indicate a leak. If any of the following parts are loose or are leaking, contact a Cummins Authorized Repair Location for service:

See View A:

- Check the turbocharger oil supply line fitting (1) for leaks and damage. Torque value: 20 N·m (15 ft·lb).
- Check the turbocharger oil return line flange bolt (2) for leaks and damage. Torque value: 27 N·m (20 ft·lb).
- Check the 4 turbocharger mounting nuts (3) for looseness and for soot around the gasket. Torque value: 61 N·m (45 ft·lb).
- Check the clamp securing the flex pipe to turbocharger reducer (4) for leaks.
- Check the turbocharger air intake tube clamp (5). Look and listen for leaks. Soot streaks at the joint or an audible whistle from the engine indicate a leak. Torque value 8.5 N·m (75 in·lb).




Engine System Detail 4 of 4: Exhaust System Connections



WARNING



The exhaust system components become extremely hot during tractor operation. Do not attempt any repairs on the exhaust system until the exhaust system has had time to cool.



Visually check exhaust pipes.

1. Park the tractor on a level surface and set the parking brake. Remove the key from the ignition and turn the battery disconnect switch to the OFF position. Open the hood.
2. Pay extra attention to flex pipes (1).
3. If required, tighten clamps. If the clamp is painted black like the rest of the engine/turbocharger, it is a connection only Cummins can service while the tractor is under warranty. Check these connections for leaks/damage but contact Cummins for service.
4. If required, re-secure parts using the same kind of plastic ties.
5. Check exhaust tube (2).
6. Check muffler tip and clamps (4).





Table 5-11: Inspections of Exhaust System Connections

Ref	Description	Torque or Action Required
1	Flex pipe and clamps (2 clamps)	8 N·m (71 in·lb)
2	Exhaust Tube (3 clamps)	8 N·m (71 in·lb)
3	Muffler tip and clamps (1 clamps)	55 N·m (41 ft·lb)





Check Accessory Drive Belt

Keep the serpentine belt (1) that powers the engine alternator and the water pump clean at all times. Inspect the belt daily. These accessories are protected by the engine compartment safety shields but the area can be viewed through the gaps between the shields and engine.

With the engine off and the parking brake applied:

1. Open the hood and inspect the engine accessory drive belt area for build up of debris.
2. Remove debris; use compressed air if necessary. Keep the air pressure under 690 kPa (100 psi) to prevent equipment damage.

Remove the protective shields and proceed to "Check Air Conditioner Drive Belt" on page 5-33 if the debris cannot be removed or if there is concern about the engine accessory drive belt.




Check Air Conditioner Drive Belt

The air conditioner (1) belt needs to be adjusted and checked. Check the belt tension in the following procedure. If the deflection is out of spec or the belt itself is found to be damaged, replace it with a new one. It is protected by the engine compartment safety shields but the area can be viewed through the gaps between the shields and engine.

With the engine off and the parking brake applied:


1. Stop the engine and remove the key.
2. Open the hood and inspect the engine accessory drive belt area for build up of debris.
3. Press on the spot indicated in the image to measure the deflection.
4. Remove debris; use compressed air if necessary. Keep the air pressure under 690 kPa (100 psi) to prevent equipment damage.



Check Fuel Filter and Connections

Park the tractor on a level surface, stop the engine and apply the parking brake.

1. Inspect the fuel line and fuel filter connections (2). Check for leaks around fittings and seals.



Engine Oil Level



Park the tractor on a level surface, stop the engine and apply the parking brake, then wait at least five minutes:

1. Pull out the engine oil dipstick (1), wipe it clean and re-insert fully.
2. Pull the dipstick out again and check the oil level. Make sure the oil level is in the crosshatched area (2) of the dipstick.

IMPORTANT: Do not operate the engine when the oil level is below the ADD mark on the dipstick. Do not fill the oil above the FULL mark. Do not operate the engine with the dipstick or the oil filler cap removed.

IMPORTANT: Use oil of the recommended type only. The oil grade and viscosity specifications are in Section 7 of this manual and in the Cummins engine manual.

IMPORTANT: The diesel particulate filter (DPF) will be damaged by continued use of incorrect lubricating oil. Failure to use CK-4 low ash oil will result in damage to the DPF over time. The use of low ash oils is essential because other types of oil will fill the DPF over time and inhibit the DPF's ability to regenerate because ash will not oxidize.



Engine Coolant Level

Park the tractor on a level surface, shut the engine off and apply the parking brake. Wait until engine is cool and then check coolant level.

1. Check the engine coolant level at the surge tank/reservoir (1). With the engine cold, the coolant should be visible on the sight glass and fully covered. There is no overflow reservoir on the tractor.
2. If coolant level is low, add coolant to the surge tank/reservoir till the coolant is fully covering the sight glass.


NOTE: Use the surge tank fill tube to refill the system after servicing the radiator or other cooling system components.

Use the 50/50 coolant/water mixture with ASTM D6210, D6211 rating in accordance with manufacturer's recommendations.

For more information on coolant specifications, refer to Section 7 of this manual or the Cummins engine owner's manual or contact a KUBOTA dealer.

IMPORTANT: Do not add coolant to a hot engine. Allow the engine to cool to below 50°C (120°F) to prevent damage to the engine castings.

IMPORTANT: Do not continue to operate the engine if the coolant level is below the sight glass or if the coolant level will not remain in the normal range. Continued loss of coolant indicates a problem in the engine cooling system that requires attention and repair. Contact a KUBOTA dealer for service.



Check Oil Level for Transmission, and Rear Axle




Transmission Oil/Rear differential oil are combined in the transaxle housing. They are checked with the sight glass located to the left of the PTO.

To check the transmission/rear differential oil.

1. Look at the sight glass (1) located beside the PTO stub shaft cover.
2. The transmission/rear differential oil level must be kept between the full mark (2) and the low mark (3) in the sight glass.
3. Add or remove transmission/rear differential oil as necessary to maintain the transmission/rear differential oil level. Add oil at the transmission/rear differential oil filler tube (4) when required to maintain the level between the marks on the sight glass.

IMPORTANT: Do not overfill the transmission/rear differential oil system reservoir.

NOTE: For more information on hydraulic oil, refer to *Fluid Capacities and Lubricants and Fluids in Section 7 of this manual.*



Check and Drain the Fuel/Water Separator



WARNING

Never open the fuel system with the engine running. High pressure fuel spray can cause serious injury or death.



Diesel fuel is a flammable and hazardous material. Use appropriate safe handling precautions.

Check the fuel/water separator (1) daily.

Rotate the drain valve (2) counterclockwise about two and one half turns. The drain will drop about 20 mm (0.75 in) and the contents of the separator will flow out.


NOTE: Attach a 9.50 mm (0.375 in) flexible tube to the drain. Use a pan to collect the liquid.

The separator is free of water when the flow is clear with no cloudiness or bubbles. It should not require draining more than 1 L (0.26 gal) of liquid to remove the water from this filter.

Push the drain up and rotate the drain valve clockwise. Tighten by hand.

IMPORTANT: Do not overtighten the drain valve.

NOTE: Disconnect the sensor harness if the separator must be removed.



Check Diesel Exhaust Fluid Level



CAUTION

Wear gloves and eye protection when adding diesel exhaust fluid (DEF). DEF is not harmful to handle but will corrode certain metals.



- In case of eye contact: Remove contact lenses. Immediately wash your eyes with a lot of water for least 15 minutes.
- In case of skin contact: First aid is normally not required. Immediately wash your skin with soap and water. Avoid prolonged contact with DEF.
- If swallowed: Do not give milk or alcoholic beverages. Never give anything by mouth to an unconscious person. If symptoms persist, contact a physician immediately.

Check the DEF level indicator on the EIC or on the display monitor home screen (not shown).


If the DEF Level Low indicator lamp appears on the EIC, add diesel exhaust fluid to the DEF tank immediately.

Before using anything to store or dispense DEF, such as containers or funnels, wash these items with distilled water, not tap water. Tap water will contaminate the DEF. If distilled water is not available, rinse the items with tap water first and then with DEF.

To add diesel exhaust fluid (DEF):

Before using anything to store or dispense DEF, such as containers or funnels, wash these items with distilled water, not tap water. Tap water will contaminate the DEF. If distilled water is not available, rinse the items with tap water first and then with DEF.

1. The DEF tank (1) is on the left side of the tractor.
2. Clean the area around the DEF cap (2), the cap itself and any funnels before filling the tank. DEF must not be contaminated.
3. Fill up the tank. Tighten the DEF cap.
4. Clean up any spills immediately. DEF will wreck the paint on the tractor. DEF is not harmful to handle but is corrosive to certain metals.
5. Store DEF supplies properly. See “DEF Storage” on page 7-19.



Check Engine Air Filters

NOTICE

It is recommended that the engine air filters be changed every 1000 hours of engine operation. However, change the engine air filters more frequently depending on operating conditions.



Engine Air Filter Inspection Procedure



DANGER




Always wear a mask when servicing the air filters. Do not breathe in the dust.

NOTICE

- Do not service the engine air filters or open the filter compartment unless there is an air filter restriction warning.
- To obtain replacement elements, contact a KUBOTA dealer. Inspect the seals on new filter elements before installing. Do not use an element with cracks or chips in the element sealing rubber.
- Make sure to clean the inside filter housing with a damp cloth before removing the secondary filters and again before installing the primary filters to prevent dust entering the intake pipe.

The engine air cleaner consists 1 primary filter and 1 safety filter. The engine air filter is located at the top of the engine. The engine air filter housing is mounted on the upper frame in the engine compartment and the filter elements are inside the air filter housing.

1. Park the tractor on a level surface, shut off the engine and apply the parking brake.
2. Open the hood and find the engine air filter. Use a suitable step ladder to access the filter.
3. Release the four snap latches (1) and pull the air filter cover away from the housing.





4. Clean the inside of the filter housing before the safety filter element is removed.
5. Pull the primary filter (1) from the housing. The safety filter (2) is now accessible.
6. Check the primary filter for damage. Inspect the safety filter in place.

IMPORTANT: Do not allow dirt or dust from the filters to contaminate the intake plenum. Use a clean cloth and soap solution to clean the inside of the filter housing before removing the safety filter element.

7. Install the new safety filter. Carefully press the filter into place by pushing on the plastic edge of filter.

IMPORTANT: Do not press on the paper filter element.

8. Install the new primary filter elements.
9. When the filter elements are in place, reinstall the cover on the filter housing and fasten the snaps.



Check Front Differential Oil and Final Drive Oil Level (Front and Rear)



CAUTION




Check the level when the oil is cool. Hot oil may spray out and cause injury when the plug is removed from the drain/fill opening.

IMPORTANT: Check the oil level when the oil is cool. Hot oil may spray out and cause injury when the plug is removed from the drain/fill opening.

1. Park the tractor on a level surface and set the parking brake. Remove the key from the ignition, wait for the power on indicator light to turn off and turn the battery disconnect switch to the OFF position.
2. Clean the area around the front axle fill plug (1) located on the front left side axle housing.
3. Slowly remove the fill plug. The oil should be level with the bottom of the fill plug opening.

NOTE: If oil is required, see *Lubricants in this section for oil specifications.*

4. If the oil is low, add oil until it is level with the bottom of the opening.
5. Install the fill plug and tighten securely.




Final Drive Oil Level

1. Move the tractor until the oil level line (2) and the planetary oil drain/fill plug (3) is horizontal.
2. Slowly remove the drain/fill plug. The oil should be level with the bottom of the drain/fill plug opening.

NOTE: If oil is required, see *"Fuel Storage" on page 7-19.*

3. If the oil is low, add oil until it is level with the bottom of the opening.
4. Install the fill/drain plug and tighten securely.



Lubricate 3-pt Hitch

Park the tractor on a level area, shut the engine off and apply the parking brake.

Remove debris. Use a pressure washer and suitable cleaner to clean the 3-pt hitch linkage.

Lubricate the 3-pt hitch linkage to maximize performance.

Grease: STD Grease Lithium base High Temperature EP 2 (NLGI 2), available from a KUBOTA dealer.

1. Lubricate the 14 grease fittings (1). These are the only points that require lubrication on the 3-pt hitch.
2. Check that the 4 ball ends (2) are free and not seized.

NOTE: Lubricate at 10-hour intervals when operating in extremely wet, muddy or very dusty conditions.







Table 5-12: 3-pt Hitch Grease fittings

Ref	Description
1	Lift links (2 fittings per link) Center link (2 fittings) Roc shaft ends (1 per side) Back of Roc shaft (1 per side) Top of lift cylinders (1 per side) Bottom of lift cylinders (1 per side)





Lubricate Front Axle Grease fittings

Grease the front axle at 10-hour intervals (daily) when operating in wet, muddy or dusty conditions.

NOTE: Clean grease fittings before applying grease.


IMPORTANT: Use lithium-based EP high-temperature EP 2 (NLGI 2) grease with Moly available from KUBOTA Parts.

Ref	Description
①	Main Pivot Pin
②	Suspension Cylinders (Suspended Axle only)



Check Stop Adjustment

1. Loosen the jam nut (1) on the steering stop.
2. Check the steering stop (2) in or out to provide a minimum clearance of 38 mm (1.5 in) between the tires or fenders if installed and any part of the tractor with the wheels turned full left and right with the axle fully oscillated.
3. Tighten jam nut securely.
4. Repeat this procedure to adjust the other steering stop.
5. Adjust if necessary.




Check the Hydraulic Oil

NOTE: *Dispose of used oil in accordance with local environmental regulations.*

1. Park the tractor on a level surface, shut the engine off and apply the parking brake.
2. Check the oil level on the sight glass (1) and top up as necessary.
3. Clean up any spills.

NOTE: *Dispose of oil or contaminated materials in accordance with local environmental regulations.*



Initial 50 Hours

Complete the following maintenance procedures after the initial 50 hours of operation, in addition to the daily maintenance schedule.



DANGER

- Always engage the parking brake fully, place the transmission in neutral, shut the engine off, turn the battery shut-off switch to OFF and block the wheels before performing any maintenance operations.



- Allow the engine to cool before performing maintenance.
- Do not check, lubricate, service or adjust the tractor with the engine running unless otherwise instructed.

First 50-hour Service Checklist

Perform First 50-hour Service Checklist on page 7-41 in the manual.

Every 50 Hours

Complete the following maintenance procedures after every 50 hours of operation, in addition to the daily maintenance schedule.



DANGER

- Always engage the parking brake fully, place the transmission in neutral, shut the engine off, turn the battery shut-off switch to OFF and block the wheels before performing any maintenance operations.
- Allow the engine to cool before performing maintenance.
- Do not check, lubricate, service or adjust the tractor with the engine running unless otherwise instructed.



Clean Alternator




WARNING




Always wear appropriate eye and face protection when using compressed air. Flying dirt and debris can cause serious personal injury.

1. Park the tractor on a level surface and set the parking brake. Remove the key from the ignition, wait for the power on indicator light to turn off and turn the battery disconnect switch to the OFF position.
2. Open the hood.
3. Remove the engine guard (1) from the tractor.



4. Blow away the fine dust accumulated in and around the alternator (2) with compressed air.
5. Re-Install the engine guard to the tractor.
6. Close the hood.



Check and Clean the Cab Air Filter



WARNING



Wear a suitable mask to service or replace the air filters. Do not breathe in the dust.



Always wear appropriate eye and face protection when using compressed air. Flying dirt and debris can cause serious personal injury.

The tractor cab is equipped with a single air filter cartridge installed in the cab frame above the left side door.

1. With the cab door closed, hold the cover panel (1) closed and remove the screw (2).
2. Lower the cover panel and swing back.
3. Carefully pull the filter forward to release the filter from the filter housing.
4. Clean the filter housing and ducting with a cloth to remove dust that may have collected. Do not use shop air to clean these components.
5. Gently tap the air filter (3) to remove any dust and debris. Wash the foam pre filter in soap and water.
6. Install the foam pre filter and air filter into housing.





Check Weight Hardware; Front and Rear Wheel Weights

Clean the parts to be inspected.

Check the front and rear wheel hardware. Use a torque wrench to tighten the rear wheel weight hardware.

The specified torque values are in the table below.

Table 5-14: Wheel and Wheel Weight Bolt Torque	
Item	Torque Specification
Front disc-to-hub nuts (1)	700 N·m (515 ft·lb)
Front disc-to-rim nuts (2)	345 N·m (255 ft·lb)
Rear wedge-to-disc bolts (cast disc wheels) (3)	391 N·m (290 ft·lb)
Rear disc-to-rim nuts (cast disc wheels) (Grade 8) (2)	596 N·m (440 ft·lb)
Rear wedge-to-hub bolts (steel disc wheels) (4)	391 N·m (290 ft·lb)
Rear disc-to-hub bolts (steel disc wheels) (1)	800 N·m (590 ft·lb)
Rear wedge-to-hub bolts (dual wheel – four wedge bolts) (4)	391 N·m (290 ft·lb)
Rear wedge-to-hub bolts (dual wheel – four wedge bolts) (4)	391 N·m (290 ft·lb)
Rear wheel weight mounting bolts (5)	258 N·m (190 ft·lb)




Front Weight Bolt Torque

Tighten the front weight retaining bolts (6) to the correct torque.

Tighten the mounting bolts at the bracket clamps to 417 N·m (308 ft·lb).

Check and tighten the tie-rod flange nuts (7) to 550 N·m (406 ft·lb).



Reinstall wheels

- Tighten the wheel nuts in sequence according to Table 5-15.
- Rotate the criss-cross sequence clockwise until all the wheel hub nuts are tightened.
- For wheels mounted to a large hub (A), tighten mounting nuts to 597 N·m (440 ft·lb).
- For wheels mounted to a small hub (B), tighten mounting bolts to 800 N·m (590 ft·lb).





Table 5-15: Torque Sequence for Wheels

Sequence	Nut
1	①
2	②
3	③
4	④
5	⑤
6	⑥
7	⑦
8	⑧
9	⑨
10	⑩
11	⑪
12	⑫
13	Again ①





Check Tire Pressure and Condition

Check and adjust the front and rear tire pressures. Inspect tire treads (1) and sidewalls (2) for damage.

1. Clean the tire valve stems and inspect for damage.
2. Position each wheel so you can easily insert the tire pressure gauge over the tire valve (3).

See Tire Pressures and Permissible Loads in Section 7 of this manual.

NOTE: Have damaged tires or wheels replaced by trained, qualified tire service technicians.



Front Tire Pressures and Permissible Loads

Table 5-16: Front Tire Pressures and Permissible Loads (four-wheel drive) Metric Units																			
Inflation Pressure (bar)																			
Radial Tire Size	Ply	☆Rating	0.40	0.50	0.55	0.60	0.70	0.80	1.00	1.10	1.20	1.40	1.50	1.60	1.80	1.90	2.00	2.20	2.30
Load Capacity (kg)																			
14.9-28	10	3	800	870	945	1010	1075	1195	1305	1415	1500	1615	1705	1800	1880	1960	2060		
16.9-28	8	2	965	1055	1145	1225	1300	1450	1590	1715	1850	1960	2070	2240					
14.9-30	10	3	820	900	970	1045	1105	1235	1345	1460	1550	1660	1760	1850	1940	2025	2120		
480/70-30		-	1180	1285	1400	1550	1650	1800	1900		2120	2360		2575	2800		3075	3350	3550
16.9-30	8	2	1000	1095	1180	1265	1345	1495	1640	1770	1900	2015	2130	2300					

Table 5-17: Front Tire Pressures and Permissible Loads (four-wheel drive) Imperial Units																			
Inflation Pressure (psi)																			
Radial Tire Size	Ply	☆Rating	6	7	8	9	10	12	14	16	18	20	22	24	26	28	30	32	34
Load Capacity (lb)																			
14.9-28	10	3	1760	1920	2080	2230	2370	2630	2880	3120	3300	3560	3760	3960	4140	4320	4540		
16.9-28	8	2	2130	2330	2520	2700	2870	3200	3500	3780	4080	4320	4560	4940					
14.9-30	10	3	1810	1980	2140	2300	2440	2720	2970	3220	3420	3660	3880	4080	4280	4460	4680		
480/70-30		-	2600	2830	3080	3420	3640	3960	4180		4680	5200		5680	6150		6800	7400	7850
16.9-30	8	2	2200	2410	2600	2790	3300	3620	3900	4180	4440	4700	5080						

Rear Tire Pressures and Permissible Loads

Table 5-18: Rear Tire Pressure and Permissible Loads (Metric Units)

Bias Tire Size	Ply	☆Rating	Inflation Pressure (bar)					
			0.80	1.00	1.10	1.20	1.40	1.50
			Load Capacity (kg)					
480/80R46	8	-			2 387	2 559	2 718	
R1 20.8-38	10	-			1 663	3 100	3 295	3 486
R2 30.5L-32	12	-			4 145	4 440	4 722	
R2 20.8-38	10	-			2 980	3 100	3 295	3 486

Table 5-19: Rear Tire Pressure and Permissible Loads (Imperial Units)

Bias Tire Size	Ply	☆Rating	Inflation Pressure (psi)					
			12	14	16	18	20	22
			Load Capacity (lb)					
480/80R46	8	-			5 250	5 630	5 980	
R1 20.8-38	10	-			6 360	6 820	7 250	7 670
R2 30.5L-32	12	-			9 120	9 770	10 390	
R2 20.8-38		-			6 360	6 820	7 250	7 670

Lubricate the Front Axle Grease Points

The front axle has a number of grease fittings for proper lubrication of the moving parts.

Locate the service points described below. Clean the fittings and apply fresh grease. Check for damage and repair or replace damaged components.

NOTE: Contact a KUBOTA dealer for repair service.



Grease Specification: Use lithium base EP high temperature grease available from a KUBOTA dealer.

Front Axle Grease Fitting Locations:

Front axle pivot pin


- The front grease fitting (1) is located on the end of the pivot shaft.
- The rear grease fitting (2) is located on the rear end of the pivot shaft.

NOTE: Lubricate at 10-hour intervals when operating in extremely wet, muddy or very dusty conditions.



Axle King Pin Bearings

1. Locate the upper (1) and lower (2) grease fittings on the left end of the front axle and apply grease until new grease appears at the joint.
2. Grease the upper and lower fittings on the right end of the front axle.



Lubricate 3-pt Hitch (Front)

Park the tractor on a level area, shut the engine off and apply the parking brake.


Remove debris. Use a pressure washer and suitable cleaner to clean the 3-pt hitch linkage.

Lubricate the 3-pt hitch linkage to maximize performance.

Grease: STD Grease Lithium base High Temperature EP 2 (NLGI 2), available from a KUBOTA dealer.

1. Lubricate the grease fittings (1). These are the only points that require lubrication on the front 3-pt hitch.
2. Lubricate the grease fittings on the lower links (2). Also check they are free and not seized.

NOTE: Lubricate at 10-hour intervals when operating in extremely wet, muddy or very dusty conditions.




Lubricate Drive Shaft Splines

Rotate the drive-shaft (3) till grease fitting is accessible, grease fitting is located at the back of the drive shaft. Clean dirt and debris from the area.

Apply a liberal amount of grease to the fitting for thorough lubrication of the driveshaft splines. Grease forced out of the spline coupling may be visible through the access port.

Make sure the drive shaft shield is fastened securely.




Inspect and Tighten Drawbar Components


Park the tractor on a level area, shut the engine off and apply the parking brake.

Clean the area around the drawbar mounting bolts.

Check the bolts holding the drawbar locator pin (4) and tighten to 60 N·m (44 ft·lb).



Check the clevis mounting bolts (5) and tighten to 590 N·m (435 ft·lb).



Every 100 Hours


After every 100 hours of operation, complete the following maintenance procedures.

Check Front PTO Gear Box

Park the tractor on a level area, shut the engine off and apply the parking brake.

Remove debris. Use a pressure washer and suitable cleaner to clean the front 3-pt hitch linkage.

1. Check the front PTO gear box (1) for leaks.



Every 250 Hours

After every 250 hours of operation, complete the following maintenance procedures. This is in addition to the maintenance performed every 10 (daily), 50 hours and 100 hours.



DANGER

- Always engage the parking brake fully, place the transmission in neutral, shut the engine off, turn the battery shut-off switch to OFF and block the wheels before performing any maintenance operations.



- Allow the engine to cool before performing maintenance.
 - Do not check, lubricate, service or adjust the tractor with the engine running unless otherwise instructed in a specific maintenance operation.
-

Check the Air Conditioner Dryer and Connections




DANGER



Do not attempt to service the air-conditioning system. Severe skin and eye injury may result from escaping refrigerant. Special equipment and procedures are required to service the system. Contact a KUBOTA dealer.

Park the tractor on a level surface, place the transmission in neutral and apply the parking brake. Exit the tractor and open the hood.

Check the sight glass (1) on the air conditioner (A/C) dryer for bubbles and the color of the moisture indicator (2) when the outside temperature is 21 °C (70 °F) or higher.



Check the A/C Dryer


1. Start engine and run at 2000 rpm
2. Press the A/C switch
3. Adjust the cab temperature control to the minimum setting and set the cab blower fan to maximum
4. Operate the system for 10 minutes, then check the sight glass (1) with the A/C compressor running
5. Shut the engine off after the inspection.

If bubbles are visible in the sight glass or the moisture indicator (2) is a pink color, the air conditioning system requires service. Contact a KUBOTA dealer.

Check the A/C Connections

Check the connections at the A/C dryer and at the compressor for damage or signs of leakage. A build-up of dirt around the A/C connections may indicate a leak.

IMPORTANT: Do not allow R-134A refrigerant to escape into the atmosphere. A KUBOTA dealer has the proper handling and recycling equipment to service the system.



Check Condition of Battery



CAUTION



Wear gloves and protective eyewear when handling batteries. Keep open flames or sparks away from the batteries.



DANGER



Batteries contain sulfuric acid. Flush the affected area with water for five minutes. In case of contact with skin, seek medical attention immediately.




Do not try to open sealed no-maintenance batteries.

Park the tractor on a flat surface, shut off the engine and apply the parking brake.

1. Remove the cover from the battery box.
2. Remove any debris and then wash and dry the battery tops.
3. Inspect components for damage and replace or repair as required.

For serviceable type batteries only:

4. Use a flat-bladed screwdriver to remove the fill caps and check that the electrolyte level is 6 mm (0.75 in) below the filler neck of each cell.
5. Add distilled or demineralized water to the cells if the level is low. Do not overfill.
6. Replace the fill plugs. Check for loose cable connections and tighten if required.
7. Re-install the battery box cover.



Drain the Fuel Tanks



WARNING





Diesel fuel is a flammable and hazardous material. Use appropriate safe handling precautions.

Perform this operation when the tanks are near empty.

Park the tractor on a flat surface, shut off the engine and apply the parking brake. Block the front and rear wheels. The fuel tank (1) on the left side of the tractor has a 2 drain valve (2) located near the bottom outside corner of the tank.

1. Close the fuel shut-off valves near the bottom of the left side fuel tank.
2. Remove any debris and clean the area around the drain valve on the fuel tank.
3. Place a container under the drain valve.
4. Open the drain valve and allow all the remaining fuel in the tank to flow into the container.
5. Close the drain valve.
6. Inspect the fuel connections, hoses and clamps for signs of leakage, damage or deterioration and make repairs if required. Tighten the hose clamps to 5 N·m (44 in-lb).
7. Open the fuel shut-off valves when the procedure is completed.
8. Fill the tanks with fresh diesel fuel.
9. Dispose of the old fuel properly and in compliance with regulatory requirements in your area.



Initial 500 Hours



DANGER

- Always engage the parking brake fully, place the transmission in neutral, shut the engine off, turn the battery shut-off switch to OFF and block the wheels before performing any maintenance operations.




- Allow the engine to cool before performing maintenance.
- Do not check, lubricate, service or adjust the tractor with the engine running unless otherwise instructed.

After the initial 500 hours of operation, complete the following maintenance procedures. This is in addition to the maintenance performed every 10 (daily), 50, 100 and 250 hours.

Clean Suction Filter

1. Place vessel under the filter (1).
2. Loosen the hexagon screws (2).
3. Clean the filter.
4. Re-assemble in reverse order.


NOTE: The suction filter (screen insert) must be cleaned at every oil change and checked whether it is in a perfect condition.




Change and Fill Oil for Transmission and Rear Axle Final Drives

NOTE: Drain oil only at operating temperature


1. Oil drain plugs are located at the bottom side of the transmission.
2. Loosen the oil plugs (1) to drain oil from the transmission and rear axle.
3. Loosen the oil drain plugs (2) located at the bottom of rear final drives, right and left sides to drain oil from the rear final drives.
4. Once all oil has been drained, reinstall all oil drain plugs with new seal rings and tighten.



5. Remove transmission/rear differential fill cap (3).
6. Fill with 72 L (19 gal) of oil. Oil level is near the upper marking at the oil sight glass.





7. Remove rear final drive plugs (4) from the right and left sides.
8. Fill final drive till oil is at the bottom of the tank fill plug holes. Approximately 11 L (2.9 gal).
9. Re-install rear final drives with new seal rings and tighten.



Change Transmission Oil Filter

NOTE: Drain oil only at operating temperature.



1. Unscrew housing on the filter housing (1).
2. Change filter element (2).
3. Replace O-ring (3) and place into the groove of the filter housing and insert in the filter.
4. Refit pressure filter (4) with filter element into the housing until contact. Torque to 50 N·m (37 ft·lb).



Change Rear Planetary Oil

NOTE: Drain oil only at operating temperature.

1. Loosen the oil plugs to drain oil from the rear planetary (1).
2. Once all oil has been drained, reinstall all oil drain plugs with new seal rings and tighten.



Change Hydraulic Filters (Steering, Charge and Return)



WARNING

Never under any circumstances try to disconnect a fitting or open the hydraulic system with the engine running. High pressure oil spray can cause serious injury or death.





Never start the engine when a hydraulic component is disconnected.

Change Steering Hydraulic Filter


Removal

1. Always engage the parking brake fully, place the transmission in neutral, shut the engine off, wait for the power on indicator light (1) to turn off.
2. Turn the battery shut-off switch (2) to OFF and block the wheels before performing any maintenance operations.
3. Switch off the hydraulic system and release filter pressure.
4. Unscrew the filter head (3), drain the fluid into a suitable container and clean or dispose in accordance with environment regulations.
5. Remove the filter (4). Check the surface of element for contamination residue and larger particles. These can indicate damage to components.
6. Replace the filter.
7. Clean the filter bowl and filter head. Pay attention to the threads.
8. Examine the filter especially the sealing surfaces for mechanical damage.
9. Check o-rings and replace if necessary.



Installing

1. Wet the sealing surfaces and thread on the filter head (1) and the o-ring with clean operating fluid.
2. Place the filter element (2) on the filter head.
3. Apply silver grade anti-seize (per Mil-PRF 907E) to the threads.
4. Tighten the filter head and then unscrew by one-quarter turn.
5. Switch the hydraulic system on and vent filter at a suitable point in the system.
6. Check for leakage.



Change Hydraulic Oil Return Filter



WARNING


Escaping fluids under high pressure can penetrate skin and cause serious and life-threatening injury.



Relieve hydraulic pressure before opening any component. Wear gloves and eye protection when carrying out hydraulic tests.

Never use your hands to check for fluid leaks. Use a piece of cardboard or paper to search for a suspected leak.

1. Always engage the parking brake fully, place the transmission in neutral, shut the engine off, wait for the power on indicator light (1) to turn off.
2. Turn the battery shut-off switch (2) to OFF and block the wheels before performing any maintenance operations.
3. Place an oil pan under the tractor to catch any hydraulic fluid that may drain.



4. Spin off the canister (3).
5. Lube the o-ring on the filter. Fill the filter with oil and install the filter.
6. Start the tractor and check for hydraulic oil leaks.
7. Check the hydraulic oil level on the sight glass and add hydraulic oil if needed.



Change Hydraulic Charge Filter



WARNING


Escaping fluids under high pressure can penetrate skin and cause serious and life-threatening injury.



Relieve hydraulic pressure before opening any component. Wear gloves and eye protection when carrying out hydraulic tests.

Never use your hands to check for fluid leaks. Use a piece of cardboard or paper to search for a suspected leak.

1. Always engage the parking brake fully, place the transmission in neutral, shut the engine off, wait for the power on indicator light (1) to turn off.
2. Turn the battery shut-off switch (2) to OFF and block the wheels before performing any maintenance operations.
3. Place an oil pan under the tractor to catch any hydraulic fluid that may drain.



4. Spin off the canister (3).
5. Lube the o-ring on the filter. Fill the filter with oil and install the filter.
6. Start the tractor and check for hydraulic oil leaks.
7. Check the hydraulic oil level on the sight glass and add hydraulic oil if needed.



Change the Hydraulic Oil

NOTE: Dispose of used oil in accordance with local environmental regulations.

1. Disconnect any attached equipment.
2. Operate the tractor to warm up the hydraulic system.
 - Lift the 3-pt hitch to the fully raised position, then lower it fully.
 - Cycle the remote hydraulic valves.
 - Center the steering.
 - Apply the service brake pedals.
3. Park the tractor on a level surface, shut the engine off and apply the parking brake.
4. Clean the area around the drain plug (1) and the fill cap (3).
5. Place a container that will hold 140 L (37 gal) below the drain remove the drain plug.

NOTE: Expect oil retention in the system. Up to 20 L (5.25 gal) may remain in passages and filters.




6. Replace the drain plug when the hydraulic fluid stops draining. Tighten plug.

NOTE: Before refilling the system, perform "Change Hydraulic Filters (Steering, Charge and Return)" on page 5-71. Specified oil is Shell Spirax S4 TXM™ or equivalent.

NOTE: Refer to specifications in Section 7 of this manual.

7. Remove the hydraulic oil filler cap (2) and add fresh transmission oil until the oil level is between the marks in the sight glass (3).
8. Wait 5 minutes before starting the engine to allow air to escape from the oil and the fluid level to stabilize.
9. Start the engine and run at 1 200 rpm for 2 minutes.
10. Raise the 3-pt hitch to fully extend the cylinders.
11. Check the oil level and top up as necessary.
12. Clean up any spills.

NOTE: Dispose of oil or contaminated materials in accordance with local environmental regulations.



Every 500 Hours

After every 500 hours of operation, complete the following maintenance procedures. This is in addition to the maintenance performed every 10 (daily), 50, 100 and 250 hours.



DANGER

- Always engage the parking brake fully, place the transmission in neutral, shut the engine off, turn the battery shut-off switch to OFF and block the wheels before performing any maintenance operations.



- Allow the engine to cool before performing maintenance.
- Do not check, lubricate, service or adjust the tractor with the engine running unless otherwise instructed in a specific maintenance operation.

Check Batteries

Follow the Battery Safety Guide and Battery Disconnect Procedure below before performing the following:

- Checking battery connections.
- Checking battery electrolyte level.
- Checking alternator power cables.

NOTE: Before disconnecting batteries, record the tire size from the Tire Size Adjustment calibration screen on the EIC. After disconnecting batteries, check the tractor configuration as it appears on the EIC (wheel speed, lighting, etc.).

Battery Safety Guide



DANGER



- Wear personal protective equipment. Batteries are full of corrosive acid.
- Always wear safety glasses to protect eyes and protective clothing when working with batteries.
- Flush the affected area with water for 5 minutes and seek immediate medical attention in case of contact with skin.

Batteries generate corrosive gas.



- Do not smoke or expose the battery to open flame. Batteries generate hydrogen gas, which is highly flammable. The gas may explode, causing a spray of battery acid and fragments which can cause severe personal injury if ignited by a spark or flame.
- Do not open sealed valve regulated batteries (AGM or Gel types).
- Always cover vents with a damp cloth to minimize gas seepage.
- Never lean over battery while testing, boosting or charging.
- Do not remove or damage vent caps.

NOTICE

Battery connections must be clean and tight for the electrical system to work properly.

Battery Disconnect Procedure



DANGER

Follow this battery disconnect procedure before servicing batteries or electrical parts to avoid sparks or explosions:



1. Turn the battery shut-off switch to OFF and lockout the switch.
 2. Always disconnect the negative (-) black cables before the positive (+) red cables.
 3. Always connect the positive (+) red cables before the negative (-) black cables.
-



CAUTION



Do not contact the positive and negative terminals at the same time with a metal tool. This will cause an arc.

Check Battery Connections



DANGER



- Wear safety glasses and protective clothing for this task. Keep battery away from sparks or flames.
- Do not try to open sealed no-maintenance batteries.
- Cover vents with a damp cloth to minimize gas seepage (flooded types).
- Never lean over battery while testing, boosting or charging.



Keep battery connections clean and tight for proper operation of the electrical system. Remove debris and clean the area, then inspect as follows:

1. Shut off the main power disconnect switch (1) and remove the battery cover.
2. Remove the black rubber boot protecting the negative (-) battery terminals. Disconnect the negative (-) battery ground cable connections (2).
3. Remove the red rubber boot protecting the positive (+) battery terminals. Disconnect the positive (+) cable connections (3).
4. Use a wire brush to thoroughly clean the battery studs, battery cables and mounting nuts.
5. Reconnect the cables. Make sure to connect the positive cables first and then the negative cables.
6. Replace worn or damaged parts.

NOTE: Tighten the battery connections to 20 N·m (15 ft·lb) maximum. Do not overtighten. Contact a KUBOTA dealer for parts and service information.



Inspect the Electrical Cables at the Starter



DANGER





Disconnect the cables at the battery before inspecting or working on the cables at the starter.

IMPORTANT: To reduce the risk of sparks and battery explosion:

IMPORTANT: Always connect the positive cables first and then the negative cables.

1. Disconnect the cables at the battery.
2. Open the hood. The starter is located on the right hand side of the engine.
3. Use compressed air at less than 690 kPa (100 psi) to clean the starter and adjacent areas.
4. Check the starter ground cable (1) to make sure the cable and connection are clean and tight.
5. Check the starter power cable (2) to ensure the cable and connection are clean and tight.
6. Check the connections to the starter solenoid (3).
7. Remove the cables and clean the terminal posts (4) with a wire brush if the connections are dirty or corroded. Replace any damaged connector terminations and rubber covers.
8. Reconnect the components and tighten carefully to 17.5 to 24.5 N·m (13 to 18 ft lb).



Change the Engine Oil and Filter

NOTICE

Use CJ4 low ash oil to prevent damage to the DPF over time. The DPF's cannot regenerate ash because it does not oxidize.

NOTICE




Do not over-tighten the filter. Install the new filter and tighten the filter by hand until the gasket just contacts the filter head surface. Use a strap wrench to tighten the filter an additional one-half turn.

NOTICE


Do not overfill. If necessary, drain oil to adjust to the proper level.

NOTE: Discard used engine oil and filter according to local laws and regulations.


1. Park the tractor on a level surface and apply the parking brake.
2. Operate the engine until the coolant temperature reaches at least 82°C (180°F) then shut the engine off.
3. Remove the drain plug (1) from the engine oil pan and allow the oil to drain completely into an appropriate container with a capacity of at least 25 L (6.60 gal).
4. Clean the area around the oil filter head (2). Rotate the oil filter (3) counterclockwise to remove and discard the used filter in accordance with local regulations.
5. Clean the sealing surface of the filter head. Make sure the O-ring from the old filter did not stick to the filter head.
6. Lubricate the inner O-ring on the new filter with clean engine oil prior to installation.



7. Clean and check the oil drain plug threads and the sealing surfaces. Reinstall and tighten the oil drain plug to 80 N·m (59 ft·lb). Do not over tighten.
8. Clean the area around the fill port (1) and the dipstick (2). Add oil until it reaches the FULL mark (3) on the dipstick. Use the dipstick to check for the proper level of oil before the engine is started. Oil change capacity of the oil pan and filter is approximately 23 L (6.1 gal).
9. Start the engine and run at idle speed. Inspect for leaks at the filter and drain plug.
10. Shut off the engine. Wait at least 15 minutes to allow the oil to drain down from the upper engine. Check the oil level and adjust to the FULL mark on the dipstick.



NOTE: The maximum engine oil capacity is 25.6 L (6.76 gal).



Replace the Fuel Filters




WARNING

Never try to open fuel system components or connections with the engine running. High pressure fuel spray can cause serious injury or death.



Diesel fuel is a flammable and hazardous material. Use appropriate safe handling precautions.

The Cummins fuel system uses 2 filters. The first or primary filter is a combined filter and fuel/water separator (1) located at the rear of the left hand side of the engine. The secondary filter (2) is the particulate filter.



CAUTION




Wear eye protection and gloves when handling fuel. Observe the safety precautions for flammable liquids.

NOTE: Use only the manufacturer's recommended replacement filters.

Park the tractor on level ground, shut the engine off and apply the parking brake. Use a suitable container and cloths to control and absorb spills.

1. Clean the area around the fuel filters and connections.
2. Disconnect the sensor connector (3) from the fuel/water separator.
3. Rotate the filter counterclockwise with a filter wrench to loosen, then remove the filter by hand. Use a container to collect fuel that may spill.
4. Replace the primary filter first. Make sure the seal is in place and lubricated and add approximately 1 IL (0.26 qt) of clean fuel to the filter before installation.
5. Tighten the new fuel filter by hand, then use a filter wrench to tighten an additional 1/4 turn.



6. Reconnect the sensor connection.
7. Use a similar procedure to replace the secondary filter.

IMPORTANT: Do not add fuel to the secondary fuel filter (2) before installing.


NOTE: Always lubricate the rubber seals on filters unless otherwise noted. Rotate filters by hand counterclockwise to install until the O-ring contacts the filter head sealing face, then use a filter wrench to tighten another 1/4 turn.

Front PTO Oil Change and Filter Clean

NOTE: Clean the filter area before proceeding. Keep hydraulic components and systems free of contamination.

1. Drain the oil from the gear box. The draining plugs (1) are on the underside of the gear box.
2. Remove the snap ring (2) from the pump unit and loosen the M8 bolt (3) to remove the cover.
3. Take the oil filter from the pump unit and clean it with an air compressor.
4. Replace the oil filter, the lid and snap ring and fill the gear box to the filling plug (4) with oil.

NOTE: Contact a KUBOTA dealer for service advice or materials.




Check the PTO Gearbox Mounting Bolts

Check the security of all PTO and 3PT hitch mounting all bolts.

Lubricate the PTO Drive Shaft

Lubricate the the PTO drive shaft lubrication fitting (1) with high temperature EP grease.



Every 1 000 Hours or 1 Year

After every 1 000 hours or 1 year of operation, complete the following maintenance procedures. This is in addition to the maintenance performed every 10 (daily), 50, 250 and 500 hours.



DANGER



- Always engage the parking brake fully, place the transmission in neutral, shut the engine off, turn the battery shut-off switch to OFF and block the wheels before performing any maintenance operations.
- Allow the engine to cool before performing maintenance.
- Do not check, lubricate, service or adjust the tractor with the engine running unless otherwise instructed in a specific maintenance operation.

IMPORTANT: *The maintenance procedures in this category must be performed once a year even if the tractor was used less than 1 000 hours during the year. These maintenance procedures must be performed at the 1 000-hour service interval if the tractor is used more than 1 000 hours a year.*

Check the Accessory Drive Belt and Tensioner

Remove the engine compartment safety shields to access the engine accessory drive belt.

Inspect the drive belt for cracks or wear. Replace the belt if there is any indication of damage or wear.

Check the automatic tensioner for wear or looseness. Consult with a KUBOTA dealer if there are concerns about the belt tensioner.

Refer to the Cummins engine manual or a KUBOTA dealer for details.

Replace the Cab Air Filter



WARNING

Wear a suitable mask to service or replace the air filters. Do not breath in the dust.



Always wear appropriate eye and face protection when using compressed air. Flying dirt and debris can cause serious personal injury.



WARNING

The cab air filter is designed to remove dust and particulate from the air that is used for ventilation.





The filter does not provide protection from chemical vapor and is not a safe barrier from pesticides.

Always follow the chemical manufacturers safety instructions for use of their products.

The tractor cab is equipped with a single air filter cartridge installed in the cab frame above the left side door.


1. With the cab door closed, hold the cover panel (1) closed and remove the screw (2).
2. Lower the cover panel and swing the panel back.
3. Carefully pull the filter (3) forward to release the filter from the filter housing.
4. Clean the filter housing and ducting with a cloth to remove dust that may have collected. Do not use shop air to clean these components.
5. Use soap and water solution to clean and lubricate the seal.
6. Push the new filter and foam pre-filter onto the filter housing and reinstall the cover.
7. Dispose of the used cab air filter.



Replace the Engine Air Filter

The engine air cleaner consists of 1 primary and 1 secondary filters located at the top of the engine. To change the engine air filters:

1. Park the tractor on a level surface, shut off the engine and apply the parking brake.
2. Open the hood and find the engine air filter. Use a suitable step ladder to access the filter.
3. Release the four snap latches (1) and pull the air filter cover away from the housing.





4. Clean the inside of the filter housing before the safety filter element is removed.
5. Pull the primary filter (2) from the housing.
6. Pull the safety filter (3) from the housing.

IMPORTANT: Do not allow dirt or dust from the filters to contaminate the intake plenum. Use a clean cloth and soap solution to clean the inside of the filter housing before removing the safety filter element.

7. Install the new safety filter. Carefully press the filter into place by pushing on the plastic edge of filter.

IMPORTANT: Do not press on the paper filter element.

8. Install the new primary filter elements.
9. When the filter elements are in place, reinstall the cover on the filter housing and fasten the snaps.



Inspect the Turbocharger Connections



DANGER



- Keep hands and clothing away from moving parts.
- Do not wear loose clothing.
- Do not touch hot parts.
- Wear appropriate eye and face protection.

1. Turbocharger maintenance affects the engine warranty. Refer to the Cummins Engine Manual or contact a KUBOTA dealer for details.
2. Inspect the air inlet and outlet connections for the turbocharger for cracks. Check flexible hoses for damage, cracking, abrasion or soft spots.
3. Check clamps (1) for damage and make sure the clamps are properly tightened.

Clamp Type	Torque Specification
Hose clamp	5 N·m (44 in-lb)
Tee bolt (T-bar) clamp (Charge Air System)	8 N·m (71 in-lb)
Exhaust outlet pipe, V-band clamp	8 N·m (71 in-lb)



4. Check the charge air components from the charge air cooler (2) to the intake charger and from the charge air cooler to the engine intake manifold (3).
5. Leaks in the turbocharger system can sometimes be detected by visual inspection or by a whistling sound in the area of a connection.

Visual Leak Test

With the aid of a second person to operate the engine:

6. Start and run the tractor engine with the parking brake applied and the tractor in neutral.
7. Have the operator adjust the engine speed from idle to 1 700 rpm and listen for air leaks. Use a spray bottle with soap-and-water solution to wet the area around hoses and pipe fittings and watch for bubbles which indicate air leaks. Note the location of air leaks and shut the engine off.

Contact a KUBOTA dealer for service and parts advice.



Check the Radiator and Heating System Hoses and Connections



WARNING

- Never open the radiator or cooling system when the engine is hot.
- Observe all safety and environmental precautions with regard to engine antifreeze handling and spills. Engine antifreeze is an environmental hazard and there is no acceptable level of leakage or loss.



1. Inspect radiators and all fittings and attachment points for cracks, leakage or other signs of damage.
2. Inspect hoses for cracks and wear. Check for soft spots which indicate internal failure. Inspect the clamps and fittings for corrosion and damage; make sure the clamps are properly tightened.

3. Replace components that show any indication of damage or deterioration.


Contact a KUBOTA dealer if there is any doubt about the condition of hoses, clamps or radiators.

4. Tighten cooling system hose clamps to 5 N·m (44 in-lb).
5. Check the level at the cooling system surge tank (1). Use the filler neck (2) when replacing coolant.
6. Run the engine until operating temperature is reached and then recheck the coolant levels at the surge tank (1).

Recommended coolant is ASTM4985 specification such as Fleetguard™.

Fully formulated coolant must meet ASTM D-6210/D-6211 specification.

Contact a KUBOTA dealer for service advice.



Every 1 000 Hours

Perform these maintenance procedures after every 1 000 hours of operation, in addition to the regular service at 10, 50, 250 and 500 hours.



DANGER

- Always engage the parking brake fully, place the transmission in neutral, shut the engine off, turn the battery shut-off switch to OFF and block the wheels before performing any maintenance operations.



- Allow the engine to cool before performing maintenance.
- Do not check, lubricate, service or adjust the tractor with the engine running unless otherwise instructed in a specific maintenance operation.



WARNING



Avoid contact with hot oil. Allow the oil to cool to a safe temperature before proceeding.

Change Hydraulic Filters (Steering, Charge and Return)



WARNING

Never under any circumstances try to disconnect a fitting or open the hydraulic system with the engine running. High pressure oil spray can cause serious injury or death.





Never start the engine when a hydraulic component is disconnected.

Change Steering Hydraulic Filter


Removal

1. Always engage the parking brake fully, place the transmission in neutral, shut the engine off, wait for the power on indicator light (1) to turn off.
2. Turn the battery shut-off switch (2) to OFF and block the wheels before performing any maintenance operations.
3. Switch off the hydraulic system and release filter pressure.
4. Unscrew the filter head (3), drain the fluid into a suitable container and clean or dispose in accordance with environment regulations.
5. Remove the filter (4). Check the surface of element for contamination residue and larger particles. These can indicate damage to components.
6. Replace the filter.
7. Clean the filter bowl and filter head. Pay attention to the threads.
8. Examine the filter especially the sealing surfaces for mechanical damage.
9. Check o-rings and replace if necessary.



Installing

1. Wet the sealing surfaces and thread on the filter head (1) and the o-ring with clean operating fluid.
2. Place the filter element (2) on the filter head.
3. Apply silver grade anti-seize (per Mil-PRF 907E) to the threads.
4. Tighten the filter head and then unscrew by one-quarter turn.
5. Switch the hydraulic system on and vent filter at a suitable point in the system.
6. Check for leakage.



Change Hydraulic Oil Return Filter



WARNING


Escaping fluids under high pressure can penetrate skin and cause serious and life-threatening injury.



Relieve hydraulic pressure before opening any component. Wear gloves and eye protection when carrying out hydraulic tests.

Never use your hands to check for fluid leaks. Use a piece of cardboard or paper to search for a suspected leak.

1. Always engage the parking brake fully, place the transmission in neutral, shut the engine off, wait for the power on indicator light (1) to turn off.
2. Turn the battery shut-off switch (2) to OFF and block the wheels before performing any maintenance operations.
3. Place an oil pan under the tractor to catch any hydraulic fluid that may drain.



4. Spin off the canister (3).
5. Lube the o-ring on the filter. Fill the filter with oil and install the filter.
6. Start the tractor and check for hydraulic oil leaks.
7. Check the hydraulic oil level on the sight glass and add hydraulic oil if needed.



Change Hydraulic Charge Filter



WARNING


Escaping fluids under high pressure can penetrate skin and cause serious and life-threatening injury.



Relieve hydraulic pressure before opening any component. Wear gloves and eye protection when carrying out hydraulic tests.

Never use your hands to check for fluid leaks. Use a piece of cardboard or paper to search for a suspected leak.

1. Always engage the parking brake fully, place the transmission in neutral, shut the engine off, wait for the power on indicator light (1) to turn off.
2. Turn the battery shut-off switch (2) to OFF and block the wheels before performing any maintenance operations.
3. Place an oil pan under the tractor to catch any hydraulic fluid that may drain.



4. Spin off the canister (3).
5. Lube the o-ring on the filter. Fill the filter with oil and install the filter.
6. Start the tractor and check for hydraulic oil leaks.
7. Check the hydraulic oil level on the sight glass and add hydraulic oil if needed.



Change the Hydraulic Oil

NOTE: Dispose of used oil in accordance with local environmental regulations.

1. Disconnect any attached equipment.
2. Operate the tractor to warm up the hydraulic system.
 - Lift the 3-pt hitch to the fully raised position, then lower it fully.
 - Cycle the remote hydraulic valves.
3. Park the tractor on a level surface, shut the engine off and apply the parking brake.
4. Clean the area around the drain plug (1) and the fill cap (2).
5. Place a container that will hold 140 L (37 gal) below the drain remove the drain plug.

NOTE: Expect oil retention in the system. Up to 20 L (5.25 gal) may remain in passages and filters.



6. Replace the drain plug when the hydraulic fluid stops draining. Tighten plug.

NOTE: Before refilling the system, perform "Change the Hydraulic Oil Filters" on page 5-91. Specified oil is Shell Spirax S4 TXM™ or equivalent.

NOTE: Refer to specifications in Section 7 of this manual.

7. Remove the hydraulic oil filler cap (2) and add fresh transmission oil until the oil level is between the marks in the sight glass (3).
8. Wait 5 minutes before starting the engine to allow air to escape from the oil and the fluid level to stabilize.
9. Start the engine and run at 1 200 rpm for 2 minutes
10. Raise the 3-pt hitch to fully extend the cylinders.
11. Check the oil level and top up as necessary.
12. Clean up any spills.


NOTE: Dispose of oil or contaminated materials in accordance with local environmental regulations.



Clean Suction Filter

1. Place vessel under the filter (1).
2. Loosen the hexagon screws (2).
3. Clean the filter.
4. Re-assemble in reverse order.




NOTE: *The suction filter (screen insert) must be cleaned at every oil change and checked whether it is in a perfect condition.*



Change and Fill Oil for Transmission and Rear Axle Final Drives

NOTE: Drain oil only at operating temperature



1. Oil drain plugs are located at the bottom side of the transmission.
2. Loosen the oil plugs (1) to drain oil from the transmission and rear axle.
3. Loosen the oil drain plugs (2) located at the bottom of rear final drives, right and left sides to drain oil from the rear final drives.
4. Once all oil has been drained, reinstall all oil drain plugs with new seal rings and tighten.
5. Remove transmission/rear differential fill cap (3).
6. Fill with 72 L (19 gal) of oil. Oil level is near the upper marking at the oil sight glass.
7. Remove rear final drive plugs (4) from the right and left sides.
8. Fill final drive till oil is at the bottom of the tank fill plug holes. Approximately 11 L (2.9 gal).
9. Re-install rear final drives with new seal rings and tighten.



Change Transmission Oil Filter

NOTE: Drain oil only at operating temperature.

1. Unscrew housing on the filter housing (1).
2. Change filter element (2).
3. Replace O-ring (3) and place into the groove of the filter housing and insert in the filter.
4. Refit pressure filter (4) with filter element into the housing until contact. Torque to 50 N·m (37 ft·lb).



Change Diesel Exhaust Fluid (DEF) In-Tank Filter



WARNING



To avoid structural damage and personal injury, do not remove the ladder or any feature supporting the ladder without first emptying the fuel tanks.



CAUTION

Wear gloves and eye protection when adding diesel exhaust fluid (DEF). DEF is not harmful to handle but will corrode certain metals.




- In case of eye contact: Remove contact lenses. Immediately wash your eyes with a lot of water for least 15 minutes.
- In case of skin contact: First aid is normally not required. Immediately wash your skin with soap and water. Avoid prolonged contact with DEF.
- If swallowed: Do not give milk or alcoholic beverages. Never give anything by mouth to an unconscious person. If symptoms persist, contact a physician immediately.

The DEF tank filter (1) is located on the DEF tank sensor (2).

To change the DEF Doser Unit Filter or if you need to access the DEF Doser Unit for any other purpose, remove the cover on top of the Diesel Exhaust Fluid (DEF) tank.



See “Step 2: Remove DEF Sensor and Change Filter” on page 5-101.



Step 1: Remove the DEF Tank Cover and Hoses


NOTE: Label all hoses and wires and mark their location before disconnecting them from the DEF tank.

1. Park the tractor on a level surface and set the parking brake. Remove the key from the ignition, wait for the power on indicator to turn off and turn the battery disconnect switch to the OFF position.
2. Remove the 4 capscrews (1) on top of the diesel exhaust fluid (DEF) tank cover (2).
3. Remove the 2 bolts (3) on the side of the DEF tank cover
4. Remove the DEF tank cover from the tractor.
5. Disconnect the DEF harness electrical connector (4) from the DEF Sensor unit (5). Remove plastic ties if needed.
6. Tag and disconnect the coolant supply line (6) from heater valve, DEF supply line (7), DEF return line (8) from the DEF injector and coolant line (9) to DEF module/pump. Cap and plug all openings to prevent contamination and fluid loss.




Step 2: Remove DEF Sensor and Change Filter


1. Remove the 2 capscrews (1) from the DEF sensor (2) to the DEF tank (3).



2. Pull the DEF sensor completely out of the tank.



3. Remove the bolt (1) and old filter (2) from the DEF Sensor Tube (3).
4. Install the new filter.
5. Reinsert the DEF sensor into the tank.
6. Follow the reverse of this procedure to reinstall the DEF tank sensor.
7. Reinstall DEF Tank cover and reconnect all hoses and wiring harnesses.
8. Fill the DEF tank.
9. Start the engine and allow the DEF to circulate through the system. Check for any warning indicator lamps on the EIC.



Before Changing the Coolant

- Check the coolant level. Low coolant may indicate leaks in the system.
- Check for leaks. Look for signs of coolant leaks around connections or below coolers.
- Inspect coolant hoses and connections.
- Check for damaged or cracked hoses. Replace any hose that has soft spots or bulges.
- Replace corroded or damaged hose clamps before refilling the system.



WARNING



Do not remove the pressure cap on a hot engine. Hot coolant spray or steam can cause personal injury. Allow the engine temperature to drop to 50°C (120°F) before removing the pressure cap. Wear eye protection and protective clothing when working on the cooling system.



DANGER



- Always engage the parking brake fully, place the transmission in neutral, shut the engine off, turn the battery shut-off switch to OFF and block the wheels before performing any maintenance operations.
- Allow the engine to cool before performing maintenance.
- Do not check, lubricate, service or adjust the tractor with the engine running unless otherwise instructed in a specific maintenance operation.



WARNING



Coolant is toxic. Observe all safety precautions when handling coolant. Wear eye protection and gloves. Dispose of coolant safely and in compliance with environmental regulations.

Replace Engine Coolant and Service the Cooling System

IMPORTANT: Do not allow the cooling system to dry out.

The rust and corrosion inhibitors in the antifreeze and the filter/conditioner deteriorate with use and require replacement.

The tractor is equipped with a filter system that maximizes the service life of the coolant. The continued life and performance of the engine requires proper maintenance of the cooling system

Change the Coolant




WARNING



Do not allow coolant to spill onto ground. The toxic components of the chemicals are proven health hazards and will find their way into the water supply. Always observe the environmental regulations in disposing of containers and fluids.

Park the tractor on a level service pad, shut the engine off and apply the parking brake. Use a 20 L (5 gal) catch basin and a splash tray to drain the coolant. Prepare a drain hose and hose adapters and have a supply of clean absorbent cloths for wiping and emergency clean up.

1. Allow the engine temperature to cool below 50°C (120°F).
2. Use a thick cloth to carefully open and remove the pressure cap from the overflow tank.
3. Turn the heater control to the full hot position.
4. Open the lower drain valve (1) on bottom of the radiator and drain the coolant into the basin.
5. Loosen the lower hose clamp and pull the hose off the radiator to drain the remaining coolant from the radiator and the engine.



Flushing the Cooling System

NOTE: Contact a Kubota dealer for questions about cooling system maintenance.

NOTE: Follow the directions provided in your Cummins operation and maintenance manual.

Flush the cooling system using Fleetguard Restore™ and refill with the specified coolant mixture.

NOTE: Extreme environment and heavy duty use may shorten the service life of the coolant system. Contact a KUBOTA dealer for more information and service.

Engine Coolant Mixture

The use of premixed coolant is recommended. Use fully formulated antifreeze/coolant that meets Cummins Engineering Standard 14603 and use distilled water if mixing is necessary.

IMPORTANT: Do not use additives of any kind.

Water must not exceed 170 ppm hardness or contain more than 40 ppm chloride or 100 ppm sulfate. Do not use water if you are unsure of the water quality.

IMPORTANT: Do not add cold coolant to a hot or overheating engine. Serious engine damage can occur. Allow the engine temperature to cool below 50 °C (120 °F) before adding coolant.

Refilling the Cooling System


IMPORTANT: Make sure the air is purged from the cooling system before returning the vehicle to service.

NOTE: The cooling system capacity is approximately 72 L (19 gal).

1. Make sure all coolant connections are tight and the drains are closed.
2. Remove the pressure cap (1) from the vent fitting on the top of the coolant surge tank and check that the coolant filter bypass is open.
3. Slowly pour the fresh coolant mixture into the upper reservoir fill opening. Avoid spills.
4. Add coolant until the level on the sight glass.
5. Wait two to three minutes and check the coolant level in the sight glass (2) on the surge tank. Add coolant until the level shows in the middle of the reservoir sight glass.
6. Start the engine and idle at 1 000 rpm for two minutes with the fill cap off. Shut the engine off and top up the upper reservoir if required.
7. Install the pressure cap.
8. Start the engine and run at 1 700 rpm until the thermostat opens. Make sure the temperature is at least 82 °C (180 °F).
9. Reduce engine speed to 1 000 rpm for two minutes to cool the engine and turbocharger components.
10. Shut the engine off and allow the system to cool until the coolant temperature is below 50 °C (120 °F).
11. Check the coolant level at the surge tank (1).

NOTE: Check for leaks and check the level at the surge tank sight glass if the overflow tank level is low (4).

12. Top up the coolant if necessary and repeat steps 5 through 11 as required. Do not overfill the system.
13. Add coolant to the surge tank when required to maintain the level in the cooling system.



Change the Front Axle Differential Oil

NOTE: For severe or high ambient temperature applications, reduce the oil change interval to 500 hours or 6 months, whichever comes first.

Operate the tractor for at least ten minutes to warm



WARNING



Hot oil may spray out when the plug is removed. Wear protective clothing and safety glasses to help prevent injury.





the oil in the differential. Park the tractor on a level surface and center the front wheels. Shut the engine off and apply the parking brake.

1. Place a suitable container approximately 16 L (4 gal) in capacity under the axle drain plug.
2. Loosen the fill/check plug (1) to allow air to enter.
3. Carefully remove the axle drain plug (2) and allow the oil to drain completely into the container. Dispose of the used oil properly.
4. Re-install the axle drain plug.
5. Remove the fill/check plug (1) and fill the axle with fresh oil until it reaches the bottom of the fill/check plug hole.

NOTE: Oil Specification: Shell Spirax S4 TXM™ or equivalent. See Lubricants and Fluids in Section 7 of this manual. Rated oil capacity: 14.5 L (3.83). Contact a KUBOTA dealer for service advice or materials.

6. Re-install the fill/check plug (1) and operate the tractor; stop the tractor and check for leaks.

NOTE: Dispose of oil and contaminated materials in accordance with local environmental regulations.



Change the Front Planetary Hub Oil

NOTE: Operate the tractor to warm the oil and help remove contaminants when the oil is drained. Contaminants may settle out and not be removed if the oil is not warm.

1. Park the tractor on a level surface and center the front wheels. Shut the engine off and apply the parking brake.
2. Rotate the hub to position the fill/drain plug near the top (1). Loosen the plug to allow air to escape; the hub is not vented.
3. Hand tighten the plug and rotate the hub until the plug is at the bottom (2).
4. Place a suitable container of at least 6 L (1.59 gal) capacity under the plug. Remove the plug and allow the oil to drain completely.
5. Rotate the hub to position the plug opening level with the center of the hub.
6. Refill the hub with fresh oil and install the fill/drain plug. The capacity of each hub is 5 L (1.32 gal).



NOTE: The oil level is correct when the oil is at the bottom of the plug opening when the opening is level with the center of the hub.

NOTE: Oil Specification: Shell Spirax S4 TXM™ or equivalent. See Lubricants and Fluids in Section 7 of this manual.

7. Use the same procedure to change the oil in the other front planetary hub.

NOTE: Rated oil capacity of each hub is approximately 5 L (1.32 gal).

NOTE: Dispose of oil and contaminated materials in accordance with local environmental regulations.



Every 4 500 Hours or Three Years

Change Diesel Exhaust Fluid (DEF) Dosing Unit Filter



CAUTION

Wear gloves and eye protection when adding diesel exhaust fluid (DEF). DEF is not harmful to handle but will corrode certain metals.





- In case of eye contact: Remove contact lenses. Immediately wash your eyes with a lot of water for least 15 minutes.
- In case of skin contact: First aid is normally not required. Immediately wash your skin with soap and water. Avoid prolonged contact with DEF.
- If swallowed: Do not give milk or alcoholic beverages. Never give anything by mouth to an unconscious person. If symptoms persist, contact a physician immediately.

NOTE: Do not powerwash or steam clean the DEF Doser Unit. Use compressed air to remove any loose debris.

The DEF Doser Unit filter (1) is located inside the DEF Doser Unit (2).

To change the DEF Doser Unit Filter or if you need to access the DEF Doser Unit for any other purpose, remove the third step of the ladder on the left side of the tractor and the shield of the (Diesel Exhaust Fluid) DEF module access panel.


Change the DEF Doser Unit filter. See Step 2: DEF Dosing Unit Filter Change..




Step 1: Remove the DEF Doser Pump Cover

NOTE: Label all hoses and wires and mark their location before disconnecting them from the DEF tank.

1. Park the tractor on a level surface and set the parking brake. Remove the key from the ignition, wait for the power on indicator to turn off and turn the battery disconnect switch to the “OFF” position.
2. Remove the third step (1) on the ladder on the left side of the tractor by removing 4 bolts (2). Remove the third step.



3. Remove the 4 bolts (3) from the DEF (Diesel Exhaust Fluid) module access panel (4).




Step 2: DEF Dosing Unit Filter Change

NOTE: Inspect the area around the seal and vent of the aftertreatment DEF dosing unit filter cap for signs of leakage such as white deposits. Refer to *Clean and Inspect for Reuse* later in the section.


NOTE: There may be residual DEF in the filter housing. It is recommended to place a collection container below the DEF filter cap.

The aftertreatment DEF dosing unit consists of the following components:


1. Aftertreatment DEF dosing unit (1).
2. Aftertreatment DEF dosing unit filter element (2).
3. Aftertreatment DEF dosing unit frost protection membrane (3).
4. Aftertreatment DEF dosing unit filter housing (4).



1. Inspect the aftertreatment DEF dosing unit threads (5). This is important if the aftertreatment DEF dosing unit cap was damaged.
2. Replace the entire aftertreatment DEF dosing unit if the threads are damaged.
3. Make sure the frost protection membrane groove is clean and free of debris. Use a clean damp cloth, warm water and mild detergent.



4. Remove the DEF filter cap (1) from the DEF Dosing Unit (2) with a 46 mm (1.8 in) socket.
5. Remove DEF frost protection membrane (3) from the DEF Dosing Unit (2).




6. Remove the old DEF dosing unit filter (4).
7. Discard the frost protection membrane and filter element.
8. Install new frost protection membrane and filter.

NOTE: The sealing bead of the frost protection membrane must sit completely in the groove of the pump housing.

NOTE: The provided lubricant must be used when installing the filter housing.

9. Spray the supplied lubricant to the threads on the pump housing and sealing bead of the frost protection membrane.
10. Install and torque the filter housing to 80 N·m (59 ft-lb).
11. Follow the reverse of this procedure to reinstall.



Every 5 000 Hours or Four Years



DANGER

- Always engage the parking brake fully, place the transmission in neutral, shut the engine off, turn the battery shut-off switch to OFF and block the wheels before performing any maintenance operations.



- Allow the engine to cool before performing maintenance.
- Do not check, lubricate, service or adjust the tractor with the engine running unless otherwise instructed in a specific maintenance operation.

After every 5000 hours of operation or every four years (which ever comes first) complete the following maintenance procedures. This is in addition to regular service at 10, 50, 250, 500, 1 000 and 2 000 hour service.

Adjust the Engine Valve Lash

The valve lash in your Cummins engine requires adjustment every 5 000 hours or four years of operation. Contact a KUBOTA dealer.

Every 5 000 Hours

Clean the Diesel Particulate Filter (DPF)

The Diesel Particulate Filter (DPF) must be removed and cleaned every 5 000 hours to remove ash that has collected during engine operation.

The DPF requires a special cleaning procedure and the Engine Control Module (ECM) must be adjusted after a new or cleaned DPF is installed.

Contact a KUBOTA dealer when the DPF needs to be cleaned.

As Required

Perform the following maintenance operations as required.



DANGER

- Before performing any maintenance operations, always engage the parking brake fully, place the transmission in neutral, shut the engine off, turn the battery shut-off switch to OFF and block the wheels.



- Allow the engine to cool before performing maintenance.
 - Do not check, lubricate, service or adjust the tractor with the engine running unless otherwise instructed in a specific maintenance operation.
-




Windshield Washer Fluid and Wiper Blades

The washer fluid reservoir (1) is located at the rear of the cab.

Remove the cap and fill the reservoir with a formulated automotive type washer fluid.

Use the following procedure to replace the front and rear windshield wiper blades:

1. Pivot the wiper arm outward away from the window.
2. Remove the lockwasher (2) and the pivot bolt from the center of the blade.
3. Install the new blade and reinstall the pivot bolt at the center of the blade.
4. Use 713 mm (28 in) wiper blades for the front and rear wipers.



Check and Adjust the Parking Brake

Set the parking brake each time the operator leaves the driver's seat and release the parking brake before operating the tractor. Checking the parking brake is part of the daily inspection. Adjustment of the parking brake when required for safe operation of the tractor.

IMPORTANT: The parking brake should be fully applied when the parking brake lever (1) is raised to the third or fourth notch (click) on the quadrant (position 4 in the diagram at right). the cable has stretched and requires adjustment if the parking brake lever must be raised above the fourth notch to fully apply the brake.



IMPORTANT: Adjust the parking brake when the parking brake lever must be raised above the fourth notch on the quadrant to fully apply the brake.

Park the tractor on a level surface, shut the engine off and block the front and rear wheels.

1. Put the parking brake lever in the fully lowered 0 position.
2. Raise the parking brake lever to the second notch on the quadrant.
3. Loosen the forward jam nut (2) as far as possible on the cable housing (3).
4. Pull the cable housing rearward until a 9 kg (20 lb) resistance is felt. Hold the cable in that position.
5. Tighten the rear jam nut (4) until it contacts the bracket (5).
6. Tighten the forward jam nut against the bracket.

IMPORTANT: Do not overtighten the jam nuts.

7. Raise the parking brake lever and check for proper adjustment.



Fuse and Relay Replacement

The tractor has 4 fuse and relay panels. Locate the fuse and relay panel for the circuits and systems that are under inspection and use the layout drawings provided to identify the correct component to be replaced or checked.

NOTICE

- Disconnect battery to cut power to the fuse panel before attempting to remove any fuse or relay.
- Use replacement fuses that have exactly the same rating as the original fuse.
- Do not replace any relay with a different component or part number.
- Stop the tractor and investigate to identify and repair the fault if a blown fuse has been replaced and the circuit blows again.

Locating the Fuse and Relay Panels

Main Fuse and Relay Panel

The main fuse and relay panel is made up of 2 modular blocks and located on the right side inner fender of the cab (1).

NOTE: A component layout diagram is provided on the inner surface of the access panel.

NOTE: A repeat failure in a relay indicates an electrical system fault. If this happens, stop using the tractor and take steps to find and repair the fault.



When a fuse blows, investigate to determine the cause and take steps to correct the problem.

Relays may fail as a result of normal use and once replaced should provide a reliable service period.

Electrical system diagnostics and repairs must be performed by trained service personnel.

Contact a KUBOTA dealer for service and parts advice.

A decal of this fuse and relay panel is located inside the access panel.



Main Fuse and Relay Panel Layout




Table 5-21: Main Panel Relays

Relay Number	Relay Description
F01/R01	Accessory Switch (Key Switch)
F02/R02	Ignition Key Supply
F03/R03	Column
R04	Dome Light
D07	Vehicle Controller Electronics
D08	VCU Acc Wake-up
D09	Vehicle Controller Electronics
D10	Hazard
D11	Front Wiper High
F12	Dome Light
D13	Front Wiper Low
F14	Front Console
D15	Dome Light
F16	Front Console
R17	Mirror Timer
R20	VCU Electronics
F21/R21	VCU Timed
F23	Diagnostic 1
F24	Raven Autosteer HC
F25	Diagnostic 2
F26	Raven Autosteer Cruise
F27	Armrest Live
F28/R28	Armrest




Table 5-21: Main Panel Relays

Relay Number	Relay Description
F29/R29	Diagnostic 2
R30	Wiper Sw
F31	Front Wiper
F32	Rear Wiper
R33	Rear Wiper
R34	Rear Wiper Low Speed
R35	Front Wiper
R36	Front Wiper High
R37	Front Wiper Low
F38/R38	Cab Seat
F39	PP1
F40	PP2
F41	Power Plug Accessory
F42	PP4
F43	PP5
F44	PP4 Live
R45	Power Point switched
F46/R46	PP3 (USB)
F47/R47	Suspended Cab and Axle

Locating Rear Cab Fuse and Relay Panel Layout

The accessory relay panel is located at the rear of the cab under the rear interior trim panel.

Loosen the fasteners (1) and remove the trim panel to access the relay panel (2).



Rear Cab Fuse and Relay Panel Layout




Table 5-22: Relays



Relay	Function
R54	TPT20
R56	Trailer Brake Hydraulic Solenoid
R57	ISOBUS Trailer
R58	Vehicle Control Unit (VCU)
R59	Trailer Accessory Power
R60	Trailer Marker Lights
R61	Trailer Stop Lights
R62	Rear Washer Pump
R63	Mid A-post Worklights
R64	EHR Remote
R65	ECM Enable
R66	Worklight Control Panel
R69	Rear Defrost
R78	Back Lighting
R79	HVAC Manual Blower
R80	HVAC Blower
R81	HVAC Main

Table 5-23: Fuses

Fuse	Rating	Function
F54	7.5	TPT20-VPI
F56	5A	Trailer Brake Hydraulic Solenoid
F57	10A	ISOBUS Trailer
F59	20A	Trailer Accessory Power
F60	15A	Trailer Marker Lights
F61	10A	Trailer Stop Lights
F62	5A	Rear Washer Pump
F63	15A	Mid A-post Worklights
F64	10A	EHR Remote
F65	5A	ECM Enable
F66	5A	Worklight Control Panel
F70	30A	Controller
F71	30A	Rear Defrost
F72	15A	TPT20-VPE
F74	3A	V-PAS Module
F76	25A	Trailer Power (EU)
F78	5A	Back Lighting
F79	25A	HVAC Manual Blower
F80	20A	HVAC Blower
F81	15A	HVAC Main

Lighting Fuse and Relay Panel

The lighting fuse and relay panel (1) is located inside the cab behind the overhead accessory panel on the right. These fuses and relays provide circuit overload protection and a means to complete electrical circuits for the worklights and beacon.



Relay	Function
R90	Right-Front Worklights 1, 2, and 3
R91	Right-Rear Worklights 4, 5, and 6
R92	Left-Rear Worklights 7, 8, and 9
R93	Left-Front Worklights 10, 11, and 12
R94	Beacon +12V
R95	Not Used

Fuse	Rating	Function
F90	30A	Right-Front Worklights 1, 2, and 3
F91	30A	Right-Rear Worklights 4, 5, and 6
F92	30A	Left-Rear Worklights 7, 8, and 9
F93	30A	Left-Front Worklights 10, 11, and 12
F94	15A	Beacon +12V
F95		Not Used

Engine Fuse and Relay Panel

The engine fuse and relay panel is located on the left side hood support frame at the rear of the engine compartment.




Table 5-26: Front Frame Relays (PDM-1)

Relay	Function
R101	Horn
R102	High Beam
R103	Low Beam
R104	WL 90mm
R105	WL 70mm




Table 5-27: Front Frame Fuses (PDM-1)

Fuse	Rating	Function
1	7.5A	Horn
2		Not Used
3	20A	High Beam
4		Not Used
5	20A	Low Beam
6		Not Used
7	20A	WL 90mm
8		Not Used
9	20A	WL 70mm
10		Not Used




Table 5-29: Front Frame Relays (PDM-2)

Relay	Function
R107	Aftertreatment System
R108	Diesel Exhaust Fluid (DEF) Supply
R109	Diesel Exhaust Fluid (DEF) Heater
	Not Used
R110	Starter Interlock





Table 5-30: Front Frame Fuses (PDM-2)



Fuse	Rating	Function
1	30A	Engine Control Module
2	15A	Aftertreatment System
3	20A	DEF Supply Module
4		Not Used
5	20A	DEF Heater Power
6		Not Used
7		Not Used
8		Not Used
9		Not Used
10		Not Used



Change the Console Light

The console light is mounted in the roof liner above the right side control console. The light is powered whenever the key switch is turned on. When the key switch is turned off, the light can remain on and will be turned off by a timer.

1. With the main power off, insert a small screwdriver and gently push against the clips to pry the light from the headliner.
2. Disconnect the electrical connector (1). The console light is sealed in the case and must be replaced as a unit.
3. Connect the electrical connector to the new light and install the light fixture into the headliner.



Replace Batteries



WARNING



Batteries generate hydrogen gas, which is highly flammable. If ignited by a spark or flame the gas may explode causing a spray of battery acid and fragments causing severe personal injury. Do not smoke or expose the battery to open flame.



CAUTION



Always wear goggles to protect eyes and protective clothing when working with batteries. In case of contact with skin, flush the affected area for 5 minutes and seek immediate medical attention.



CAUTION



Always follow the proper connect and disconnect procedures. Always disconnect the negative (-) black cables before the positive (+) red cables. Always connect the positive (+) red cables before the negative (-) black cables to reduce the possibility of sparking and an explosion.

If the batteries are no longer functioning or seem to be functioning incorrectly, they may need to be replaced.

Contact a KUBOTA dealer for any questions regarding battery replacement.

Before beginning, park the tractor, set the parking brake and shut off the engine.

Remove Batteries

1. Turn the main power disconnect switch (1) to the OFF position.
2. Remove the rubber boots covering the black negative (-) battery ground cable connections.
3. Disconnect the black negative (-) battery ground cable connections by turning the nut counterclockwise and pulling the connection from the battery mounting stud.
4. Remove the rubber boots covering the red positive (+) battery ground cable connections.
5. Disconnect the red positive (+) battery ground cable connections by turning the nut counterclockwise and pulling the connection from the battery mounting stud.
6. Loosen the wing nuts until the clamp can be lowered away from the batteries.
7. Lift the battery from the battery tray.
8. Examine the battery for cracks and/or leakage. If required, replacing using the “Install Batteries” instructions provided.
9. Clean the battery and neutralize any corrosion with a solution of baking soda and water.
10. Clean the battery cables and terminals using a wire brush.

Install Batteries

11. Set the batteries in place with the negative terminals toward the tractor.
12. Return the clamps into position and tighten the wing nuts.
13. Connect the red positive (+) battery ground cable connections and the protective rubber boots.
14. Connect the black negative (-) battery ground cable connections and the protective rubber boots.



Prepare the Tractor For Storage

NOTE: *Storage refers to periods of approximately three months or greater.*

1. Change the hydraulic and transmission oil.
2. Change the engine coolant.
3. Drain and flush the oil from the differentials and planetary housings. Fill with new oil.
4. Change the engine oil and filter.
5. Start the engine. While the engine is warming up, operate the transmission, hydraulic system, steering and differentials to distribute new lubricant to components. Warm the engine to at least 70°C (160°F). Stop the engine.
6. Clean the tractor of all debris, dirt and accumulated grease.
7. Drive the tractor to the storage location.
8. Release the tension on the engine accessory drive belt(s).
9. Coat all exposed hydraulic cylinder shaft areas with grease or a rust preventive.
10. Fill the fuel tanks with fresh fuel.
11. Refer to the Cummins Owner's Manual for more engine related preparations.

Store the Tractor

Use plastic bags or tape to seal the muffler, fuel tank breather, air intake filter and engine crankcase breather openings.

1. Touch up all scratches or chips in the paint.
2. Support the tractor on blocks to remove weight from the tires.
3. Cover the tires if they will be exposed to heat or direct sunlight.
4. If the tractor is to be stored outside, cover it with a waterproof canvas or other protective material.
5. Remove the batteries from the tractor and store them in a cool, dry, weatherproof area. Do not store the batteries on a concrete floor.

Prepare the Tractor for Use After Storage

Perform the following checks and make any necessary

NOTICE

Fuel poured directly into the filter will go into the fuel pump without being filtered. Ensure the fuel used for priming is clean. Remove the fuel filter and fill it with clean filtered fuel.

Refer to the Cummins Owner's Manual for the manufacturer's notes on engine related preparations after storage.

adjustments or repairs before starting the tractor after storage.

1. Remove the protective covering from the tractor tires and remove the sealing materials from the muffler, fuel tank breather, air intake filter and engine crankcase breather openings.
2. Remove the blocks. Lower the tractor onto the tires.
3. Repair any leaks.
4. Inflate the tires to the recommended pressure.
5. Install fully charged batteries. Tighten the battery connections to 20 N·m (15 ft·lb) torque.
6. Check the condition and tension of the engine accessory drive belt(s).
7. Check the fluid level of the engine crankcase, differentials, planetaries, transmission, hydraulic reservoir, brake cylinder reservoir and engine cooling system.
8. Drain sediment from the fuel tanks.
9. If the fuel filter is changed during or after storage, prime the new fuel filter, the fuel pump and the fuel lines.

Initial Engine Startup (after storage)



DANGER

Do not use chemical starting aids.



An explosion can occur in the engine turbocharger or inlet heater if chemicals are injected into the intake or added to the fuel.

NOTICE

Do not use the throttle to increase speed when the engine is first started after storage. The engine will idle at low speed until the engine oil pressure is normal. Contact a KUBOTA dealer if the engine does not start.

Follow the normal starting procedure with the throttle in the slow idle position when all of the steps in Operation 53 have been completed.

Initial engine startup after long periods of storage can place abnormal loads on the starting system.

Do not crank the engine for longer than 30 seconds.

Allow at least two minutes between cranking cycles to permit the starting motor to cool and the batteries to recover.

Clean Tractor

Pressure Wash Tractor

NOTICE

Avoid cleaning the greasing system pump to prevent possible entry of water through the vent openings if a high pressure steam cleaner is used to clean the tractor. Water will not enter the greasing system pump during normal operating conditions.

Never spray cold water on a hot tractor engine. Do not use caustic soaps that can cause damage to the paint finish on the tractor. Read the manufacturer's instructions carefully on the soap package.

Do not spray high pressure water into the cooler/radiator area of the front grille. Damage to the cooling fins will result.

A clean tractor experiences fewer breakdowns and improves overall safety. Keeping the tractor clean will also improve its value in later years.

Use a steam cleaner or high pressure washer to clean the tractor from end to end. Pay particular attention to the underside of the tractor and the wheel area.

Clean Cab Seat and Upholstery

The interior molding and seat inside the cab can be cleaned with a mild water/detergent solution.

1. Dip a soft cloth in a warm water/detergent solution.
2. Wring out as much water as possible.
3. Wipe the interior of the cab and seat with damp cloth as required.

Clean Cab Floor

Keep the cab floor free of dirt and debris that may cause obstructions and contribute to safety hazards. This is especially important around the brake and inching pedal area.

Keep the cab floor clean by periodically vacuuming or sweeping and washing.

The floor mat can be removed from the cab floor by rolling it away from the walls of the cab and pulling it upward and away from the floor. The floor mat is a 2 piece rubber mat that can be washed using a mild detergent.

This Page Is Intentionally Left Blank.

Section 6: Troubleshooting – Contents

Troubleshooting	6-3
Tractor Fault Indicators	6-16
Tractor Fault Codes	6-17
Introduction	6-17
Checking Fault Codes Using the Display Monitor	6-18
Armrest Fault Codes	6-19
Display Fault Codes	6-24
Engine Fault Codes	6-26
Transmission Fault Codes	6-29
DPS-C Fault Codes	6-34
Front Suspension and Suspended Cab Fault Codes	6-36
Electronic Hydraulic Remote (EHR) Fault Codes	6-38
Raw Fault Codes	6-40
3-pt Hitch and Power Take-off (PTO) Fault Codes	6-44

This Page Is Intentionally Left Blank.

Troubleshooting

This section provides information about common operating problems you may experience during the service life of your tractor.

Mechanical problems are often caused by improper operation and maintenance. Regularly scheduled maintenance and service is the best way to avoid problems.

Refer to the maintenance instructions provided in Section 5: Lubrication and Maintenance.

The following tables provide a short description of problems, possible causes and suggestions for corrective procedures.

Table 6-1: Engine Troubleshooting

Concern	Possible Cause	Correction
Engine Does Not Turn Over	Main power disconnect switch is Off	Check disconnect switch position and turn On
	Battery has no charge	Check and charge battery; boost to start
	Starter connections loose or broken	Check and repair starter connections
	Starter failed or damaged	Check and replace or repair starter
	Other electrical problems	Check fuses. Contact a KUBOTA dealer
	Mechanical problem in engine	Contact a KUBOTA dealer
Engine Cranks But Will Not Start, or Starts Hard	Incorrect starting procedure	Review starting procedures
	Low or no fuel	Check fuel level
	Air leaks in fuel lines	Test and repair fuel system
	Insufficient (slow) cranking rpm	Refer to Table 6-3: Electrical Troubleshooting
	Low engine oil or incorrect viscosity	Check and top up. Use the correct oil
	Incorrect fuel for temperature	Use correct fuel
	Restricted fuel filter	Replace fuel filter(s)
	Water in fuel	Drain the fuel/water separator. Review correct maintenance procedures
	Malfunctioning fuel injector(s)	Contact a KUBOTA dealer
	Malfunctioning fuel solenoid	Contact a KUBOTA dealer
	Restricted air filter	Replace air filter(s)
Engine Runs Poorly and/or Stalls	Combustion temperature too low	Wait for the engine to reach operating temperature.
	Restricted fuel filter	Replace fuel filter(s)
	Restricted air filter	Replace air filter(s)
	Contaminated fuel system	Replace fuel and fuel filters
	Malfunctioning fuel injector(s)	Contact a KUBOTA dealer
	Turbo-charger malfunction	Contact a KUBOTA dealer

Concern	Possible Cause	Correction
High Engine Operating Temperature	Over loading	Stop tractor operation and adjust loading factors. Review correct operating procedures
	High environmental temperatures	Stop tractor and allow engine to cool at idle speed
	Blocked coolers or fan failure	Check coolers and remove debris. Check fan drive operation and repair if necessary.
	Cooling system blocked or coolant level low	Check coolant level, service cooling system
High Engine Operating Temperature	Turbo-charger malfunction	Stop operation and contact a KUBOTA dealer
Low Engine Operating Temperature	Engine temperature gauge faulty	Contact a KUBOTA dealer
	Malfunctioning thermostat(s)	Contact a KUBOTA dealer
Low Power/ Poor Tractor Performance	Engine overloaded	Shift to lower gear or reduce load
	Air cleaner restricted	Replace air filter(s)
	Restricted fuel filter	Replace fuel filter(s)
	Incorrect type of fuel	Use correct fuel
	Engine overheating	Refer to High Engine Operating Temperature
	Implement malfunction	Refer to the implement operator's manual
	Low engine operating temperature	Contact a KUBOTA dealer
	Malfunctioning fuel injector(s)	Contact a KUBOTA dealer
	High idle speed is low	Contact a KUBOTA dealer
Engine power derate	Refer to EIC operation in Section 3	
Abnormal Engine Noise	Low oil level	Add oil to required level
	Low oil pressure	Contact a KUBOTA dealer
	Engine overheated	Refer to Engine Overheating
	Internal mechanical failure	Contact a KUBOTA dealer
Low Oil Pressure	Low oil level	Add oil as to required level
	Oil pressure gauge faulty	Contact a KUBOTA dealer
	Incorrect grade or viscosity oil	Drain and refill with correct oil
	Internal engine component failure	Contact a KUBOTA dealer

Table 6-1: Engine Troubleshooting

Concern	Possible Cause	Correction
Excessive Oil Consumption	Engine oil level too high	Reduce oil to required level. Review correct maintenance procedures
	Incorrect viscosity oil	Use the correct viscosity oil
	External oil leaks	Contact a KUBOTA dealer
	Restricted crankcase vent	Contact a KUBOTA dealer
	Internal engine component failure	Contact a KUBOTA dealer

Concern	Possible Cause	Correction
Tractor Will Not Move	Tractor is mired or obstructed	Check for and remove obstructions. Review and follow correct operating procedures
	Attached equipment is grounded or obstructed	Check operation of attached equipment and disconnect if necessary to move tractor
	Parking brake applied	Release parking brake. Review operating procedures.
	Transmission oil low	Check for leaks. Add hydraulic oil to the required level. Review maintenance procedures.
	Hydraulic system pressure low	Check for leaks; perform maintenance
	Transmission mechanical failure	Contact a KUBOTA dealer
	Control failure	Review electrical troubleshooting procedures. Contact a KUBOTA dealer
Low Transmission Oil Temp	Insufficient warm up time	Allow tractor to run at idle until all fluid pressures reach operating range. Review and follow correct operating procedures.
	Low transmission oil level	Check for leaks. Add hydraulic oil to the required level. Review maintenance procedures.
	Defective sensor circuit	Contact a KUBOTA dealer
	Pressure sender failure	Contact a KUBOTA dealer
High Transmission Oil Temp	Hot operating environment	Stop operating tractor and allow to cool with the engine idling
	Obstructed cooling system	Remove debris from coolers
	Overloaded tractor	Stop operation and reduce loading. Review correct operating procedures.
Transmission Oil Filter Bypass	Filter is restricted	Replace Filter
	Extremely cold temperature	Run tractor at low idle for 30 minutes to warm up the system. Contact a KUBOTA dealer if problem persists.
	Sensor circuit failure	Contact a KUBOTA dealer
	Sensor failure	Contact a KUBOTA dealer

Concern	Possible Cause	Correction
No Electrical Power	Battery disconnect switch turned Off	Turn disconnect switch to On
	Loose or corroded battery connections	Clean and tighten connections
	Defective starting batteries	Test and replace defective batteries
	Fuse or relay failure	Inspect fuses and relays*
	Ignition switch failure	Contact a KUBOTA dealer
Engine Cranks Slowly	Loose or corroded battery connections	Clean and tighten connections
	Low battery output	Test and replace defective batteries
	Incorrect engine oil viscosity	Use the correct oil
	Defective starter	Contact a KUBOTA dealer
Engine Will Not Crank	Parking brake lever not applied	Apply parking brake
	Inching pedal not pushed down	Push down inching pedal when starting
	Loose or corroded battery connection	Clean and tighten loose connections
	Defective starting batteries	Test and replace defective batteries
	PTO switch on	Turn off PTO switch
	Incorrect ignition switch operation	Turn ignition switch to Off, then to Start.
	Neutral safety or PTO switch malfunction	Contact a KUBOTA dealer.
	Fuse or relay failure	Inspect fuses and relays at fuse box*
	Ignition switch failure	Contact a KUBOTA dealer
Charge Indicator Light Stays On With Engine Running (Over/Under Voltage)	Low engine idle speed	Contact a KUBOTA dealer
	Loose or corroded battery connections	Clean and tighten connections
	Loose, damaged or missing engine accessory drive belt	Inspect belt and adjust tension. Replace if necessary.
	Malfunctioning batteries	Test and replace defective batteries
	Malfunctioning alternator	Contact a KUBOTA dealer
	Short circuit in electrical system	Contact a KUBOTA dealer
Batteries Will Not Charge	Batteries defective or sulfated	Test and replace batteries
	Malfunctioning alternator	Contact a KUBOTA dealer
	Loose or corroded battery connections	Clean and tighten connections
	Loose, damaged or missing engine accessory drive belt	Inspect belt and adjust tension. Replace if necessary.

Concern	Possible Cause	Correction
Tractor Runs a Short Time and Shuts Off	Automatic shutdown mode activated	Check alarm indicators for cause of shutdown. Contact a KUBOTA dealer.
	Air filter restriction	Replace air filter elements. Review correct maintenance procedures.
	Turbo-charger or air induction system failure	Contact a KUBOTA dealer.
	Fuel restriction	Inspect/replace fuel filter(s), contact a KUBOTA dealer.
Filter Warning Lights On	Filter restriction	Service filter, review maintenance procedures.
	Wiring problem	Contact a KUBOTA dealer.
	Sensor failure	Contact a KUBOTA dealer.
Lights Not Working	Fuses	Check fuses. Replace blown fuses*.
	Failed lights or ballasts	Check lights and ballasts.
	Loose connectors	Check lighting connectors.

NOTE: * Replace as required. Use only fuses and relays of the correct current rating to prevent damage to the electrical system.

Table 6-4: Hydraulic System Troubleshooting

Concern	Possible Cause	Correction
No Hydraulic System Operation	Low oil level	Add oil to proper level.
	Restricted hydraulic filter	Replace hydraulic filter.
	Restricted reservoir suction screen	Replace hydraulic filter.
	Malfunctioning hydraulic system	Replace hydraulic filter.
	Blown fuse or faulty relay	Replace fuses and or relays*.
Hydraulic Oil Overheats	Oil level too low or too high	Adjust oil level.
	Oil cooler or radiator plugged	Clean oil cooler and radiator.
	Blocked oil filter element	Replace filter.
	Flow control improperly adjusted	Adjust flow control to lower rate.
	Hydraulic load or orbit motor system is not matched to tractor	Contact a KUBOTA dealer.
Hoses Will Not Uncouple	Hoses being pulled at 15° angle or greater	Pull straight back on hoses.
	Dirty or damaged coupler	Clean or replace coupler.
Hoses Will Not Couple	Pressure in hydraulic lines	Place hydraulic system into float.
	Incompatible male connectors	Replace connectors with ISO standard connectors 12.7 mm (0.5 in) available from a KUBOTA dealer.
Detent Disengages Prematurely	Equipment exceeds pressure settings	Contact a KUBOTA dealer.
	High pressure standby set too low	Contact a KUBOTA dealer.
	Detent release pressure set too low	Contact a KUBOTA dealer.
	Incorrect time set on electric valve	Contact a KUBOTA dealer.

Concern	Possible Cause	Correction
Implement Speed is Incorrect	Flow control not properly adjusted	Adjust flow control.
	Incorrect oil viscosity	Replace oil with correct viscosity.
Hydraulic Filter Bypass Warning Light On	Clogged filter	Replace filter.
	Kinked or damaged hose	Repair or replace hose.
Implements and Accessories Will Not Operate	Hoses are not completely connected	Attach hoses correctly (see implement or accessory operation manual).
	Load exceeds system capacity	Reduce load or increase size of hydraulic cylinder.
	Lever lock restricts control lever movement	Reposition the lever lock.
	Low oil level	Add oil to proper level.

NOTE: * Replace as required. Use only fuses and relays of the correct current rating to prevent damage to the electrical system.

Concern	Possible Cause	Correction
Dust Enters the Cab	Poor seal around cabin filter element	Check seal condition. Adjust or replace as necessary.
	Plugged cabin filter	Clean or replace filter.
	Torn or defective cabin filter	Replace filter.
	Poor cabin sealing	Repair or adjust doors/windows for proper alignment and sealing.
Poor Airflow from Vents	Plugged cabin air filter	Clean or replace filter.
	Heater core or air-conditioning evaporator core is plugged or frozen	Contact a KUBOTA dealer.
Cab Windows Fog Up	Excessive moisture in the cab air system	Use the A/C system and recirculation control along with the heating system to dehumidify cab air. Position air vents toward windows. Check the A/C drain hoses for restriction.
Poor Heater Output	Heater valve shut off at engine	Turn heater valve to the fully open position.
	Defective engine thermostats	Contact a KUBOTA dealer.
	Heater core plugged	Contact a KUBOTA dealer.
	Cab heater controls not functioning	Contact a KUBOTA dealer.

Table 6-6: Brakes Troubleshooting		
Concern	Possible Cause	Correction
Parking Brake Does Not Work	Lever or cable damaged	Repair or replace damaged parts. Contact a KUBOTA dealer.
	Broken parking brake cable or actuator lever at the rear axle	Stop operating the tractor immediately. Contact a KUBOTA dealer.
	Brake out of adjustment	Contact a KUBOTA dealer.
Brake Pedal Bottoms Out or Feels Spongy	Air in the hydraulic brake system	Review maintenance procedures and bleed the brake system. Contact a KUBOTA dealer.
	Brake bleed screw will not seal	Review maintenance procedures and tighten bleeder. Contact a KUBOTA dealer.
	Worn brake discs	Contact a KUBOTA dealer.
	Hydraulic malfunction	Contact a KUBOTA dealer.
Brake Pedal Does Not Work	Mechanical failure	Stop operating the tractor. Contact a KUBOTA dealer.

NOTICE

The internal components of the parking brake may become damaged if the tractor is driven with a broken actuator arm. The actuator arm must be supported. To avoid costly and major repairs to the rear axle assembly, inspect the brake cable and actuator components on a daily basis before operating.



WARNING

Do not operate the tractor if the service brakes or the parking brake do not work properly. Inspect the brake mechanisms and make repairs before operating the tractor.

Table 6-7: PTO Troubleshooting		
Concern	Possible Cause	Correction
Rough PTO Engagement	Equipment loading is too high	Check operation and condition of attached equipment; review correct operating procedures for the attached equipment; review correct operating procedures for tractor PTO.
	Engine speed set too high for engagement	Adjust engine speed (reduce to 1 200 rpm) to lessen shock of engagement. Review correct operating procedures.
PTO Will Not Engage	Incorrect speed selection for stub shaft	Make sure the PTO speed is selected correctly for the installed stub shaft. Review correct operating procedures and use the correct stub shaft and speed settings.
	PTO control failure	Contact a KUBOTA dealer.
	PTO system mechanical failure	Contact a KUBOTA dealer.
PTO Overspeed Alarm	Engine speed too high	Set the correct engine speed for PTO operation.
	Improper equipment use	Review equipment operating procedures provided by the manufacturer. Review correct operating procedures for tractor PTO.
PTO Slips Under Load	Malfunction in the PTO system	Contact a KUBOTA dealer.
PTO Turns When in the Off Position	Malfunction in the PTO system	Contact a KUBOTA dealer.

Table 6-8: 3-pt Hitch Troubleshooting		
Concern	Possible Cause	Correction
Hitch Will Not Operate	Low oil level	Check and fill the hydraulic reservoir.
	Loose electrical connections	Check and repair the connections at the electro-hydraulic valve and controls.
	Blown fuse	Replace fuse*.
	Hydraulic pump failure	Contact a KUBOTA dealer.
Hitch Raises Too Slowly or Too Quickly	Rate of raise adjustment incorrectly set	Adjust the flow control on the 3-pt point hitch valve section.
Hitch Drops Too Slowly or Too Quickly	Lowering rate adjustment incorrectly set	Adjust rate of lowering flow control knob.
Hitch Over Raises or Lowers Causing Pump Pressure Relief	Feedback potentiometer incorrectly adjusted	Adjust the potentiometer.
NOTE: * Use only fuses of the correct current rating to prevent damage to the electrical system.		

Table 6-9: Traction and Ride Troubleshooting

Concern	Possible Cause	Correction
Tractor Rides Roughly	Incorrect seat dampener adjustments	Adjust the seat
	Faulty seat suspension	Contact a KUBOTA dealer
	Too much ballast	Ballast the tractor correctly
	Tire inflation pressure too high	Adjust tire inflation correctly
	Implement mismatched with tractor	Use a suitable implement
	Implement adjusted incorrectly	Review the implement operator's manual for proper adjustments
Tractor Hops or Bounces During Operation	Incorrect ballast	Ballast the tractor correctly
	Incorrect tire pressure	Adjust tire inflation correctly
	Incorrect tire size, type or configuration	Select the proper tire combination
Incorrect Wheel Slippage or Poor Traction	Incorrect ballast	Ballast the tractor correctly
	Incorrect tire size, type or configuration	Select proper tire combination
	Incorrect tire pressure	Adjust tire inflation correctly
	Implement mismatched with tractor	Use a suitable implement
	Implement adjusted incorrectly	Review the implement operator's manual for proper adjustments

Tractor Fault Indicators

An indicator will flash on the EIC panel when a fault is detected by the tractor monitor systems. Read the tractor fault information and codes from the fault display screen and record the information for troubleshooting and repair.

The SPN and FMI information can be used by a KUBOTA dealer to obtain detailed fault descriptions from the OEM service data.

See also: Active Fault in Section 2: Controls and Instruments of this manual.

Use the general troubleshooting notes that follow in this section as a guide to identifying the correct actions when faults occur.

NOTICE

Contact a KUBOTA dealer for assistance and quote the fault code (SPN and FMI) number.

Always contact a KUBOTA dealer when directed to in the manual notes.




Table 6-10: Active Fault Display

1	Numeric Value of SPN	2	Numeric Value of FMI	3	SPN Description
4	Description of FMI	5	String Identifier	6	Total Number of Alarms
7	Group Description	8	Numeric Value of Priority	9	Numeric Value of Group
10	Description of Priority				

Tractor Fault Codes

Introduction

The electronic instrument cluster (EIC) and the display monitor will warn you if there are faults with the following systems:

- Armrest: Fault code list starts on Table 6-11.
- Display: Fault code list starts on Table 6-12.
- Engine: Fault code list starts on Table 6-13.
- Transmission: Fault code list starts on Table 6-14.
- DPS-C: Fault code list starts on Table 6-15.
- FAS/FCS: Front Suspension and Cab suspension fault code list starts on Table 6-16.
- EHR: Fault code list starts on Table 6-17
- Raw: Fault code list starts on Table 6-18
- TPH/PTO: 3-pt hitch and Power Take-off (PTO) fault code list starts on Table 6-19.

To check for faults, start the engine (a vehicle with the ignition key only turned to RUN will only detect some of the faults).

If a fault occurs with any of the systems listed above the following will occur:

- A fault icon will appear on the EIC LCD screen.
- A malfunction indicator (such as the yellow engine warning light) may flash on the electronic instrument cluster (EIC).


For more information on specific codes contact a KUBOTA dealer and quote the fault code number.

Implement Valve Faults

Models M8-181 and M8-201 are equipped with electro-hydraulic remote (EHR) implement valves.

NOTE: The vehicle controller detects faults in the electro-hydraulic system. These faults are listed in

Checking Fault Codes Using the Display Monitor



NOTE: The fault code menu will only be accessible if there is an active fault code. A notification (1) on the display monitor will appear.

To check active fault codes:

1. Press on the notification (1).
2. Any active faults will appear in the fault menu/ screen. Swipe up and down to scroll through the fault code list. Fault code information is described as follows:
 - Source: Source of the active fault code (Engine, Transmission, Vehicle, Aftertreatment)
 - SPN: Suspect Parameter Number
 - FMI: Fault Mode Indicator
 - Count: The number of times the fault has occurred

Armrest Fault Codes

The fault codes listed in Table 6-11 may appear in the “Armrest” category of active faults.

NOTE: The fault codes are listed by SPN-FMI pairs in ascending order.

Table 6-11: Armrest Fault Codes				
LIGHT CODES: R = Red, A = Amber, N = None, P = Protect, Blink = Light is blinking				
Source	SPN	FMI	RX/TX	Description (SPN-FMI)
ForwardDirection Switch	454656	2	Receive	Forward gear direction switch on multi-function lever - CAN data received on VCU from armrest is invalid or incorrect
ForwardDirectionSwitch	454657	9	Receive	Forward gear direction switch on multi-function lever - CAN data on VCU from armrest was not received during the transmission period
NeutralDirectionSwitch	454658	2	Receive	Neutral gear direction switch on armrest - CAN data received on VCU from armrest is invalid or incorrect
NeutralDirectionSwitch	454659	9	Receive	Neutral gear direction switch on armrest - CAN data on VCU from armrest was not received during the transmission period
ReverseDirectionSwitch	454660	2	Receive	Reverse gear direction switch on multi-function lever - CAN data received on VCU from armrest is invalid or incorrect
ReverseDirectionSwitch	454661	9	Receive	Reverse gear direction switch on multi-function lever - CAN data on VCU from armrest was not during the transmission period
TransmissionNeutralLockSwitch	454662	2	Receive	Transmission neutral lock switch on armrest - CAN data received on VCU from armrest is invalid or incorrect
TransmissionNeutralLockSwitch	454663	9	Receive	Front PTO normally closed switch on armrest - CAN data on VCU from armrest was not during the transmission period
GearShiftUpSwitch	454664	2	Receive	Shift up on multi-function lever - CAN data received on VCU from armrest is invalid or incorrect
GearShiftUpSwitch	454665	9	Receive	Shift up on multi-function lever - CAN data on VCU from armrest was not received during the transmission period
GearShiftDownSwitch	454666	2	Receive	Shift down on multi-function lever - CAN data received on VCU from armrest is invalid or incorrect
GearShiftDownSwitch	454667	9	Receive	Shift down on multi-function lever - CAN data on VCU from armrest was not received during the transmission period
ArmrestStatus	454668	2	Receive	Armrest status - CAN data received on VCU from armrest is invalid or incorrect
ArmrestStatus	454669	9	Receive	Armrest status - CAN data on VCU from armrest was not received during the transmission period
ArmrestVersion	454670	2	Receive	Armrest version - CAN data received on VCU from armrest is invalid or incorrect
ArmrestVersion	454671	9	Receive	Armrest version - CAN data on VCU from armrest was not received during the transmission period
HMSPlayback1Switch	454672	2	Receive	HMS playback 1 switch on armrest - CAN data received on VCU from armrest is invalid or incorrect
HMSPlayback1Switch	454673	9	Receive	HMS playback 1 switch on armrest - CAN data on VCU from armrest was not received during the transmission period

Table 6-11: Armrest Fault Codes				
LIGHT CODES: R = Red, A = Amber, N = None, P = Protect, Blink = Light is blinking				
Source	SPN	FMI	RX/TX	Description (SPN–FMI)
HMSPlayback2Switch	454674	2	Receive	HMS playback 2 switch on armrest - CAN data received on VCU from armrest is invalid or incorrect
HMSPlayback2Switch	454675	9	Receive	HMS playback 2 switch on armrest - CAN data on VCU from armrest was not received during the transmission period
TPHRaiseUpSwitch	454676	2	Receive	TPH raise switch on multi-function lever - CAN data received on VCU from armrest is invalid or incorrect
TPHRaiseUpSwitch	454677	9	Receive	TPH raise switch on multi-function lever - CAN data on VCU from armrest was not received during the transmission period
TPHLowerDownSwitch	454678	2	Receive	TPH lower switch on multi-function lever - CAN data received on VCU from armrest is invalid or incorrect
TPHLowerDownSwitch	454679	9	Receive	TPH lower switch on multi-function lever - CAN data on VCU from armrest was not received during the transmission period
AutoPowerShiftSwitch	454680	2	Receive	Auto power shift switch on multi-function lever - CAN data received on VCU from armrest is invalid or incorrect
AutoPowerShiftSwitch	454681	9	Receive	Auto power shift switch on multi-function lever - CAN data on VCU from armrest was not received during the transmission period
DeadmanEnableSwitch	454682	2	Receive	Deadman enable switch on armrest - CAN data received on VCU from armrest is invalid or incorrect
DeadmanEnableSwitch	454683	9	Receive	Deadman enable switch on armrest - CAN data on VCU from armrest was not received during the transmission period
RangeShiftEnableSwitch	454684	2	Receive	Range shift enable switch on multi-function lever - CAN data received on VCU from armrest is invalid or incorrect
RangeShiftEnableSwitch	454685	9	Receive	Range shift enable switch on multi-function lever - CAN data on VCU from armrest was not received during the transmission period
EHRValvesLockSwitch	454686	2	Receive	Hydraulics valve lock switch on armrest - CAN data received on VCU from armrest is invalid or incorrect
EHRValvesLockSwitch	454687	9	Receive	Hydraulics valve lock switch on armrest - CAN data on VCU from armrest was not received during the transmission period
TPHLockSwitch	454688	2	Receive	TPH lock switch on armrest - CAN data received on VCU from armrest is invalid or incorrect
TPHLockSwitch	454689	9	Receive	TPH lock switch on armrest - CAN data on VCU from armrest was not received during the transmission period
EngineSpeedMemoASwitch	454690	2	Receive	Engine speed memo A switch on armrest - CAN data received on VCU from armrest is invalid or incorrect
EngineSpeedMemoASwitch	454691	9	Receive	Engine speed memo A switch on armrest - CAN data on VCU from armrest was not received during the transmission period
EngineSpeedMemoBSwitch	454692	2	Receive	Engine speed memo B switch on armrest - CAN data received on VCU from armrest is invalid or incorrect

Table 6-11: Armrest Fault Codes				
LIGHT CODES: R = Red, A = Amber, N = None, P = Protect, Blink = Light is blinking				
Source	SPN	FMI	RX/TX	Description (SPN-FMI)
EngineSpeedMemoBSwitch	454693	9	Receive	Engine speed memo B switch on armrest - CAN data on VCU from armrest was not received during the transmission period
FrontPTONCSwitch	454694	2	Receive	Front PTO normally closed switch on armrest - CAN data received on VCU from armrest is invalid or incorrect
FrontPTONCSwitch	454695	9	Receive	Front PTO normally closed switch on armrest - CAN data on VCU from armrest was not received during the transmission period
FrontPTONOSwitch	454696	2	Receive	Front PTO normally open switch on armrest - CAN data received on VCU from armrest is invalid or incorrect
FrontPTONOSwitch	454697	9	Receive	Front PTO normally open switch on armrest - CAN data on VCU from armrest was not received during the transmission period
RearPTONCSwitch	454698	2	Receive	Rear PTO normally closed switch on armrest - CAN data received on VCU from armrest is invalid or incorrect
RearPTONCSwitch	454699	9	Receive	Rear PTO normally closed switch on armrest - CAN data on VCU from armrest was not received during the transmission period
RearPTONOSwitch	454700	2	Receive	Rear PTO normally open switch on armrest - CAN data received on VCU from armrest is invalid or incorrect
RearPTONOSwitch	454701	9	Receive	Rear PTO normally open switch on armrest - CAN data on VCU from armrest was not received during the transmission period
DeflectionFingertipTV1	454702	2	Receive	Hydraulics fingertip 1 on multi-function lever - CAN data received on VCU from armrest is invalid or incorrect
DeflectionFingertipTV1	454702	9	Receive	Hydraulics fingertip 1 on multi-function lever - CAN data on VCU from armrest was not received during the transmission period
DeflectionFingertipTV2	454703	2	Receive	Hydraulics fingertip 2 on multi-function lever - CAN data received on VCU from armrest is invalid or incorrect
DeflectionFingertipTV2	454703	9	Receive	Hydraulics fingertip 2 on multi-function lever - CAN data on VCU from armrest was not received during the transmission period
DeflectionFingertipTV3	454704	2	Receive	Hydraulics fingertip 3 on armrest - CAN data received on VCU from armrest is invalid or incorrect
DeflectionFingertipTV3	454704	9	Receive	Hydraulics fingertip 3 on armrest - CAN data on VCU from armrest was not received during the transmission period
DeflectionFingertipTV4	454705	2	Receive	Hydraulics fingertip 4 on armrest - CAN data received on VCU from armrest is invalid or incorrect
DeflectionFingertipTV4	454705	9	Receive	Hydraulics fingertip 4 on armrest - CAN data on VCU from armrest was not received during the transmission period
DeflectionFingertipTV5	454706	2	Receive	Hydraulics fingertip 5 on armrest - CAN data received on VCU from armrest is invalid or incorrect
DeflectionFingertipTV5	454706	9	Receive	Hydraulics fingertip 5 on armrest - CAN data on VCU from armrest was not received during the transmission period

Table 6-11: Armrest Fault Codes				
LIGHT CODES: R = Red, A = Amber, N = None, P = Protect, Blink = Light is blinking				
Source	SPN	FMI	RX/TX	Description (SPN–FMI)
DeflectionFingertipTV6	454707	2	Receive	Hydraulics fingertip 6 on armrest - CAN data received on VCU from armrest is invalid or incorrect
DeflectionFingertipTV6	454707	9	Receive	Hydraulics fingertip 6 on armrest - CAN data on VCU from armrest was not received during the transmission period
HandThrottlePosition	454708	2	Receive	Hand throttle lever on armrest - CAN data received on VCU from armrest is invalid or incorrect
HandThrottlePosition	454708	9	Receive	Hand throttle lever on armrest - CAN data on VCU from armrest was not received during the transmission period
AWDSwitch	454709	2	Receive	Front wheel assist switch on armrest - CAN data received on VCU from armrest is invalid or incorrect
AWDSwitch	454709	9	Receive	Front wheel assist switch on armrest - CAN data on VCU from armrest was not received during the transmission period
DifflockSwitch	454710	2	Receive	Differential lock switch on armrest - CAN data received on VCU from armrest is invalid or incorrect
DifflockSwitch	454710	9	Receive	Differential lock switch on armrest - CAN data on VCU from armrest was not received during the transmission period
JoystickThumbWheel	454711	2	Receive	Joystick thumb wheel on loader joystick - CAN data received on VCU from armrest is invalid or incorrect
JoystickThumbWheel	454711	9	Receive	Joystick thumb wheel on loader joystick - CAN data on VCU from armrest was not received during the transmission period
Joystick4thFunctionSwitch	454712	2	Receive	Joystick 4th function switch on loader joystick - CAN data received on VCU from armrest is invalid or incorrect
Joystick4thFunctionSwitch	454712	9	Receive	Joystick 4th function switch on loader joystick - CAN data on VCU from armrest was not received during the transmission period
JoystickLockSwitch	454713	2	Receive	Joystick lock switch on armrest - CAN data received on VCU from armrest is invalid or incorrect
JoystickLockSwitch	454713	9	Receive	Joystick lock switch on armrest - CAN data on VCU from armrest was not received during the transmission period
EHROrFrontLoaderModeSwitch	454714	2	Receive	Hydraulic and front loader mode change switch on armrest - CAN data received on VCU from armrest is invalid or incorrect
EHROrFrontLoaderModeSwitch	454714	9	Receive	Hydraulic and front loader mode change switch on armrest - CAN data on VCU from armrest was not received during the transmission period
TPHPosition	454715	2	Receive	Three point hitch position potentiometer on armrest - CAN data received on VCU from armrest is invalid or incorrect
TPHPosition	454715	9	Receive	Three point hitch position potentiometer on armrest - CAN data on VCU from armrest was not received during the transmission period
CreeperSwitch	454716	2	Receive	Creeper switch on armrest - CAN data received on VCU from armrest is invalid or incorrect
CreeperSwitch	454716	9	Receive	Creeper switch on armrest - CAN data on VCU from armrest was not received during the transmission period

Table 6-11: Armrest Fault Codes				
LIGHT CODES: R = Red, A = Amber, N = None, P = Protect, Blink = Light is blinking				
Source	SPN	FMI	RX/TX	Description (SPN-FMI)
FreezeRatioSwitch	454717	2	Receive	Freeze ratio switch on armrest - CAN data received on VCU from armrest is invalid or incorrect
FreezeRatioSwitch	454717	9	Receive	Freeze ratio switch on armrest - CAN data on VCU from armrest was not received during the transmission period
CruiseControlOnOffSwitch	454718	2	Receive	Cruise control enable switch on armrest - CAN data received on VCU from armrest is invalid or incorrect
CruiseControlOnOffSwitch	454718	9	Receive	Cruise control enable switch on armrest - CAN data on VCU from armrest was not received during the transmission period

Display Fault Codes

The fault codes listed in Table 6-12 on page 6-24 may appear category of active faults.

Source	SPN	FMI	RX/TX	Description (SPN-FMI)
Display	454784		Receive	EngineSpeedMemoASoftSwitch - No Fault codes available
Display	454785		Receive	EngineSpeedMemoBSoftSwitch - No Fault codes available
Display	454786		Receive	EngineSpeedMemoASetpoint - No Fault codes available
Display	454787		Receive	EngineSpeedMemoBSetpoint - No Fault codes available
Display	454788		Receive	EngineSpeedUpperLimitSetpoint - No Fault codes available
Display	454789		Receive	TransmissionSensitivitySetpoint - No Fault codes available
Display	454790		Receive	AutoshiftSynchronicGearBegin - No Fault codes available
Display	454791		Receive	AutoshiftSynchronicGearEnd - No Fault codes available
Display	454792		Receive	AutoshiftPowershiftGearBegin - No Fault codes available
Display	454793		Receive	AutoshiftPowershiftGearEnd - No Fault codes available
Display	454794		Receive	AutoshiftConfigurationSelect - No Fault codes available
Display	454795		Receive	EHRExtendFlowSetpoint - No Fault codes available
Display	454796		Receive	EHRRetractFlowSetpoint - No Fault codes available
Display	454797		Receive	EHRExtendTimerSetpoint - No Fault codes available
Display	454798		Receive	EHRRetractTimerSetpoint - No Fault codes available
Display	454799		Receive	EHRValve1LockSoftSwitch - No Fault codes available
Display	454800		Receive	EHRValve2LockSoftSwitch - No Fault codes available
Display	454801		Receive	EHRValve3LockSoftSwitch - No Fault codes available
Display	454802		Receive	EHRValve4LockSoftSwitch - No Fault codes available
Display	454803		Receive	EHRValve5LockSoftSwitch - No Fault codes available
Display	454804		Receive	EHRValve6LockSoftSwitch - No Fault codes available
Display	454805		Receive	EHRValve1TimerSoftSwitch - No Fault codes available
Display	454806		Receive	EHRValve2TimerSoftSwitch - No Fault codes available
Display	454807		Receive	EHRValve3TimerSoftSwitch - No Fault codes available
Display	454808		Receive	EHRValve4TimerSoftSwitch - No Fault codes available
Display	454809		Receive	EHRValve5TimerSoftSwitch - No Fault codes available
Display	454810		Receive	EHRValve6TimerSoftSwitch - No Fault codes available
Display	454811		Receive	EHRMasterLockSoftSwitch - No Fault codes available
Display	454812		Receive	FrontLoaderExtendFlowSetpoint - No Fault codes available
Display	454813		Receive	FrontLoaderRetractFlowSetpoint - No Fault codes available
Display	454814		Receive	FrontLoaderSoftDriveSoftSwitch - No Fault codes available
Display	454815		Receive	DifflockSoftSwitch - No Fault codes available
Display	454816		Receive	DifflockAutoSoftSwitch - No Fault codes available
Display	454817		Receive	AWDSoftSwitch - No Fault codes available
Display	454818		Receive	AWDAutoSoftSwitch - No Fault codes available
Display	454819		Receive	SuspendedAxleSoftSwitch - No Fault codes available
Display	454820		Receive	SuspendedCabSoftSwitch - No Fault codes available
Display	454821		Receive	HMSRecordSoftSwitch - No Fault codes available
Display	454822		Receive	HMSDeleteSoftSwitch - No Fault codes available
Display	454823		Receive	HMSToggleSoftSwitch - No Fault codes available

Source	SPN	FMI	RX/TX	Description (SPN-FMI)
Display	454824		Receive	HMSLockSoftSwitch - No Fault codes available
Display	454825		Receive	AutoPTOSoftSwitch - No Fault codes available
Display	454826		Receive	Auto PTO Off Height Set point - No Fault codes available
Display	454827		Receive	AutoPTOOnHeightSetpoint - No Fault codes available
Display	454828		Receive	TPHLockSoftSwitch - No Fault codes available
Display	454829		Receive	TPHRideControlSoftSwitch - No Fault codes available
Display	454830		Receive	TPHDraftControlSoftSwitch - No Fault codes available
Display	454831		Receive	TPHWheelSlipSoftSwitch - No Fault codes available
Display	454832		Receive	TPHUpperLimitSetpoint - No Fault codes available
Display	454833		Receive	TPHLoweringSpeedSetpoint - No Fault codes available
Display	454834		Receive	TPHDraftControlSetpoint - No Fault codes available
Display	454835		Receive	TPHWheelSlipSetpoint - No Fault codes available
Display	454836		Receive	CreeperMaxSpeedSetpoint - No Fault codes available
Display	454837		Receive	AccelerationSpeedSetpoint - No Fault codes available
Display	456704		Transmit	AutoshiftModeDisplay - No Fault codes available
Display	456705		Transmit	EngineSpeedMemoA - No Fault codes available
Display	456706		Transmit	EngineSpeedMemoB - No Fault codes available
Display	456707		Transmit	EngineSpeedMemoASetpoint - No Fault codes available
Display	456708		Transmit	EngineSpeedMemoBSetpoint - No Fault codes available
Display	456709		Transmit	EngineSpeedLimit - No Fault codes available
Display	456710		Transmit	RadarDistance - No Fault codes available
Display	456711		Transmit	HMSEdit - No Fault codes available
Display	456712		Transmit	HMSRecord - No Fault codes available
Display	456713		Transmit	HMSRecordState - No Fault codes available
Display	456714		Transmit	HMSPlayState - No Fault codes available
Display	456715		Transmit	HMSLock - No Fault codes available
Display	456716		Transmit	HMSLockState - No Fault codes available
Display	456717		Transmit	HMSSequenceToggle - No Fault codes available
Display	456718		Transmit	HMSActiveSequence - No Fault codes available
Display	456719		Transmit	HMSActiveSet - No Fault codes available
Display	456720		Transmit	HMSCurrentActionNumber - No Fault codes available
Display	456721		Transmit	HMSCurrentSequence - No Fault codes available
Display	456722		Transmit	HMSCurrentAction - No Fault codes available

Engine Fault Codes

The fault codes listed in may appear in the “Engine” or “Aftertreatment” category of active faults.

Table 6-13: Engine Fault Codes				
LIGHT CODES: R = Red, A = Amber, N = None, P = Protect, Blink = Light is blinking				
Source	SPN	FMI	RX/TX	Description (SPN–FMI)
EngineTotalFuelUsed	250	2	Receive	Engine total fuel used - CAN data received on VCU is invalid or incorrect
EngineTotalFuelUsed	250	9	Receive	Engine total fuel used - CAN data on VCU was not received during the transmission period
EngineSpeed	190	2	Receive	Engine speed - CAN data received on VCU is invalid or incorrect
EngineSpeed	190	9	Receive	Engine speed - CAN data on VCU was not received during the transmission period
EngineSpeedAverage	454912	2	Receive	Engine speed average - CAN data received on VCU is invalid or incorrect
EngineSpeedAverage	454912	9	Receive	Engine speed average - CAN data on VCU was not received during the transmission period
EngineCoolantTemperature	110	2	Receive	Engine coolant temperature - CAN data received on VCU is invalid or incorrect
EngineCoolantTemperature	110	9	Receive	Engine coolant temperature - CAN data on VCU was not received during the transmission period
EngineOilPressure	100	2	Receive	Engine oil pressure - CAN data received on VCU is invalid or incorrect
EngineOilPressure	100	9	Receive	Engine oil pressure - CAN data on VCU was not received during the transmission period
EngineTotalHoursOfOperation	247	2	Receive	Engine total hours of operation - CAN data received on VCU is invalid or incorrect
EngineTotalHoursOfOperation	247	9	Receive	Engine total hours of operation - CAN data on VCU was not received during the transmission period
EngineFuelRate	183	2	Receive	Engine fuel rate - CAN data received on VCU is invalid or incorrect
EngineFuelRate	183	9	Receive	Engine fuel rate - CAN data on VCU was not received during the transmission period
DefTankLevel	1761	2	Receive	Aftertreatment 1 diesel exhaust fluid tank level - CAN data received on VCU is invalid or incorrect
DefTankLevel	1761	9	Receive	Aftertreatment 1 diesel exhaust fluid tank level - CAN data on VCU was not received during the transmission period
ExhaustSystemHighTemperatureLampCommand	3698	2	Receive	Exhaust system high temperature lamp command - CAN data received on VCU is invalid or incorrect
ExhaustSystemHighTemperatureLampCommand	3698	9	Receive	Exhaust system high temperature lamp command - CAN data on VCU was not received during the transmission period

Table 6-13: Engine Fault Codes				
LIGHT CODES: R = Red, A = Amber, N = None, P = Protect, Blink = Light is blinking				
Source	SPN	FMI	RX/TX	Description (SPN-FMI)
DpfActiveRegenerationInhibitedStatus	3702	2	Receive	Diesel particulate filter active regeneration inhibited status - CAN data received on VCU is invalid or incorrect
DpfActiveRegenerationInhibitedStatus	3702	9	Receive	Diesel particulate filter active regeneration inhibited status - CAN data on VCU was not received during the transmission period
DieselParticulateFilterLampCommand	3697	2	Receive	Diesel particulate filter lamp command - CAN data received on VCU is invalid or incorrect
DieselParticulateFilterLampCommand	3697	9	Receive	Diesel particulate filter lamp command - CAN data on VCU was not received during the transmission period
DpfActiveRegenerationInhibitedDueToInhibitSwitch	3703	2	Receive	Diesel particulate filter active regeneration inhibited due to inhibit switch - CAN data received on VCU is invalid or incorrect
DpfActiveRegenerationInhibitedDueToInhibitSwitch	3703	9	Receive	Diesel particulate filter active regeneration inhibited due to inhibit switch - CAN data on VCU was not received during the transmission period
EngineProtectionSystemApproachingShutdown	1109	2	Receive	Engine protection system approaching shutdown - CAN data received on VCU is invalid or incorrect
EngineProtectionSystemApproachingShutdown	1109	9	Receive	Engine protection system approaching shutdown - CAN data on VCU was not received during the transmission period
EngineWaitToStartLamp	1081	2	Receive	Engine wait to start lamp data - CAN data received on VCU is invalid or incorrect
EngineWaitToStartLamp	1081	9	Receive	Engine wait to start lamp data - CAN data on VCU was not received during the transmission period
EngineProtectLampCommand	5077	2	Receive	Engine protect lamp - CAN data received on VCU is invalid or incorrect
EngineProtectLampCommand	5077	9	Receive	Engine protect lamp - CAN data on VCU was not received during the transmission period
EngineAmberWarningLampCommand	5078	2	Receive	Engine amber warning lamp command - CAN data received on VCU is invalid or incorrect
EngineAmberWarningLampCommand	5078	9	Receive	Engine amber warning lamp command - CAN data on VCU was not received during the transmission period
EngineRedStopLampCommand	5079	2	Receive	Engine red stop lamp command - CAN data received on VCU is invalid or incorrect
EngineRedStopLampCommand	5079	9	Receive	Engine red stop lamp command - CAN data on VCU was not received during the transmission period
EngineBrakeActiveLampCommand	5081	2	Receive	Engine brake active lamp command - CAN data received on VCU is invalid or incorrect
EngineBrakeActiveLampCommand	5081	9	Receive	Engine brake active lamp command - CAN data on VCU was not received during the transmission period

Table 6-13: Engine Fault Codes				
LIGHT CODES: R = Red, A = Amber, N = None, P = Protect, Blink = Light is blinking				
Source	SPN	FMI	RX/TX	Description (SPN–FMI)
EngineOilPressureLowLampCommand	5082	2	Receive	Engine oil pressure low lamp command - CAN data received on VCU is invalid or incorrect
EngineOilPressureLowLampCommand	5082	9	Receive	Engine oil pressure low lamp command - CAN data on VCU was not received during the transmission period
EngineCoolantTempHighLampCommand	5083	2	Receive	Engine coolant temperature high lamp command - CAN data received on VCU is invalid or incorrect
EngineCoolantTempHighLampCommand	5083	9	Receive	Engine coolant temperature high lamp command - CAN data on VCU was not received during the transmission period
EngineCoolantLevelLowLampCommand	5084	2	Receive	Engine coolant level low lamp command - CAN data received on VCU is invalid or incorrect
EngineCoolantLevelLowLampCommand	5084	9	Receive	Engine coolant level low lamp command - CAN data on VCU was not received during the transmission period
ParticulateTrapRegenerationInhibitSwitch	3695		Transmit	Not available
ParticulateTrapRegenerationForceSwitch	3696		Transmit	Not available
DpfMode	3699		Transmit	Not available
EngineShutdownOverrideSwitch	1237		Transmit	Not available

Transmission Fault Codes

The fault codes listed in Table 6-14 will appear in the “Transmission” category of active faults.

NOTE: The fault codes are listed by SPN-FMI pairs in ascending order.

Source	SPN	FMI	Description (SPN-FMI)
Transmission	0	0	--- no error present ---
Transmission	520222	31	CPU - Processor arithmetic, push, pop, system stack
Transmission	520223	31	CPU - Processor register
Transmission	520224	31	CPU - Processor watchdog
Transmission	520225	31	CPU - Processor peripherals, external watchdog
Transmission	520226	31	CPU - Timeout at interrupt für digital inputs
Transmission	520251	13	EEPROM - ECU in shipment condition, parameters invalid
Transmission	520227	31	Flash EPROM - checksum at Init inconsistent
Transmission	520227	31	Flash EPROM - checksum at Run inconsistent
Transmission	520229	31	ECU - Application Error - application data's don't correspond to software
Transmission	520250	13	ECU - wrong configured - no or a not existing data set is selected
Transmission	520208	31	CPU - RAM addressing error - internal at Init
Transmission	520209	31	CPU - RAM addressing error - internal at Run
Transmission	520210	31	CPU - RAM addressing error - external at Init
Transmission	520211	31	CPU - RAM addressing error - external at Run
Transmission	520240	2	EEPROM - Checksum 0 (Manufacturer and ISO data) inconsistent
Transmission	520241	2	EEPROM - Checksum 1 (Vehicle data) inconsistent
Transmission	520242	2	EEPROM - Checksum 2 (History track) inconsistent
Transmission	520243	2	EEPROM - Checksum 3 (Calibration data) inconsistent
Transmission	520252	13	EEPROM - Checksum 4 (Configuration data) inconsistent
Transmission	520244	2	EEPROM - Checksum 5 (Error memory FMGR) inconsistent
Transmission	520245	2	EEPROM - Checksum 7 (acquired data) inconsistent
Transmission	520212	31	CPU - ILLBUS illegal external bus access
Transmission	520213	31	CPU - ILLINA illegal instruction access
Transmission	520214	31	CPU - ILLOPA illegal word operand access
Transmission	520215	31	CPU - PRTFLT Protection fault flag
Transmission	520216	31	CPU - UNDOPC no valid C167 instruction
Transmission	520217	31	CPU - STKUF Stack underflow
Transmission	520218	31	CPU - STKOF Stack overflow
Transmission	520219	31	CPU - NMI Non maskable interrupt
Transmission	520720	9	Timeout Message PTC DN1
Transmission	520721	9	Timeout Message PTC DN2
Transmission	520722	9	Timeout Message PTC DN3
Transmission	520723	9	Timeout Message AXCDN1
Transmission	520724	9	Timeout Message EEC1
Transmission	520725	9	Timeout Message EEC2
Transmission	520726	9	Timeout Message TFLUID

Table 6-14: ZF Transmission Fault Codes

Source	SPN	FMI	Description (SPN-FMI)
Transmission	520727	9	Timeout Message EEC3
Transmission	520728	9	Timeout Message ET
Transmission	520729	9	Timeout Message FE
Transmission	520730	9	Timeout Message TSC1_VE
Transmission	520731	9	Timeout Message TSC1_VER
Transmission	520704	31	Powertrain CAN Tx/Rx Broadcast inhibited because of DM13 reception
Transmission	520705	11	Powertrain - Bus off
Transmission	520256	4	Vehicle Power Supply - Low voltage terminal 30 (9V for 1.5s)
Transmission	520256	3	Vehicle Power Supply - High voltage terminal 30 (36V immediately or 15V for 0.8s)
Transmission	520220	31	ECU Internal Main Switch - not switchable (at Init)
Transmission	520221	31	ECU Internal Main Switch - permanently on (at Init)
Transmission	520248	13	Handthrottle - Calibration values out of limits
Transmission	520340	12	PTO NAO - Duty Cycle not detectable
Transmission	520288	3	Driving Lever - Channel 2 Signal voltage out of range high
Transmission	520288	4	Driving Lever - Channel 2 Signal voltage out of range low (SG,OC)
Transmission	520289	3	Handthrottle - Signal voltage out of range high
Transmission	520289	4	Handthrottle - Signal voltage out of range low (SG,OC)
Transmission	520290	3	Drivingpedal - Signal voltage out of range high
Transmission	521286	31	Drivingpedal - Check with APP
Transmission	520290	4	Drivingpedal - Signal voltage out of range low(SG,OC)
Transmission	520291	3	Driving Lever - Channel 1 Signal voltage out of range high
Transmission	521287	31	Driving Lever - Wrong synchronity between channel 1 and 2
Transmission	520291	4	Driving Lever - Channel 1 Signal voltage out of range low (SG,OC)
Transmission	520292	3	Lube-Oil Pressure Sensor - Signal voltage out of range high
Transmission	520292	4	Lube-Oil Pressure Sensor - Signal voltage out of range low (SG,OC)
Transmission	520293	3	Clutch Pedal - Signal voltage out of range high
Transmission	521288	31	Clutch Pedal - Plausibility check with CCO-Switch
Transmission	520293	4	Clutch Pedal - Signal voltage out of range low (SG,OC)
Transmission	520320	3	PTO Tip Switch Fender NO Position -Short to plus
Transmission	520320	8	PTO Tip Switch Fender NO Position - Wrong PSS
Transmission	520321	3	PTO Tip Switch Cabine NO Position -Short to plus
Transmission	520321	8	PTO Tip Switch Cabine NO Position - Wrong PSS
Transmission	520322	3	Seat Switch - Short to plus
Transmission	520322	8	Seat Switch - Wrong PPS
Transmission	520323	10	Brake Pedal Switch Left - Activated too long (OC)
Transmission	520323	3	Brake Pedal Switch Left - Short to plus
Transmission	520323	8	Brake Pedal Switch Left - Wrong PPS
Transmission	520324	10	Brake Pedal Switch Right - activated too long(OC)
Transmission	520324	3	Brake Pedal Switch Right - Short to plus
Transmission	520324	8	Brake Pedal Switch Right - Wrong PPS
Transmission	520325	10	Neutral Switch - Activated too long (OC)
Transmission	520325	3	Neutral Switch - Short to plus
Transmission	520325	8	Neutral Switch - Wrong PPS
Transmission	520326	3	Control Head Forward switch - Short to plus

Source	SPN	FMI	Description (SPN-FMI)
Transmission	520326	8	Control Head Forward switch - Wrong PPS
Transmission	520327	3	Control Head Reverse switch - Short to plus
Transmission	520327	8	Control Head Reverse switch - Wrong PPS
Transmission	520328	3	PTO Tip Switch Cabine NC Position -Short to plus
Transmission	520328	8	PTO Tip Switch Cabine NC Position - Wrong PSS
Transmission	520329	3	Control Head TemporaryCC switch - Short to plus
Transmission	520329	8	Control Head TemporaryCC switch - Wrong PPS
Transmission	520330	10	Control Head Cruise Control Minus - Activated too long
Transmission	520330	3	Control Head Cruise Control Minus - Short to plus
Transmission	520330	8	Control Head Cruise Control Minus - Wrong PPS
Transmission	520331	10	Control Head Cruise Control Plus - Activated too long
Transmission	520331	3	Control Head Cruise Control Plus - Short to plus
Transmission	520331	8	Control Head Cruise Control Plus - Wrong PPS
Transmission	520332	10	Control Head Cruise Control On/Off - activated too long
Transmission	520332	3	Control Head Cruise Control On/Off - Short to plus
Transmission	520332	8	Control Head Cruise Control On/Off - Wrong PPS
Transmission	521223	31	Overspeed TransOutSpeed
Transmission	520333	3	PTO Tip Switch Fender NC Position -Short to plus
Transmission	520333	8	PTO Tip Switch Fender NC Position - Wrong PSS
Transmission	520334	3	Shuttle Shift Lever F-Position - Short to plus
Transmission	520334	8	Shuttle Shift Lever F-Position - Wrong PPS
Transmission	520335	3	Shuttle Shift Lever R-Position - Short to plus
Transmission	520335	8	Shuttle Shift Lever R-Position - Wrong PPS
Transmission	520336	3	Shuttle Shift Lever O-Position - Short to plus
Transmission	520336	8	Shuttle Shift Lever O-Position - Wrong PPS
Transmission	520337	10	Control Head Dead Man - Activated too long
Transmission	520337	3	Control Head Dead Man - Short to plus
Transmission	520337	8	Control Head Dead Man - Wrong PPS
Transmission	520338	3	DIFFLOCK Tip Switch - Short to plus
Transmission	520338	8	DIFFLOCK Tip Switch - Wrong PPS
Transmission	520339	3	FWD Tip Switch - Short to plus
Transmission	520339	8	FWD Tip Switch - Wrong PPS
Transmission	520257	17	Driving Lever - Supply voltage out of range low
Transmission	520257	16	Driving Lever - Supply voltage out of range high
Transmission	520257	3	Driving Lever - Supply voltage short to plus
Transmission	520257	4	Driving Lever - Supply voltage short to ground
Transmission	520258	17	Lubricating Oil Sensor - Supply voltage out of range low
Transmission	520258	16	Lubricating Oil Sensor - Supply voltage out of range high
Transmission	520258	3	Lubricating Oil Sensor - Supply voltage short to plus
Transmission	520258	4	Lubricating Oil Sensor - Supply voltage short to ground
Transmission	520259	17	Driving Pedal - Supply voltage out of range low
Transmission	520259	16	Driving Pedal - Supply voltage out of range high
Transmission	520259	3	Driving Pedal - Supply voltage short to plus
Transmission	520259	4	Driving Pedal - Supply voltage short to ground

Table 6-14: ZF Transmission Fault Codes

Source	SPN	FMI	Description (SPN-FMI)
Transmission	520260	17	Hand Throttle - Supply voltage out of range low
Transmission	520260	16	Hand Throttle - Supply voltage out of range high
Transmission	520260	3	Hand Throttle - Supply voltage short to plus
Transmission	520260	4	Hand Throttle - Supply voltage short to ground
Transmission	520261	17	Clutch Pedal - Supply voltage out of range low
Transmission	520261	16	Clutch Pedal - Supply voltage out of range high
Transmission	520261	3	Clutch Pedal - Supply voltage short to plus
Transmission	520261	4	Clutch Pedal - Supply voltage short to ground
Transmission	520262	31	PPS1 for switch modules - Short to other PPS
Transmission	520262	3	PPS1 for switch modules - Short to plus
Transmission	520262	4	PPS1 for switch modules - Short to ground
Transmission	520263	31	PPS2 for switch modules - Short to other PPS
Transmission	520263	3	PPS2 for switch modules - Short to plus
Transmission	520263	4	PPS2 for switch modules - Short to ground
Transmission	520264	31	PPS3 for switch modules - Short to other PPS
Transmission	520264	3	PPS3 for switch modules - Short to plus
Transmission	520264	4	PPS3 for switch modules - Short to ground
Transmission	520352	5	PTO Solenoid - Open circuit or not operating security relays
Transmission	521289	31	PTO Clutch - Slip or wrong speed
Transmission	520352	3	PTO Solenoid - Short to plus
Transmission	520352	4	PTO Solenoid - Short to ground
Transmission	520353	5	LCO Solenoid - Open circuit
Transmission	520353	3	LCO Solenoid - Short to plus
Transmission	520353	4	LCO Solenoid - Short to ground
Transmission	520354	5	FWD Solenoid - Open circuit
Transmission	520354	3	FWD Solenoid - Short to plus
Transmission	520354	4	FWD Solenoid - Short to ground
Transmission	520355	5	DIFFLOCK Solenoid -Open circuit
Transmission	520355	3	DIFFLOCK Solenoid -Short to plus
Transmission	520355	4	DIFFLOCK Solenoid -Short to ground
Transmission	520976	9	Timeout Message DispVehicleConfig2
Transmission	520977	9	Timeout Message DispDrivetrainStateDes
Transmission	520978	9	Timeout Message ExtDrivetrainStateDes
Transmission	520979	9	Timeout Message ExtPoti00
Transmission	520980	9	Timeout Message ExtSwitch00
Transmission	520960	31	Drivetrain CAN Tx/Rx Broadcast inhibited because of DM13 reception
Transmission	520961	11	Drivetrain Bus Off
Transmission	521312	31	Transmission - Gear forward does not engage (after 5s)
Transmission	521313	31	Transmission - Gear reverse does not engage (after 5s)
Transmission	521316	31	Transmission - CCO not acknowledged(after 200ms)
Transmission	521314	31	Transmission - Neutral status unplausible (not neutral, 200ms after demand)
Transmission	521315	31	Engine - Speed variation impossible
Transmission	521248	31	Vehicle - Overspeed with engaged gear (> 65km/h for 100ms)
Transmission	521249	31	Vehicle - Overspeed while neutral (> 55km/h for 100ms)

Source	SPN	FMI	Description (SPN-FMI)
Transmission	521250	31	Vehicle - Engine overspeed (> 2500rpm for 100ms)
Transmission	520784	19	Powertrain CAN - TCU - Transmission input shaft speed faulty or not available
Transmission	520785	19	Powertrain CAN - EEC - Engine speed faulty or not available
Transmission	520787	19	Powertrain CAN - TCU - Transmission output shaft speed faulty or not available
Transmission	520246	13	Driving Pedal - Calibration value out of range
Transmission	520249	13	Clutch Pedal - Calibration value out of range
Transmission	520247	13	Driving Lever - Calibration value out of range
Transmission	520356	10	Brake Light - Fault OC, SG, SS
Transmission	521251	31	Hand Brake - Vehicle speed is limited to 2kph because of engaged hand brake
Transmission	521280	31	Shuttle Shift Lever3(CanReverser) - Signals implausible
Transmission	521281	31	Shuttle Shift Lever1(LeftHandReverser) - Signals implausible
Transmission	521282	31	Shuttle Shift Lever2(RightHandReversr) - Signals implausible
Transmission	521283	31	PTO Tip Switch Cabine - Signals implausible
Transmission	521284	31	PTO Tip Switch Fender - Signals implausible
Transmission	521290	31	PTO NAO - Speed range exceeded
Transmission	521040	11	AXCDN1 MsgCounter incorrect
Transmission	521041	11	AXCDN1 MsgChecksum incorrect

DPS-C Fault Codes

The fault codes listed in may appear category of active faults.

NOTE: The fault codes are listed by SPN-FMI pairs in ascending order.

Table 6-15: DPS-C Fault Codes

Source	SPN	FMI	Description (SPN-FMI)
DPS-C	455168	2	Hazard switch - CAN data received on VCU is invalid or incorrect
DPS-C	455168	9	Hazard switch - CAN data on VCU was not received during the transmission period
DPS-C	455169	2	Engine shutdown override - CAN data received on VCU is invalid or incorrect
DPS-C	455169	9	Engine shutdown override - CAN data on VCU was not received during the transmission period
DPS-C	455170	2	Rear defog switch - CAN data received on VCU is invalid or incorrect
DPS-C	455170	9	Rear defog switch - CAN data on VCU was not received during the transmission period
DPS-C	455171	2	Shifter neutral lock lever switch - Voltage above normal or shorted to high source
DPS-C	455171	3	Shifter neutral lock lever switch - Voltage below normal or shorted to ground
DPS-C	455171	4	Shifter neutral lock lever switch - Voltage is out of range
DPS-C	455172	2	Shifter forward lever switch - Voltage above normal or shorted to high source
DPS-C	455172	3	Shifter forward lock lever switch - Voltage below normal or shorted to ground
DPS-C	455172	4	Shifter forward lock lever switch - Voltage is out of range
DPS-C	455173	2	Shifter reverse lever switch - Voltage above normal or shorted to high source
DPS-C	455173	3	Shifter reverse lever switch - Voltage below normal or shorted to ground
DPS-C	455173	4	Shifter reverse lever switch - Voltage is out of range
DPS-C	455174	2	Shifter neutral lever switch - Voltage above normal or shorted to high source
DPS-C	455174	3	Shifter neutral lever switch - Voltage below normal or shorted to ground
DPS-C	455174	4	Shifter neutral lever switch - Voltage is out of range
DPS-C	455175	2	DPS-C left button - CAN data received on VCU is invalid or incorrect
DPS-C	455175	9	DPS-C left button - CAN data on VCU was not received during the transmission period
DPS-C	455176	2	DPS-C right button - CAN data received on VCU is invalid or incorrect
DPS-C	455176	9	DPS-C right button - CAN data on VCU was not received during the transmission period
DPS-C	455177	2	Brake lock switch - CAN data received on VCU is invalid or incorrect, switches are either shorted to high or shorted to ground
DPS-C	455680	2	Raven source address request - CAN data received on VCU is invalid or incorrect
DPS-C	455680	9	Raven source address request - CAN data on VCU was not received during the transmission period
DPS-C	455681	2	Suspended axle calibration request - CAN data received on VCU is invalid or incorrect
DPS-C	455681	9	Suspended axle calibration request - CAN data on VCU was not received during the transmission period
DPS-C	455682	2	Steering angle calibration request - CAN data received on VCU is invalid or incorrect
DPS-C	455682	9	Steering angle calibration request - CAN data on VCU was not received during the transmission period
DPS-C	455683	2	Suspended cab calibration request - CAN data received on VCU is invalid or incorrect
DPS-C	455683	9	Suspended cab calibration request - CAN data on VCU was not received during the transmission period
DPS-C	455684	2	Requested reverse characteristic - CAN data received on VCU is invalid or incorrect
DPS-C	455684	9	Requested reverse characteristic - CAN data on VCU was not received during the transmission period
DPS-C	455685	2	Tire size configuration - CAN data received on VCU is invalid or incorrect

Source	SPN	FMI	Description (SPN-FMI)
DPS-C	455685	9	Tire size configuration - CAN data on VCU was not received during the transmission period
DPS-C	455686	2	Rear PTO curve shape - CAN data received on VCU is invalid or incorrect
DPS-C	455686	9	Rear PTO curve shape - CAN data on VCU was not received during the transmission period
DPS-C	455687	2	DPF inhibit/forced regeneration request - CAN data received on VCU is invalid or incorrect
DPS-C	455687	9	DPF inhibit/forced regeneration request - CAN data on VCU was not received during the transmission period
DPS-C	455688	2	Imperial enabled - CAN data received on VCU is invalid or incorrect
DPS-C	455688	9	Imperial enabled - CAN data on VCU was not received during the transmission period
DPS-C	455689	2	Tire size calibration request - CAN data received on VCU is invalid or incorrect
DPS-C	455689	9	Tire size calibration request - CAN data on VCU was not received during the transmission period
DPS-C	455690	2	Steering angle installed - CAN data received on VCU is invalid or incorrect
DPS-C	455690	9	Steering angle installed - CAN data on VCU was not received during the transmission period
DPS-C	455691	2	Suspended axle installed - CAN data received on VCU is invalid or incorrect
DPS-C	455691	9	Suspended axle installed - CAN data on VCU was not received during the transmission period
DPS-C	455692	2	Suspended cab installed - CAN data received on VCU is invalid or incorrect
DPS-C	455692	9	Suspended cab installed - CAN data on VCU was not received during the transmission period
DPS-C	455693	2	Zero slip calibration request - CAN data received on VCU is invalid or incorrect
DPS-C	455693	9	Zero slip calibration request - CAN data on VCU was not received during the transmission period
DPS-C	2872	2	Main light command - CAN data received on VCU is invalid or incorrect
DPS-C	2872	9	Main light command - CAN data on VCU was not received during the transmission period
DPS-C	2347	2	High beam headlight command - CAN data received on VCU is invalid or incorrect
DPS-C	2347	9	High beam headlight command - CAN data on VCU was not received during the transmission period
DPS-C	2349	2	Low beam headlight command - CAN data received on VCU is invalid or incorrect
DPS-C	2349	9	Low beam headlight command - CAN data on VCU was not received during the transmission period
DPS-C	2351	2	Alternate beam headlight command - CAN data received on VCU is invalid or incorrect
DPS-C	2351	9	Alternate beam headlight command - CAN data on VCU was not received during the transmission period
DPS-C	2369	2	Right turn signal command - CAN data received on VCU is invalid or incorrect
DPS-C	2369	9	Right turn signal command - CAN data on VCU was not received during the transmission period
DPS-C	2367	2	Left turn signal command - CAN data received on VCU is invalid or incorrect
DPS-C	2367	9	Left turn signal command - CAN data on VCU was not received during the transmission period
DPS-C	2863	2	Front wiper switch - CAN data received on VCU is invalid or incorrect
DPS-C	2863	9	Front wiper switch - CAN data on VCU was not received during the transmission period
DPS-C	2866	2	Front washer switch - CAN data received on VCU is invalid or incorrect
DPS-C	2866	9	Front washer switch - CAN data on VCU was not received during the transmission period
DPS-C	455695	2	DPS-C language configuration - CAN data received on VCU is invalid or incorrect
DPS-C	455695	9	DPS-C language configuration - CAN data on VCU was not received during the transmission period

Front Suspension and Suspended Cab Fault Codes

This tractor is equipped with a front suspension. The fault code is listed in

NOTE: The vehicle controller detects faults in the suspended axle system .

NOTE: The fault codes are listed by SPN-FMI pairs in ascending order.

Table 6-16: Front Suspension and Suspended Cab Fault Codes

System Effected	SPN	FMI	Failure Mode	Error Saved (Requires Recalibration to clear)	Description (SPN-FMI)
Both	0	0	None	FALSE	No Error
Cab	709	3	Failed Position Sensor	TRUE	Position Sensor Voltage is below 0 mm (approximately 0.040 Volts).
Cab	709	4	Failed Position Sensor	TRUE	Position Sensor Voltage is above 175 mm (approximately 4.70 Volts).
Cab	709	0	Failed Linkage / Vehicle Mechanics	TRUE	During calibration, Lower Stop is below 10 mm
Cab	709	1	Failed Linkage / Vehicle Mechanics	TRUE	During calibration, Upper Stop is above 160 mm
Axle	710	3	Failed Position Sensor	TRUE	Position Sensor Voltage is below 0 mm (approximately 0.040 Volts).
Axle	710	4	Failed Position Sensor	TRUE	Position Sensor Voltage is above 175 mm (approximately 4.70 Volts).
Axle	710	0	Failed Linkage / Vehicle Mechanics	TRUE	During calibration, Lower Stop is below 10 mm
Axle	710	1	Failed Linkage / Vehicle Mechanics	TRUE	During calibration, Upper Stop is above 160 mm
Cab	701	5	Wire Broken Cab Raise or Lower Coil	FALSE	Desired current differs from feedback by more the 500 milliamps for more the 300 milliseconds
Axle	702	5	Wire Broken/Shorted Axle Raise Coil	FALSE	Desired current differs from feedback by more the 500 milliamps for more the 300 milliseconds
Axle	703	5	Wire Broken/Shorted Axle Lower Coil	FALSE	Desired current differs from feedback by more the 500 milliamps for more the 300 milliseconds
Axle	704	5	Wire Broken Axle/Shorted Compression Coil	FALSE	Desired current differs from feedback by more the 500 milliamps for more the 300 milliseconds
Cab	701	7	Failed Valve #1 / Pump Issues	TRUE	During calibration, Suspension did not raise above 85 mm within 60 seconds of command.
Cab	702	7	Failed Valve #2	TRUE	During calibration, Suspension did not lower below 85 mm within 60 seconds of command.
Axle	711	7	Failed Valve #1 / Pump Issues	TRUE	During calibration, Suspension did not raise above 85 mm within 60 seconds of command.
Axle	712	7	Failed Valve #2	TRUE	During calibration, Suspension did not lower below 85 mm within 60 seconds of command.
Cab	701	13	Failed Valve #1 / Pump Issues	TRUE	During Suspension operation, did not return to upper target band within 60 seconds of raise command.
Cab	702	13	Failed Valve #2	TRUE	During Suspension operation, did not return to lower target band within 60 seconds of lower command.
Axle	711	13	Failed Valve #1 / Pump Issues	TRUE	During Suspension operation, did not return to upper target band within 60 seconds of raise command.

Table 6-16: Front Suspension and Suspended Cab Fault Codes

System Effected	SPN	FMI	Failure Mode	Error Saved (Requires Recalibration to clear)	Description (SPN-FMI)
Axle	712	13	Failed Valve #2	TRUE	During Suspension operation, did not return to lower target band within 60 seconds of lower command.
Axle	712	13	Failed Valve #2	TRUE	During Lock Down mode, the suspension did not lower past the Calibration Lower Stop (XXX mm) within 20 seconds.
Cab	709	16	Damaged Linkage / Vehicle Mechanics	TRUE	Position sensor exceed calibrated upper stop by 20 mm.
Cab	709	18	Damaged Linkage / Vehicle Mechanics	TRUE	Position sensor below calibrated lower stop by 20 mm.
Axle	710	16	Damaged Linkage / Vehicle Mechanics	TRUE	Position sensor exceed calibrated upper stop by 20 mm.
Axle	710	18	Damaged Linkage / Vehicle Mechanics	TRUE	Position sensor below calibrated lower stop by 20 mm.
Cab	701	14	Calibration Aborted	FALSE	One of the following conditions has occurred during the Calibration process: 1. SUSPENSION_MODE_REQUEST = Calibration Abort 2. PARK_BRAKE_SIGNAL <> Park Brake Active 3. OPERATOR_PRESENCE <> Operator Present 4. VEHICLE_SPEED <> 0
Axle	711	14	Calibration Aborted	FALSE	One of the following conditions has occurred during the Calibration process: 1. SUSPENSION_MODE_REQUEST = Calibration Abort 2. PARK_BRAKE_SIGNAL <> Park Brake Active 3. OPERATOR_PRESENCE <> Operator Present 4. VEHICLE_SPEED <> 0
Both	597	9	CCVS Message not received on CAN	FALSE	CAN message containing the Park Brake signal has not been received for 2.000 seconds; this error will clear when the message is received and if no other errors are present, then the Cab and/ or Axle will enter its respective Start-Up state.
Both	628	12	ECU Failure	TRUE	Controller memory failure
Axle	455296	2	VCU Failure	TRUE	FAS mode status - CAN data received on VCU is invalid or incorrect
Axle	455296	9	VCU Failure	TRUE	FAS mode status - CAN data on VCU was not received during the transmission period
Axle	455297	2	VCU Failure	TRUE	FAS calibration status - CAN data received on VCU is invalid or incorrect
Axle	455297	9	VCU Failure	TRUE	FAS calibration status - CAN data on VCU was not received during the transmission period
Cab	455298	2	VCU Failure	TRUE	FCS mode status - CAN data received on VCU is invalid or incorrect
Cab	455298	9	VCU Failure	TRUE	FCS mode status - CAN data on VCU was not received during the transmission period
Cab	455299	2	VCU Failure	TRUE	FCS calibration status - CAN data received on VCU is invalid or incorrect
Cab	455299	9	VCU Failure	TRUE	FCS calibration status - CAN data on VCU was not received during the transmission period

Electronic Hydraulic Remote (EHR) Fault Codes

The EHR fault code is listed in

NOTE: The fault codes are listed by SPN-FMI pairs in ascending order.

Source	SPN	FMI	RX/TX	Description (SPN-FMI)
EHR	455552	2	Receive	Valve 1 CAN error information - CAN data received on VCU is invalid or incorrect
EHR	455552	9	Receive	Valve 1 CAN error information - CAN data on VCU was not received during the transmission period
EHR	455553	2	Receive	Valve 2 CAN error information - CAN data received on VCU is invalid or incorrect
EHR	455553	9	Receive	Valve 2 CAN error information - CAN data on VCU was not received during the transmission period
EHR	455554	2	Receive	Valve 3 CAN error information - CAN data received on VCU is invalid or incorrect
EHR	455554	9	Receive	Valve 3 CAN error information - CAN data on VCU was not received during the transmission period
EHR	455555	2	Receive	Valve 4 CAN error information - CAN data received on VCU is invalid or incorrect
EHR	455555	9	Receive	Valve 4 CAN error information - CAN data on VCU was not received during the transmission period
EHR	455556	2	Receive	Valve 5 CAN error information - CAN data received on VCU is invalid or incorrect
EHR	455556	9	Receive	Valve 5 CAN error information - CAN data on VCU was not received during the transmission period
EHR	455557	2	Receive	Valve 6 CAN error information - CAN data received on VCU is invalid or incorrect
EHR	455557	9	Receive	Valve 6 CAN error information - CAN data on VCU was not received during the transmission period
EHR	455558	2	Receive	Valve 1 CAN minor error information - CAN data received on VCU is invalid or incorrect
EHR	455558	9	Receive	Valve 1 CAN minor error information - CAN data on VCU was not received during the transmission period
EHR	455559	2	Receive	Valve 2 CAN minor error information - CAN data received on VCU is invalid or incorrect
EHR	455559	9	Receive	Valve 2 CAN minor error information - CAN data on VCU was not received during the transmission period
EHR	455560	2	Receive	Valve 3 CAN minor error information - CAN data received on VCU is invalid or incorrect
EHR	455560	9	Receive	Valve 3 CAN minor error information - CAN data on VCU was not received during the transmission period
EHR	455561	2	Receive	Valve 4 CAN minor error information - CAN data received on VCU is invalid or incorrect
EHR	455561	9	Receive	Valve 4 CAN minor error information - CAN data on VCU was not received during the transmission period
EHR	455562	2	Receive	Valve 5 CAN minor error information - CAN data received on VCU is invalid or incorrect
EHR	455562	9	Receive	Valve 5 CAN minor error information - CAN data on VCU was not received during the transmission period
EHR	455563	2	Receive	Valve 6 CAN minor error information - CAN data received on VCU is invalid or incorrect
EHR	455563	9	Receive	Valve 6 CAN minor error information - CAN data on VCU was not received during the transmission period
EHR	455564	2	Receive	Valve 1 CAN miscellaneous error information - CAN data received on VCU is invalid or incorrect

Source	SPN	FMI	RX/TX	Description (SPN-FMI)
EHR	455564	9	Receive	Valve 1 CAN miscellaneous error information - CAN data on VCU was not received during the transmission period
EHR	455565	2	Receive	Valve 2 CAN miscellaneous error information - CAN data received on VCU is invalid or incorrect
EHR	455565	9	Receive	Valve 2 CAN miscellaneous error information - CAN data on VCU was not received during the transmission period
EHR	455566	2	Receive	Valve 3 CAN miscellaneous error information - CAN data received on VCU is invalid or incorrect
EHR	455566	9	Receive	Valve 3 CAN miscellaneous error information - CAN data on VCU was not received during the transmission period
EHR	455567	2	Receive	Valve 4 CAN miscellaneous error information - CAN data received on VCU is invalid or incorrect
EHR	455567	9	Receive	Valve 4 CAN miscellaneous error information - CAN data on VCU was not received during the transmission period
EHR	455568	2	Receive	Valve 5 CAN miscellaneous error information - CAN data received on VCU is invalid or incorrect
EHR	455568	9	Receive	Valve 5 CAN miscellaneous error information - CAN data on VCU was not received during the transmission period
EHR	455569	2	Receive	Valve 6 CAN miscellaneous error information - CAN data received on VCU is invalid or incorrect
EHR	455569	9	Receive	Valve 6 CAN miscellaneous error information - CAN data on VCU was not received during the transmission period

Raw Fault Codes

The fault codes listed in may appear category of active faults.

NOTE: The fault codes are listed by SPN-FMI pairs in ascending order.

Table 6-18: Raw Fault Codes

Source	SPN	FMI	RX/TX	Description (SPN-FMI)
Raw	456192	0	Receive	Left brake switch - voltages of both switches are above normal operational range
Raw	456192	3	Receive	Left brake switch - voltage of one or more switches is/ are above normal or shorted to high source
Raw	456192	4	Receive	Left brake switch - voltage of one or more switches is/ are below normal or shorted to low source
Raw	456192	7	Receive	Left brake switch - both switches are either open or both switches are closed
Raw	456193	0	Receive	Right brake switch - voltages of both switches are above normal operational range
Raw	456193	3	Receive	Right brake switch - voltage of one or more switches is/ are above normal or shorted to high source
Raw	456193	4	Receive	Right brake switch - voltage of one or more switches is/ are below normal or shorted to low source
Raw	456193	7	Receive	Right brake switch - both switches are either open or both switches are closed
Raw	70	0	Receive	Park brake switch - voltages of both switches are above normal operational range
Raw	70	3	Receive	Park brake switch - voltage of one or more switches is/ are above normal or shorted to high source
Raw	70	4	Receive	Park brake switch - voltage of one or more switches is/ are below normal or shorted to low source
Raw	70	7	Receive	Park brake switch - both switches are either open or both switches are closed
Raw	456194	2	Receive	Seat switch - voltage of the switch is incorrect or invalid; in between mid and max range or min and mid range
Raw	456194	3	Receive	Seat switch - voltage of the switch is above normal operational range or shorted to high source
Raw	456194	4	Receive	Seat switch - voltage of the switch is below normal operational range or shorted to low source
Raw	456195	2	Receive	Key switch crank - voltage of the switch is incorrect or invalid; in between mid and max range or min and mid range
Raw	456195	3	Receive	Key switch crank - voltage of the switch is above normal operational range or shorted to high source
Raw	456195	4	Receive	Key switch crank - voltage of the switch is below normal operational range or shorted to low source
Raw	2602	2	Receive	Hydraulic oil level switch - voltage of the switch is incorrect or invalid; in between mid and max range or min and mid range
Raw	2602	3	Receive	Hydraulic oil level switch - voltage of the switch is above normal operational range or shorted to high source
Raw	2602	4	Receive	Hydraulic oil level switch - voltage of the switch is below normal operational range or shorted to low source
Raw	456196	2	Receive	Hydraulic charge filter switch - voltage of the switch is incorrect or invalid; in between mid and max range or min and mid range
Raw	456196	3	Receive	Hydraulic charge filter switch - voltage of the switch is above normal operational range or shorted to high source
Raw	456196	4	Receive	Hydraulic charge filter switch - voltage of the switch is below normal operational range or shorted to low source
Raw	456197	2	Receive	Hydraulic steering filter switch - voltage of the switch is incorrect or invalid; in between mid and max range or min and mid range

Source	SPN	FMI	RX/TX	Description (SPN-FMI)
Raw	456197	3	Receive	Hydraulic steering filter switch - voltage of the switch is above normal operational range or shorted to high source
Raw	456197	4	Receive	Hydraulic steering filter switch - voltage of the switch is below normal operational range or shorted to low source
Raw	456198	2	Receive	Hydraulic return filter switch - voltage of the switch is incorrect or invalid; in between mid and max range or min and mid range
Raw	456198	3	Receive	Hydraulic return filter switch - voltage of the switch is above normal operational range or shorted to high source
Raw	456198	4	Receive	Hydraulic return filter switch - voltage of the switch is below normal operational range or shorted to low source
Raw	3353	2	Receive	Alternator status switch - voltage of the switch is incorrect or invalid; in between mid and max range or min and mid range
Raw	3353	3	Receive	Alternator status switch - voltage of the switch is above normal operational range or shorted to high source
Raw	3353	4	Receive	Alternator status switch - voltage of the switch is below normal operational range or shorted to low source
Raw	456199	2	Receive	Implement status switch - voltage of the switch is incorrect or invalid; in between mid and max range or min and mid range
Raw	456199	3	Receive	Implement status switch - voltage of the switch is above normal operational range or shorted to high source
Raw	456199	4	Receive	Implement status switch - voltage of the switch is below normal operational range or shorted to low source
Raw	456200	2	Receive	Rear wiper low speed switch - voltage of the switch is incorrect or invalid; in between mid and max range or min and mid range
Raw	456200	3	Receive	Rear wiper low speed switch - voltage of the switch is above normal operational range or shorted to high source
Raw	456200	4	Receive	Rear wiper low speed switch - voltage of the switch is below normal operational range or shorted to low source
Raw	456201	2	Receive	Rear wiper intermittent switch - voltage of the switch is incorrect or invalid; in between mid and max range or min and mid range
Raw	456201	3	Receive	Rear wiper intermittent switch - voltage of the switch is above normal operational range or shorted to high source
Raw	456201	4	Receive	Rear wiper intermittent switch - voltage of the switch is below normal operational range or shorted to low source
Raw	456202	2	Receive	Radar presence status switch - voltage of the switch is incorrect or invalid; in between mid and max range or min and mid range
Raw	456202	3	Receive	Radar presence status switch - voltage of the switch is above normal operational range or shorted to high source
Raw	456202	4	Receive	Radar presence status switch - voltage of the switch is below normal operational range or shorted to low source
Raw	456203	2	Receive	Front fender 3PH raise switch - voltage of the switch is incorrect or invalid; in between mid and max range or min and mid range
Raw	456203	3	Receive	Front fender 3PH raise switch - voltage of the switch is above normal operational range or shorted to high source
Raw	456203	4	Receive	Front fender 3PH raise switch - voltage of the switch is below normal operational range or shorted to low source
Raw	456204	2	Receive	Front fender 3PH lower switch - voltage of the switch is incorrect or invalid; in between mid and max range or min and mid range
Raw	456204	3	Receive	Front fender 3PH lower switch - voltage of the switch is above normal operational range or shorted to high source
Raw	456204	4	Receive	Front fender 3PH lower switch - voltage of the switch is below normal operational range or shorted to low source

Table 6-18: Raw Fault Codes

Source	SPN	FMI	RX/TX	Description (SPN–FMI)
Raw	456205	2	Receive	Front fender PTO pulse switch - voltage of the switch is incorrect or invalid; in between mid and max range or min and mid range
Raw	456205	3	Receive	Front fender PTO pulse switch - voltage of the switch is above normal operational range or shorted to high source
Raw	456205	4	Receive	Front fender PTO pulse switch - voltage of the switch is below normal operational range or shorted to low source
Raw	456206	2	Receive	Rear fender PTO pulse switch - voltage of the switch is incorrect or invalid; in between mid and max range or min and mid range
Raw	456206	3	Receive	Rear fender PTO pulse switch - voltage of the switch is above normal operational range or shorted to high source
Raw	456206	4	Receive	Rear fender PTO pulse switch - voltage of the switch is below normal operational range or shorted to low source
Raw	456207	2	Receive	Auto steer status switch - voltage of the switch is incorrect or invalid; in between mid and max range or min and mid range
Raw	456207	3	Receive	Auto steer status switch - voltage of the switch is above normal operational range or shorted to high source
Raw	456207	4	Receive	Auto steer status switch - voltage of the switch is below normal operational range or shorted to low source
Raw	456208	8	Receive	Radar speed sensor - frequency of the sensor is higher than high threshold
Raw	1638	0	Receive	Hydraulic temperature sensor - temperature is above 104.4 degrees celcius (most severe level)
Raw	1638	15	Receive	Hydraulic temperature sensor - temperature is above 93.3 degrees celcius (moderately severe level)
Raw	1638	16	Receive	Hydraulic temperature sensor - temperature is above 82.2 degrees celcius (least severe level)
Raw	456209	0	Receive	Steering angle sensor - voltage of the sensor is above 4.9 (most severe level)
Raw	456209	1	Receive	Steering angle sensor - voltage of the sensor is below 0.2 (most severe level)
Raw	456209	15	Receive	Steering angle sensor - voltage of the sensor is above 4.6 (least severe level)
Raw	456209	16	Receive	Steering angle sensor - voltage of the sensor is above 4.75 (moderately severe level)
Raw	456209	17	Receive	Steering angle sensor - voltage of the sensor is below 0.5 (least severe level)
Raw	456209	18	Receive	Steering angle sensor - voltage of the sensor is below 0.35 (moderately severe level)
Raw	29	0	Receive	Foot pedal - voltage of the sensor is above 4.9 (most severe level)
Raw	29	1	Receive	Foot pedal - voltage of the sensor is below 0.2 (most severe level)
Raw	29	15	Receive	Foot pedal - voltage of the sensor is above 4.3 (least severe level)
Raw	29	16	Receive	Foot pedal - voltage of the sensor is above 4.6 (moderately severe level)
Raw	29	17	Receive	Foot pedal - voltage of the sensor is below 1.0 (least severe level)
Raw	29	18	Receive	Foot pedal - voltage of the sensor is below 0.5 (moderately severe level)
Raw	96	0	Receive	Fuel level - resistance is below normal operational range (moderately severe level)
Raw	96	1	Receive	Fuel level - resistance is above normal operational range (moderately severe level)
Raw	456210	2	Receive	Rear fender 3PH raise switch - voltage of the switch is incorrect or invalid; in between mid and max range or min and mid range
Raw	456210	3	Receive	Rear fender 3PH raise switch - voltage of the switch is above normal operational range or shorted to high source
Raw	456210	4	Receive	Rear fender 3PH raise switch - voltage of the switch is below normal operational range or shorted to low source
Raw	456211	2	Receive	Rear fender 3PH lower switch - voltage of the switch is incorrect or invalid; in between mid and max range or min and mid range
Raw	456211	3	Receive	Rear fender 3PH lower switch - voltage of the switch is above normal operational range or shorted to high source

Source	SPN	FMI	RX/TX	Description (SPN-FMI)
Raw	456211	4	Receive	Rear fender 3PH lower switch - voltage of the switch is below normal operational range or shorted to low source
Raw	458240	-	Transmit	StarterInterlock - No fault codes available
Raw	458241	-	Transmit	FrontWheelAssistEngaged - No fault codes available
Raw	458242	-	Transmit	DifflockEngaged - No fault codes available
Raw	458243	-	Transmit	FrontWipersLow - No fault codes available
Raw	458244	-	Transmit	FrontWipersHigh - No fault codes available
Raw	458245	-	Transmit	FrontWipersWasher - No fault codes available
Raw	458246	-	Transmit	RearWipersLow - No fault codes available
Raw	458247	-	Transmit	LowBeam - No fault codes available
Raw	458248	-	Transmit	HighBeam - No fault codes available
Raw	458249	-	Transmit	ParkLights - No fault codes available
Raw	458250	-	Transmit	FrontLeftTurnLight - No fault codes available
Raw	458251	-	Transmit	FrontRightTurnLight - No fault codes available
Raw	458252	-	Transmit	RearLeftFrontTurnLight - No fault codes available
Raw	458253	-	Transmit	RearRightTurnLight - No fault codes available
Raw	458254	-	Transmit	TrailerBrakeLight - No fault codes available
Raw	458255	-	Transmit	RearDefog - No fault codes available
Raw	458256	-	Transmit	RearDefogLed - No fault codes available
Raw	458257	-	Transmit	HVACCommand - No fault codes available
Raw	458258	-	Transmit	DPScWakeupStatus - No fault codes available
Raw	458259	-	Transmit	DelayShutdownStatus - No fault codes available
Raw	458260	-	Transmit	EngineEnable - No fault codes available
Raw	458261	-	Transmit	IsobusEcuPowerEnable - No fault codes available

3-pt Hitch and Power Take-off (PTO) Fault Codes

The fault codes listed may appear in category of active faults.

NOTE: The fault codes are listed by SPN-FMI pairs in ascending order.

Table 6-19: 3-pt Hitch and Power Take-off (PTO) Fault Codes				
Source	SPN	FMI	RX/TX	Description (SPN-FMI)
TPH/PTO	457728	-	Transmit	FrontTphFlow - No Fault codes available
TPH/PTO	457729	-	Transmit	FrontTphDirection - No Fault codes available
TPH/PTO	457730	-	Transmit	RearPTOEnabledStatus - No Fault codes available
TPH/PTO	457731	-	Transmit	RearPTOSpeedSelected - No Fault codes available
TPH/PTO	457732	-	Transmit	RearPTOSpeed - No Fault codes available
TPH/PTO	457733	-	Transmit	FrontPTOEnabledStatus - No Fault codes available
TPH/PTO	457734	-	Transmit	FrontPTOSpeed - No Fault codes available
TPH/PTO	457735	-	Transmit	AutoPtoEnabledStatus - No Fault codes available
TPH/PTO	457736	-	Transmit	TphLockSwitch - No Fault codes available
TPH/PTO	457737	-	Transmit	TphRideControlSwitch - No Fault codes available
TPH/PTO	457738	-	Transmit	TphDraftControlSwitch - No Fault codes available
TPH/PTO	457739	-	Transmit	TphWheelControlSwitch - No Fault codes available
TPH/PTO	457740	-	Transmit	TphUpperLimitSetpoint - No Fault codes available
TPH/PTO	457741	-	Transmit	TphLoweringSpeedSetpoint - No Fault codes available
TPH/PTO	457742	-	Transmit	TphDraftConrtolSetpoint - No Fault codes available
TPH/PTO	457743	-	Transmit	TphWheelSlipSetpoint - No Fault codes available
TPH/PTO	457744	-	Transmit	TphPositionRequested - No Fault codes available
TPH/PTO	457745	-	Transmit	CalculatedWheelSlip - No Fault codes available

Section 7: Specifications – Contents

Tractor Dimensions	.7-3
Overall Height	.7-4
Overall Width	.7-4
Wheel Tread Width	.7-4
Tractor Weight	.7-7
Tractor Specifications	.7-8
Operation Specifications	.7-8
QSB 6.7 Engine	.7-9
Cooling System	7-10
Hydraulics	7-11
Transmission	7-11
Transmission Oil	7-12
Transmission Oil Temperature	7-13
3-pt Hitch	7-14
Drawbar	7-14
Brake System	7-15
Steering System	7-15
Electrical System	7-15
Fluid Capacities	7-16
Adding Hydraulic Oil for Hydraulic Remote Operation	7-16
Lubricants and Fluids	7-17
Summary of Lubricants and Fluids	7-17
Front Axle Lubricants	7-19
Engine Coolant Specifications	7-20
DEF Storage	7-22
Testing Diesel Exhaust Fluid	7-22
Fuel Storage	7-22
Speed Chart	7-23
Tire Data, Combinations, Pressures and Loads	7-24
Introduction	7-24
Tire Pressures and Permissible Loads	7-24
Service Techniques	7-29
General	7-29
Hoses and Tubes	7-29
Standard Hardware Torque Specifications	7-30
Metric Hardware and Locknuts	7-30
Imperial Hardware	7-31
Torque Values for Hydraulic Fittings (Imperial)	7-32

This Page Is Intentionally Left Blank.


Tractor Dimensions

Ref	Description	mm (in)
1	Front Ground Clearance	686 (27)
2	Overall length from nose to end of drawbar.	5055 (199)
3	Wheelbase from center of axle to center of axle.	2896 (114)
4	Distance from center of front axle to nose of tractor	1245 (49)
5	Distance from center of rear axle to end of drawbar	940 (37)
6	Distance from front bracket to end of 3-pt hitch	5334 (210)
7	Distance from nose end of 3-pt hitch	4945 (194)

NOTICE

The specifications on the following pages are given for information and guidance only. Our policy is one of continuous improvement and we reserve the right to change prices, specifications, or equipment at any time without noticed. For further information concerning the tractor, contact a KUBOTA dealer.

All specifications are given metric units then standard imperial units.



Overall Height

The overall height of the tractor is determined by the tire size chosen. The tire combination used for this example are 380/85R34 (Front) and 480/80R46 (Rear). Single or dual configuration does not affect the height.

Overall Width

The overall width of the tractor is determined by the tire size chosen and whether the tractor is configured with single or dual tires in the rear.


Wheel Tread Width

The wheel tread width of the tractor will be determined by the tire size chosen. Single or dual tire configuration will also affect wheel tread width. details overall width by tire size and configuration. Tread width is shown from center to center of outer wheels. The specification provided is just an example based on the tire combination.

Table 7-2: Tractor Height and Width Examples mm (in) 380/85R34 (Front) and 480/80R46 (Rear) Tires

Dimension	mm (in)
Height to Front of Roof (A)	3 200 (126)
Height to Rear of Roof (B)	3 226 (127)
Height to Exhaust Tip (C)	3 150 (124)
Tire Width Front and Rear (singles) (D)	1 850 (72.8)

NOTE: This table provides example heights and widths based on 2 possible tire sizes. Contact a KUBOTA dealer for assistance in measuring a tractor.



Ref	Description	mm (in)
1	Overall Length (with weight pack to end of 3-pt hitch)	5334 (210)
2	Overall Length (with weight pack to center of drawbar pin)	5055 (199)
3	Overall Length (without weight pack to center of drawbar pin)	4623 (182)
4	Overall length wheelbase	2896 (114)
5	Distance without weight pack to center of 3-pt hitch pin	4877 (192)






Table 7-4: Suspended Axle Dimensions mm (in)		
Ref	Description	mm (in)
A	Planetary Carrier to Planetary Carrier	2235 (88)
B	Swivel Housing to Swivel Housing	1930 (76)
C	Planetary Cover Diameter	279 (11)
D	Wheel Stud to Wheel Stud Diameter	305 (12)



Tractor Weight

NOTICE

It is the owner's responsibility to determine the exact weight of the tractor. Exact weights are only obtainable by weighing the tractor.

Weigh the tractor to obtain the exact weight. Both factory and dealer-installed accessories/options affect the weight of the tractor.

Table 7-5: Maximum Gross Vehicle Weight (GVW) and Estimated Shipping Weights

Description	kg (lb)
M8-181 and M8-201TMT20 GVW	10929 (24094)
Front Axle Weight	5670 (12500)
Rear Axle Weight	4926 (10860)
Front Weight Package	600 (1323)
Total Base Tractor Weight	7257.5 (16000)

NOTE: These weights are a manufacturer's estimate and do not include factory installed options.

NOTE: Weights are based on normal shipping configuration and are used as a guide for field applications.

Table 7-6: Tractor Weight

Axle and Drive Components	kg (lb)
Axles 3048 mm (120 in)	34 (75)
Front Weight Packages (FWP)	kg (lb)
20 x 30 Front	600 (1323)
33 x 30 Front	990 (2432)
Rear Weight Packages (RWP)	kg (lb)
10 x 39	390 (860)
Front Fenders	kg (lb)
Dynamic Front Fenders	39 (86)

NOTE: These weights are a manufacturer's estimate and do not include factory installed options.

NOTE: Contact a KUBOTA dealer for additional information or accessories and modifications. All measures are approximate and are to be used only as a guide.

Tractor Specifications

The specifications on the following pages are given for your information and guidance. Contact a KUBOTA dealer for further information concerning the tractor.

All data given in this book is subject to production variations. Dimensions and weights are approximate only. For exact information about any particular tractor, contact a KUBOTA dealer.



DANGER



Extreme angles may result in loss of control. Tipping the tractor will cause severe damage and may result in severe personal injury or death.

Operation Specifications

	mm	in
Outside Wheel Track Radius	6 400	252
Drawbar Center Turn Radius	4 810	189

NOTE: Turning radius dimensions are estimated based on geometry of the components and do not allow for brake assisted turning which decreases the turning radius. Wheel spacing used for measurement is 1 524 mm (60 in).

Front End – Rear End	25 degrees off horizontal
Side to Side	25 degrees off horizontal

QSB 6.7 Engine

Table 7-9: Engine and Fuel System Specifications	
Models	M8-181 and M8-201
Engine Type	Cummins Model QSB6.7
Engine Displacement	6.7 litres (409 C.I.D.)
Engine Weight (wet)	583 kg (1 285 lb)
Emissions Control	Tier IV Final
Electronic Control	Fully Integrated Electronic Control (ECM)
Rated Engine Speed	2100 rpm
Engine Power Rating	180 HP 200 HP
Peak Torque	M8-181: 863 N·m (637 ft·lb) M8-201: 906 N·m (668 ft·lb)
PTO Power	M8-181: 145 HP @ 2000 rpm M8-201: 159 HP @ 2000 rpm
PTO Speed @ PTO Standard rpm (2000 rpm)	1000 rpm
Rear PTO Type 1	35 mm (1.375 in) 540 rpm PTO shaft
Rear PTO Type 2	35 mm (1.375 in) 1000 rpm PTO shaft
Rear PTO Type 3	45 mm (1.750 in) 1000 rpm PTO shaft
Number of Cylinders	6
Cylinder Bore and Stroke	107 mm (4.21 in) x 124 (4.88 in)
Firing Order	153624
Compression Ratio	17.3:1
Induction	Turbo-Charged with Charge Air Cooling
Turbocharger	Variable Geometry (VGT™)
Exhaust	Selective Catalytic Reduction with Diesel Oxidization Catalyst (SCR with DOC)
Crankcase Ventilation	High Performance Coalescing Filter
Fuel System	Cummins Extra High Pressure Injection (XPI)
Injection Pump	Cummins/Bosch
Fuel Filtration	Two Stage: Water Separator and Particulate Filter
Fuel Inlet Restriction (max)	33.8 kPa (4.9 psi)
Return Pressure	30 kpa (4.3 psi)
Lift Pump	Mechanical

Table 7-12: QSB 6.7 Power Ratings

Model	Rated kW (hp) @ 2 100 rpm	Max kW (hp) @ 1 900 rpm
M8-181	134 (180)	153 (205)
M8-201	149 (200)	164 (220)

NOTE: Engine warranty requires full compliance with Cummins service procedures.

NOTE: The engine is entirely controlled by the Cummins Engine Control Module (ECM) and there are no user adjustable components.

NOTE: The Cummins Owner's Manual provides details of user service recommendations for fluid and filter checks and changes. See the Cummins Owner's Manual for details or contact a KUBOTA or Cummins dealer.

Table 7-10: Engine Lubricating Oil System Specifications

Regulated Operating Pressure	517 kpa (75 psi)
Minimum Oil Pressure (low idle)	69 kpa (10 psi)
Minimum Oil Pressure (at rated engine speed)	380 kpa (55 psi)
Lubricating Oil Filter Capacity	0.950 L (0.25 gal)
Engine Oil Pan Capacity	14.2 L (3.75 gal)
Maximum Engine Oil Capacity	16.7 L (4.41 gal)
Oil Pan Drain Plug Torque	80 N·m (59 ft·lb)

Cooling System

Table 7-11: Cooling System Specifications

Thermostats	1
Begin to Open	70 °C (160 °F)
Fully Open	82.8 °C (181°F)
Radiator Pressure Cap	1.0 bar (15 psi)
Block Heater	1 000 Watt

Hydraulics

Table 7-13: Hydraulics Specifications	
Hydraulic System	Closed Center Load Sensing
Nominal System Pressure	200 bar (2 900 psi)
Hydraulic Pump	118 lpm (31 gpm) standard flow pump 166 lpm (44 gpm) high flow pump
Rated Flow/Engine Speed Standard Flow	118 lpm (31 gpm)/2 100 rpm 126 lpm (33 gpm)/2 250 rpm max speed
Rated Flow/Engine Speed High Flow	166 lpm (44 gpm)/2 100 rpm 178 lpm (47 gpm)/2 250 rpm max speed
Remote Control SB24 Valve	120 Lpm (31.7 gpm)
Remote Hydraulic Brake (Option)	145 bar (2 150 psi) maximum output pressure

Transmission

- Continuously variable, hydrostatic-mechanical powersplit transmission consists of 4 planetary stages and 4 multi-disk clutches.
- The transmission is equipped with a reversing transmission with starting and reversing clutch in countershaft design.
- The shifting elements have synchronous speed in all gear-change points.
- High level of operating comfort.
- Selection of different operating modes optimally matched to the individual applications, e.g. constant speed during cultivation, harvesting and traction work, constant engine speed during PTO shaft operations, automatic, efficiency-oriented driving within economic engine performance characteristics
- Increased field productivity by optimum utilization of engine power.
- Optimized emission levels through appropriate engine control. Equal tractive efforts forward / reverse.

Table 7-14: Transmission Specifications	
	TMT 16/18/20
Transmission input speed	2200 min ⁻¹
Input torque max.	703 N·m (519 ft·lb)
Transmission input power max.	121 kW (162 hp)
Vehicle speed forward	50 km/h (31 mph)
Vehicle speed reverse	30 km/h (19 mph)
Vehicle weight transport/ PTO at 50 km/h	10 000 kg (22 046 lb)
Vehicle weight field operations	8 766 kg (19 326 lb)
Rear axle load transport/PTO	8 400 kg (18 519 lb)
Rear axle load traction operations	7 000 kg (15 432 lb)
Tire size max. rear	855 mm (34 in)
Tire size max. front	675 mm (27 in)

Transmission Oil

**CAUTION**

Only use oils listed in the valid ZF List of Lubricants.

For transmission TMT16/18/20 ZF requests the use of high-quality oils. The oils are released by ZF and indicated in the ZF List of Lubricants TE-ML06.

Prescribed/approved transmission oils for rear axle final drives (planetary drive) see ZF-list of lubricants TE-ML 21.

The ZF List of Lubricants is being continuously updated to consider newly added oils and changed trade names. Only the latest version is applicable. It can be obtained or viewed as follows:

- at all ZF plants
 - at all ZF service organizations
 - Internet <http://www.zf.com>
-

Transmission Oil Temperature

The transmission oil temperature must be $>-7^{\circ}\text{C}$.

If the transmission oil temperature is $< -7^{\circ}\text{C}$ warm up the transmission in neutral.

Table 7-16: Transmission Oil Temperature Specifications		
Oil Temperature	Permanently	Temporarily (<2 h)
Up to 20 km/h	80 °C (176 °F) max	90 °C (194 °F) max
Above 20 km/h	90 °C (194 °F) max	100 °C (212 °F) max

3-pt Hitch

Table 7-17: 3-pt Hitch Specifications	
Linkage	Category 3N/3
Maximum lift capacity @ 610 mm (24 in) behind hitch point	5080 kg (11200 lb)
Cylinder Diameter	2 x 114.3 mm (4.5 in)
Stroke	305 mm (12 in)
Drawbar	Adjustable Swinging Drawbar
Maximum Drawbar Offset	214 mm (8.4 in)

Drawbar

Table 7-18: Drawbar Specification	
Drawbar Pin Diameter	38 mm (1.5 in)
Drawbar Clevis Throat	92 mm (3.6 in)
Hitch Point to PTO Shaft Distance	Rear 406 mm (16 in) Center 508 mm (20 in) Forward 609 mm (24 in)
Drawbar Maximum Static Downward Load:	
Shortest Drawbar Position	2700 kg (5952 lb)
Regular Drawbar Position	1800 kg (3968 lb)
Extended Drawbar Position	1300 kg (2866 lb)
Heavy Duty Drawbar Option at Shortest position	2900 kg (6393 lb)

Brake System

Table 7-19: Brakes Specifications	
Brakes	Self Adjusting Inboard (differential/axle housing) Hydraulic Wet Discs
Number of Discs	5
Disc Diameter (O.D.– I.D.)	368–305 mm (9.5 – 7 in)

Steering System

Table 7-20: Steering Specifications	
Type	Hydrostatic with Tilt and Telescopic Steering Wheel
Maximum Pressure	186 bar (2700 psi)
Toe-in Adjustment	0 – 6.3 mm (0 – 0.25 in)

Electrical System

Table 7-21: Electrical Specifications	
Batteries	2 x 950 Cold Cranking Amps (CCA) Rated
Alternator	Heavy Duty 12V (200A)
Starter Motor	Positive Engagement Solenoid Operated 7.2 kW (9.6 hp)
Radar (option)	58.9 Hz/mph
Radio (option)	Consult a KUBOTA dealer

Fluid Capacities

Table 7-22: Fluid Capacities		
	litres (L)	gallons (gal)
Total Fuel Capacity	375 L	(99 gal)
DEF Tank	35 L	(9.2 gal)
Cooling System	11 L	(3.0 gal)
Engine Oil with Filter	25.6 L	(6.76 gal)
Front Hubs (individual)	5 L	(1.32 gal)
Rear Planetary Oil	11 L	(2.9 gal)
Transmission/Rear Axle/Hydraulic System	83 L	(22 gal)
Working Hydraulic	40 L	(10 gal)

NOTE: *Operating remote cylinders may require adding extra hydraulic oil to the rear axle.*

Adding Hydraulic Oil for Hydraulic Remote Operation

This must be done with all the rams fully extended. Make sure not to add more than the necessary amount needed to bring the level to the full mark on the dipstick. Remote cylinders with a total capacity of up to 23 L (6 gal) may be connected to the tractor without adding oil provided the tractor is operated on level ground.

Normal oil changes require less than the total fill capacity of the axle assembly. The difference may be as much as 23 litres (6 gal) and is the result of oil being retained in passages and control systems.

Lubricants and Fluids

Summary of Lubricants and Fluids

Table 7-23: Summary of Lubricants and Fluids																									
Components	Specification																								
Engine Oil (See note 1 below)	<p>Recommended: CES 20086 or oil classification API CK-4</p> <p>Permitted: Cummins Engineering Standard (CES) 20081 or oil classification API CJ-4, ACEA E9, JAMA DH-2</p> <ul style="list-style-type: none"> • 15W-40 (All season – recommended for diesel engines) • 10W-30 (Winter conditions – recommended for diesel engines) • 5W-30 (Arctic conditions – recommended for diesel engines) • Do not use aftermarket oil additives 																								
	<p>Recommended SAE Oil Viscosity Grades vs. Ambient Temperatures</p> <table border="1"> <thead> <tr> <th>Condition</th> <th>Oil Grade</th> <th>Temperature Range (°F)</th> <th>Temperature Range (°C)</th> </tr> </thead> <tbody> <tr> <td>All Seasons</td> <td>5W40 or 15W40</td> <td>-30 to 140</td> <td>-30 to 60</td> </tr> <tr> <td>All Seasons</td> <td>CJ-4</td> <td>-10 to 120</td> <td>-10 to 50</td> </tr> <tr> <td>Winter Conditions</td> <td>10W30</td> <td>0 to 100</td> <td>0 to 40</td> </tr> <tr> <td>Winter Conditions</td> <td>5W30</td> <td>-10 to 100</td> <td>-10 to 40</td> </tr> <tr> <td>Arctic Conditions</td> <td>0W30</td> <td>-30 to 0</td> <td>-30 to 0</td> </tr> </tbody> </table>	Condition	Oil Grade	Temperature Range (°F)	Temperature Range (°C)	All Seasons	5W40 or 15W40	-30 to 140	-30 to 60	All Seasons	CJ-4	-10 to 120	-10 to 50	Winter Conditions	10W30	0 to 100	0 to 40	Winter Conditions	5W30	-10 to 100	-10 to 40	Arctic Conditions	0W30	-30 to 0	-30 to 0
Condition	Oil Grade	Temperature Range (°F)	Temperature Range (°C)																						
All Seasons	5W40 or 15W40	-30 to 140	-30 to 60																						
All Seasons	CJ-4	-10 to 120	-10 to 50																						
Winter Conditions	10W30	0 to 100	0 to 40																						
Winter Conditions	5W30	-10 to 100	-10 to 40																						
Arctic Conditions	0W30	-30 to 0	-30 to 0																						
Fuel	<p>Use Ultra-low Sulphur Diesel (ULSD) only (less than 15 ppm in North America, less than 10 ppm in the European Union).</p> <ul style="list-style-type: none"> • For ambient temperatures above 0 °C (32 °F), use Number 2D diesel with a minimum cetane level of 42. • For ambient temperatures below 0 °C (32 °F), use a blend of Number 1D and 2D diesel with a minimum cetane level of 45. • Fuel must be free of dirt and water. • Never use blended fuels. • Biodiesel: A B20 blend of ULSD and biodiesel (up to 20 % biodiesel). In North America, biodiesel must be purchased from a BQ-9000 Certified Marketer (website: http://www.bq-9000.org). If outside of North America, contact a Cummins Inc. representative. • Contact a KUBOTA dealer for more information and suppliers of ULSD fuels and about cold weather operations. • Fuel storage: see . page 7-22. • 2-D – ABOVE -7°C (20°F) 1-D (blended with 2D) – BELOW -7°C (20°F) 																								
Diesel Exhaust Fluid (DEF)	Must meet ISO 22241-1 or DIN 70070. Commercial grade only.																								
Hydraulic, Transmission and Rear Axle	<p>ZF 21A, 21C, 21G</p> <p>10w-30 Universal Tractor Transmission Oil (U.T.T.O)</p>																								

Components	Specification	
	Examples of acceptable brand name oils	
	Brand	Equivalent Specification
	KUBOTA	KUBOTA UDT-HD fluid (Canada makert: K4-Trans Hydraulic Oil)
	Imperial Oil (Esso)	Hydraul 56
	Shell	Spirax S4 TXM
	Texaco	TDH
	Amoco	2016 (United States) 01055 (Canada)
	Petro-Canada	Duratran
	Exxon Mobil	424
Grease Fittings	STD Grease Lithium base High Temperature EP 2 (NLGI 2): Use to lubricate the 3-pt hitch.	
Front Wheel Bearings	Lithium Base EP High Temperature	
Air-conditioning Refrigerant	R134a	
A/C Compressor Oil	PAG 46	

NOTE: Use only Ultra Low Sulfur Fuel. Failure to use proper fuel could result in emissions control failure and damage to the exhaust after treatment system.

* Factory Fill

NOTE: Cummins Inc. recommends the use of high-quality 15W-40 multi-viscosity heavy duty engine oil that meets the minimum requirements of Cummins Engineering Specification CES 20081. American Petroleum Institute (API) specifications are similar to Cummins but the Cummins specification always takes precedence. Use of lower grade oils will invalidate the manufacturer's warranty and may cause severe damage to the engine.

Most popular brand Heavy Duty engine oils that meet API specifications will also meet the Cummins specification. Always read the product description and specifications to determine its suitability for use.

(See the Cummins QSL Engine Operation and Maintenance Manual for further details.)

Front Axle Lubricants

Brand	Type
KUBOTA	KUBOTA UDT-HD fluid (Canada makert: K4-Trans Hydraulic Oil)
Imperial Oil Esso	GX
Shell	Spirax S3 AX
Texaco	Multigear
Petro Canada	TRAXON
Exxon Mobil	Mobilube

Component	Fluid Type	Type
Differential and Planetary	Gear Oil	SAE 80W/90 (API GL4 or GL5)
Final Drive	Gear Oil	SAE 80W/90 (API GL4 or GL5)
Bearings, Bushings and Seals	Grease	Lithium-EP 2 or NLGI EP 3 with Moly Additive

Engine Coolant Specifications

Table 7-25: Coolant Specifications

Engine Coolant*	<ul style="list-style-type: none"> • Factory Filled – Includes DCA4 Additive, Fully Formulated (Propylene or Ethylene Glycol) (Pink Color) • Coolant must meet Cummins Engineering Standard (CES) 14603. • See for water quality, contaminate limits, SCA levels and freezing points.
-----------------	--

Table 7-26: Coolant Properties

Property	Ethylene Glycol (% by volume)			Propylene Glycol (% by volume)			Pure H ₂ O
	40	50	60	40	50	60	
Glycol Concentration	40	50	60	40	50	60	0
Specific Gravity, 16 °C (50 °F)	1.062	1.076	1.088	1.038	1.043	1.047	1.000
Freezing Point °C (°F)	-24 (-12)	-37 (-34)	-52 (-62)	-21 (-6)	-33 (-27)	-49 (-56)	0 (32)
Boiling Point °C (°F) at Sea level	106 (222)	108 (226)	111 (232)	104 (219)	106 (222)	109 (228)	100 (212)

For operation of Diesel Engines in Cold Climates (Arctic conditions) -32°C to -54°C (-25°F to -65°F), Cummins Inc. recommends use of a 65% ethylene glycol antifreeze mixture. 68% antifreeze (ethylene glycol) is the absolute maximum allowable. Propylene glycol is not recommended for Arctic conditions due to possible gelling.

IMPORTANT: The coolant must be replaced if any contaminant level exceeds the following limits:

*Factory Fill

IMPORTANT: The coolant must meet Cummins Engineering Standard CES 14603.

Antifreeze or coolant must be used in all climates for both freeze and boiling point protection. Cummins Inc. recommends filling the cooling system with premixed fully formulated coolant or with a 50/50 mixture of high-quality water and fully formulated concentrated antifreeze for most conditions.

Contaminate	Allowable Level
Sulfate (SO ₄)	1 500 ppm. Maximum
Chloride (Cl)	200 ppm. Maximum
Oil or fuel contamination	Must not contain any oil or fuel
PH	6.5 minimum
Grease, solder bloom, silica gel, rust or scale	Must be free of these contaminants

DEF Storage

Before using anything to store or dispense (diesel exhaust fluid) DEF, such as containers or funnels, wash these items with distilled water, not tap water. Tap water will contaminate the DEF.

- If distilled water is not available, rinse the items with tap water first, and then with DEF.

Ambient temperature and the duration of storage are the 2 major factors that affect the shelf life of DEF. In ideal storage conditions, DEF will have a minimum shelf life of 18 months. Ideal conditions are:

- Storage temperature between -5 °C to 25 °C (-65 °F to 77 °F)
- Store in sealed, approved containers made of polyethylene or polypropylene.
- No direct sunlight

Higher temperatures and extended storage periods will reduce DEF shelf life.

- The shelf life will be reduced by 6 months for every 5 °C (9 °F) above 25 °C (77 °F).
- Avoid storing DEF in the tractor for more than 6 months.
- Test the DEF if it has been stored for extended periods of time.

Testing Diesel Exhaust Fluid

Test the DEF quality if:

- The DEF has been stored for an extended period of time, or
- You suspect water has been added to the DEF tank. If any other incorrect fluid has been added to the DEF tank, such as coolant or fuel, contact an Authorized Cummins Repair Location for help.

To test the DEF quality:

1. Obtain the Cummins Diesel Exhaust Fluid Refractometer, part number 4919554.
2. Follow the instructions included with the tool.
3. A Urea concentration between 31 % to 34 % is acceptable.
 - If the concentration is outside of this specification, then drain the DEF tank, flush with distilled water, re-fill with DEF and re-test the DEF.

Fuel Storage

Contaminated fuel is a leading cause of potential malfunctions and breakdowns. Keep the fuel clean and free of dirt, water or other contaminants as an important part of maintaining a KUBOTA tractor in operating condition. Take these precautions to keep stored fuel free of dirt, water and other contaminants.

- Store fuel in black iron tanks. Do not use galvanized tanks as the zinc coating will react with the fuel and form compounds that will contaminate the injection pump and injectors.
- Install bulk storage tanks away from direct sunlight and tilt them slightly so sediment in the tanks will settle away from the outlet pipe. Check the fuel storage tanks regularly for condensation by draining from the tank bottom.
- Provide a drain plug at the lowest point of the storage tank, at the opposite end from the outlet pipe, to facilitate moisture and sediment removal.
- B20 biodiesel can be used with a KUBOTA tractor but use this fuel within 6 months of its date of manufacture. With lower oxidation stability, rubber components may degrade over time. Hot, humid conditions may lead to increased fuel degradation. Avoid storing the tractor for periods of longer than 3 months with biodiesel in the fuel system.
- If the fuel is not filtered from the storage tank, always use a funnel with a fine mesh screen when refueling the tractor.
- Arrange fuel purchases so summer grade fuels are not held over and used in winter.
- Ground fuel storage tanks to prevent static buildup.

Speed Chart

The speed chart below is based on a Continuously Variable Transmission.

Table 7-28: Speed Chart for 40 km/h (25 mph) rated engine rpm													
V (km/h)		Range	K1	K2	K3	K4	BG	KV	KR	P1	P2	P3	P4
0.00-7.72	Forward	I	•				•	•		•	•	•	•
7.72-15.44		II		•			•	•		•	•		•
15.44-30.87		III		•	•			•		•			
30.87-63.29		IV		•		•		•		•	•		
0.00-5.04	Reverse	I	•				•		•	•	•	•	•
5.04-10.07		II		•			•		•	•	•		•
10.07-20.14		III		•	•				•	•			
20.14-40.28		IV		•		•			•	•	•		

Tire Data, Combinations, Pressures and Loads

Introduction

The tires fitted to tractors with optional four wheel drive have been carefully selected to match the gearing of the transmission and axles. Always install tires of the same make, model and size as those removed when replacing worn or damaged tires. The installation of other tire combinations may result in excessive tire wear, loss of usable power or severe damage to driveline components. If in doubt, contact a KUBOTA dealer.

Radial Tire Identification

Radial tires are identified according to a star code on the tire sidewall:

1. Tires with ☆ are inflated to a maximum of 1.2 bar (18 psi).
2. Tires with ☆☆ are inflated to a maximum of 1.6 bar (24 psi).
3. Tires with ☆☆☆ are inflated to a maximum of 2.0 bar (30 psi).

Tire Pressures and Permissible Loads

IMPORTANT: *The figures in the following charts are for guidance only. Tire specifications vary by tire manufacturer. For exact tire loading information, refer to the information provided by the manufacturer of the tires on the tractor.*

To avoid the possibility of tire to rim creep, do not use tire pressures below 0.4 bar (6 psi) with radial tires and 0.8 bar (12 psi) with bias ply for operations having a high torque requirement, e.g., subsoiling, plowing, heavy cultivation, etc.

Tire loading figures in the following tables are for a single wheel. To determine the maximum tire loading for single wheel applications, multiply the load figure in the table by two, the total number of wheels on the axle.

Example: Rear Wheels 2 wheels (singles) x table figure = Maximum tire load

To determine the maximum tire loading for units with duals, multiply the load figure in the table by the total number of wheels on the axle, then multiply by 88%.

Example: Rear Wheels 4 wheels (models with duals) x table figure x 88% = Maximum tire load

Axle loading must be within the capacities listed in Section 3 of this manual.

Remember the information in the charts and the examples cited are for guidance only. For exact information regarding inflation pressures and tractor loading, contact a Kubota dealer or the tire manufacturer.

When front mounted implements are fitted, front tire loads may be increased by up to 35% with no increase in inflation pressure when operated at speeds not exceeding 20 km/h (12 mph).

At speed not exceeding 8 km/h (5 mph), the load on the front tires may be increased by 50% provided the inflation pressures are increased by 25%.

Table 7-30: Tire Technical Data - Front (380/85 R34) Rear (380/90 R50) RCI 42				
Front (380/85 R34)				
Overall Diameter	Overall Width	Max Load	RC	SLR
1 516 (59.7 in)	378 mm (14.9 in)	2835kg (6250 lb)	4 519 mm (177.9 in)	691 mm (27.2 in)
Rear (380/90 R50)				
1935 (76.2 in)	(15.5 in)	3447 kg (7600 lb)	5814 (229 in)	912 mm (35.9 in)

Table 7-31: Tire Technical Data - Front (380/85 R34) Rear (380/90 R50) RCI 42				
Front (480/70 R30)				
Overall Diameter	Overall Width	Max Load	RC	SLR
1 516 (58.3 in)	497 mm (19.6 in)	2835kg (6220 lb)	4 389 mm (172.8 in)	691 mm (25.8 in)
Rear (620/70 R42)				
1953 (76.9 in)	640 mm (25.2 in)	3447 kg (10870 lb)	5 781 (227.6 in)	864 mm (34 in)

Table 7-32: Tire Technical Data - Front (600/65 R28) Rear (710/70 R38) RCI 42				
Front (600/65 R28)				
Overall Diameter	Overall Width	Max Load	RC	SLR
1 491 (58.7 in)	589 mm (23.2 in)	2835kg (7 440 lb)	4 448 mm (175.1 in)	660 mm (26 in)
Rear (710/70 R38)				
1956 (77 in)	719 mm (28.3 in)	5307 kg (11 700 lb)	5 781 (227.6 in)	864 mm (34 in)

Tire Load and Inflation Tables

Metric Units

Table 7-33: Tire Load and Inflation Table - 380/85 R34					
380/85 R34					
30 mph (for reference)	25 mph	20 mph	6 mph	25 mph Dual	Pressure
50 km/h (for reference)	40 km/h	30 km/h	10 km/h	40 km/h Dual	
Load Capacity					
3 640 lb	3 640 lb	3 895 lb	4 878 lb	N/A	6 psi
1 650 kg	1 650 kg	1 766 kg	2 211 kg	N/A	0.4 bar
5 200 lb	5 200 lb	5 564 lb	6 968 lb	N/A	12psi
2 360 kg	2 360 kg	2 525 kg	3 162 kg	N/A	0.8 bar
5 840 lb	5 840 lb	6 249 lb	7 826 lb	N/A	15psi
2 650 kg	2 650 kg	2 836 kg	3 551 kg	N/A	1.0 bar
6 600 lb	6 600 lb	7 062 lb	8 844 lb	N/A	17 psi
3 000 kg	3 000 kg	3 210 kg	4 020 kg	N/A	1.2 bar
7 850 lb	7 850 lb	8 400 lb	10 519 lb	N/A	23 psi
3 550 kg	3 550 kg	3 799 kg	4 757 kg	N/A	1.6 bar
8 800 lb	8 800 lb	9 416 lb	11 792 lb	N/A	29 psi
4 000 kg	4 000 kg	4 280 kg	5 360 kg	N/A	2.0 bar
9 350 lb	9 350 lb	10 005 lb	12 529 lb	N/A	35 psi
4 250 kg	4 250 kg	4 548 kg	5 695 kg	N/A	2.4 bar
10 500 lb	10 500 lb	11 235 lb	14 070 lb	N/A	41 psi
4 750 kg	4 750 kg	5 083 kg	6 365 kg	N/A	2.8 bar

Tire Load and Inflation Tables

Metric Units

Table 7-34: Tire Load and Inflation Table - 600/65 R28						
600/65 R28						
30 mph	25 mph	20 mph	15 mph	6 mph	25 mph Dual	Pressure
50 km/h	40 km/h	30 km/h	25 km/h	10 km/h	40 km/h Dual	
Load Capacity						
		3550 lb			2910 lb	6 psi
		1610 kg			1320 kg	0.4 bar
		4880 lb			4190 lb	12 psi
		2215 kg			1900 kg	0.8 bar
	5490 lb	5560 lb	5750 lb	6940 lb	4830 lb	15 psi
	2490 kg	2520 kg	2610 kg	3150 kg	2190 kg	1.0 bar
5970 lb	5970 lb	6230 lb	6450 lb	7730 lb	5260 lb	17 psi
2710 kg	2710 kg	2825 kg	2925 kg	3505 kg	2385 kg	1.2 bar
6460 lb	6460 lb	6890 lb	7150 lb	8500 lb	5680 lb	20 psi
2930 kg	2930 kg	3125 kg	3245 kg	3855 kg	2575 kg	1.4 bar
6940 lb	6940 lb	7560 lb	7850 lb	9280 lb	6110 lb	23 psi
3150 kg	3150 kg	3430 kg	3560 kg	4210 kg	2770 kg	1.6 bar
7280 lb	7280 lb	7880 lb	8180 lb	10060 lb	6390 lb	26 psi
3300 kg	3300 kg	3575 kg	3710 kg	4565 kg	2900 kg	1.8 bar
7610 lb	7610 lb	8200 lb	8510 lb	10850 lb	6690 lb	29 psi
3450 kg	3450 kg	3720 kg	3860 kg	4920 kg	3035 kg	2.0 bar
7940 lb	7940 lb	8520 lb	8840 lb	11630 lb	6990 lb	32 psi
3600 kg	3600 kg	3865 kg	4010 kg	5275 kg	3170 kg	2.2 bar
8270 lb	8270 lb	8840 lb	9170 lb	12410 lb	7280 lb	35 psi
3750 kg	3750 kg	4010 kg	4160 kg	5630 kg	3300 kg	2.4 bar

Tire Load and Inflation Tables

Metric Units

Table 7-35: Tire Load and Inflation - RCI 47						
RCI 47						
30 mph	25 mph	20 mph	15 mph	6 mph	25 mph Dual	Pressure
50 km/h	40 km/h	30 km/h	25 km/h	10 km/h	40 km/h Dual	
Load Capacity						
			6 150 lb	8 020 lb	5 160 lb	6 psi
			2 790 kg	3 640 kg	2 340 kg	0.4 bar
	6 750 lb	7 030 lb	7 360 lb	9 370 lb	6 170 lb	9 psi
	3 060 kg	3 190 kg	3 340 kg	4 250 kg	2 800 kg	0.6 bar
7 390 lb	7 870 lb	8 200 lb	8 580 lb	10 710 lb	7 190 lb	12 psi
3 350 kg	3 570 kg	3 720 kg	3 890 kg	4 860 kg	3 260 kg	0.8 bar
9 530 lb	10 090 lb	10 520 lb	11 010 lb	13 250 lb	9 230 lb	17 psi
4 325 kg	4 575 kg	4 770 kg	4 995 kg	6 010 kg	4 185 kg	1.2 bar
11 680 lb	12 270 lb	12 800 lb	13 440 lb	15 640 lb	11 250 lb	23 psi
5 300 kg	5 565 kg	5 805 kg	6 095 kg	7 095 kg	5 105 kg	1.6 bar
12 620 lb	13 250 lb	13 820 lb	14 510 lb	18 020 lb	12 160 lb	29 psi
5 725 kg	6 010 kg	6 270 kg	6 580 kg	8 175 kg	5 515 kg	2.0 bar
13 100 lb	13 730 lb	14 330 lb	15 050 lb	18 610 lb	12 610 lb	32 psi
5 940 kg	6 230 kg	6 500 kg	6 825 kg	8 440 kg	5 720 kg	2.2 bar
13 560 lb	14 230 lb	14 850 lb	15 590 lb	19 180 lb	13 060 lb	35 psi
6 150 kg	6 455 kg	6 735 kg	7 070 kg	8 700 kg	5 925 kg	2.4 bar
				19 750 lb		38 psi
				8 960 kg		2.6 bar
				20 340 kg		41 psi
				9 225 kg		2.8 bar

Service Techniques

General

Clean the exterior of all components before carrying out any form of repair. Dirt and abrasive dust can reduce the efficient working life of a component and lead to costly replacement.

Time spent on the preparation and cleanliness of working surfaces will pay dividends in making the job easier and safer. This will result in overhauled components being more reliable and efficient in operation.

Use cleaning fluids which are known to be safe. Certain types of fluid can cause damage to O-rings and cause skin irritation. Check solvents for their suitability for the cleaning of components and also that they do not risk the personal safety of the user.

Replace O-rings, seals or gaskets whenever they are disturbed. Never mix new and old seals or O-rings, regardless of condition. Always lubricate new seals and O-rings with hydraulic oil before installation. When replacing component parts, use the correct tool for the job.

Hoses and Tubes

- Always replace hoses and tubes if the cone end or the end connections on the hose are damaged.
 - When installing a new hose, loosely connect each end and make sure the hose takes up the designed position before tightening the connection. Tighten clamps sufficiently to hold the hose without crushing and to prevent chafing.
 - After hose replacement to a moving component, check that the hose does not foul by moving the component through the complete range of travel.
 - Always check to make sure newly installed hoses are not kinked or twisted.
 - Damaged, dented, crushed or leaking hose connections restrict oil flow and the productivity of the components being served. Connectors that show signs of movement from the original swaged position have failed and will ultimately separate completely.
 - A hose with a chafed outer cover will allow water entry. Concealed corrosion of the wire reinforcement will subsequently occur along the hose length with resultant hose failure.
 - A ballooning hose indicates an internal leakage due to structural failure. This condition rapidly deteriorates and total hose failure soon occurs.
 - Kinked, crushed, stretched or deformed hoses generally suffer internal structural damage which can result in oil restriction, a reduction in the speed of operation and hose failure.
 - Free-moving, unsupported hoses must never be allowed to touch each other or related working surfaces. This causes chafing, which reduces hose life.
-

Standard Hardware Torque Specifications

Check the tightness of hardware periodically.

Use the following charts to determine the correct torque when checking, adjusting or replacing hardware on the tractor.

IMPORTANT: Torque values listed are for general use only. Always follow directions where torque values are specified.

NOTE: Use a torque wrench to properly tighten hardware. Make sure fastener threads are clean and not damaged.

Metric Hardware and Locknuts


N·m (ft·lb) for normal assembly.

Table 7-36: Metric Hardware and Locknuts Torque Values


Nominal Size	Class 5.8		Class 8.8		Class 10.9		Locknut CL.8 w/CL8.8 Bolt
	Unplated	Plated w/zncr	Unplated	Plated w/zncr	Unplated	Plated w/zncr	
M4	1.7 (15*)	2.2 (19*)	2.6 (23*)	3.4 (30*)	3.7 (33*)	4.8 (42*)	1.8 (16*)
M6	5.8 (51*)	7.6 (67*)	8.9 (79*)	12 (102*)	13 (115*)	17 (150*)	6.3 (56*)
M8	14 (124*)	18 (159*)	22 (195*)	28 (248*)	31 (274*)	40 (354*)	15 (133*)
M10	28 (21)	36 (27)	43 (32)	56 (41)	61 (45)	79 (58)	30 (22)
M12	49 (36)	63 (46)	75 (55)	97 (72)	107 (79)	138 (102)	53 (39)
M16	121 (89)	158 (117)	186 (137)	240 (177)	266 (196)	344 (254)	131 (97)
M20	237 (175)	307 (226)	375 (277)	485 (358)	519 (383)	671 (495)	265 (195)
M24	411 (303)	531 (392)	648 (478)	839 (619)	897 (662)	1160 (855)	458 (338)

* Torque values shown with* are inch-pounds.

Identification of Hex Cap Screws and Carriage Bolts - Classes 5, 6 and Up



Hex Nuts and Locknuts Classes 05 and Up



Imperial Hardware

In N·m (ft-lb) for normal assembly applications.




Nominal Size	SAE Grade 2		SAE Grade 5		SAE Grade 8		Locknuts	
	Unplated or Plated Silver	Plated w/zncr Gold	Unplated or Plated Silver	Plated w/zncr Gold	Unplated or Plated Silver	Plated w/zncr Gold	GR.B w/GR5 Bolts	GR.C w/GR5 Bolts
1/4	6.2 (55*)	8.1 (72*)	9.7 (86*)	13 (112*)	14 (121*)	18 (157*)	6.9 (61*)	9.8 (86*)
5/16	13 (115*)	17 (149*)	20 (178*)	26 (229*)	28 (250*)	37 (324*)	14 (125*)	20 (176*)
3/8	23 (17)	30 (22)	35 (26)	46 (34)	50 (37)	65 (48)	26 (19)	35 (26)
7/16	37 (27)	47 (35)	57 (42)	73 (54)	80 (59)	104 (77)	41 (30)	57 (42)
1/2	57 (42)	73 (54)	87 (64)	113 (83)	123 (91)	159 (117)	61 (45)	88 (64)
9/16	81 (60)	104 (77)	125 (92)	163 (120)	176 (130)	229 (169)	88 (65)	125 (92)
5/8	112 (83)	145 (107)	174 (128)	224 (165)	244 (180)	316 (233)	122 (90)	172 (127)
3/4	198 (146)	256 (189)	306 (226)	397 (293)	432 (319)	560 (413)	217 (160)	306 (226)
7/8	193 (142)	248 (183)	495 (365)	641 (473)	698 (515)	904 (667)	350 (258)	494 (364)
1	289 (213)	373 (275)	742 (547)	960 (708)	1048 (773)	1356 (1000)	523 (386)	739 (545)

NOTE: Torque values shown with * are inch-pounds.

Identification of Hex Cap Screws and Carriage Bolts



Locknuts



Marks need not be located at corners

Torque Values for Hydraulic Fittings (Imperial)

Use the following charts to determine the common torque specification for hose and tube fittings. These specifications refer to the minimum hardware tightening torque for normal assembly applications.

NOTE: Torque values listed here are for general use only.

IMPORTANT: Always follow tightening procedure where specified in the manual for a specific application.

Table 7-38: Torque Requirements for all Flare Fittings

Thread Size	Torque (N·m)	Torque (ft-lb)
7/16 - 20	14	10
1/2 - 20	19	14
9/16 - 18	22	16
3/4 - 16	42	31
7/8 - 14	64	47
1 1/16 - 12	94	69
1 3/16 - 12	110	82
1 5/16 - 12	150	110
1 5/8 - 12	195	140
Torque Requirements SAE O-ring (Boss) Fittings		
7/16 - 20	9	7
1/2 - 20	14	10
9/16 - 18	19	14
3/4 - 16	29	21
7/8 - 14	40	29
1 1/16 - 12	80	59
1 3/16 - 12	90	66
1 5/16 - 12	100	74
1 5/8 - 12	150	110
Torque Requirements O-ring Face Seal Fittings		
9/16 - 18	14	10
11/16 - 16	25	18
13/16 - 16	46	33
1 - 14	65	48
1 3/16 - 12	95	70
1 7/16 - 12	132	97
1 11/16 - 12	175	129
2 - 12	224	165

Index

3PT Hitch	3-128	Aftertreatment System Operation	3-180
3PT Hitch Control Panel	3-131, 2-83	Air Conditioner Dryer and Connections	5-58
3PT Hitch Overview	3-129	Air Intake Restriction	5-23
Adjusting the Stabilizers	3-145	Alternator	5-46
Adjust Lift Rods	3-142	Ammonia Oxidation Catalyst (AMOX)	3-181
Adjust Top Link	3-142	Attaching and Detaching Trailed Equipment	3-156
Category III Position	3-144	Attaching Equipment to the PTO Shaft	3-169
Category II or Category III Position	3-143	Automatic Hitch Pin	3-150
Enable 3PT Hitch	3-136	Auto Steer (option)	3-56
External raise/ lower switches	3-137	Axle Lengths	3-96
Fender-mounted 3PT Hitch Switches	3-135	Ballasting	3-114
Guide Blocks, Spacers and Shims	3-143	Adjust for Type of Load	3-124
Hook-end Hitch	3-144	Automatic Wheel Slip Monitor	3-119
Hydraulic Trailer Brake Coupling	3-147	Ballast Benefits and Limitations	3-116
Implement Hook-up	3-146	Ballasting Decisions	3-118
Linkage Category Conversion	3-144	Ballasting Front End for Transport	3-123
Rigid Position	3-143	Ballast Limitations	3-119
Stabilizers	3-145	Calculating Tire and Axle Loads	3-121
Sway Blocks	3-143	Checking Wheel Slippage	3-119
Swing Position	3-143	Determining Maximum Front Ballast	3-124
3PT Hitch Control Panel	3-130, 2-83	Estimating Ballast Requirements	3-120
250-hour inspection	5-56, 5-57, 5-61	Front Tires - Liquid Weight	3-126
Accessories	2-94	General Weight-Split Guidelines	3-117
Heated Mirrors	2-102	Installing Cast Iron Rear Wheel Weights	3-122
Power Mirrors (option)	2-102	Installing Front Weights	3-125
Radio Options	2-94	Integral and Semi-integral Implements	3-117
Accessory Drive Belt	5-30	Manual Wheel Slip Measurement	3-119
Accessory Drive Belt and Tensioner	5-77	Rear Tire Weighting	3-121
A/C Connections	5-58	Rear Wheel Cast Iron Weights	3-122
A/C Dryer	5-58	Selecting Ballast	3-117
A/C Connections	5-58	Static Weight Distribution	3-114
Air Conditioner Dryer and Connections	5-58	Tire and Ballast Factors	3-115
Active Fault Display	6-15	Total Weight	3-114
Adding Diesel Exhaust Fluid (DEF)	5-9	Towed Draft Implements	3-117
Adjusting Cast Center Wheel	3-102	Trailers and Towed Tanks	3-117
Adjusting Pressed Steel Wheel	3-102	Ballasting and Tires	3-114
Adjusting Rear Wheels	3-101	Adjust for Type of Load	3-124
Adjusting Speed	3-25	Automatic Wheel Slip Monitor	3-119
Adjusting Speed with the Foot Throttle	3-26	Ballast	3-114
Adjusting Speed with the Hand Throttle	3-25	Ballast Benefits and Limitations	3-116
Adjusting the Stabilizers	3-145	Ballasting Decisions	3-118
Adjust Lift Rods	3-142	Ballasting Front End for Transport	3-123
Adjust Steering Wheel Position	2-11	Ballast Limitations	3-119
Adjust Top Link	3-142	Calculating Tire and Axle Loads	3-121
Aftertreatment	3-180	Checking Wheel Slippage	3-119
Aftertreatment System Operation	3-180	Determining Maximum Front Ballast	3-124
(DEF) warning lamp	3-185, 3-186, 3-187, 3-188, 3-189, 3-190	Estimating Ballast Requirements	3-120
Forcing DPF Regeneration	3-194	Front Tires - Liquid Weight	3-126
Inhibiting DPF Regeneration	3-193	General Weight-Split Guidelines	3-117
Selective Catalytic Reduction (SCR)	3-181	Installing Cast Iron Rear Wheel Weights	3-122
		Installing Front Weights	3-125

-
- Integral and Semi-integral Implements3-117
 - Manual Wheel Slip Measurement3-119
 - Rear Tire Weighting3-121
 - Rear Wheel Cast Iron Weights3-122
 - Selecting Ballast3-117
 - Static Weight Distribution3-114
 - Tire and Ballast Factors3-115
 - Total Weight3-114
 - Towed Draft Implements3-117
 - Trailers and Towed Tanks3-117
 - Battery1-47, 5-59, 1-25, 5-13
 - Battery Box1-47, 5-13
 - Battery Disconnect Procedure5-68
 - Battery Safety1-25
 - Battery Safety Guide5-67
 - Battery Shut-off Switch1-47, 5-13
 - Check Batteries5-67
 - Check Battery Connections5-69
 - Check Condition of Battery5-59
 - Inspect the Electrical Cables at the Starter5-70
 - Install Batteries5-111
 - Power Off Indicator Light1-48
 - Remove Batteries5-111
 - Replace Batteries5-110
 - Battery Connections5-69
 - Battery Disconnect Procedure5-68
 - Battery Shut-off Switch1-47, 5-13
 - Brake Locking Plate2-14
 - Brakes Troubleshooting6-11
 - Brake System Overview4-6
 - Break-in Precautions5-5
 - Cab2-90, 3-11
 - Cab Air Filter5-78
 - Cab Air Vents2-91, 2-92
 - Clean Cab Floor5-113
 - Clean Cab Seat and Upholstery5-113
 - Console Light5-109
 - Interior Cab Lights3-54
 - Interior Dome Light2-93
 - Sun Blinds (option)2-93
 - Cab Accessory Panel2-90
 - Heating and Cooling Controls2-95, 2-96
 - Radio Options2-94
 - Cab Air Filter5-47, 5-78
 - Cab Air Vents2-91, 2-92
 - Cab/Roll-over Protection Structure (ROPS)1-43
 - Category III Position3-144
 - Category II or Category III Position3-143
 - Changing the Coolant5-91
 - Check and Charge the Batteries3-20
 - Check and Tighten Wheel Torques5-4
 - Checking Wheel Slippage3-119
 - Automatic Wheel Slip Monitor3-119
 - Manual Wheel Slip Measurement3-119
 - Clean Alternator5-46
 - Clean Cab Floor5-113
 - Clean Cab Seat and Upholstery5-113
 - Clean Tractor5-113
 - Cold Weather Starting3-17
 - Console Light5-109
 - Continuous Flow Hydraulic Equipment4-11
 - Coolant Mixture and Additives5-11
 - Cooler Package Access5-12
 - Cooling Package5-24
 - Cooling System5-94
 - Refilling the Cooling System5-94
 - Couplers4-9
 - Connecting and Adjusting Couplers4-9
 - Connecting Double-acting Cylinders4-10
 - Connecting Single-acting Cylinders4-10
 - Daily Service5-3
 - DEF Sensor and Change Filter5-89, 5-97
 - DEF Tank Cover and Hoses5-88, 5-96
 - Remove the DEF Tank Cover and Hoses5-88, 5-96
 - Diesel Exhaust Fluid (DEF)3-181, 3-182
 - DEF Tank Cover and Hoses5-88, 5-96
 - Diesel Exhaust Fluid (DEF) In-Tank Filter5-87, 5-20, 5-95
 - Diesel Exhaust Fluid (DEF) In-Tank Filter5-87, 5-20, 5-95
 - Diesel Exhaust Fluid Level5-36
 - Diesel Exhaust Fluid Tank3-181
 - Diesel Particulate Filter (DPF)5-100
 - Clean the Diesel Particulate Filter (DPF)5-100
 - Differential Lock2-25, 3-58
 - EIC - signal light2-25
 - TCS – Steering Angle and Speed Charts3-61
 - Differential Oil5-40, 5-19, 5-74
 - Differential Oil and Final Drive Oil Level5-40
 - dimensions7-2
 - general7-4
 - height - overall7-3
 - wheel tread width7-3
 - width - overall7-3
 - Disengaging the PTO3-160
 - Display Monitor4-21
 - Change Display Brightness3-69
 - Change Language3-69
 - Change Units of Measurement3-69
 - Fault Codes6-17
 - Operating the Hydraulic System4-13
 - Touch-based Operation2-63
 - DPF3-179
 - DPF Regeneration3-193

Foot Throttle	2-14	Adjusting Speed with the Hand Throttle	3-25
Inching Pedal	2-14	Hardware Torque Specifications	7-29
Left Wheel Foot Brake Pedal	2-14	Hazard Warning Lights	2-13, 3-53
Right Wheel Foot Brake Pedal	2-14	Headland Management System Panel	2-86
Foot Brakes	3-22	Heated Mirrors	2-102
Foot Throttle	2-14	Heating and Cooling Controls	2-95, 2-96
Front Axle	5-53	HMS	3-196
Change the Front Axle Differential Oil	5-19, 5-74	Horn	2-103, 1-41
Front Axle Grease Fitting Locations	5-53	Hub and Wheel Placement	3-92, 3-97, 3-98
Lubricate Front Axle Grease fittings	5-42	HVAC Troubleshooting	6-10
Lubricate the Front Axle Grease Points	5-53	Hydraulic Brake System	4-7
Front Axle Lubricants	7-18	Hydraulic Fitting Torque	7-31
Front Axle Serial Number	2-7	Hydraulic Levers	4-21
Front Axle Track Spacing	3-92	Continuous Flow Mode	4-23
Front Fenders (Suspended Axle)	3-105	Float Mode	4-22
Adjust Fender Height and Pitch	3-106	Neutral Mode	4-22
Adjusting Front Fenders (Suspended Axle)	3-105	Hydraulic Motor Application	4-12
Adjust the Distance between the Fender and the Side of the Tractor	3-107	Hydraulic Oil	5-85, 5-34, 5-43, 5-66
Fender Spacing Specifications	3-108	Hydraulic Oil Filters	4-4
Spacing Position A (480 mm Fender, Single Wheels)	3-109	Hydraulic System Overview	4-2
Spacing Position B (480 mm Fender, Single Wheels)	3-110	Brake System Overview	4-6
Spacing Position C (540 mm Fender, Single Wheels)	3-111	Filters	2-24
Spacing Position D (620 mm Fender, Single Wheels)	3-112	Hydraulic Brake System	4-7
Spacing Position E (620 mm Fender, Single Wheels)	3-113	Hydraulic Oil Filters	4-4
Front Grill	1-46	Low-pressure Hydraulic System	4-3
Front Planetary Hub Oil	5-75	Standard Flow Single Pump System Overview	4-3
Front Suspended Axle	3-63	Steering System Overview	4-5
Suspended Axle Dimensions	3-65, 7-5	Hydraulic System Troubleshooting	6-8
Front Tires - Liquid Weight	3-126	Hydraulic Trailer Brake Coupling	3-147
Front Weights	3-125	Implement Hook-up	3-146
Front Wheel Positions	3-93	Implement Valve Faults	6-16
Fuel Filter and Connections	5-31	Inching Pedal	2-14, 3-29
Fueling the Tractor	5-7	Inching Pedal: Calibration	3-29
Fuel Requirements	5-6	Inhibiting DPF Regeneration	3-193
Fuel Requirements	5-6	Initial Engine Startup (after storage)	5-113
Fuel Tanks	5-60	Inner Wheels	3-104
Drain the Fuel Tanks	5-60	Inspection Access	5-12
Fuel/Water Separator	5-35	Inspect the Turbocharger Connections	5-80
Fuse and Relay Panels	5-104	Install Batteries	5-111
Front Fuse and Relay Panel	5-108	Integral and Semi-integral Implements	3-117
Main Fuse and Relay Panel	5-104	Interior Cab Lights	3-54
Fuse and Relay Replacement	5-104	Interior Dome Light	2-93
General Dimensions	7-7	Jacking Points	3-214
General Weight Split Guidelines	3-117	Language and Units of Measurement	3-69
Guide Blocks, Spacers and Shims	3-143	Lights	3-50
Hand Throttle	2-78	Exterior Light Identification	3-51
		Exterior Worklights	3-51
		Extremity Lights	3-54
		Linkage Category Conversion	3-144
		Lubricate 3PT Hitch	5-41
		Lubricate Front Axle Grease fittings	5-42
		Lubrication and Maintenance Schedule	5-18

Master PTO Shield	1-50	PTO Shield	5-17
Maximum Tractor Operating Angle	7-7, 7-8, 7-9, 7-13, 7-14, 7-15, 7-20	PTO Troubleshooting	6-12
MFWD Front Axle Track Spacing	3-92	Radial Tire Identification	7-23
Adjusting Cast Center Wheel	3-102	Radiator and Heating System Hoses and Connections	5-82
Adjusting Pressed Steel Wheel	3-102	Radio Options	2-94
Adjusting Rear Wheels	3-101	Rear Wheel Track Adjustment	3-100
Adjusting Toe-in - Standard Steer MFWD	3-94	Rear Wheel Track Spacing	3-96
Dual Rear Wheels	3-103	Rear Windshield Washer/Wiper Switches	2-105
Front Wheel Positions	3-93	Removing the Drive Shaft Shield	5-16
MFWD Steering Stops	3-95	Replace Batteries	5-110
Outer Wheels	3-103	Rotary Beacon	2-107
Rear Wheel Track Adjustment	3-100	Rotary Beacon (option)	3-57
Rear Wheel Track Spacing	3-96	Safety	1-25
Wheel Toe-in	3-94	Battery Safety	1-25
Mirrors	2-102	Battery Safety Guide	5-67
Heated Mirrors	2-102	Cab Safety	1-14
Power Mirrors (option)	2-102	Electrical Safety	1-24
neutral lock	3-37	General Safety	1-13
Neutral Lock	2-80	Hydraulic System Safety	1-26
Operating the Hydraulic System	4-13	Maintenance and Storage Safety	1-23
Operator Console	2-75	Operating Safety	1-16
Hand Throttle	2-78	Precautionary Safety Statements	1-12
Operating the Hydraulic System	4-13	PTO Safety	1-20
operator seating	2-15	Welding Safety	1-27
Parking Brake	3-24	Safety Chain	3-155
Check and Adjust the Parking Brake	5-103	Safety Labels	1-29
Check Parking Brake	5-21	seat	2-15
Personal Safety	1-3	instructional	2-20
Planetary Hub Oil	5-75	seat belt	2-15
Front Planetary Hub Oil	5-75	standard	2-16
Power Mirrors (option)	2-102	seat belt	2-15
Power Off Indicator Light	1-48	Selective Catalytic Reduction (SCR)	3-181
Power Outlets	2-104	Shipping Weight	3-120
Power Take-off (PTO)	3-157, 3-158	Software	3-74
Changing the PTO Output Shaft [single speed (1000 rpm) system].	3-168	specifications	7-2
Fender-mounted PTO Switches	2-89	dimensions	7-2
PTO Controls	2-88, 3-159	Specifications	3-66
PTO Operation	3-170, 3-171	Front Axle Specifications	3-66
PTO Options	3-166	Speed	3-25
PTO Requirements	3-157	Adjusting Speed with the Foot Throttle	3-26
Prepare the Tractor For Storage	5-112	Stabilizers	3-145
Prepare the Tractor for Use After Storage	5-112	Adjusting the Stabilizers	3-145
Preventing System Contamination	3-10, 5-5	Standard Hardware Torque Specifications	7-29
Protective Shielding	1-45	Starter Cables	5-70
PTO	1-20	Starter Motor Protection Switch	3-15
PTO Safety	1-20	Starting the Tractor	3-15
PTO Controls	2-88, 3-159	Steering Angle Sensor	3-62
PTO Master Shield	3-167	Steering Column and Pedals	2-9
PTO Operation	3-170, 3-171	Adjust Steering Wheel Position	2-11
PTO Requirements	3-157	Horn	2-103
		Steering Stops	3-95

Steering System Overview	4-5	Towing Operations	3-154
Stop Adjustment	5-43	Traction and Ride Troubleshooting	6-14
Stopping in an Emergency	3-21	Tractor Boosting	3-18
Stopping the Tractor	3-21	Tractor Fault Codes	6-16
Store the Tractor	5-112	Engine and Aftertreatment Fault Codes	6-25
Sun Blinds	2-93	Implement Valve Faults	6-16
Suspended Axle	3-63	Transmission Fault Codes	6-28
Component Identification and Function	3-64	Tractor Fault Indicators	6-15
Front Axle Dimensions	3-65	Tractor Identification	2-5
Front Axle (Lockable Differential shown)	3-64	Engine Serial Numbers	2-6
Front Axle Lubricants	3-67	Front Axle Serial Number	2-7
Front Axle Specifications	3-66	Transmission Serial Number	2-8
Identification Plate	3-63	Tractor Orientation	2-3
Suspended Axle Dimensions	3-65, 7-5	Tractor Serial Number	2-5
Suspended Front Axle Dimensions	3-65	Tractor Specifications	7-7
Suspended Front Axle Lubricants	3-67	Tractor Start-up	3-14
Sway Blocks	3-143	Tractor Towing	3-212
Swinging Drawbar	3-149	Freeing a Mired Tractor	3-213
Swing Position	3-143	Jacking Points	3-214
TCS - Steering Angle and Speed Charts	3-61	Transporting the Tractor	3-215
temperature controls	2-95, 2-96	Trailers and Towed Tanks	3-117
Tire Clearance	3-104	Trailer Socket	3-76
Tire Data	7-23	Transmission	2-8, 2-24
Tire Maintenance Procedures	3-78	Oil Pressure	2-24
Tire Pressure and Condition	5-50	Oil Temperature	2-24
Tire Pressures and Permissible Loads	3-81	Transmission Fault Codes	6-28
tires	3-84	Transmission Oil Filters	2-24
compatibility and selection	3-85	Transmission Fault Codes	6-28
Tires	3-77, 3-127	Transmission Oil	5-34
Factors Determining Best Tire Performance	3-78	Check Hydraulic Oil Level for Transmission, Rear differential and Rear Axle Housings	5-34
Front Tires - Liquid Weight	3-126	Transmission Serial Number	2-8
Radial Tire Identification	3-79	Transmission Troubleshooting	6-5
Tire Clearance	3-104	Transporting the Tractor	3-215
Tire Combinations	3-79	Troubleshooting	6-2
Tire Maintenance Procedures	3-78	3PT Hitch Troubleshooting	6-13
Tire Pressures and Permissible Loads	3-79	Brakes Troubleshooting	6-11
Tire Selection	3-78	Electrical System Troubleshooting	6-6
Tire Selection	3-78	Engine Troubleshooting	6-2
Toe-In - Adjusting	3-94	HVAC Troubleshooting	6-10
torque values	7-28	Hydraulic System Troubleshooting	6-8
Torque Values – Hardware	7-29	PTO Troubleshooting	6-12
Torque Values – Hydraulic Fittings	7-31	Traction and Ride Troubleshooting	6-14
Towed Draft Implements	3-117	Transmission Troubleshooting	6-5
Towing Attachments and Drawbar Operation	3-148	Turbocharger Connections	5-80
Adjusting Drawbar Length	3-153	Unit of Measure Screen	2-58, 2-59, 2-60, 3-72, 3-73
Attaching and Detaching Trailed Equipment	3-156	Warning Lights	2-23
Automatic Hitch Pin	3-150	weight	7-6
Drawbar Height Adjustment	3-152	shipping	7-6
Drawbar Length	3-152	Weights and Weighting	3-120
Safety Chain	3-155	Front Tires - Liquid Weight	3-126
Swinging Drawbar	3-149		
Towing Operations	3-154		

Front Weights3-124
Installing Cast Iron Rear Wheel Weights3-122
Installing Front Weights3-125
Rear Tire Weighting3-121
Rear Wheel Cast Iron Weights3-122
Shipping Weights3-120
Weighing the Tractor3-120
Wheel Removal/Installation3-104
Wheels3-103
Adjusting Cast Center Wheel3-102
Adjusting Pressed Steel Wheel3-102
Adjusting Rear Wheels3-101
Inner Wheels3-104
Outer Wheels3-103
Rear Wheel Track Adjustment3-100
Wheel Removal/Installation3-104
Wheel Slippage3-119
Wheel Toe-In	3-94
Windshield Washer Fluid and Wiper Blades	.5-102
Windshield Wiper - Operation	3-55
Windshield Wipers2-106
Windshield Washer Fluid and Wiper Blades	.5-102

This Page Is Intentionally Left Blank.

First 50-hour Service (Check and adjust, as required)

Description	OK
Stationary Checks - Engine Off	
Tire pressures and condition	
Check radiator coolant level and specific gravity	
Level of DCA4 coolant additive	
Engine accessory drive belt(s)	
Check engine oil level	
Check transmission and rear final drive oil level	
Check hydraulic oil level	
Change transmission oil filter	
Change all hydraulic filters (charge, steering and power steering)	
Change front axle and final drive oil	
Drain fuel/water separator	
Battery, starter and alternator electrical connections	
Air cleaner element and hose connections	
Coolant lines and clamps	
Windshield wiper/operation and washer fluid level	
Wheel-to-rim hardware torque	
Wheel disc-to-hub hardware torque	
Front end weight clamp bolts for tightness	
Front wheel toe-in and steering stops	
Lubricate all grease fittings	
Seat for proper operation	
All electrical cables, terminals and wires	
Exhaust manifold bolt torque	
Clean cab air filter	
Inspect and tighten drawbar components	

Description	OK
Safety Items Checks	
Seat belt operation	
All safety decals and warnings are legible	
All safety shields installed	
Parking brake operation and adjustment	
Start switches operation (operator presence and parking brake)	
Cab mounting bolt torques (ROPS)	
Stationary Checks – Engine Running at Normal Operating Temperature	
Lights, instruments and controls for proper operation	
Fluid and oil leaks	
Air intake, turbocharger and cooler for air leaks	
PTO operation and braking	
Shift lever operation and EIC display	
Hydraulic System	
3-pt hitch – controls function	
Remote hydraulic – controls function	
Extend – retract – float modes function	
Remote valves – connection and flow correct	
Flow control operation	
Road Test Service Checks	
Engine operation including throttle	
Direction control + response (speed/slow down)	
Steering control	
Differential locks and MFWD engagement/disengagement	
Service brake operation	
All optional equipment and accessories	
Ballasting – correct weights installed and securely fastened	

Service Performed

Tractor Model No. _____

Print Name _____

Signature _____

Tractor Serial No. _____

Actual Engine Hours _____

Date _____



- U.S.A. : **KUBOTA TRACTOR CORPORATION**
1000 Kubota Drive, Grapevine, TX 76051
Telephone : 888-4KUBOTA
- Canada : **KUBOTA CANADA LTD.**
5900 14th Avenue, Markham, Ontario, L3S 4K4, Canada
Telephone : (905)294-7477
- France : **KUBOTA EUROPE S.A.S**
19-25, Rue Jules Verceyusse, Z.I. BP88, 95101 Argenteuil Cedex, France
Telephone : (33)1-3426-3434
- Italy : **KUBOTA EUROPE S.A.S Italy Branch**
Via Grandi, 29 20068 Peschiera Borrome (MI) Italy
Telephone : (39)02-51650377
- Germany : **KUBOTA (DEUTSCHLAND) GmbH**
Senefelder Str. 3-5 63110 Rodgau /Nieder-Roden, Germany
Telephone : (49)6106-873-0
- U.K. : **KUBOTA (U.K.) LTD.**
Dormer Road, Thame, Oxfordshire, OX9 3UN, U.K.
Telephone : (44)1844-214500
- Spain : **KUBOTA ESPAÑA S.A.**
Avenida Recomba No.5, Poligno Industrial la Laguna, Leganes, 28914 (Madrid) Spain
Telephone : (34)91-508-6442
- Australia : **KUBOTA AUSTRALIA PTY LTD.**
25-29 Permas Way, Truganina, VIC 3029, Australia
Telephone : (61)-3-9394-4400
- Malaysia : **SIME KUBOTA SDN. BHD.**
No.3 Jalan Sepadu 25/123 Taman Perindustrian Axis,
Seksyen 25, 40400 Shah Alam, Selangor Darul Ehsan Malaysia
Telephone : (60)3-736-1388
- Philippines: **KUBOTA PHILIPPINES, INC.**
232 Quirino Highway, Baesa, Quezon City 1106, Philippines
Telephone : (63)2-422-3500
- Taiwan : **SHIN TAIWAN AGRICULTURAL MACHINERY CO., LTD.**
16, Fengping 2nd Rd, Taliuo Shiang Kaohsiung 83107, Taiwan R.O.C.
Telephone : (886)7-702-2333
- Indonesia : **PT KUBOTA MACHINERY INDONESIA**
Tower A at EightyEight@Kasablanka Lantai 16
Jalan Raya Casablanka Kav. 88, Jakarta 12870 Indonesia
Telephone : (62)-21-29568-720
- Thailand : **SIAM KUBOTA CORPORATION CO., LTD.**
101/19-24 Moo 20, Navanakorn Industrial Estate, Tambon Khlongnueng, Amphur Khlongluang,
Pathumthani 12120, THAILAND
Telephone : (66)2-909-0300
- Korea : **KUBOTA KOREA CO., LTD.**
41-27, Jayumyeok-gil, Baeksan-myeon, Gimje-si, Jeollabuk-do, Korea
Telephone : (82)-63-544-5822
- India : **KUBOTA AGRICULTURAL MACHINERY INDIA PVT. LTD.**
No.15, Medavakkam Road, Sholinganallur, Chennai-600119, T.N., India
Telephone : (91)44-6104-1500
- Vietnam : **KUBOTA VIETNAM CO., LTD.**
Lot B-3A2-CN, My Phuoc 3 Industrial Park, Ben Cat District, Binh Duong Province, Vietnam
Telephone : (84)-650-3577-507

KUBOTA Corporation

English (U.S.A.)
Code No.LBT00-13934