




ZIP™ Shutter

For use with Dymax
EC & PC Flood Lamps
User Guide





About Dymax

UV/Visible light-curable adhesives. Systems for light curing, fluid dispensing, and fluid packaging.

Dymax manufactures industrial, light-curable, epoxy, and activator-cured adhesives. We also manufacture a complete line of manual fluid dispensing systems, automatic fluid dispensing systems, and light-curing systems. Light-curing systems include LED light sources, spot, flood, and conveyor systems designed for compatibility and high performance with Dymax adhesives.

Dymax adhesives and light-curing systems optimize the speed of automated assembly, allow for 100% in-line inspection, and increase throughput. System designs enable stand-alone configuration or integration into your existing assembly line.

Please note that most dispensing and curing system applications are unique. Dymax does not warrant the fitness of the product for the intended application. Any warranty applicable to the product, its application, and use is strictly limited to that contained in the Dymax standard Conditions of Sale. Dymax recommends that any intended application be evaluated and tested by the user to ensure that desired performance criteria are satisfied. Dymax is willing to assist users in their performance testing and evaluation by offering equipment trial rental and leasing programs to assist in such testing and evaluations. Data sheets are available for valve controllers or pressure pots upon request.

Contents

Introduction.....	4
Where to Get Help.....	4
Safety.....	4
General Safety Considerations.....	4
Specific Safety Considerations.....	5
Product Overview	5
Description of the Dymax ZIP Shutter	5
System Components.....	5
Assembly and Setup.....	6
Unpacking and Inspecting Your Shipment.....	6
Parts Included in the ZIP Shutter (PN 37863)	6
Assembly	7
Electrical Interconnect	9
Operation	9
Maintenance.....	10
Check and Adjust Curtain Drive-Belt Tension	10
Curtain Assembly Replacement	10
Troubleshooting	12
Spare Parts and Accessories.....	12
Specifications	13
Definition of Terms	14
Warranty	15
Index	15

Introduction

This guide describes how to assemble, use, and maintain the Dymax ZIP™ Shutter safely and efficiently.

Intended Audience

Dymax prepared this user guide for experienced process engineers, technicians, and manufacturing personnel. If you are new to UV light curing and do not understand the instructions, contact Dymax Application Engineering to answer your questions before using the equipment.

Where to Get Help

Dymax Customer Support and Application Engineering teams are available in the United States, Monday through Friday, from 8:00 a.m. to 5:30 p.m. Eastern Standard Time. You can also email Dymax at info@dymax.com. Contact information for additional Dymax locations can be found on the back cover of this user guide.

Additional resources are available to ensure a trouble-free experience with our products:

- Detailed product information on www.dymax.com
- Dymax adhesive Product Data Sheets (PDS) on our website
- Material Safety Data Sheets (SDS) provided with shipments of Dymax adhesives

Safety



WARNING! *If you use a Dymax shutter without first reading and understanding the information in this user guide, injury can result from exposure to high-intensity light. To reduce the risk of injury, read and ensure you understand the information in this user guide before assembling and operating a Dymax shutter in a UV flood lamp system.*

General Safety Considerations

All users of Dymax equipment should read and understand this user guide before assembling and using the equipment.

To learn about the safe handling and use of light-curable formulations, obtain and read the SDS for each product. Dymax includes an SDS with each adhesive sold. In addition, fluid product SDS can be requested through our website.

Specific Safety Considerations

Dymax shutters are designed to maximize operator safety and minimize exposure to UV light. To use the shutter safely, it must be set up and operated in accordance with the instructions in this user guide. Please also read and understand the following safety considerations.



WARNINGS! *To prevent eye injury, always wear protective goggles when working near a UV light-curing system.*

Long-sleeved shirts or a lab coat are recommended to protect the arms and use of UV opaque gloves will protect the hands from UV exposure.

Product Overview

Description of the Dymax ZIP Shutter

The Dymax ZIP Shutter was developed as an auxiliary device to control the dose of curing energy directed onto adhesives in a flood-lamp curing system. The Dymax ZIP Shutter is compatible with most Dymax EC- and PC- series flood lamps. The shutter can be used as an integral part of the Dymax light shield and can be used with other Dymax flood lamps (Blue Series) with the appropriate adapters.

Dymax flood lamps use a medium-pressure arc bulb as a source of curing energy. The bulb requires a few minutes to warm up after ignition before it reaches a steady state and needs a few minutes to cool before being able to re-ignite after being turned off. Repeatedly turning the power to the bulb off and on negatively affects its lifetime. With a Dymax shutter installed, the flood lamp may stay on continuously. Objects needing curing may be loaded and unloaded from underneath the shutter when it is closed without exposing parts or operators to UV light. In addition, control of curing times can be achieved by timed shutter operation.

Dymax flood lamp systems are used for a wide variety of applications where a relatively large area of illumination is needed. These applications may be cured using one of two types of systems: the first is with continuous illumination in conveyORIZED curing systems where the dose is defined by the conveyor belt speed. The second type uses a free-standing flood lamp where accurate timing is required. In the second type, the shutter can ensure the proper dose.

System Components

Clear Aperture - The ZIP Shutter has a clear aperture; therefore there is no distraction of the light flow when the shutter is open.

Timer - The operator sets the shutter's "open time" using the timer. The digital potentiometer is coupled with an electronic timer (inside the front panel) which in turn operates the gear-motor located inside the front control panel. The shutter's "open time" can be set from 1 to 99 seconds.

Actuate Button - Depressing the actuate button activates the gear-motor. The unit can also be actuated by foot switch that plugs into the foot switch connection on top of the rear panel.


Mode Selector Rocker Switch - There are two operation modes available: manual and timed. The mode selector rocker switch is used to select the mode of operation.

Mounting Plates/Adapter Plates - The ZIP Shutter includes two mounting plates for various reflector housings. The first has a clear aperture of 5" x 5" and should be used with the 5000-EC or PC Lamp. The second has a clear aperture of 8" x 8" for use with a 2000-EC or PC lamp.

Reflector Cable Connection - The power (24V) to the ZIP Shutter comes directly from the flood lamp's power supply, which is connected through this receptacle on top of the shutter's rear panel.

Belt Tension Adjustment Screw – Used to tighten the curtain drive belt.

Figure 1.
ZIP Shutter (PN 37863) Components



Assembly and Setup

Unpacking and Inspecting Your Shipment

When your shutter arrives, inspect any boxes for damage and notify the shipper immediately of box damage.


Open each box and check for equipment damage. If parts are damaged, notify the shipper and submit a claim for the damaged parts. Contact Dymax so that new parts can be shipped to you immediately.

Check that the parts included in your order match those listed below. If parts are missing, contact your local Dymax representative or Dymax Customer Support to resolve the problem.

Parts Included in the ZIP Shutter (PN 37863)

- ZIP Shutter (1)
- Mounting Plates for the EC or PC Series Flood Lamps (3)
- Screws – 8-32 x 3/8" (4), 6-32 x 1/4" (2), 8-32 x 1/4" (Not Shown)
- Top Fan Assembly for the 2000 Flood Lamp (5)
- Hex Wrenches– 3/32", 5/64", & 1/8" (6)
- Dymax ZIP Shutter User Guide (7)
- Interconnect Cable, Shutter to Reflector (8)
- Foot Switch (9)
- Adapter Plug (Not Shown)

Figure 2.
ZIP Shutter Unpacking Diagram



Assembly

NOTE: Setup of the EC- or PC-series flood lamps are covered in the flood lamp user guides. Refer to MAN007 – EC-Series Flood Lamp User Guide or MAN006 – PC-Series Flood Lamp User Guide.

5000-EC/PC Flood Lamp

1. Remove the Adapter Plate from the ZIP Shutter by removing the four 8-32 x $\frac{3}{8}$ " screws (Figure 3 & Figure 4).

Figure 3.
Remove 4 Screws from ZIP Shutter



Figure 4.
Adapter Plate Removed



2. Install the Adapter Plate on the base of the 5000-EC/PC Lamp Housing by removing the four 8-32 x $\frac{1}{4}$ " screws and attaching the plate to the Lamp Housing with four new 8-32 x $\frac{3}{8}$ " screws (Figure 5).
3. Install the Lamp Housing Assembly into the ZIP Shutter and attach it with four 8-32 x $\frac{3}{8}$ " screws (Figure 6).

Figure 5.
ZIP Shutter with Adapter Plate Installed




Figure 6.
5000-EC Flood Lamp Assembly Installed
on a ZIP Shutter



2000-EC/PC Flood Lamps

1. Remove the Adapter Plate from the ZIP Shutter by removing the four 8-32 x 3/8" screws (Figure 7).

Figure 7.
ZIP Shutter



Figure 8.
Adapter Plate Removed



2. Install the two Mounting Plates (Figure 9) on the base of the 2000 EC/PC Lamp Housing by removing the four 6-32 x 1/2" screws and attaching the Mounting Plates to the Lamp Housing by reinstalling the screws (Figure 10).
3. Install the assembly into the Shutter and attach it with four 8-32 x 3/8" screws.

Figure 9.
Mounting Plates



Figure 10.
Bottom of Lamp Housing with
Plates Installed





Figure 11.
2000-EC Lamp Housing Assembly
Installed into ZIP Shutter



Electrical Interconnect

Figure 12.
ZIP Shutter Electrical Interconnect Diagram



1. Connect Shielded Cable (4) from J2 on rear of Power Supply (2) to J3 on rear of Reflector Housing (3).
2. Connect Cable (5) from J4 on rear of Reflector (3) to 8-Pin Connector on rear of Shutter (1).
3. Connect Plug (6) into J5 on rear of Reflector (3).
NOTE: Shutter will not operate unless Plug is installed.
4. Install Foot Switch to 4-Pin Connector on rear of Shutter (7).
5. Connect Power Cord to J1 on rear of Power Supply (2).

Dymax Flood Lamp Electrical Interconnect with Retrofit

To retrofit Shutters for use with older Dymax "Blue Series" Flood Lamps, please contact the Dymax Application Engineering or Equipment Group.

Operation

1. Have the ZIP Shutter in the closed position.
2. Open the Access Door to the Workstation or Dymax Light Shield and place the object to be cured on the work surface (preferably in line with the center of the Shutter).

NOTE: The ZIP Shutter will close automatically if the Light Shield has an Interlock Kit (PN 41166) installed and the Access Door is opened.

3. Adjust the distance from the bottom plane of the ZIP Shutter to the surface to be cured.
4. Close the Access Door.
5. Set the exposure (ZIP Shutter "Open Time") by adjusting +/- the Timer located next to the Actuate Button on the Front Panel.
6. Open the ZIP Shutter using the most convenient method for you by using Push Actuator Button or Foot Switch.


NOTE: The ZIP Shutter will close automatically in the timed mode or it will stay open until you release the Foot Switch or Actuate Button in the manual mode.

7. Close the ZIP Shutter to end the cycle.

Maintenance

Check and Adjust Curtain Drive-Belt Tension

Figure 13.
Belt Tension Adjustment



Dymax recommends that the ZIP Shutter's Curtain Drive-Belt's tension be checked at least once every three months. Follow the instructions below to check the Curtain Drive-Belt's tension.

1. Turn off and disconnect the Lamp Reflector Housing from the external AC source.
2. Remove the *ZIP Shutter* from the Flood Lamp Reflector Housing and place it on the bench, bottom-side up.
3. Remove the screws that attach the ZIP Shutter's bottom panel.
4. Very lightly press in the center of the Curtain Drive Belt with a finger; the Belt should deflect no more than $\frac{1}{4}$ " to $\frac{3}{8}$ ".
5. If deflection exceeds this value, tighten the Curtain Drive Belt by adjusting the Tension Screw in the back of the *ZIP Shutter*.

NOTE: Make sure that both belts are tightened equally.

6. Replace the bottom cover and secure it with its screws.
7. Place the ZIP Shutter back on the Flood Lamp Reflector Housing and re-position it.
8. Reconnect the cables and plug the AC cord into wall socket.


Curtain Assembly Replacement

Dymax recommends that you check the ZIP Shutter curtain for wear each time you change the lamp. If it shows any signs of wear, replace it. Additional curtain assembly replacements can be purchased through Dymax Customer Service.



CAUTION! SHARP EDGES! The edge of the stainless-steel curtain is extremely sharp. To prevent injuries, always wear gloves that are resistant to cuts when handling or installing equipment. We recommend, at a minimum, CE Cut Level 5 gloves (included with kit).

Figure 14.
ZIP™ Curtain Assembly Diagram



#	Description
1	Curtain
2	Roller Bar
3	Screws (5)
4	Side Screws (2)
5	Clamp Bar
6	Belts
7	Roller and Pulley
8	Limit Switch
9	Limit Switch Standoff
10	Belt Tension
11	Belt Drive Motor

1. Remove the Flood Lamp Reflector Assembly from the ZIP Shutter and flip the Shutter onto its top.
2. Remove the bottom cover of the ZIP Shutter to expose the inside Roller (7) and Belt Drive Motor. Depending on which revision level your Shutter is, there will be either six screws or twenty-six screws.
3. Manually unroll the Curtain (1) until it reaches Front Limit Switch (8).
4. Loosen the Belt (6) tension by unscrewing the rear screws.
5. Remove the old Curtain (1) by removing the five screws (3) on the Roller (7) and loosening the two Side Screws (4) on the Clamp Bar (5) and slide curtain off Belts (6).
6. Attach the new Curtain (1) to the Roller (7) and Roller Bar (2) with the 6-32 screw (3) previously removed from the Roller.
7. Stretch the new Curtain (1) toward front of ZIP Shutter.
8. Slide the Clamp Bar (5) onto the Belt (6) where Curtain is fully outstretched. The Curtain should be stretched short of front Limit Switch (8).
9. Tighten the end screws 4-40 (4).
10. Manually roll-up the Curtain until the Curtain reaches rear Limit Switch (8). If the Clamp Bar (5) bows, loosen the screws (4) and allow the Clamp Bar to find its natural straightness and retighten.
11. Replace the ZIP Shutter's bottom cover.
12. Set-up the ZIP Shutter according to the ZIP Shutter directions. Tighten the Belt Tension (10) as needed to improve Belt performance.

Troubleshooting

CAUTION: Only qualified maintenance personnel should attempt the following procedures.

Problem	Possible Cause	Testing	Corrective Action
The shutter curtain does not open or close smoothly	One of the tension screws is not tight enough	All functions of the ZIP Shutter operate properly	Adjust the curtain tension.
The shutter's motor continuously runs	One of the Limit Switches is not engaging properly	All functions of the ZIP Shutter operate properly	Adjust the micro-switch activating blade.
The shutter will not operate	No power at the shutter	Verify the supply voltage being delivered to the shutter. Test the voltage at pins 1 & 2 of the 8-pin connector (24 VDC)	Check and replace wiring If light source is operational and ZIP Shutter is not. If a problem occurs within the light source, consult manual.
	The plug (38317 or 38318) is not installed in J5 of the reflector housing	All functions of the ZIP Shutter operate properly	Install the plug as described in the installation instructions.


Spare Parts and Accessories

Item	Part Number
Replacement Parts	
Clutch	39396
Stainless Steel Curtain Assembly	41097
Motor	39395
Relay	37789
Timer Board, 0-99 Seconds	40315
Cables, Foot Switches, & Plugs	
Cable, Reflector Housing to Shutter, EC/PC Series	40879
Standard Foot Switch	36051
Foot Switch with Extended Cable	38992
Standard Adapter Plug	41068

Specifications

Property	Specification
Part Numbers	37863 ZIP Shutter for EC- and PC-Series Flood Lamps
Operating Voltage	24 VDC (Supplied by the Dymax EC or PC Power Supply)
Exposure Time	Digital Setting - From 1 to 99 Seconds (1 second increments)
Aperture	8" x 8" [20.3 cm x 20.3 cm]
Operation Modes	Timed/Manual
Accuracy & Repeatability	For settings below 30 seconds (± 1 second) For settings above 30 seconds (± 2 seconds)
Dimensions	12.5" x 12.9" x 3.8" [31.8 cm x 32.8 cm x 9.7 cm]
Weight	5.8 lbs [2.6 kg]

Figure 15.
ZIP Shutter Dimensions



Definition of Terms

UV-Curing Light Source - a reflector housing and a power supply furnished with an appropriate bulb (burner) for generating light energy of required spectra and intensity.

Flood Lamp System - a set of components arranged to generate, collect, condition and direct UV radiant energy to perform curing of engineering adhesives, coatings, and inks in a safe and controlled process. It includes a lamp housing and power supply and may also include a shutter, workstation, UV enclosure, Dymax light shield, and accessories.

Lamp - light source (bulb or burner) generating Ultraviolet, Visible, or Infrared radiant energy from burning matter stimulated by electrical power. A bulb or burner is usually placed into a reflector to increase light source efficiency by collecting and directing radiant energy of selected spectra for a specific curing process.

Intensity - a measure of light energy over the unit of surface area (usually at a specified working distance from the bottom of the reflector housing) in W/cm^2 or mW/cm^2 . For the UV portion of light, this measure is often called in literature “irradiance”, i.e. radiant energy arriving at a point on a surface per unit area.

Brightness, also known as Luminance - description of energy in the visible region of the spectrum (approximately from 400 to 700 nm) and recorded in photometric units. “**Intensity**” (see below) of visible light energy is called luminance.

Luminance - luminous flux (energy of visible light) incident per unit area and measured in **Lx** (lux) or **Lumen/cm²**.

Ultraviolet (UV) - the invisible region of the spectrum just beyond the violet end of the visible region. UV is divided into three spectral parts:

1. **Ultraviolet A (UV-A)** - UV of long wavelength from within approximately 400 to 320 nm of the spectral band (4000 to 3200 $\oplus$) - predominately produced by Dymax Flood Lamps.
2. **Ultraviolet B (UV-B)** - UV of medium wavelength from within approximately 320 to 280 nm - Dymax Flood Lamps produce some amount of their energy within this bandwidth.
3. **Ultraviolet C (UV-C)** - UV of short wavelength below 280 nm (we say from 280 to 200 nm) – a large amount of this energy is present in the sunlight.

Dose - is irradiance integrated over time, or Irradiance (W/cm^2) x Time (s) = Dose (Joules/cm²). Note: Watt is the power that gives rise to the production of energy at the rate of 1-joule (J) per second (s).

As irradiance can be a far more significant factor in the efficiency of curing adhesives and other UV curable materials, the dose and spectral response can also be substantial contributors to the quality cure performance.

OSHA 1910.145: “Regulation of Accident prevention Signs and Tags” defines the following headers as:

- **WARNING** – is used when there is a hazardous situation that has some probability of severe injury.
- **CAUTION** - is used to indicate a hazardous situation that may result in minor or moderate injury.
- **NOTICE** - is used to convey a message related directly or indirectly to the safety of personnel, or protection of property.

Warranty

From date of purchase, Dymax Corporation offers a one-year warranty against defects in material and workmanship on all system components with proof of purchase and purchase date. Unauthorized repair, modification, or improper use of equipment may void your warranty benefits. The use of aftermarket replacement parts not supplied or approved by Dymax Corporation, will void any effective warranties and may result in damage to the equipment.

IMPORTANT NOTE: DYMAX CORPORATION RESERVES THE RIGHT TO INVALIDATE ANY WARRANTIES, EXPRESSED OR IMPLIED, DUE TO ANY REPAIRS PERFORMED OR ATTEMPTED ON DYMAX EQUIPMENT WITHOUT WRITTEN AUTHORIZATION FROM DYMAX. THOSE CORRECTIVE ACTIONS LISTED ABOVE ARE LIMITED TO THIS AUTHORIZATION.

Index

Adjust Curtain Drive Belt Tension	10
Assembly and Setup	6
Contact Information	4
Definition of Terms	14
Glossary	14
Help	4
Maintenance	10
Operation	9
Parts Included	6
Product Overview	5
Safety	4
Spare Parts and Accessories	12
Specifications	13
Support	4
Troubleshooting	12
Unpacking	6
Warranty	15
Zip Shutter Curtain Replacement	10

