



## FORNO COMMERCIAL 24" and 36" GAS RANGE OVEN

FCMGR0093-24(4 BURNER TOP) FCMGR0093-36(6 BURNER TOP)





ANSI Z83.11 • CSA 1.8-(2016) Food Service Equip. Conforms to ANSI STD Z83.11-2016 Certified to CSA STD 1.8-2016 Food Service Equip. CONFORMS TO NSF/ANSI 4:2020

# **INSTRUCTION MANUAL**

Read these instructions carefully before using your appliance, and keep it carefully. If you follow the instructions, your appliance will provide you with many years of good service.

# **TABLE OF CONTENTS**

Customer Care	4
Important For Your Safety	5
Installation, Operation and Care	6
Troubleshooting Guide	15
Limited Warranty	16
Conversion Kit Instructions	17
Warranty	20

# FORNO COMMERCIAL 24" and 36" GAS RANGE OVEN,4-BURNER TOP



#### **Customer Care**

Thank you for purchasing a Forno product. Please read the entire instruction manual before operating your new appliance for the first time. Whether you are an occasional user or an expert, it will be beneficial to familiarize yourself with the safety practices, features, operation and care recommendations of your appliance.

Both the model and serial number are listed inside the product. For warranty purposes, you will also need the date of purchase .

Record this information below for future reference.

Product Information  Model Number :	Service Information
Serial Number :	
!	!
I I	 
1	1
1	i
1	
i	l
Date of Purchase :	
Purchase Address And Phone:	

#### Service Information

Use these numbers in any correspondence or services calls concerning your product.

If you received a damaged product, immediately contact Forno.

To save time and money, before you call for serviced, check the troubleshooting guide. It listed the causes of minor operation problems that you can correct yourself.



"Need some quick help? Simply scan the qr code and get access to our fast support form. We're always here to assist you with any questions or concerns you may have. So, don't hesitate to reach out!"

#### **Services in Canada and Untied States**

Keep the instruction manual handy to answer your questions. If you don't understand something or need more assistance, please visit our website for fast support. Please provide us your name, number, address, serial number of the product that troubleshooting, proof of purchase, and a short description of the issue. A customer service representative will contact you as soon as possible. All warranty work needs to be authorized by FORNO customer service. All our authorized service providers are carefully selected and rigorously trained by us.

# IMPORTANT FOR YOUR SAFETY

THIS MANUAL HAS BEEN PREPARED FOR PERSONNEL QUALIFIED TO INSTALL GAS EQUIPMENT, WHO SHOULD PERFORM THE INITIAL FIELD START-UP AND ADJUSTMENTS OF THE EQUIPMENT COVERED BY THIS MANUAL.

POST IN A PROMINENT LOCATION THE INSTRUCTIONS TO BE FOLLOWED IN THE EVENT THE SMELL OF GAS IS DETECTED. THIS INFORMATION CAN BE OBTAINED FROM THE LOCAL GAS SUPPLIER.

#### NOTICE

IN THE EVENT A GAS ODOR IS DETECTED. SHUTDOWN UNITS AT MAIN SHUTOFF VALVE ANDCONTACT THE LOCAL GAS COMPANY OR GASSUPPLIER FOR SERVICE.

# Installation, Operation and Care: PLEASE KEEP THIS MANUAL FOR FUTURE REFERENCE GENERAL

Ranges are produced with quality workmanship and material. Proper installation, usage and maintenance of your range will result in many years of satisfactory performance.

Suggests that you thoroughly read this entire manual and carefully follow all of the instructions provided.



THIS APPLIANCE IS EQUIPPED FOR NATURAL GAS.

for conversion to LP gas please see gas conversion instruction manual attached. Orifices necessary for LP (propane) (natural) conversion are provided. Please refer to page 3 the orifice size list when you do gas conversion

#### INSTALLATION

#### **UNCRATING**

This range was inspected before leaving the factory. The transportation company assumes full responsibility for safe delivery upon acceptance of the shipment. Immediately after unpacking, check for possible shipping damage. If the range is found to be damaged, save the packaging material and contact the carrier within 15 days of delivery.

Uncrate unit carefully and place in a work-accessible area as near to its final installed position as possible. Remove all shipping wire and wood blocking.

Before installing, check the type of gas supply (natural or propane) to make sure they agree with the specifications on the rating plate located on the inside of the lower kick panel. If the supply and equipment requirements do not agree, do not proceed with the installation. Contact your dealer or company immediately.

#### **LOCATION**

The appliance must be installed under a ventilation hood.

The equipment area must be kept free and clear of combustible substances.

The range, when installed, must have a minimum clearance from combustible construction of 12" (304 mm) at the sides and 10" (253 mm) at the rear. Clearance from non-combustible construction is 0" at the sides and 6" (152 mm) at the rear.

The installation location must allow adequate clearances for servicing and proper operation. A minimum front clearance of 40" (1016 mm) is required.

The range must be installed so that the flow of combustion and ventilation air will not be obstructed. Adequate clearance for air openings into the combustion chamber must be provided. Make sure there is an adequate supply of air in the room to allow for combustion of the gas at the burners.

For adapt to the ground level, should be adjust four foot.

#### **INSTALLATION CODES AND STANDARDS**

Ranges must be installed in accordance with:

#### In the United States of America:

1.State and local codes.

2.National Fuel Gas Code, ANSI/Z223.1 (latest edition). Copies may be obtained from The American Gas Association, Inc., 1515 Wilson Blvd., Arlington, VA22209.

#### In Canada:

1.Local codes.

2.CSA B149.1 Natural Gas and Propane Installation Code.

3.CSA C22.1 Canadian Electric Code.

4.CSA C22.2 Canadian Electric Code.

The above are available from the Canadian Standard Association, 5060 Spectrum Way, Suite 100, Mississauga, Ontario, Canada L4W 5N6.


#### Backsplash

No.	Accessory	Q'TY	Fig
1	Top shelf plate	1	
2	Backsplash assemly	1	
3	Backsplash column support	2	
4	FCMGR0093-36 screw	30	
5	FCMGR0093-24 screw	10	

No.	Accessory	Q'TY	Fig
6	FCMGR0093-24 Top burner orifice	4	
7	FCMGR0093-36 Top burner orifice	6	
8	Oven orifice	1	
9	Oven pilot orifice	1	
10	Regulators	1	<b>②</b>


The standard Restaurant Range is equipped with a 23" (584 mm) high backsplash and shelf.

- 1.Remove the backsplash components from the crating materials.
- 2. Assemble the required components as shown.




3. Tighten the four screws to secure the shelf.






4 Lift the assembly up, sliding the channels into the space provided at the rear of the range.



5.Install four #10 sheet metal screws (2 to each channel leg)




#### **LEVELING**

Check the leveling of the range. Place a level inside the oven cavity across the oven rack(s). Level front-to-back and side-to-side.

To adjust the leveling, tilt the range to one side and, using channel locks, unscrew the adjustable leg insert as required. Repeat this procedure as necessary for each leg.

Optional casters for this range are of the non-adjustable type. Therefore, the floor must be level. If floor surface is not level, the range will experience cooking problems.



#### GAS CONNECTIONS

CAUTION: All gas supply connections and any pipe joint compound used must be resistant to the action of propane gases.

Each range is factory-equipped for the type gas specified on the rating plate. The installation gas connection is a 3/4" (19 mm) 14 FPT ANSI schedule #40 standard pipe. Connect gas supply. Make sure the pipes are clean and free of obstructions. Codes require that a gas shutoff valve be installed in the gas line ahead of the range. Standard ranges are equipped with fixed burner orifices which coincide with installation elevation. Install the gas pressure regulator.

Before installing, ensure that regulator supplied agrees with rating plate gas supply. The gas pressure regulator is NOT factory installed. The regulator for this gas type is sealed within a plastic bag attached to the oven rack inside the oven cavity. This regulator must be field installed by a qualified installer.

Natural gas regulators are preset for 5" W.C. (Water Column) (.99 kPa); propane gas regulators for 10.0" W.C. (2.5 kPa)

- 1.Locate 3/4" (19 mm) gas connection pipe extending from rear of range.
- 2. Cover pipe threads with leak sealant.
- 3. Screw regulator hand-tight onto pipe with regulator arrow pointing towards range body back.
- 4. Using pipe wrench, tighten regulator securely in an upright position.

The arrow on the regulator shows the direction of the gas flow. The pressure regulator must be mounted horizontally to ensure proper preset outlet pressure. If the regulator is installed in any other position, the outlet pressure must be reset for proper operation.

A leak limiter is supplied with every regulator to allow excess gas pressure to escape. Do not obstruct leak limiter on gas pressure regulator, as obstruction may cause regulator to malfunction.

WARNING: PRIOR TO LIGHTING, CHECK ALL JOINTS IN THE GAS SUPPLY LINE FOR LEAKS. USE SOAP AND WATER SOLUTION. DO NOT USE AN OPEN FLAME.

After piping has been checked for leaks, all piping receiving gas should be fully purged to remove air. Before operation, verify thermocouple is securely seated in the safety valve. The thermocouple should be tightened a 1/4 turn past finger tight. DO NOT OVERTIGHTEN. Over-tightening may damage the thermocouple or safety magnet.

#### TESTING THE GAS SUPPLY SYSTEM

When gas supply pressure exceeds 1/2 psig (3.45 kPa), the range and its individual shutoff valve must be disconnected from the gas supply piping system.

When gas supply pressure is 1/2 psig(3.45kPa) or less, the range should be isolated from the gas supply system by closing its individual manual shutoff valve until the range is ready for start-up.



This product can expose you to chemicals including [Lead & Lead Compounds], which is [are] known to the State of California to cause cancer, birth defects and / or reproductive harm. To minimize exposure to these substances. Always operate this unit according the Owner's Manual, and ensure that you provide proper ventilation. For more information go to www.P65Warnings.ca.gov

**FLUE CONNECTIONS DO NOT** obstruct the flow of flue gases from the flue located on the rear of the range. It is recommended that the flue gases be ventilated to the outside of the building through a ventilation system installed by qualified personnel.

From the termination of the flue to the filters of the hood venting system, a minimum clearance of 18" (457 mm) must be maintained.

Information on the construction and installation of ventilating hoods may be obtained from the standard for the "Removal of Vapors from Commercial Cooking Equipment", NFPA No. 96 (latest edition), available from The National Fire Protection Association, Batterymarch Park, Quincy, MA 02269.

#### **OPERATION**

**WARNING:** THE RANGE AND ITS PARTS ARE HOT. BE VERY CAREFUL WHEN OPERATING, CLEANING OR SERVICING THE RANGE.

#### LIGHTING AND SHUTTING DOWN PILOTS

All adjustment procedures associated with pilot lighting must be performed by an authorized vender installation or service person.

#### **INSTALLATION CODES AND STANDARDS**


- 1.Turn main gas supply ON.
- 2. Wait 30 seconds and, using a taper, light the open top pilot
- 3.If pilot fails to light, turn main gas supply OFF. Wait 5 minutes and repeat the above procedures.
- 4. Turn one open top burner valve ON to remove air from the gas line. Turn burner OFF when gas begins to flow.

#### **INSTALLATION CODES AND STANDARDS**

Turn burner valve OFF; pilot will remain lit.

#### **Complete Shutdown**

- 1. Turn burner valve OFF; pilot will remain lit.
- 2. Turn main gas supply OFF.



#### **GRIDDLE** (optional models)

- 1. Turn main gas supply ON. Wait 30 seconds and, using a taper, light broiler/griddle pilot.
- 2.If pilot fails to light, turn main gas supply OFF. Wait 5 minutes and repeat Steps 1 and 2.
- 3. Turn burner valve ON to purge air from the lines. Turn burner valve OFF when gas begins to flow.

#### **Nightly Shutdown**


1. Turn burner valve OFF; pilot will remain lit.

#### **Complete Shutdown**

- 1.Turn burner valve OFF; pilot will remain lit.
- 2.Turn main gas supply OFF.

# STANDARD OVEN LIGHTING AND SHUTDOWN INSTRUCTIONS NOTE: Light open top/griddle pilots before lighting oven pilot.

- 1. Turn thermostat to the "OFF" POSITION.
- 2. Rotate bottom tick-plate, expose the ignition hole.
- 3. Depress down the knob and rotate about 15° anti-clockwise, Ignite the pilot flame with fire gun via the ignition hole.
- 4. After the pilot flame is ignited, press the knob for more than 20 seconds to heat up the thermocouple. If the ignition is out when you loosen the knob, repeat this operation.
- 5. Keep rotating the temperature control knob counterclockwise to ignite the main burner of the oven.
- 6. Select appropriate temperature according to food requirement. The oven temperature can be controlled between 250F and 500F.




#### **Nightly Shutdown**

1.Turn oven thermostat OFF.

#### **Complete Shutdown**

- 1.Turn oven thermostat OFF.
- 2.Turn main gas supply OFF.



#### **RACK ARRANGEMENT -STANDARD OVEN**

The standard oven has three rack positions and is supplied with one two oven racks. Additional racks may be obtained through a vender parts depot.

#### Installation, Operation and Care(continued)

#### INSERTING AND REMOVING RACK

The oven rack has a stop to keep the rack from being pulled all the way out when unloading product. To install rack, place rack alongside of top of side liner runners and slide rack completely to the rear of the oven compartment until rack drops into place

To remove rack, reverse the procedure above by raising rear of oven rack stop above runner and pulling rack forward.

#### **PREHEATING**

**Standard Oven** Turn thermostat control to the desired cooking temperature and preheat oven for 25 minutes. To save on gas consumption, do not operate oven at maximum heat when it is not necessary. Turn thermostat down to 250°F (121°C) or OFF when oven is not in use or during idle cooking periods.

#### **Griddle (optional models)**

Turn the three manual gas valve knobs to full ON. After preheating for 5 minutes, turn valves down until desired flame or heating level is achieved. Position the removable broiler grid into one of the two slide positions, depending on which will achieve the proper product results.

#### **CLEANING**

Do not use scouring powder or abrasives anywhere on this range Clean only using a soft cloth and mild detergent solution.

#### **MAINTENANCE**

**WARNING:** THE RANGE AND ITS PARTS ARE HOT. BE VERY CAREFUL WHEN OPERATING, CLEANING OR SERVICING THE RANGE.

#### **VENT**

When cool, the vent should be checked every six months for obstructions.

#### SERVICE AND PARTS INFORMATION

To obtain repairs, service and parts information concerning this model, contact supplier. When calling for service, the following information must be available: model number, serial number, manufacture date (MD) and voltage (optional models).

# TROUBLESHOOTING GUIDE

#### STANDARD OVEN RESTAURANT RANGE OVEN

PROBLEM	CAUSES
1.Too much bottom heat	a) Insufficient ventilation
	b) Improper fluing
1a. Too low temperature	c) Improper thermostat bypass setting
1b. Side burning	d) Thermostat out of calibration
1c. Too much top heat	e) Fluctuating gas pressure
	a) Not level side to side
Uneven bake side to side	b) Oven burner, bottom or baffles improperly installed
	c) Warped pans
	a) Overactive flue
3. Uneven bake front to rear	b) Not level front to back; check casters and legs
	c) Door not closing properly
	a) Too low temperature (overcooking)
Dried out products	b) Too long baking time
	c) Thermostat calibration
	a) Pilot flame to low
5. Pilot outage	b) Restriction in pilot orifice
	c) Problem with shutoff valve
	d) Possible fluing problems
	e) Low pressure
	f) Improper gas line sizing
	g) Burner box cover not properly installed
	h) Oven cavity requires resealing

#### **TOP BURNER OPERATION**

Improper burner combustion     Excessive valve handle temperatures     Sticking top burner valves	a) Improper ventilation b) Poor door fit c) Oven door left open d) improper use of excessively large pans or pots
2. Poor ignition	a) Insufficient input b) Poor air-gas adjustment c) Restriction in pilot orifice d) Restriction in main burner ignition port

### **Limited Warranty**

Products warrants to the original owner/user that any unit manufactured by Products ("the products") shall be free of defects in material or workmanship under normal and proper use and maintenance service as specified by Products and upon proper installation (not to exceed 120 days from date of original shipment) and start-up in accordance with the instruction manual supplied with the Product.

The obligation of Products and the rights and remedies of the owner/user under this warranty are exclusively limited to (1) the repair or replacement, including labor charges, of parts or assemblies that in Products opinion are defective within one year after the original date of installation; The labor warranty shall include standard straight time labor charges at the product location only and shall exclude charges for travel time, mileage or other premium charges. Any labor service required to fulfill the warranty obligation must be performed by a service company qualified and accepted.

This warranty does not include parts or labor coverage for component failure or other damage resulting from:

- External electrical power failure or miss wiring to Product for any reason.
- Adverse operating conditions as set forth in the owner/user manual for the Product.
- Failure to clean and/or maintain Product as set forth in the owner/ user manual for the Product.

All claims for labor or parts must be made through Products. The defective part, for which labor reimbursement is claimed, together with the service invoice, must be returned to the Products within fifteen days from the date of service to be eligible for labor and parts warranty coverage. All replacement parts must be approved Products parts. Incidents of failure that do not require replacement of a part shall be explained in sufficient detail on the service invoice to identify the failure. All claims shall include the product model number, serial number, original date of installation and customer identification.

The foregoing warranty shall not apply to (1) any part or assembly (a) that has been altered, modified, or changed, (b) that has been subjected to misuse, abuse, neglect or accidents, or (c) any Product on which the serial or model number has been removed or altered, or (2) any Product that has been installed and /or maintained inconsistent with Product's technical publications, or

(3) any Product that has been installed or is located outside the standard warranty coverage area. Warranty valid in Continental United States only.

#### "LIMITATION OF LIABILITY AND OTHER WARRANTIES"

Products assumes no liability for misuse or inadequate maintenance of the Product. In no event shall the user be entitled to recover incidental or consequential damages, including but not limited to, damages for inconvenience, food loss, rental or replacement equipment, loss of profits, or other commercial loss.

Warranties stated above are the only warranties made in connection with the sale and distribution of the Products. ANY AND ALL OTHER EXPRESSED, STATUTORY AND IMPLIED WARRANTIES APPLICABLE TO THE PRODUCT INCLUD-

WITHOUT LIMITATION, ALL IMPLIED WARRANTIES OF MERCHANTABILITY AND FITNESS FOR USE ARE **EXPRESSLY** 

DISCLAIMED.

The warranty information set forth above shall be governed by and construed in accordance with the laws of the State of

Carolina and, if applicable, the laws of the United States of America. The warranty, as stated, is extended only to the original owner/user

and is not assignable.

# **Conversion Kit Instructions** for the Gas restaurant ranges

### **WARNING**

This conversion kit shall be installed by a qualified service agency in accordance with the manufacturer's instructions and all applicable codes and requirements of the authority having jurisdiction. If the information in these instructions is not followed exactly, a fire, an explosion or production of carbon monoxide may result causing property damage, personal injury or loss of life. The qualified service agency is responsible for the proper installation of this kit. The Installation is not proper and complete until the operation of the converted appliance is checked as specified in the manufacturer's instructions supplied with the kit."

# Range Conversion Kit Instructions




Do not attempt gas conversion by yourself. Gas conversion of your unit is to be made by a certified/licensed technician.

#### CONVERSION


Instructions are for conversion from Natural Gas to Propane (L.P.) on 24" & 36" models. The conversion should be done before connecting the unit to the gas supply. Units are shipped from the factory equipped for use on natural gas. Parts necessary for L.P. (liquid propane) are provided with the unit. Please refer to page 5 the orifice size list when you do gas conversion.

#### Turn off the main gas supply before doing any maintenance.

1.Remove the top grate



3. Loose orifice by hex wrench.



2. Raise the top burner and pull, Exposed the orifice.




Replace orifice and locked.Note: orifice number markd on orifice







- 5. Put back top burner, Caution: air shutter must be toward orifice.
- 6. Put back top grate.
- 7. Remove the oven bottom drop pan, and radiator plate.



9. Loose orifice by hex wrench




8. Loose the screw of oven burner back, raise burner and pull backward.



10. Replace orifce and locked.


Note: orifice number marked on orifice




- 11. Put back oven burner, Caution: air shutter must be toward orifice, lock burner fix screw
- 12. Put back radiator plate and drop pan.


#### 13. Regulator convert

Before installing the included convertible regulator, unscrew the octagon cap. You can read (NAT) on the plastic insert attached to the head of the cap; flip it over and snap back in place.





#### **Conversion Kit Instructions**



Pictured is the plastic insert. Pull off insert from octagon cap and reverse the plastic insert position so that the L.P. position is attached to the octagon cap head.

- 14. Continue with installation.
- 15. Completed gas conversion.
- 16. Check all joints in the gas supply line for leaks. use soap and water solution. do not use an open flame.

#### Warranty

#### What this limited warranty covers:

The Warranty coverage provided by Forno Appliances in this statement applies exclusively to the original Forno appliance ("Product") sold to the consumer ("Purchaser") by an authorized Forno dealer/distributor/retailer, purchased and installed in the United States or Canada, and which has always remained within the original country of purchase (the United States or Canada). Warranty coverage is activated on the date of the Product's original retail purchase and has a duration of two (2) years.

Warranty coverage is non-transferable. In the event of replacement of parts or of the entire product, the replacement Product (or parts) shall assume the remaining original Warranty activated with the original retail purchase document. This Warranty shall not be extended with respect to such replacement. Forno Appliances will repair or replace any component/part which fails or proves defective due to materials and/or workmanship within 2 years of the date of the original retail purchase and under conditions of ordinary residential, non-commercial use. Repair or replacement will be free of charge, including labor at standard rates and shipping expenses. Purchaser is responsible for making the Product reasonably accessible for service. Repair service must be performed by a Forno Authorized Service company during normal working hours.

#### **Important**

Retain proof of original purchase to establish warranty period. Forno's liability on any claim of any kind, with respect to the goods and/or services provided, shall in no event exceed the value of the goods or service or part there of which has given rise to the claim.

#### **30-Day Cosmetic Warranty**

The Purchaser must inspect the product at the time of delivery. Forno warrants that the Product is free from manufacturing defects in materials and workmanship for a period of thirty (30) days from date of the original retail purchase of the Product.

This coverage includes: Paint blemishes Chips Macroscopic finish defects

#### Cosmetic warranty does NOT cover:

Issues resulting from incorrect transport, handling and/or installation (e.g.: dents, broken, warped or deformed structures or components, cracked or otherwise damaged glass components);

Slight color variations on painted/enameled components;
Differences caused by natural or artificial lighting, location or
other analogous factors; > stains/corrosion/discoloration
caused by external substances and/or environmental
factors; > labor costs, display, floor, B-stock, outof-box, "as is" appliances and demo units.

#### How to receive service

To receive warranty services, the Purchaser must contact the Forno Support department in order to determine the problem and the required service procedures. Troubleshooting with

a customer service representative will be necessary before moving forward with the service. Model number, serial number and date of original retail purchase will be requested.

#### Warranty Exclusions: What Is Not Covered.

- Use of the Product in any non-residential, commercial application.
- Use of the Product for anything other than its intended purpose.
- Repair services provided by anyone other than a Forno Authorized Service agency.
- Damages or repair services to correct services provided by unauthorized parties or the use of unauthorized parts.
- Installation not in accordance with local/state/city/county fire codes, electrical codes, gas codes, plumbing codes, building codes, laws or regulations.
- Defects or damage due to improper storage of the Product.
- Defects, damage or missing parts on products sold out of the original factory packaging or from displays.
   Service calls or repairs to correct an incorrect installation of the Product and/or related accessories.
- Replacement of parts/service calls to connect, convert or otherwise repair the electrical wiring and/or gas line in order to properly use the product.
- Replacement of parts/service calls to provide instructions and information on the use of the Product.
- Replacement of parts/service calls to correct issues arising from the product being used in a manner other than what is normal and customary for residential use.
- Replacement of parts/service calls due to wear and tear
  of components such as seals, knobs, pan supports,
  shelving, cutlery baskets, buttons, touch displays,
  scratched or broken ceramic-glass tops.
- Replacement of parts/service calls for lack of/improper maintenance, including but not limited to: build up of residues, stains, scratches, discoloration, corrosion.
- Defects and damages arising from accidents, alteration, misuse, abuse or improper installation.
- Defects and damages arising from Product transport, logistics and handling. Inspection of the product must be made at time of delivery. Following receipt and inspection, the selling dealer/delivery company must be notified of any issues arising from handling, transport and logistics.
- Defects and damages arising from external forces beyond the control of Forno Appliances, including but not limited to wind, rain, sand, fires, floods, mudslides, freezing temperatures, excessive moisture or extended exposure to humidity, power surges, lightning, structural failures surrounding the appliance and other acts of God.
- Products whose serial number has been altered/damaged/tampered with. In no case shall Forno be held liable or responsible for damage to surrounding property, including furniture, cabinetry, flooring, panels, and other structures surrounding the Product. Forno is neither liable nor responsible for the Product if it is located in a remote area or an area where certified trained technicians are not reasonably available. Purchaser must bear any transportation and delivery costs of the Product to the nearest Authorized Service Center or the additional travel expenses of a certified trained technician

#### Warranty (continued)

THERE ARE NO EXPRESS WARRANTIES OTHER THAN THOSE LISTED AND DESCRIBED ABOVE, AND NO WARRANTIES, EITHER EXPRESS OR IMPLIED, INCLUDING, BUT NOT LIMITED TO, ANY IMPLIED WARRANTIES OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE THAT SHALL APPLY AFTER THE EXPRESS WARRANTY PERIODS STATED ABOVE, AND NO OTHER EXPRESS WARRANTY OR GUARANTEE GIVEN BY ANY PERSON. FIRM OR CORPORATION WITH RESPECT TO THIS PRODUCT SHALL BE BINDING ON FORNO. FORNO SHALL NOT BE LIABLE FOR LOSS OF REVENUE OR PROFITS, FAILURE TO REALIZE SAVINGS OR OTHER BENEFITS, TIME AWAY FROM WORK, MEALS, LOSS OF FOOD OR BEVERAGES, TRAVELING OR HOTEL EXPENSES, EXPENSES TO RENT OR PURCHASE APPLIANCES, REMODELING/CONSTRUCTION EXPENSES IN EXCESS OF DIRECT DAMAGES WHICH ARE UNDENIABLY CAUSED EXCLUSIVELY BY FORNO OR ANY OTHER SPECIAL, INCIDENTAL OR CONSEQUENTIAL DAMAGES CAUSED BY THE USE, MISUSE OR INABILITY TO USE THIS PRODUCT, REGARDLESS OF THE LEGAL THEORY ON WHICH THE CLAIM IS BASED, AND EVEN IF FORNO HAS BEEN ADVISED OF THE POSSIBILITY OF SUCH DAMAGES. NOR SHALL RECOVERY OF ANY KIND AGAINST FORNO BE GREATER IN AMOUNT THAN THE PURCHASE PRICE OF THE PRODUCT SOLD BY FORNO AND CAUSING THE ALLEGED DAMAGE. WITHOUT PREJUDICE TO THE FOREGOING, PURCHASER ASSUMES ALL RISK AND LIABILITY FOR LOSS. DAMAGE OR INJURY TO PURCHASER AND PURCHASER'S PROPERTY AND TO OTHERS AND THEIR PROPERTY ARISING FROM THE USE. MISUSE. OR INABILITY TO USE THIS PRODUCT SOLD BY FORNO THAT IS NOT A DIRECT RESULT OF NEGLIGENCE ON THE PART OF FORNO THIS LIMITED WARRANTY SHALL NOT EXTEND TO ANYONE OTHER THAN THE ORIGINAL PURCHASER OF THIS PRODUCT, IS NON-TRANSFERABLE, AND STATES YOUR EXCLUSIVE REMEDY.



