



INSTALLATION INSTRUCTIONS

SpeedFlex® Track Top Gasket (Part Numbers: TTG350F2, TTG350F2-BK, TTG600F2, TTG600F2-BK)

1

Pull end of TTG from center of roll. Peel optional adhesive from end.

2

Place TTG at one end of track and center along its entire length.

3

Flip track and cut TTG along other end of track.

4

Secure track to floor/ceiling as described in reference wall design.

5

Verify that downward projecting flaps are sandwiched between gypsum board and steel ceiling track. Seams in adjoining lengths of gasket may be butted or overlapped.

6

The TTG can be cut along the center score line to be placed on wider tracks.

Note: For more information on firestop installation, refer to ASTM E3157.

Page 1 of 1

Warranty: www.stifirestop.com/legal/warranty
Made in USA • Printed in USA
ZIS01406 23163



Specified Technologies Inc.
Somerville, NJ 08876 USA
T: (800) 992-1180 • F: (908) 526-9623
www.stifirestop.com

