

## WS1 Custom Charge Head (AC252-B) & Sensor (AC262-B) Installation



- 1 Align the micro USB plug on the charge head with the port on the stand.



- 2 Place the charge head onto a previously installed WS1 stand.



- 3 Use the TT15 bit from the multitool to fully tighten the screw to secure the charge head to the stand.



- 4 Use the provided alcohol wipe to clean the underside of the watch body.



- 5 Peel the clear film from the adhesive on the sensor tray.



- 6 With the cable facing towards the top of the watch, place the sensor tray onto the watch body and apply pressure for at least 10 seconds.



- 7 The sensor and watch should look like the above image.



- 8 Plug the sensor cable into the back of the WS1 stand.

## WS1 Custom Charge Head (AC252-B) & Sensor (AC262-B) Installation

---



- 9 Place the watch and sensor onto the stand. Ensure that the charging contacts on the watch align with the pins on the charge head.