

Lite/Lock Conflict with Wide Trim Locks

New “Wide” Trims are becoming more common in the Healthcare field. Being aware of these new designs is important when specifying the door design. The new designs extend past the mortise lock pockets unlike traditional trims. This extension can cause a lite/lock conflict if it is not considered in the design process.

Below lists some of trims that extend past mortise lock pockets. This list is not a complete list so check design if standard trims are not specified.

- Corbin BHSS Trim
- Sargent BHW Trim
- Schlage HSLR with L4 Template
- Accurate 9100 SEC Institutional Trim



For reference only: Wide Trim Lock