

## 2021-2024 FORD BRONCO 2/4 DOOR MESH TOP PART NO. 91001

When installing the mesh top, it's easier to do so with no hard top on the vehicle. You can still install the mesh top with the hard top on. It's just easier to get around the roll cage without it in the way.

Here is a link on how to remove the hard top for reference. [https://youtu.be/r1dThtJTR\\_Y?si=3h9SqFK5vkux4cmj](https://youtu.be/r1dThtJTR_Y?si=3h9SqFK5vkux4cmj)

Once you have removed the hard top, go ahead and lay the mesh top over the top of the vehicle. Make sure the Velcro squares and zipper open towards the inside of the vehicle.

If you plan to reinstall the full hard top after installing the mesh top, please skip to Step 1B.

If you plan to use the mesh top without the front section of the hard top proceed below.

**Step 1A-** Starting from the front of the vehicle. Where the roof latches are in the front corners of the vehicle by the windshield frame. You will remove the two bolts that hold the latches onto the vehicle (marked in blue in photo below). These bolts require torx bits to loosen and remove. (This part is only necessary when using the mesh top with no front section of the hard top installed.)



You will then feed the bolts you just removed from the latch, through the holes in the mesh top and back through the latches reinstalling the latches in the process. Proceed to do the same to the other side latch. Then go ahead and take the two center hooks and put them in the alignment holes for the hard top to anchor the front portion down (Marked in purple). Do not tighten them up yet. (Again this is only necessary when using the mesh top with no front section of the hard top installed.)



**Step 1B.** Once you lay the mesh top on the vehicle. Fold over the front section and secure it to using the Velcro strips marked in red. (Only necessary when reinstalling the front portion of the Hard top)



**Step 2-** Proceed to work your way down the sides of the mesh top using the hooks to hook the mesh top to the lip in between the door frames and the roll cage. The hook closest to the front of the vehicle will go into a hole located on the roll cage. (Marked in purple). Once both sides are secured. Go ahead and tighten both sides evenly, then tighten the front two anchor hooks in the alignment holes from Step 1A.



**Step 3 -** Go ahead and use the bungees provided to secure the rear of the mesh top around the rear sound bar/ roll cage. (marked in yellow)





# INSTALLATION INSTRUCTIONS

You can now enjoy the Mesh Top in the sun, or down the coast, or out in the wilderness. When you want to reinstall the hard top on the vehicle. You do not have to remove the mesh top. You can leave it installed, just be sure to refer to Step 1B to reinstall the front section of the Hard top back on. During the reinstallation process of the hard top, you will see the Velcro squares and zipper in the mesh top are designed for you to reach the latches on the hard top for easy securing.