



INSTALLATION INSTRUCTIONS

2005-2015 TOYOTA TACOMA CREW CAB SPORT RACK REQUIRES 5129 BASKET

Part # TC-6124



**** Inspect all parts prior to installation. Contact us at 951-808-0750 for missing parts.**

Hardware list:

QTY 8 M10X1.5X60mm
QTY 6 M10X1.5 nut
QTY 4 M10X1.5X25mm
QTY 16 M10 washer

Installing Sport Rack:

We recommend you have help with lifting of the Sport Rack to avoid injury or damage to Sport Rack and vehicle.

- 1 Remove two bed bolts closest to front of bed. Retain hardware for latter use.
- 2 Support basket on cab about 3 inches above cab. We recommend caution to protect cab and basket from scratching.
- 3 Slide nut plates into bed tie down channel, 2 per side channel.



- 4 Install front legs into bottom holes on basket. Install factory bed bolts at bottom of legs and supplied M10x1.5x60mm hardware. Do not tighten at this time.

- 5 Locate and install middle support legs in top holes of cab basket and at bed side channel locations.



- 6 Install rear legs and rear cross bar.
7 Check for alignment to body and tighten all Hardware at this time.

Note: Recheck all hardware after the first couple hundred miles. It is advised to inspect the Sport Rack and hardware periodically. Be sure to secure all loads before traveling.



5125 Adapter

**** The Sport Rack basket pictured is different than the production model. We added a windscreen and placed the light tabs on the bottom bar. This was done to reduce wind noise.**

**** You can use our 5125 adapters on the Sport Rack if you would like to add Thule or Yakima rack accessories.**