



PRODUCT:

PRODUCT: 50208-DG

**2.0" COIL SPRING +COIL SPACERS + SHOCK EXTENDERS
2014-2020 DODGE RAM 3500 4WD LEVELING KIT
2013-2020 DODGE RAM MEG/2500 4WD LEVELING KIT**

PARTS LIST

QTY

COIL SPRING SPACER	2
SHOCK EXTENDERS	2
M14-2.0X80 HEX CAP SCREW	2
M14-2.0 NYLOCK NUT	2
M14 FLAT WASHER	4

PLEASE DOUBLE CHECK THE PARTS LIST BEFORE BEGINNING INSTALLATION,
TO ENSURE ALL PARTS ARE PRESENT, IF THERE IS SOMETHING MISSING,
PLEASE CONTACT BODY ARMOR 4X4 IMMEDIATELY

(866) 894-3351 USA AND (877)326-0933 CANADA

READ THE INSTRUCTIONS THOROUGHLY AND COMPLETELY BEFORE
BEGINNING THE INSTALLATION.

PRIOR TO INSTALLATION:

1. Factory service manual is recommended to have on hand.
2. Secure and properly block vehicle prior to beginning installation
3. Always wear safety glasses when using power tools or working under the vehicle
4. Modifications to any part will void the warranty associated with that product.

After removing parts from vehicle, save hardware for reinstallation

**IT IS RECOMMENDED THAT YOU HAVE YOUR VEHICLE'S ALIGNMENT CHECKED WHENEVER INSTALLING
NEW SUSPENSION. IT IS ALSO RECOMMENDED THAT YOU ADJUST YOUR HEADLIGHTS WHENEVER
YOUR VEHICLE'S RIDE HEIGHT IS ALTERED.**

1. Unbolt both sway bar end links.
2. Unbolt the ABS | Brake line bracket from the axle on both sides
3. Unclip the wire guide at the module on the axle.



4. Support axle with an adjustable jack, then unbolt both front shocks from either end.
5. Lower down the jack and remove each coil.
6. Install the factory isolator onto the coil spacer. The use of spray lube will help it slide on easier.
7. Spray some lubricant on the isolator where it will contact the coil and reinstall the coil with the spacer on top. Make sure both the coil spacer and coil seat properly.



8. Jack the axle up and reattach sway bar, and brake line bracket.
9. Install new shock extenders on the bottom shock mount for both sides (The extenders are not side specific) then install the shocks.