



ASSEMBLY INSTRUCTIONS

STEP 1



Folded Instacrate.

STEP 2



Lift top frame as shown.

STEP 3



Swing side panels down.

STEP 4



Firmly press side panels into slots.
Instacrate is ready to use.