

INSTALLATION:

- 1) FIRST, UN-BOLT AND REMOVE (2) STOP BLOCKS FROM FRONT SECTION OF GANGWAY BODY.
- 2) SLIDE EXISTING EXTENSION SECTION OUT OF BODY. UN-BOLT AND REMOVE EXISTING HANDLE FROM EXTENSION.
- 3) RE-BOLT EXISTING HANDLE ON TO NEW EXTENSION SECTION.
- 4) SLIDE NEW EXTENSION CAREFULLY INTO GUIDES ON GANGWAY BODY.
- 5) BOLT (2) STOP BLOCKS BACK INTO FRONT OF GANGWAY BODY.

