





BOLT-ON FORKLIFT POCKETS

- LOCATE FORKLIFT POCKETS AS SHOWN.

  DIMENSIONS SHOWN ARE RECOMMENDED, BUT POCKET LOCATION CAN BE WIDENED TO ACCOMMODATE PERSONAL FORK PLACEMENT.
  NOTE: PLACEMENT OF TUBES MUST BE CENTERED ON BASE AS SHOWN.

- MARK AND/OR MATCH DRILL HOLES INTO BASE.

- BOLT SECURELY BEFORE USE.

PART NAME	BOLT-ON FORKLIFT POCKETS		
MODELED BY:	TK	DWG	5/30/09
DRAWN BY:	TK	DWG	5/30/09
CHECKED BY:	TK	DWG	5/30/09
PROGRAMMED BY:		DWG	
PROGRAMMED CHECKED BY:		DWG	

ALL INFORMATION CONTAINED HEREIN IS CONFIDENTIAL & PROPRIETARY & MAY NOT BE DISCLOSED IN ANY FORM WITHOUT PRIOR WRITTEN CONSENT OF SAFERACK LOADING RACK TECHNOLOGIES

FINISH: Galv

SHEET SCALE: 1:24

SHEET: 1

SafeRack

LOADING RACK TECHNOLOGIES

219 Safety Ave - Andrews,SC 29510 (843)-264-8896

CUSTOMER:

JOB #:

ANSI B

SAFERACK WELDING STANDARDS

SEAL WELD UNLESS OTHERWISE NOTED

USE FILLETS LISTED BELOW UNLESS OTHERWISE NOTED

Material Thickness of Thicker Part Joined (inch)	Minimum Fillet Size - S (inch)
Over 1/4" to 1/2"	3/16"
Over 1/2" to 3/4"	1/4"
Over 3/4"	5/16"

NO.	DATE	DESCRIPTION	REV	BY
3	06-7-15	REVISED POCKETS FROM 8" CHANNEL TO C4X5.4EC TUBE.	KS	
2	11/19/09	Changed Channel Spacing From 5 1/4 to 5 3/8 for gain clearance	TK	
1	7/22/09	Released Drawings For Fabrication	TK	
1			TK	