

RLA MS TIMBER FLOORING ADHESIVE

SOLVENT & ISOCYANATE FREE FLOORING ADHESIVE



DESCRIPTION:

RLA MS TIMBER FLOORING ADHESIVE is a Green Tag Certified, single-part, permanently flexible, solvent and isocyanate free adhesive suitable for fixing timber flooring as well approved acoustic underlays to most common subfloors.

FEATURES AND BENEFITS:

- Green Tag Certified
- Non-Flammable
- Solvent & Isocyanate free
- Will not re-emulsify with water contact
- Easy to trowel & spread

RECOMMENDED USE:

- Bonding approved acoustic underlays to the most common subfloors
- Bonding, solid timber flooring, Parquet flooring, and engineered timber flooring to approved acoustic underlay and direct fixing to most common subfloors

SURFACE PREPARATION:

Subfloors must be prepared in accordance with Australian Standard 1884 for Floorcoverings. Subfloors must be dry, solid, sound, clean and free of wax, grease, oil, polishes, old adhesives, curing compounds and any other surface contaminants that may affect adhesion. If mechanical preparation is required, prepare the floor using recommended methods such as shot blasting, scarifying, and diamond grinding to provide a roughened, clean, sound, solid and open porous surface. The minimum subfloor temperature before commencing installation should be 10°C. Do not use solvents or acid etching to clean the subfloor.

Where temperatures are less than 10°C or greater than 28°C are encountered, contact RLA technical staff for advice

CONCRETE SUBSTRATES:

All concrete subfloors must be tested for moisture content. Relative humidity readings should be determined as per ASTM F2170. The relative humidity (RH) is to be below 85% (tested as per ASTM F2170 insitu probe method).

If the RH of the sub-floor is above 85%, the application of [RLA RAPID SEAL MR](#) (suitable for green substrates up to 95% RH with decreasing moisture levels) or [RLA MOISTURE SEAL](#) is recommended.

Indentations and uneven concrete subfloors should be treated with the [RLA TRUELEVEL](#) range of levelling compounds. Refer to individual product TDS for further information and application instructions

TIMBER SUBSTRATES:

Timber flooring must be solid, sound, clean and free from wax, oil, free from gaps and securely fixed and in accordance with the Timber Flooring Manufacturers Instructions and relevant Australian Standards.

Timber Flooring and Particle Board may be coated with a resin waterproof protective layer. This layer can act as a bond breaker and affect adhesion of applied finishes. It should be removed by sanding the subfloor before applying timber flooring.

For installation of timber flooring onto timber substrates, it is recommended to nail/ secretly fix Timber Flooring in combination with the adhesive application.

Ensure adequate cross-flow ventilation and that the minimum height clearance between earth and the timber flooring is in accordance with the relevant Australian Standards. Failure to have adequate ventilation can result moisture build up under the subfloor and can compromise the installation of underlayment and Floorcoverings.

APPLICATION:

BONDING ACOUSTIC UNDERLAY TO THE SUB-FLOOR:

- Apply the adhesive evenly with a 2-3mm V notched trowel (dependent on underlay type) at a rate of approx. 2m² per litre. Please refer to the underlay or timber manufacturer's instructions for specific trowel size
- Install the underlay into the wet adhesive film and ensure transfer occurs between the adhesive film and the underlay
- Roll the underlay with a suitable roller to ensure a minimum 100% transfer rate of adhesive film is achieved between the underlay and subfloor
- Allow the adhesive to dry for 24 hours prior to installing the floor-covering

BONDING TIMBER FLOORING SYSTEMS TO ACOUSTIC UNDERLAY:

- Apply adhesive evenly with a 3-5mm V notched trowel at a rate of approx. 1 – 1.4m² per litre. Please refer to the timber manufacturer's instructions for specific trowel size
- Install the timber flooring into the wet film of adhesive and ensure transfer occurs between the adhesive film and the timber flooring
- A minimum of 100% (Transfer) contact between the underlay and timber flooring is required. Maintain full contact with adhesive until full cure is achieved
- For best results timber flooring should be installed within 30 minutes of the adhesive

BONDING TIMBER FLOORING TO CONCRETE & CEMENTITIOUS SUBSTRATES:

- Apply adhesive evenly with a 4-5mm V notched trowel at a rate of approx. 1 – 1.4m² per litre. Always refer to the timber manufacturer's instructions for specific trowel size
- Install the timber flooring into the wet film of adhesive and ensure transfer occurs between the adhesive film and the timber flooring
- A minimum of 100% (Transfer) contact between the substrate and timber flooring is required. Maintain full contact with adhesive until full cure is achieved
- For best results timber flooring should be installed within 30 minutes of the adhesive's application

BONDING TIMBER FLOORING TO TIMBER SUBSTRATES:

- Apply adhesive evenly with a 4-5mm V notched trowel at a rate of approx. 1 – 1.4m² per litre. Always refer to the timber manufacturer's instructions for specific trowel size
- Install the timber flooring into the wet film of adhesive and ensure transfer occurs between the adhesive film and the timber flooring
- A minimum of 100% (Transfer) contact between the substrate and timber flooring is required. Maintain full contact with adhesive until full cure is achieved
- For best results timber flooring should be installed within 30 minutes of the adhesive's application

CURE TIME:

- MS Timber Flooring Adhesive will typically form a firm skin in two hours and an initial cure after 24 hours
- Do not allow heavy traffic for 24 hours
- Sanding can commence 3 to 7 days after the completion of the entire installation but may vary due to climatic conditions - please check with the manufacturer
- Cure times can vary substantially and are dependent on weather conditions such as temperature and humidity
- Hotter and more humid conditions will increase the rate of cure and decrease the skin time, whereas colder climates and lower humidity will decrease cure times and increase skin times

NOTE: Figures based on normal ambient temperatures of 23°C and 50% RH.

CLEAN UP:

- Clean tools and equipment immediately after use with a suitable solvent such as white spirits or alternatively Citrus based RLA Handy Wipes
- Cured MS Timber Flooring Adhesive can be removed by mechanical means or with RLA Handy Wipes

COVERAGE:

- V3 notched trowel will achieve a coverage of approximately 1.4m² per litre

NOTE: Coverage is dependent upon surface condition and will vary accordingly as uneven surfaces will require greater coverage. Consider additional allowance for wastage

PACKAGING:

- 15kg containers
- 600ml sausages

SHELF LIFE / STORAGE:

- 12 months when stored in original unopened packaging
- To be stored in a cool dry and weatherproof environment off the ground
- Once opened curing will commence – reseal as soon as possible and discard any partially cured or skinned material

PRECAUTIONS:

- Always ensure the flooring is placed into the wet film of adhesive and apply sufficient pressure to ensure transfer between the adhesive film and floor covering
- DO NOT allow the adhesive to skin, and DO NOT place timber flooring onto the skinned glue
- A minimum of 100% (Transfer) contact between the substrate and the back of each piece of timber is required. Maintain complete contact with an adhesive until full cure is achieved after a minimum of 24 hours (mechanical fixing or weighing down is recommended)
- Do not walk on laid matting during the first four hours after installation
- Avoid air entrapment when making the bond or filling joints
- For application details of timber flooring systems, contact the manufacturer
- Care should be taken to prevent any reaction or damage to pre-finished timber coatings
- Do not use adhesive in excessively hot or cold conditions, i.e., below 10°C or above 28°C
- This adhesive will not stand up to hydrostatic pressure or capillary action
- Ensure your trowel is consistently notched to the manufacturer's recommendations
- Timber flooring systems must be acclimatised; refer to the timber flooring manufacturers' recommendations before using this adhesive
- If in doubt regarding the suitability of the adhesive, always contact the manufacturer
- Do not apply over acrylic or PVA primers/sealers
- Not recommended to be used in totally confined spaces as it requires atmospheric moisture to cure properly
- Do not expose to water or alcohol-based cleaners before the complete cure
- Adhesive must be fully cured before sanding; allow a minimum of 72 hours

- Compatibility tests must be first carried out. Due to the many forms of timber flooring available today, the installer should undertake preliminary adhesion testing to confirm adhesion. RLA Technical can assist with large projects
- Do not apply over dense burnished concrete surfaces without abrading first to obtain a mechanical key for the adhesive to bond

HEALTH & SAFETY:

For information and advice on the safe handling, first aid, storage and disposal of chemical products, users must refer to the most recent Safety Data Sheet (SDS) containing physical, ecological, toxicological and other safety-related data.

WARRANTY STATEMENT:

RLA Polymers guarantees this product against manufacturing defects and guarantees it to be manufactured to our published specification.

We certify that this product is suitable for use when fully cured and will perform as described in our technical data sheet or other published materials.

RLA Polymers will replace the product free of charge when purchased from any legally verifiable source and where the product is proven to have been stored, handled, and install according to instructions published on our packaging and within the stated shelf life. The Installation of all materials must be carried out in accordance with relevant Australian Standards.

Warranty doesn't apply if damage, loss, failure to follow instructions, or other circumstances are out of our control.

Sufficient time and access to investigate any complaint must be accorded to RLA Polymers.

The consumer is responsible for any expenses incurred in making a claim.

A claim form can be requested by:

PHONE: 1800 242 931

EMAIL: info@rlapolymers.com.au

MAIL: 215 Colchester Road Kilsyth Victoria 3137
(Attention Customer Service)

WEBSITE: www.rlapolymers.com.au

AUSTRALIAN CONSUMER LAW:

Our goods come with guarantees that cannot be excluded under the Australian Consumer Law. You are entitled to a replacement or refund for a major failure and compensation for any other reasonably foreseeable loss or damage. You are also entitled to have the goods repaired or replaced if the goods fail to be of acceptable quality, and the failure does not amount to a major failure. The benefits under our warranty are in addition to other rights and remedies available to the consumer under the law in relation to the goods and services to which the warranty relates.

DISCLAIMER:

All statements and technical information contained herein are based on tests we believe to be reliable, but the accuracy thereof is not guaranteed.

Users assume all risk and liability resulting from the use of the product and must confirm the suitability thereof by their own tests. Conditions of Sale contain a limited warranty against manufacturing defects.

Version: 01

Issue date: 10/09/2026

RLA Polymers Pty Ltd ACN 004 709 915

Head Office
215 Colchester Road
Kilsyth, Victoria, 3137
Tel: 1800 242 931

New South Wales
5A 246 Miller Road
Villawood, NSW, 2163

Queensland
57 Fulcrum Street
Richlands, QLD, 4077

South Australia
Unit 2/7 Berger Road
Wingfield, SA, 5013

Western Australia
24 Hanwell Way
Bassendean, W.A., 6054
Tel: 08 9279 8911

For the latest product information please visit rlapolymers.com.au