




**BRF160/180/200
FLAIL MOWER
Parts Manual**


Hitch Components



Hitch Components

Item	Part No.	Description
1	BRF1001	HEADSTOCK – FLAIL MOWER GS
2	BRF1002	HEADSTOCK LINKAGE – FLAIL MOWER GS
3	BRF1003	BUSHING – FOR VERGE MOWER BOOMS
4	BRF1004	ROTATION LINKAGE – FOR VERGE MOWER GS
5	BRF1005	ROTATION LINKAGE PLATE – FOR VERGE MOWERS GS
6	BRF1006	U-CHASSIS FOR EXTERNAL GEARBOX
7	BRF1010	BOOM – FOR VERGE MOWERS GS
8	BRF1014	PTO SHAFT HOOK
9	BRF1026	SELF-LOCKING NUT M30 x 2
10	BRF1028	SCREW M30 x 240
11	BRF1029	SCREW M30 x 170
12	BRF1031	SCREW M22 x 85
13	BRF1032	SCREW M22 x 130
14	BRF1040	SCREW M10 x 30
15	BRF1041	SCREW M12 x 30
16	BRF1046	GALVANIZED LOCK NUT M10
17	BRF1050	SCREW
18	BRF1087	PIVOT BUSHING XS
19	BRF1058	CLICK PIN
20	BRF1059	STAND
21	BRF1061	SELF-LOCKING NUT M22
22	BRF1062	WASHER 1/2"
23	BRF1063	FIXING VALVE
24	BRF1064	WASHER 3/8"
25	BRF1065	HYDRAULIC LINE
26	BRF1066	HYDRAULIC LINE
27	BRF1067	HYD. BANJO BOLT 3/8"
28	BRF1068	HYD. QUICK DISCONNECT – MALE
29	BRF1069	HYD. ADAPTER 3/8"
30	BRF1070	HYDRAULIC LINE
31	BRF1071	HYD. BANJO BOLT 3/8"
32	BRF1072	SCREW
33	BRF1123	BRACKET
34	BRF1074	TILT CYLINDER
35	BRF1075	SCREW
36	BRF1076	HOSE HALTER
37	BRF1077	HOSE HALTER
38	BRF1114	TOWER HOOK
39	BRF1079	GALVANIZED FLANGE
40	BRF1080	SPACER JACK
41	BRF1081	SHREDDER ARM XS
42	BRF1082	UPPER PIN D19.25 L=60+80 (CAT-I/CAT-II)
43	BRF1084	PIN D19 L=125
44	BRF1085	OFFSET CYLINDER

Main Frame Components



Main Frame Components

Item	Part No.	Description
1	BRF1008	GLAVANIZED LOCKNUT M14 x 1.5
2	BRF1009	BELT SPX 1350
3	BRF1011	CHASSIS BRF-160
	BRF1012	CHASSIS BRF-180
	BRF1013	CHASSIS BRF-200
4	BRF1015	REAR ROLLER BRF-160
	BRF1016	REAR ROLLER BRF-180
	BRF1017	REAR ROLLER BRF-200
5	BRF1018	LH – ROTOR BEARING
6	BRF1019	FLAIL HAMMER 20.5
7	BRF1020	HAMMER SPACER 20mm
8	BRF1021	BOLT M20 x 1.5 x 120 (10.9)
9	BRF1022	GALVANIZED LOCKNUT M20 x 1.5
10	BRF1023	BOLT M14 x 1.5 x 45
11	BRF1024	BOLT M12 x 1.25 x 60
12	BRF1025	GALVANIZED LOCKNUT M12 x 1.5
13	BRF1027	ROLLER BRACKET
14	BRF1034	UPPER - PULLEY
15	BRF1035	LOWER - PULLEY
16	BRF1036	SELF-LOCK HUB 33 x 80
17	BRF1037	BOLT M14 x 1.5 x 35
18	BRF1039	STONE GUARD
19	BRF1042	ROD – STONE GUARD BRF-160
	BRF1043	ROD – STONE GUARD BRF-180
	BRF1044	ROD – STONE GUARD BRF-200
20	BRF1045	NUT
21	BRF1048	SELF LOCK HUB
22	BRF1049	BEARING
23	BRF1051	SELF-LOCKING NUT M18 x 1.5
24	BRF1052	BOLT M18 x 1.5 x 50
25	BRF1053	ROTOR BRF-160
	BRF1054	ROTOR BRF-180
	BRF1055	ROTOR BRF-200
26	BRF1056	GREASE NIPPLE
27	BRF1060	BOLT M8 x 25
28	BRF1097	COVER – SIDE PULLEY
29	BRF1115	BRACKET
30	BRF1116	GUARD
31	BRF1117	MOUNTING BRACKET
32	BRF1098	TENSIONER PLATE
33	BRF1099	BOLT M16 x 1.5 x 70 (8.8)
34	BRF1100	SAFETY RING D100

(Continued on next page)

Main Frame Components

(Continued from previous page)

Item	Part No.	Description
35	BRF1101	SHIM 80 x 100 x 3.5
36	BRF1102	WASHER
37	BRF1103	BEARING
38	BRF1104	SPACER
39	BRF1105	RH – BEARING SUPPORT
40	BRF1108	COVER
41	BRF1109	BOLT M10 x 30
42	BRF1110	SPRING WASHER 10.5 x 17.5 x 2.2
43	BRF1111	SKID SHOE
44	BRF1112	BOLT M10 x 35
45	BRF1113	NUT M10
46	BRF1057	GEARBOX