


Equipment

Equipment

Navigate to Setup > Equipment > Devices:

Add a Device and License

1. Click on the Manage Drop Down
2. Select "+ Add Device"
3. Enter your Device Serial Number
4. Click "Get Device Type"
5. Click the "Add License" blue hyperlink
 - a. If you have an available Display Connection License you will see green "Active" text
 - b. If you do not have an available Display Connection, contact your reseller to purchase one
6. Click "ADD"
7. Your device is licensed and automatically added to the Devices list



Create a Vehicle and Assign Device

Navigate to Setup > Equipment > Vehicles

Add a Vehicle and Assign a Device

1. Click on the + Add Drop Down
2. Select “Add Vehicle”
3. Fill out the vehicle properties and modify the icon as desired
4. Click the Display Device Drop Down
 - a. You will see licensed displays from your org in the drop down
5. Select the device you would like to associate with this vehicle
6. Click the “Save” button
7. Your vehicle is automatically added to the Vehicles list

The screenshot displays the PTx web application interface for adding a vehicle. The top navigation bar includes the PTx logo, the year 2023, and a 'Select Crop Zone' dropdown. The main navigation sidebar on the left lists various setup options, with 'Equipment' currently selected. The central panel shows the 'VEHICLES' tab, containing the 'Vehicle Properties' form. This form includes a 'Change Icon' button next to a radio tower icon, and several input fields: 'Name *', 'Manufacturer *' (with a 'Choose...' dropdown), 'Vehicle Type *' (with a 'Choose...' dropdown), 'Equipment Group' (with an 'Unassigned' dropdown and a '+' button), and 'Unit Cost' (with a '/ hr' unit selector). Below these are the 'Attached Devices' section, featuring 'Display Device' and 'Telematics Device' (with a blue info icon) dropdowns, each with an 'Unassigned' selection and a '+' button. At the bottom right of the form are 'CANCEL' and 'SAVE' buttons.

Implements


Navigate to Setup > Equipment > Implements


How to add Implements

1. Click “+ Add”
2. Select “Add Implement”
3. Give the implement a name (required)
4. Select Operation Type, Equipment Group and enter Unit Cost (optional)
5. Click “Save”

The screenshot displays the PTx software interface for adding implements. The top navigation bar shows the year 2023 and a dropdown for 'Select Crop Zone'. The left sidebar is expanded to 'Equipment', with 'Implements' selected. The main panel has tabs for 'EQUIPMENT', 'VEHICLES', 'IMPLEMENTS', and 'DEVICES'. Under 'Implement Properties', there are four fields: 'Name *' (text input), 'Operation Type' (dropdown menu), 'Equipment Group' (dropdown menu with a '+' button), and 'Unit Cost' (text input with a '/ ac' label). At the bottom right, there are 'CANCEL' and 'SAVE' buttons.


How to edit Implements


1. Navigate to Setup > Equipment > Implements
2. Click on the edit button  next to the implement that you want to edit
3. Make any required changes to the implement than click 'Save'



The screenshot shows the PTx web application interface. The top navigation bar includes the PTx logo, the year 2023, and a 'Select Crop Zone' dropdown. The left sidebar contains a 'Setup' menu with options for Fields, Crop Zones, Equipment (highlighted), Materials, Crops, People, Plan, Track, Analytics, and Data Transfer. The main content area is titled 'EQUIPMENT' and has tabs for 'VEHICLES', 'IMPLEMENTS', and 'DEVICES'. The 'IMPLEMENTS' tab is active, showing the 'Implement Properties' form. The form has the following fields: 'Name *' with the value 'Drill', 'Operation Type' with a dropdown menu set to 'Unassigned', 'Equipment Group' with a dropdown menu set to 'Unassigned' and a '+' button to its right, and 'Unit Cost' with an input field and a '/ ac' button. At the bottom right of the form are 'CANCEL' and 'SAVE' buttons.


How to retire Implements


1. Navigate to Setup > Equipment > Implements
2. Click the checkbox next to the implement you want to retire
3. Click on the trashcan button 
4. Click 'Retire' on the pop-up to confirm the retiring of the implement



The warning dialog box has a title 'Warning' and contains the following text: 'Are you sure that you want to retire these implements?' and 'Retiring these implements will also retire any profiles associated with them.' At the bottom right of the dialog are 'CANCEL' and 'RETIRE' buttons.

How to unretire Implements

1. Navigate to Setup > Equipment > Implements
2. Click the 'Show Retired' checkbox to make the retired implements visible
3. Click the checkbox next to the implement you want to unretire
4. Click on the unretire button  UNRETIRE
5. Click 'Unretire' on the pop-up to confirm the unretiring of the implement




How to Import Vehicle and Implement Profiles

Navigate to Setup > Equipment > Vehicles

Import Vehicle Profile

1. Click “+ add”
2. Select “Import Profiles”
3. Select “Choose file”
4. Navigate and select zipped AgData file for import
 - a. Note: Only Precision-IQ AgData profiles can be imported
5. Click “Open”
6. Click the checkbox for vehicles you want to import and select which vehicle to attach the profile to – either an existing vehicle in the list or ‘[New Vehicle]’ to create a new vehicle
7. Click “Import”



Import Implement Profile

1. Click “+ add”
2. Select “Import Profiles”
3. Select “Choose file”
4. Navigate and select zipped Agdata file for import
5. Click “Open”
6. Click the checkbox for vehicles you want to import and select which vehicle to attach the profile to – either an existing vehicle in the list or ‘[New Vehicle]’ to create a new vehicle
7. Click “Import”