

# **FIBER**LIGN<sup>®</sup>





## SLACKLOOP® ADJUSTABLE CABLE STORAGE

The **SLACKLOOP Adjustable Cable Storage** neatly stores slack OPGW cable on wood poles, concrete poles, and lattice towers while maintaining the appropriate cable bend radius. The Adjustable SLACKLOOP System consists of independent crossarms and spools that can be placed any distance away from each other on the structure to adjust for the desired storage length. Cable straps (not provided) can be used to neatly group cable loops and secure the cable to spools or keepers, if desired.

## **FEATURES AND BENEFITS**

- Various configurations can be created with standard crossarm and spool kits
- · Short and long crossarm options are available
- Long crossarms allow spools to be attached at various positions at each end of the crossarm
- Mounting options available to accommodate most structures
- Accommodates cable manufacturer-suggested storage diameters
- Storage spools provide a soft, smooth surface to support and protect cable
- Steel components are galvanized or zinc plated to prevent corrosion
- Can be used with the  $\textsc{COYOTE}^*$  Defender for ballistic protection
- Short crossarm: 2 ft loop creates 130 ft storage
- Long crossarm: 5 ft loop creates 300 ft storage

60 PLP.COM CO-CA-1024-3

61



## **ORDERING INFORMATION**

Select the appropriate **SLACKLOOP Adjustable Cable Storage** kit(s) based on the configurations shown at the bottom of the page.

#### SLACKLOOP Adjustable Cable Storage

SEACKLOOF Adjustable cable Storage			
Catalog Num- ber	Product	Description	
8003503	Adjustable Cable Storage Spool	Includes (1) Cable Storage Spool	
8003503B1	Cable Storage Spool with Banding Bracket	Includes (1) Cable Storage Spool, (1) Banding Bracket, (1) 5/8"-11 x 6" Bolt (1) 5/8"-11 Nut, (1) 5/8" Lock Washer, & (1) 5/8" Washer	
8003503LTC1	Cable Storage Spool with Lattice Tower Clamp	Includes (1) Cable Storage Spool, (1) Lattice Tower Clamp, (1) 5/8"-11 x 8" Bolt (1) 5/8"-11 Nut, (1) 5/8" Lock Washer, & (1) 5/8" Washer	
800011408	Single Short Crossarm with Spools	Includes (2) Cable Storage Spools, (1) Short Crossarm, (2) 5/8"-11 x 6" Bolts, (2) 5/8"-11 Nuts, (2) 5/8" Lock Washers, & (2) 5/8" Washers	
8003493	Single Long Crossarm with Spools	Includes (2) Cable Storage Spools, (1) Long Crossarm, (2) 5/8"-11 x 6" Bolts, (2) 5/16"-18 x 1" Bolts, (2) 5/8"-11 Nuts, (2) 5/8" Lock Washers, & (2) 5/8" Washers	
8003569	Dual Long Crossarms with Spools	Includes (4) Cable Storage Spools, (2) Long Crossarm, (4) 5/8"-11 x 6" Bolts, (4) 5/16"-18 x 1" Bolts, (4) 5/8"-11 Nuts, (4) 5/8" Lock Washers, & (4) 5/8" Washers	

### **System Configurations**



**NOTE**: 5/8" through bolts, 5/8" double-arming bolts, banding, and the COYOTE® Defender are not supplied. 5/8" through bolts and double-arming bolts are typically used to mount crossarms and spools to wood poles.

CO-CA-1024-3 PLP.COM