Surface Preparation

BARE CONCRETE

1 CLEAN/DEGREASE

2 ETCH



*Concrete Etch Included in Garage Floor Coating kits

3 PATCH & REPAIR CRACKS

PREVIOUSLY SEALED OR COATED CONCRETE

1 CLEAN/DEGREASE

2 PATCH & REPAIR CRACKS

3 RECOAT PRIMER



*Use in place of grinder directly over coated or sealed concrete