


VIKING PUMP, INC. • A Unit of IDEX Corporation

406 State Street • Cedar Falls, IA 50613 • Phone: 319.266.1741 • Fax: 319.273.8157

www.vikingpump.com

Exploded Diagram for Series 493/4193 (steel), 495/4195 (iron) and 4197 (SS), Sizes AS, AK & AL

NOTE: Kit may not apply to all models of these pumps. Contact your Viking Pump distributor with pump serial number for correct kit part numbers for that pump. Both a Seal Kit and a Rebuild Kit are needed to completely rebuild the pump. Additional non-kit parts, such as Rotor and Shaft Assembly, may also be required, depending on wear.



| ITEM | PART (may not exactly match parts list descriptions) | PART INCLUDED IN: | |
|------|--|-------------------|----------------|
| | | SEAL KIT | REBUILD KIT |
| 1 | Locknut | ✓ | |
| 4 | Bearing Spacer Collar | ✓ | |
| 3 | End Cap for Bearing Housing | \ | |
| 6 | Ball Bearing (Outer) | \ | |
| 7 | Bearing Housing | | |
| 7A | Setscrew for Bearing Housing | ✓ | |
| 7B | Setscrew for End Cap | ✓ | |
| 7C | Nylon Slug | ✓ | |
| 8 | Bearing Spacer | \ | |
| 25 | Ball Bearing (Inner) | ✓ | |
| 20 | Bearing Retainer Washer | ✓ | |
| 31 | Casing (4193) | | |
| 31A | Casing (4195) | | |
| 31B | Casing (495) | | |
| 31C | Casing (493) | | |
| 31D | Casing (4197) | | |
| 45A | O-Rings for Relief Valve (493/4193, 495/4195) | 1 | |

| ITEM | PART (may not exactly match parts list descriptions) | PART INCLUDED IN: | |
|------|--|-------------------|----------------|
| | | SEAL KIT | REBUILD KIT |
| 45 | Gaskets for Relief Valve (4197) | ✓ | |
| 47 | Relief Valve (or cover plate if less valve) | | |
| 30 | Pipe Plug | | |
| 46 | Capscrews for Valve | | 1 |
| 36 | Rotor and Shaft Assembly | | |
| 19 | Mechanical Seal (Buna, Viton® or Neoprene) ① | ✓ | |
| 19A | Mechanical Seal (PTFE) ①② | 1 | |
| 38 | Idler bushing (part of 37) | | |
| 37 | Idler and Bushing Assembly | | 1 |
| 35 | Head O-Ring (493/4193, 495/4195) ① | 1 | |
| 35A | Head Gasket (4197) | ✓ | |
| 39 | Idler Pin (part of 40) | | |
| 40A | Check Valves (part of 40 - not used on 4197) | | |
| 40 | Head and Idler Pin Assembly | | ✓ |
| 43 | Capscrews for Head | | ✓ |
| N/A | Seal Lubricant | 1 | |
| N/A | Seal Installation Sleeve | 1 | |

- ① Elastomers in this kit are specified in seal kit description.
- ② PTFE seal standard on 4197, optional on other series. Modifications to pump casing and rotor are required for PTFE mechanical seals in 495/4195 (iron) models. Consult factory.

Use Seal Lubricant for installing mechanical seal and O-rings.

Important safety information and rebuild instructions are found in the Technical Service Manual.

©Viking Pump, Inc. Rev. 03.01.2017

Viton® is a Registed Trademark of E.I. du Pont de Nemours and Company.

Download current Technical Service Manuals from www.vikingpump.com:

TSM 000 - Installation, Startup, Troubleshooting, Preventative Maintenance, Do's & Don'ts

TSM 154 - Series 493/4193 (steel)

TSM 144 - Series 495/4195 (iron)

TSM 164 - Series 4197 (SS)