HEAT SEALED POWDER COATED OR STAINLESS STEEL SCOPE DRYING CABINET

SureDry SCOPE CABINETS with Dri-Scope Aid® TRACKER

PART#
MAN-SURE TRACKER

DATE ISSUED:
November 2026

Dri-Scope Aid® Tracker System Models:

SC8024TD-T2310D | SC8024TDE-T2310D
SCSS8024TD-T2310D | SCSS8024TDE-T2310D
SC8030TD-T2310D | SC8030TDE-T2310D
SCSS8030TD-T2310D | SCSS8030TDE-T2310D
SC8036TD-T3316D | SC8036TDE-T3316D
SCSS8036TD-T3316D | SCSS8036TDE-T3316D
SC8044TD-T3316D | SC8044TDE-T3316D
SCSS8044TD-T3316D | SCSS8044TDE-T3316D

24" WIDE:
8 or fewer scope versions



30" WIDE:
10, 8 and 5 scope versions

36" WIDE:
16, 14, 12 and 8 scope versions



44" WIDE:
16 and 8 scope versions

HARLOFF
INNOVATING STORAGE FOR CARE

User Manual and Instruction Guide

Table of Contents

Contents of Package 3

Dri-Scope Aid® Components 4

Identifying the Cabinet 5

Scope Cabinet Features 6

Installing the Scope Cabinet 7

Plugging In the Scope Cabinet 8

Wall Retaining Instructions 9

Adjusting the Scope Support Arm Position 10

How to Replace the Filters 11

Operation of the Drying Package 12

Power Requirements 13

Electronic Components 14


Wiring Diagram 15

Air Circulation Data & Model 16


Cabinet Basic Care 17

Cabinet Door Adjustment 18


Contents of Package




Drip Pan



Medical Grade Power Cord 10 ft. [3.05 meter]



Power Adapter



Scope Filter

Contents:


- 1x Drip Pan
- Scope Support Arms (Installed)
- Scope Filters, 2x for 8030 models and 3x for all other models
- 1x Medical Grade Power Cord (Approved for use in US & Canada)

Harloff only uses electronic components that are certified to CSA and UL standards.


Dri-Scope Aid® Components


Contents:


PUMP (requires plugging into the wall for power)




MANIFOLD(s)











TABLET (requires plugging into the wall for power)

POWER CORDS AND CABLES

Five power cords are included with your Tracker cabinet:

1) Cabinet power cable, which connects to the **2)** cabinet power brick and electrical outlet

3) Pump power cable, which connects to the **4)** pump power brick and electrical outlet


5) Tablet power cable

See page 8 for details.





FLAMINGO TUBING



DRI-SCOPE AIR FILTER




CETACEA TUBING






Identifying the Cabinet


Left Side



Front



Right Side





KEY LOCK



E-LOCK




ELP LOCK




EKC LOCK

Harloff only uses electronic components that are certified to CSA and UL standards.

Scope Cabinet Features





Positive pressure HEPA filtered airflow using intake fans and exhaust fans.

The fan's electrical system is built into the cabinet's structure for a complete plug and play system. **See "INSTALLING THE SCOPE CABINET" (PG. 6) for more info.**


Timer is built in the ceiling so time settings for drying can be adjusted. **See "OPERATION OF THE DRYING PACKAGE" (PG. 10) for more info.**

Some of the scope support arms have alternate height positions that they can be placed into. **See "ADJUSTING THE SCOPE SUPPORT ARM POSITION" (PG. 8) for more info.**

The front of the top is hinged to tilt outward and provide easy access to intake fans and the HEPA Filters eliminating the need to remove all scopes for fan and filter access or replacement.

Tempered glass windows maximize visibility for internal inspections.

Installing the Scope Cabinet



Step 1: Open the crate and inspect for shipping damages. The cabinet is shipped on its back as shown to the right.


Step 2: Transport the cabinet, remaining flat on the pallet, to it's final destination.

Step 3: Once the cabinet is ready to lift into place, we recommend that a team of two or more tip the cabinet into an upright position.

Step 4: Remove drip pan from the packaging and place into the cabinet as shown.

Step 5: Open the HEPA filter panel as shown on page 11. After removing your filters from their plastic bags insert them into the filter enclosures, then close and secure the panel.

Step 6: Position the cabinet against a wall next to an electrical outlet.



DON'T FORGET!

Make sure you remove ALL filters and drip pan from their protective plastic bags before plugging in your scope cabinet.

Step 7: Thread the pump power cable and tablet power cable through the eyelet on the back of the cabinet, as shown at the lower right. Connect the cabinet to electrical power using the instructions on page 8. The Dri-Scope Aid® system will light up and the fans will turn on if the doors are closed.




Step 8: Test the system by opening and closing the doors. The fans should turn off when the doors are open and should turn on with an audible sound when the doors are closed, per the timer settings.




Plugging in the Scope Cabinet

Your Tracker scope cabinet requires power delivered to three different locations: the scope cabinet, the Dri-Scope Aid® system and the tablet interface. Since most electrical outlets only have two plugs, we recommend that you add a power strip or triple plug extension cord to provide electrical current to your powered units.



CABINET PLUG-IN:
This plug provides power to the scope cabinet fan and, if purchased, the built-in lighting. The power receptor is located at Position 1 on the back of the cabinet in the top right corner (facing the cabinet front). The plug is shown to the right.





NOTE

Both the cabinet power cable and pump power cable include power bricks which must be connected for proper operation.

DRI-SCOPE AID® SYSTEM PLUG-IN:
This plug provides power to the Dri-Scope Aid® pump for channel drying. The power receptor is located at Position 2 inside the cabinet interior on the right side of the pump. The plug is shown to the right.






TRACKER SYSTEM TABLET INTERFACE PLUG-IN:
This plug provides power to the Tracker System tablet. The power receptor is located at Position 3 inside the cabinet interior. There is a small black box affixed to the bottom of the timer. In the rear of this box is the receptor, and the plug is shown to the right.








To power on your tablet, look for a small access hole located in the door jamb or underneath the glass in the door of the scope cabinet. Insert the back of a pen in this access hole to push the on/off button. One quick push of the button will turn the device on, pushing the button for three seconds will turn the device off (then follow the on-screen directions to shut down).

Wall Retaining Instructions

Recommended for Highly Active Seismic Zones




Step 1: Locate the studs on the wall the cabinet will be set against. If bolting into a concrete wall stud locations are not necessary.

Step 2: Using a 1/4" or 5/16" bit, drill out the back panel of the cabinet and studs in two locations where the studs are. Use the two horizontal slots shown above to start the holes.

Step 3: Using the lag bolts supplied in the provided wall mounting kit or end user supplied mounting hardware, bolt the cabinet to the wall through the drilled holes.

For custom mounting requirements contact us at warranty@harloff.com

Adjusting the Scope Support Arm Position



DETAIL A

PLEASE NOTE: The cabinet is shipped with scope support arms in the highest position for maximum hang length.

Step 1: To reposition a scope support arm, unbolt the three screws shown above in Detail A.


Step 2: Move the arm vertically until the hole pattern on arm lines up with threaded holes' pattern on back-panel.

Step 3: Bolt the arm into the desired position with the screws removed in Step 1.

Mounts in four upper and two lower possible positions.

Tall cabinet maximum hanging length: Position 1 (top), 80 in. (203 cm),
Position 2 (bottom), 61 in. (155 cm) – Distance between the scope support arm's position to the bottom of the drip pan.

How to Replace the Filters




Step 1: With the cabinet doors closed use a ladder or step stool to access the panel on top of the cabinet.

Step 2: Remove the two screws at the top of the cabinet and flip the front fan plate towards front of cabinet exposing the HEPA filters as shown above.

Step 3: Remove the HEPA filters by sliding them up towards the top of the cabinet and then pull the bottom of the filter out.

Step 4: Place new HEPA filters into the cabinet. Flip the fan plate up into the closed position and fasten with two screws removed in Step 2.




PLEASE NOTE:

The number of filter enclosures and their position on the cabinet may vary by model.

A ladder or step stool is needed to replace the HEPA filters.

Operation of the Drying Package



Unplug cabinet from power before adjusting the system!

Setting Knob: This knob selects the run time of the fans from the display behind it. The arrow indicates the runtime selection. As shown the selection is between 9 & 12 on a range of 10 minutes. so the fans will run 10 (setting) X 10 M (range) or 100 minutes.

Operation Mode Selector: Preset to mode C. Do not change!

Dial Selector: This changes the numbers displayed behind the Setting Knob.

Time Range Selector: This changes the units of time that the Setting Knob can select. As shown 10 M means each unit is 10 minutes.


Fan operation: The timer sets how long the fans will run once both doors are closed. This time will reset whenever the doors are opened. Standard factory setting is 100 minutes of runtime and can be set to a maximum runtime of 180 hours.

Power Requirements

Dri-Scope Aid® TRACKER

Power Requirements

The Dri-Scope Aid TRACKER System may have up to 4 AC plugs.



Generic Installation layout shown.
(not to scale)

TRACKER Pump Power Supply (PN: 401998-146)

Description: Medical Power Supply with 42-inch DC output cord and DIN connector intended to connect directly into the pump module's Power Supply connector.

- 6' standard cord length (optional 12' available)
- Medical Grade NEMA 5-15 AC plug

INPUT VOLTAGE RANGE	80 ~ 264VAC
FREQUENCY RANGE	47 ~ 63Hz
POWER FACTOR (Typ.)	PF>0.93 / 230VAC PF>0.97 / 115VAC at full load
EFFICIENCY (Typ.)	88%
AC CURRENT (Typ.)	1.4A / 115VAC 0.7A / 230VAC
INRUSH CURRENT (Typ.)	Cold start 35A / 115VAC 70A / 230VAC
LEAKAGE CURRENT(max.)	Earth leakage current < 115μ A/264VAC Touch current <100μ A/264VAC

Cabinet Fan Power Supply

Description: Medical Approved Power supply.

- 4.7' cord length from power supply
- 10' Hospital grade AC cord (10A)
- UL/CE Approved

INPUT VOLTAGE RANGE	100 ~ 240VAC
FREQUENCY RANGE	50 ~ 60Hz
AC CURRENT (Typ.)	2.5A
Output	24V

USB Hub Power (PN: 406454-106-2)
(Optional)

Description: Optional 2 prong USB Hub power supply.

- 5' cord length from power supply

INPUT VOLTAGE RANGE	100 ~ 240VAC
FREQUENCY RANGE	50 ~ 60Hz
AC CURRENT (Typ.)	0.6A
Output	12V 2A







TRACKER Tablet Power Supply (P/O DCTB-TSI)

Description: Windows Surface Pro Tablet Power supply.

- External Power supply (6' cord)
- 3' AC Cord (9' total including supply) 2-prong

INPUT VOLTAGE RANGE	100 ~ 240VAC
FREQUENCY RANGE	50 ~ 60Hz
AC CURRENT (Typ.)	1.0A
Output	12V 2.58A

Electronic Components

ELECTRONIC COMPONENT	PICTURE	KEY FEATURES
HARLOFF PART #: 41094A DESCRIPTION: DC TUBE AXIAL FAN LONG DESCRIPTION: 24 VDC FAN W/ MOTOR AIR FLOW DIRECTION TOWARDS LABEL. THERMOPLASTIC CONSTRUCTION.		AIR FLOW: 51.2 CFM POWER/CURRENT: 1.2 W, 0.050A NOISE LEVEL: 28 dB OPERATING TEMPS: -10 TO 70 C WEIGHT: 94.8 G SAFETY: UL/CE/VDE APPROVED
HARLOFF PART #: 41081A DESCRIPTION: 24V 50 W AC/DC ADAPTER LONG DESCRIPTION: EXTERNAL DESKTOP CLASS I INPUT (SOLD SEPARATELY) 5.5 MM OUTPUT JACK.		POWER/CURRENT: 50 W, 2.5A OPERATING TEMPS: -20 TO 50 C CORD LENGTH: 4.7 FT. MOISTURE SENSITIVITY: 1 (MSL SCALE) SAFETY: UL/CE APPROVED FOR MEDICAL APPLICATIONS. LEAD FREE STATUS: LEAD FREE/ RoHS COMPLIANT.
HARLOFF PART #: 41084 DESCRIPTION: ANALOG TIMER GT3A-4 LONG DESCRIPTION: 11-PIN MULTI-MODE TIMER WITH ADJUSTABLE TIME SETTINGS		POWER/CURRENT: 0.8 W, 5 A. OPERATING TEMPS: -10 TO 50 C WEIGHT: 80 g TIME RANGE: 0.1S-180HRS. MECH.LIFE : 10,000,000 CYCLES ELEC.LIFE: 50,000 CYCLES SAFETY: UL/CE
HARLOFF PART #: 41089B DESCRIPTION: ADAPTER CORD LONG DESCRIPTION: 10 FT. WALL ADAPTER CORD. MALE PINS TO FEMALE SOCKETS. THREE PRONGED GROUNDED WALL PLUG HOSPITAL		CURRENT: 10 A. OPERATING TEMPS: UP TO 105 C CORD LENGTH: 10 FT. INPUT VOLTAGE: 90-264VAC APPROVED COUNTRIES: USA & CANADA. SAFETY: UL/CE HOSPITAL GRADE MOISTURE SENSITIVITY: 1 (MSL SCALE) LEAD FREE STATUS: LEAD FREE/ RoHS COMPLIANT.
HARLOFF PART#: 41085 DESCRIPTION: TIMER SOCKET		
HARLOFF PART#: 41083 DESCRIPTION: BARREL CONNECTOR, POWER JACK		
HARLOFF PART#: 41088 DESCRIPTION: SWITCH PROXIMITY HARLOFF PART#: 41099 DESCRIPTION: TOGGLE SWITCH		


PLEASE NOTE:

Harloff only uses electronic components that are certified to CSA and UL standards.

All internal wiring was done at the factory using 20 gauge insulated wire, all connections are soldered together and each joint is wrapped with heat shrink.

Wiring Diagram

If your scope cabinet is in need of service or repair,
WIRING OF THE ELECTRIC DRYING SYSTEM SHOULD BE DONE BY HARLOFF OR AN ELECTRICIAN.



120 VAC / 1 Amp / 60Hz

Air Circulation Data & Model


INTAKE:
Air flows in through the top intake fans, and feeds cabinet through the HEPA filters.

EXHAUST:
The lower fans pull the air out at the bottom of the cabinet.

NOTE:
Inlet has two to three fans on top, depending on model. Each fan is rated to 50 cubic feet / minute [1415 Liters/Minute].

Outlet has one or two fans on bottom, depending on model. Each fan is rated to 50 cubic feet / minute [1415 Liters/Minute].


Our standard push/pull design is a positive pressure system.



Cabinet Basic Care

Recommended Caring Steps:

1. Keep cabinets indoors in a climate controlled, ventilated environment.
2. Do not attempt to install or move cabinets alone.
3. Contact Harloff before attempting repairs.
4. Clean the cabinets with Harloff's recommended surface cleaners (list available by request or online at www.harloff.com/faqs in the Product Support section) or in accordance with the hospital campus regulations.
5. Thoroughly inspect fans and filters for cleanliness and operation. Harloff suggests replacement of filters every 3-6 months, but we recommend that each facility establish their own replacement plan for the HEPA filters. Depending on your cabinet model, you will either want to buy a 2-pack of HEPA filters **(SCFILTER2)** or a 3-pack of HEPA filters (**SCFILTER3)** to replace all filters at once. No filters are installed on bottom fans. Place filter orders at medicalsales@harloff.com or call 800-433-4064.
6. Do not place items in front of the lower exhaust or on top of the intake of the cabinet. Blocking air access will disturb airflow to cabinet, affecting its performance, and might cause fan to stop working by overloading it.



Cabinet Door Adjustment

Scope cabinet doors may fall out of alignment, inhibiting proper door swing. This can be caused by the cabinet shifting during shipping, by uneven flooring or this can happen over time through regular usage. Uneven door alignment can cause scraping during door open and close, damaging your cabinet. We highly recommend that you align your doors prior to regular use, and that you adjust your doors when they begin to not swing freely. Please use the steps below:



Step 1: Every scope cabinet comes equipped with levelers at the bottom of each of the four corners. Locate these levelers and lift up the cabinet so they can be accessed easily. You may need an extra person to assist you.

Step 2: Adjust the leveler screw by hand, tightening for less height or loosening for greater height. The leveler can also be adjusted with a 3/8" open end wrench.

Step 3: Examine your doors to check if they are level. Doors are level when there is no observable uneven gap under either side of the door. A bubble level that you provide may also be helpful. Continue adjustment until both doors are in complete horizontal alignment and swing freely without scraping.

