

ELPCB04

Connection & Control Pad



Projector A/V Control Pad for easy classroom connectivity.

Centralized classroom control — Manage projector power, volume, A/V mute and input sources directly from the wall—no remote needed

Intuitive source selection — Large, individual buttons clearly match Epson projector inputs for easy operation

Keep classrooms organized — Wall-mounted placement consolidates cables to help reduce clutter and potential trip hazards

USB-C charging and display — Simultaneously charge and display content from compatible PCs using a single USB-C connection

Optimized device connectivity — Three HDMI® control buttons make it simple to switch between connected high-definition A/V devices

Split screen instruction¹ — Connect two devices and display content side by side to support collaboration and comparison

Extended cable reach — Functions as an extension box to expand the usable range of connected cables

Front-of-room audio control — Volume dial and audio mute button allow quick sound adjustments during lessons

Simple wall installation — Designed to attach quickly and easily to the wall for fast classroom setup

Specifications

Input Power adapter, USB-A, USB-B, USB-C/HDMI1 (supports video, audio and PC charging), HDMI2, HDMI3, Microphone, Auxiliary, USB-C (pen charging only; for interactive models)

Outputs Audio in (3.5 mm), Audio out (3.5 mm), USB-A, USB-B, HDMI1, HDMI2, HDMI3

Split Screen¹

Control RS-232c (9-pin crossover/null modem type)

Functions

Projector Control

Power On/Off

Source Selection USB, USB-C/HDMI1, HDMI2, HDMI3, LAN

A/V Mute (except for AUX In/Mic Input)

Freeze

Audio Control

Audio Mute

Volume Adjustments (except AUX In/Mic Input/REC Out)

Mic volume control

Other

Operating Temperature 32 °F to 104 °F

Operating Humidity 20% – 80% RH

Power Supply Voltage 100 V – 240 V AC ± 10%

Power Frequency 50/60 Hz

Power Consumption 100 W, < 0.2 W in Standby Mode

AC Power Adapter Output Voltage DC 24 V

Dimensions (W x D x H)

9.7" x 2.4" x 7.3"

Weight: 2.7 lb

Eco Features

RoHS compliant

End-of-life options available²

Epson America, Inc. is a SmartWay® Transport Partner³

What's Included

Connection and control box, external AC power adapter with power cord, A/C adapter holder, 7.8 inch USB-C to USB-C cable (ELPPN07 pen charging for select interactive models), User Guide, installation manual, template sheet, warranty statement

Limited Warranty and Service

Epson Connection™

Pre-sales support U.S. and Canada 800-463-7766

epson.com

Service Programs

2-year limited warranty, Epson dedicated toll-free support

Ordering Information

Connection and Control Pad (ELPCB04)


V12HC49020

ELPSP02 Active Speakers

V12H467020


Interfaces

Front View (Input ports to connect external devices)




Side View

(Input ports to connect external devices)



Top View (Output ports to connect to projector)



¹ Split Screen feature requires remote control. Consult your user manual for input combinations. | ² For convenient and reasonable recycling options, visit epson.com/recycle |

³ SmartWay is an innovative partnership of the U.S. Environmental Protection Agency that reduces greenhouse gases and other air pollutants and improves fuel efficiency.

Learn more about how our products can empower your institution. Visit us at epson.com/foreducation



Epson America, Inc.
3131 Katella Ave., Los Alamitos, CA 90720

Epson Canada Limited
185 Renfrew Drive, Markham, Ontario L3R 6G3

epson.com
epson.ca

Specifications and terms are subject to change without notice. EPSON is a registered trademark of Seiko Epson Corporation. Epson Connection is a trademark of Epson America, Inc. SmartWay is a registered trademark of the U.S. Environmental Protection Agency. All other product and brand names are trademarks and/or registered trademarks of their respective companies. Epson disclaims any and all rights in these marks. Copyright 2026 Epson America, Inc. CPD-71801 5/26

Contact: