



inVue



L440
Door Brace Kit
PL920-01




A




1




2




Or




3




Or



4a




4b









5

If mounting the L440 to a glass shelf, please see the instructions for the glass mount strike plate (PL920-2).






6







CAUTION: Be sure that the shim is not wider than the thickness of the glass door.



CAUTION: Be sure that the glass goes between the 2 adhesive liners on the lock housing and that the lock is pressed against the bottom edge of the glass or shim (if needed).




14 Remove release liner #2




Note: Be sure that the lock housing is pressed firmly against the glass.


15



16a




16b Remove release liner #3




CAUTION: Hold the door in the closed position while pulling the #3 adhesive liner.

17




18




Note: If the key does not beep and makes a "knack-knack" sound it means the key was pulled away too soon. Try again and wait for the beep before pulling the key away.



19




20



21




Use Instructions:




Note: If the key does not beep and makes a “knack-knack” sound it means the key was pulled away too soon. Try again and wait for the beep before pulling the key away.

2



3



SD0459 Rev5 05/19/2017

inVue

www.invue.com

NA / LATAM // 704.752.6513 • 888.55.INVUE

EMEA // +31.23.8900150

APAC // +852.3127.6811

© 2016 InVue Security Products Inc. All rights reserved.
InVue is a registered trademark of InVue Security Products.