

SPECIFICATIONS

LIVE Door Controller (LL501):




LIVE Door Reader (LL511):




SPECIFICATIONS

Single Box Door Reader Plate (LL521):



Double Box Door Reader Plate (LL522):



PRODUCT ORDERING

ORDER CODE	DESCRIPTION	NOTES
System Components		
LL501-B	LIVE Door Controller	Includes cover, mounting plate, hardware, terminal plugs , flyback diodes & supervision resistors
LL511-B	LIVE Door Reader	Includes direct to wall mount & hardware
LL521-B	Single Box Door Reader Plate	Includes hardware
LL522-B	Double Box Door Reader Plate	Includes hardware
Replacement Parts		
LL523-B	Replacement Direct to Wall Reader Mount	
LL531-B	Replacement LIVE Door Controller Mounting Plate	
LL532-B	Replacement LIVE Door Controller Front Cover	
LL533	Replacement LIVE Door Controller Terminal Plug Kit	

©2026 InVue Security Products. No endorsement of InVue products has been made by any of the manufacturers of the products shown. Product is sold pursuant to InVue's warranty which can be found at www.invue.com/warranty.

THE AMERICAS 704.752.6513 • 888.55.INVUE
EUROPE, MIDDLE EAST & AFRICA +31.23.8900150
ASIA PACIFIC +852.3127.6811