




# INVUE

L440  
Glass Mount Strike Plate  
PL920-2





1a




**Note:** If the key does not beep and makes a “knack-knack” sound it means the key was pulled away too soon. Try again and wait for the beep before pulling the key away.


1b



2




Or



**CAUTION:** If the L440 will be installed on a double door fixture please see the instruction sheet for the door brace (PL920-01).


3a





3b







4







5






**CAUTION:** Be sure that the shim is not wider than the thickness of the glass door.




**CAUTION:** Be sure that the glass goes between the 2 adhesive liners on the lock housing and that the lock is pressed against the bottom edge of the glass or shim (if needed).

13 Remove release liner #1




Note: Be sure that the lock housing is pressed firmly against the glass.

14 Remove release liner #2




Note: Be sure that the lock housing is pressed firmly against the glass.


15



16a




16b Remove release liner #3




**CAUTION:** Hold the door in the closed position while pulling the #3 adhesive liner.

17




18




Note: If the key does not beep and makes a "knack-knack" sound it means the key was pulled away too soon. Try again and wait for the beep before pulling the key away.

19




20



### Use Instructions:

#### 1 PL901


To unlock the L440, hold the IR3 key up to the IR dot on the lock housing and press the button. When the key beeps remove the key.



**Note:** If the key does not beep and makes a "knack-knack" sound it means the key was pulled away too soon. Try again and wait for the beep before pulling the key away.


2

Open the door.



3

To lock the L440, shut the door and listen for the click to confirm that the L440 is locked.



SD0456 Rev6 06/13/2017

# invue

[www.invue.com](http://www.invue.com)

NA / LATAM // 704.752.6513 • 888.55.INVUE

EMEA // +31.23.8900150

APAC // +852.3127.6811

© 2016 InVue Security Products Inc. All rights reserved.  
InVue is a registered trademark of InVue Security Products.