

Step 1: With the tent open and fully deployed, collapse the telescoping ladder and secure it with the supplied buckle. The ladder should now be hanging freely allowing you to lay out the annex in its intended position beneath the tent.

Step 2: Located at the top of the annex, carefully slide the tongue into the grooves on the underside of the tent. See image for example. **It is easiest to start with the rear section of the annex into the tongue and groove, this would be the side closest to your vehicle. Once the rear tongue is slide into its groove, begin sliding the side tongues into the grooves along the underside of the tent



Step 3: Locate the zipper on both the top of the annex as well as the lower section of the tent fabric. Begin feeding the zipper of the annex onto to the lower section of the tent along all 3 sides.



Step 4: Locate the zipper on both the top of the annex as well as the lower section of the tent fabric. Begin feeding the zipper of the annex onto to the lower section of the tent along all 3 sides.

Step 5: Reposition the ladder to it's intended angle/position and lock it into place. Your annex is now ready to use.

Step 6: Reverse steps 1~5 to close up your annex and pack it back into the supplied storage bag.





SKY RIDGE - 20016

Pike 3-Person Annex Room

INSTALLATION INSTRUCTIONS



ANNEX STORAGE

- When storing the Annex off the vehicle, ensure it is packed away completely dry.
- Be careful not to drag the annex on the ground. This will damage the cover.
- Do not store directly on concrete floor.

ANNEX CARE

- Do not expose to petrol, oil, or solvents.
- New poly/cotton fabric will initially experience some weeping though the seams. This will reduce over time as the fabric cures, rest assured this is normal and will improve after each use.
- Well-worn products may be re-proofed using a good quality waterproofing solution. This is highly recommended after a full season's use.
- Dry your products thoroughly before closing them. We recommend air drying the annex in-between adventures to prevent mildew and mold growth. These can lead to discoloration, foul odors, and your tent material to degrade. Mold and mildew are not covered under warranty.
- Periodically lubricate zipper teeth with non-scented bees Wax to keep the zippers sliding freely. Make sure to keep them clear of dust and dirt. This will prolong the life of your zippers.
- To clean your fabric, use a mild detergent and warm water gently applied with a sponge. Rinse with a clean wet sponge and allow to completely air dry before storing.
- Avoid excess sun exposure to prolong the life of your product. UV rays can degrade fabrics and waterproof coatings. If your product begins to break down, we suggest washing the fabric with a mild detergent and water solution followed by a treatment of a water repellent designed for tent fabric. Consult your local outdoor retailer for other tent fabric care products and use as directed.