

**BOSCH**

300 Series VeroCafe


Key Tips Before Starting

Random units receive additional quality checks, which may result in small amounts of coffee bean residue or water droplets being present upon purchase.



Locate all parts inside the packaging

- Open the machine from the front to remove the **drip tray**. The **drip plate (grate)** can also be taken out for cleaning and should be realigned with the red floater during reassembly.
- The **milk frother** may be located on the left foam cover of the packaging or inside the Welcome Box.



Adjust the milk froth level

- Adjust and save the froth level to your preference for each milk-based drink. Saving the froth level on one drink option will not automatically save it for other milk-based drinks.
- Start by lowering the frother into a cup of milk or milk alternative.
- Press and hold the button for your drink of choice (Milk, Cappuccino, or Latte) until the light flashes on the button.
- Continue frothing and when the desired level is reached, press the button of your selected drink again.
- The appliance will froth milk to the same level next time that drink is brewed.



Using the water filter



- Refer to the Water Filter section of the user manual for **instructions on preparing the filter** before use.
- Insert the water filter into the water tank with **the “ring” (marked A-B-C) facing down**. Firmly press the filter down to secure.
- Shop for Original Bosch Mavea® Water Filters (SKU TCZ7003US) on **bosch-home.com/us** or **bosch-home.ca**. Designed specifically for your appliance.

SAMPLE ONLY



Register to activate Bosch | Concierge

- Leave the sticker on your appliance. To register your appliance, simply scan the QR Code. Any time after registration, rescan the QR Code to access warranty information, owner manual, self-help resources, and more.
- Or register online at: **registerbosch.com**
- Failure to register your appliance will not affect your warranty right.

Need help or have questions?
Please call Bosch Customer
Support on 1-800-701-5231.

Scan the QR code
for more tips

