## 120 VOLTS 15 AMP5

## 120 VOLTS 15 AMPS

(Use with a dedicated Circuit Breaker)



Clothes Washers Vacuum Cleaners Refrigerators Dehumidifiers Gas Appliances Air Purifiers Microwave Ovens Dishwashers LG Styler

## **240 VOLTS** 30 AMP5





Electric Dryers Large Air Conditioners

## **240 VOLTS** 50 AMPS





Electric Ranges Wall Ovens



Small Air Conditioners