



To install table leaf:

1. Unlock the table latch on the side of the table.
2. Gently pull each end of the table away from the center.
3. Place the table leaf in the open space in the center.
4. Lock the table latch.



To remove table leaf:

1. Unlock the table latch on the side of the table making sure to fully extend table.
2. Carefully remove the table leaf in the center space and return leaf to its protective storage bag.
3. Then gently place the leaf onto the leaf support rails underneath the table top.
4. Gently push each end of the table towards the center.
5. Lock the table latch.

