

# MARTIN®

## FURNITURE

### SET-UP INSTRUCTIONS FOR ITEM TUSCAN BOOKCASE


info@martinfurniture.com

N0:	Hardware List		Q'TY
A		Anti-tip hardware kit	1 PCS
B		Shelf holder	16 PCS
C		Allen wrench	1 PC
D		Bolt (1/4"*38mm)	4 PCS
E		Bolt (1/4"*19mm)	4 PCS
F		Lock washer	4 PCS
G		Flat washer	4 PCS


N0:	Parts List		Q'TY
1		Cabinet	1 PC
2		Shelf	4 PCS
3		Wooden cap	8 PCS

**Caution:** Please read all instructions before assembly and check the carton for any parts that may have come loose during shipment. It is recommended to **use two or more people during the assembly process.**


- 1 Shelf is screwed in place for shipping, use phillips head screwdriver to remove screws from shelf pins. Four screws per shelf. Refer to the drawing below:




- 2 Anti-tip hardware kit must always be used to prevent the console from tipping.



- 3 To connect multiple units together, align side panels of each cabinet making sure the holes are aligned. Levelers may need to be adjusted on either unit to achieve proper alignment.



- 4 Using the provided Allen wrench (C) lightly screw bolts through the interior of the each cabinet. Once all bolts are in place, tighten to secure in place.



### CARING FOR YOUR FURNITURE

- Use a soft, clean cloth that will not scratch the surface when dusting.
- Use of furniture polishes are not necessary. Should you choose to use polishes, test in an inconspicuous area first.
- Using solvents of any kind on your furniture may damage your furniture finish.
- Never use water to clean your furniture as it may cause damage to the finish.
- Always use coasters under beverage glasses and flowerpots.
- Liquid spills should be removed immediately. Use a soft, clean cloth, blot the spill gently. Avoid rubbing.
- Direct sunlight may damage wood finishes.
- Extreme temperature and humidity changes can cause warping, shrinking and splitting of wood furniture. It is best to keep furniture in a climate controlled environment.
- Always use protective pads under hot dishes and plates. Heat can cause chemical changes that may create spotting within the furniture finish.
- In the event that your furniture is stained or otherwise damaged during use, we recommend that you call a professional to repair your furniture.

Date: 10 / 2018

www.martinfurniture.com