



Pitbull Shaver ®
INSTRUCTION MANUAL
Pitbull Series



IMPORTANT SAFETY PRECAUTIONS

PLEASE READ CAREFULLY BEFORE USING THIS APPLIANCE.

Please follow all the precautions listed below for safety and to reduce the risk of injury or electric shock.

SAVE THESE INSTRUCTIONS!

Never pull the charger lead to unplug the appliance.

Use Skull Shaver recommended Charging Adapter only (5 volts, 1 amp, 5 watt output).

DO NOT USE ANY CHARGING PORT THAT OUTPUTS MORE THAN 5 VOLTS, 1 AMP, AND 5 WATTS OF OUTPUT.

Recharge the appliance using the supplied USB Cable and Skull Shaver branded adapter charger only. Do not use the supplied charger to charge any other appliance

Always check the blades for alignment before use.

Always check the appliance for damage prior to use. **Do not use** the appliance if the blade or shaver foil is damaged.

This appliance and charger have no user serviceable parts. Do not attempt to access the appliance covers.

Lubricate each blade with one drop of the provided oil solution once per month.

This appliance is for personal use only. It is not suitable for commercial use.

Do not place the appliance on or near a heat-sensitive surface.

Dry shaving can lead to your blade's foil increasing to a warm temperature.

Switch off the appliance before connecting it to the charger.

Switch off and unplug the appliance after use.

To protect against electric shock, never allow the charger to come into contact with water or any other liquid.

Never clean blade assemblies in hot water.

If you notice a decline in battery life, ability to hold a charge or shaver features not working as expected, please discontinue use of shaver.

Never leave the appliance unattended when connected to the main power supply.

Do not carry the appliance by the charger lead.

The batteries in this appliance are not user replaceable.

Make sure not to bend or press the shaver foil too hard. A damaged shaver foil may cause cuts while shaving. Also check the shaver foil for damage before shaving. The appliance includes a rechargeable battery; it must not be dismantled, exposed to an open flame, or short-circuited.

Avoid shaving if you are suffering from any damaged skin.



WARNING!

This appliance can be used by adults and children 13 years of age and over. It can also be used by persons with reduced physical, sensory or mental capabilities or lack of experience and knowledge if they have been given supervision or instruction concerning use of the appliance in a safe way and understand the hazards involved.

Children should not play with the appliance.

Cleaning and user maintenance shall not be performed by children without supervision.

KNOW YOUR APPLIANCE

1. Protective cap
 2. Shaver head
 3. Shaver head insert slot
 4. Shaver on/off button
 5. Charging indicator (varies between models)
 6. Charging port
 7. Rinse Stand*
 8. Travel case*
 9. USB Cable
 10. Charging Adapter*
- Blade head options are the 3 head, 4 head PRO, and 5 head*

Optional items sold separately marked with a star ()*



CHARGING

The shaving system is equipped with overcharge protection to protect the rechargeable battery from overcharging even if the shaver remains plugged in.

1. Make sure the appliance is **OFF** before charging
2. Use Skull Shaver recommended Charging Adapter only (5 volts, 1 amp, 5 watt output).
DO NOT USE ANY CHARGING PORT THAT OUTPUTS MORE THAN 5 VOLTS, 1 AMP, AND 5 WATTS OF OUT PUT.
3. Put the adapter plug into a suitable mains supply outlet. The charging indicator will illuminate.
4. Please charge the shaver for **at least** 2.5 hours. Disconnect the shaver from the adapter when charging is complete.

OPERATION

Shaving the head and face

Our recommendation would be to use a wet shave with a brush.

A shaving brush is able to whip up a soft lather while keeping your hands clean.

Use of shaving cream keeps the shaver blades and your skin cool and comfortable.

You can also use this shaver for a dry shave.

General Operation

Remove protective cover and turn on the shaver.

Against the beard, slightly press the shaver to the face and move the shaver to start shaving.

Against the hair, slightly press the shaver to the head and move the shaver to start shaving

Please replace the protective cover after shaving.

New to this shaver? We recommend to allow an adaptation period of three (3) weeks, during which you should shave regularly (at least four (4) times per week) to allow your hair and skin to adapt to the new shaver.

Glide Mode. Do not squeeze or ball your fingers when using easy gliding motions.



Backhand and Forehand Glide (for Butterfly Shaver only)



For wet shaving:

Shaving cream, shaving gel, or shaving foam will help you achieve the closest possible shave. Please avoid using shaving oil as it may build up inside the blades. Frequently rinse blades when wet shaving. For a more thorough cleaning, run the blades in warm water for up to 5 minutes.

Pitbull Silver Only*

Low battery indicator:

Three lit LEDs means the battery is fully charged. LEDs will turn off as the battery discharges. A single, blinking LED means you have less than 10 minutes of operation remaining. Recharge until the indicator shows three lit LEDs, indicating a full charge.

Pitbull Platinum Only*

The Pitbull Platinum line comes with a Travel Lock. This feature prevents your shaver from accidentally turning on while packed. It also comes with a Rinse Indication feature.

The rinse indication feature is a built-in feature that will show as a faucet symbol if your blades are clogged. It may also show as you clean your blades which you can disregard.

To turn on the travel lock:

Press and hold the On/Off switch for a few seconds and Lock icon will appear.

To turn the lock off:

Press and hold the On/Off switch for a few seconds and Lock icon will turn off. The shaver will be powered on and ready for immediate use.



Do not use this appliance to shave longer than .4 millimeter hair (normally two days hair growth). Shaver is splash resistant, but please do not submerge shaver under water. Submersion may cause premature failure and will void warranty.

For optimal performance, rinse frequently while shaving.

CLEANING

Easy 5 second rinse. Keep your blades clean and sharp!


It's simple and easy to clean and maintain the shaver head to keep it operating optimally as long as possible! Easy to follow instructions can be seen below:

		
1. Get clean (preferably warm) water in the Platinum Rinse Stand* or cup.	2. After each shave, dip the shaver head only in the water as shown.	3. Turn shaver on for five (5) seconds only. This will adequately clean the shaver head.

*Platinum Rinse Stand sold separately

For optimum performance rinse frequently while shaving.

How to open 3 or 4 blade shaver head for cleaning.



Once opened simply press together B1 and B2 to close.
For optimum performance rinse frequently while shaving.

STORAGE AND TRAVELING

If you do not plan on using the appliance for an extended period of time, please store it carefully. Ensure the unit is switched off and dry. Store the unit in a cool, dry place. Make sure the appliance is kept out of reach of children. Protect delicate cutters of shaver head by using a hard-shell travel case similar to the Skull Shaver Travel Case.

REPLACE THE SHAVER FOIL



The shaver foil is of ultimate importance for getting a smooth shave. Depending on the usage of shaver, we recommend replacing it every three (3) months or when you feel a pull on the hairs instead of a clean cut to ensure optimal shaving performance. A worn-out shaver foil can cause skin irritation. The shaver foil can only be replaced together with the cutting head. You only have to remove the old cutting head and replace it with a new one. Avoid shaving if you are suffering from any open wounds, skin infection, or damaged skin.



WARNING!

Stop using this appliance if shaver head or foil is damaged.

TECHNICAL DATA

Model no.	Pitbull Shaver® Silver	Pitbull Shaver® Gold	Pitbull Shaver® Platinum
Rechargeable Batteries	LI 1000mAh 3.7V	LI 18500-1400mAh 3.7V	LI 18500-1400mAh 3.7V
Power Consumption	5 W	5 W	5 W
Power adaptor input	100-240VAC 50/60Hz	100-240VAC 50/60Hz	100-240VAC 50/60Hz
Power adaptor output	5V 1000MA	5V 1000MA	5V 1000MA
Product Dimensions	8.2x5.8x8.5cm	8.2x5.8x8.5cm	8.2x5.8x8.5cm
Net Weight	Shaver :180g Adapter: 66g	Shaver :183g Adapter: 66g	Shaver :186g Adapter: 66g
Charge Time	2.5 Hours	2.5 Hours	2.5 Hours
Discharge Time	70 Minutes	90 Minutes	90 Minutes
Protection Class	IPX5	IPX5	IPX5

DISPOSAL INFORMATION



ELECTRICAL PRODUCTS SHOULD NOT BE DISPOSED OF WITH HOUSEHOLD WASTE. PLEASE RECYCLE WHERE FACILITIES EXIST. CHECK WITH YOUR LOCAL AUTHORITY FOR RECYCLING ADVICE FOR YOUR STATE OR COUNTRY OF RESIDENCE.

Prop. 65 Warning for California Residents

WARNING: This product may contain chemicals known To the State of California to cause cancer, birth defects, or other reproductive harm.

Pitbull Shaver® is protected by several of the following trademarks and patents worldwide:
More up to date information is available at www.skullshaver.com/ip

USA LIMITED WARRANTY



This product is covered by a warranty for 12 months from the date of purchase.
Pitbull Platinum Models are exclusively covered by a 2 Year Warranty.

Any defect that arises due to faulty materials or workmanship will be repaired or replaced with similar or newer part as long as the product was purchased from the authorized retailer or directly from Skull Shaver LLC. To make a warranty claim, do not return this product to the store where purchased. To obtain service under this warranty or to receive a refund within the first 30 days from date of purchase, contact our warranty department below and obtain a Return Authorization number.

You may either call our Customer Support line directly:

USA Tel: 609-284-9780

OR

You may submit an online form to request service under this warranty:

USA RMA Submission Form: <https://skullshaver.com/rma>

This warranty is void and no repair/replacement will be made under this warranty or otherwise if:

1. The product is modified in any manner or repaired by anyone other than Skull Shaver LLC or our authorized service provider.
2. The product has been used commercially or subjected to unreasonable use.
3. No other written express warranty is given.

Any implied warranty, including any warranty of merchantability which may arise from purchase or use, is limited to the 1-year period provided in this express warranty. Some states may not allow such limitation, so it may not apply to you. No responsibility is assumed for incidental or consequential damages of any type, or for the use of unauthorized attachments. Some states may not allow the exclusion or limitation of incidental or consequential damages, so the limitation or exclusion may not apply to you. Warranty is valid in the USA only. Outside USA, check with the retailer for our authorized distributor's warranty.

For additional details regarding our warranty policy:

USA warranty: <https://skullshaver.com/pages/warranty>

UK/EU LIMITED WARRANTY



This product is covered by a warranty for 2 Years from the date of purchase.

Any defect that arises due to faulty materials or workmanship will be repaired or replaced with similar or newer part as long as the product was purchased from the authorized retailer or directly from Skull Shaver EU Ltd. To make a warranty claim, do not return this product to the store where purchased. To obtain service under this warranty or to receive a refund within the first 30 days from date of purchase, contact our warranty department below and obtain a Return Authorization number.

You may either call our Customer Support line directly:

UK Tel: 0203 372 4109

OR

You may submit an online form to request service under this warranty:

UK/EU RMA Submission Form: <https://skullshaver.eu/rma>

This warranty is void and no repair/replacement will be made under this warranty or otherwise if:

1. The product is modified in any manner or repaired by anyone other than Skull Shaver EU Ltd or our authorized service provider.
2. The product has been used commercially or subjected to unreasonable use.
3. No other written express warranty is given.

Any implied warranty, including any warranty of merchantability which may arise from purchase or use, is limited to the 1-year period provided in this express warranty. Some states may not allow such limitation, so it may not apply to you. No responsibility is assumed for incidental or consequential damages of any type, or for the use of unauthorized attachments. Some countries may not allow the exclusion or limitation of incidental or consequential damages, so the limitation or exclusion may not apply to you. Warranty is valid in the UK/EU only. Outside UK/EU, check with the retailer for our authorized distributor's warranty.

For additional details regarding our warranty policy:

UK/EU warranty: <https://skullshaver.eu/pages/warranty>

End