


Chair Assembly Instructions

Your chair comes packaged in one box.

DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.


Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching the finish.




Parts List		Hardware List	
A 1 x Seat Back		* E 9 x Bolts With Lock Washers & Flat Washers	M8 x 60mm
B 1 x Seat		* F 1 x Hex Key	M6 x 77x 27mm
* C 2 x Front Legs		* Replaceable Parts	
D 1 x Dust cover		Hardware bag can be found under the seat.	

Assembly


Step 1



Step 2




Step 3




Step 4

Warning: Please make sure all bolts are fully tightened or chair will feel unstable. Once tightened, go over all bolts to tighten again until fully secure and stable.



Step 5



Your style may differ from images. Care for your furniture by periodically tightening all bolts using the included hex key.

About your furniture piece:

- Softening of foam is natural and will happen over time with use.
- Fabric will fade or discolor in direct sunlight. Minimize exposure to direct sunlight to extend the life of your furniture.
- Wood grain, knots, streaks, and color variation occur naturally in wood and are not considered defects.

CAUTION: Tighten all components securely before use. Failure to do so may result in personal injury.

Customer Support: 866-238-0531
Mon-Fri 8:00am - 4:30pm CST
customerservice@furniturequestions.com