

# Chair Assembly Instructions

Your chair comes packaged in one box.






**DO NOT use any sharp objects to open plastic wrapped components as damage to product or components may result.**


Carefully remove all of the components from the packaging and set aside for assembly. Assemble on a soft surface to prevent scratching the finish.

Estimated Assembly Time in Minutes

★ ☆ ☆  
 <15 <45 60+


## Parts List

<p><b>A</b> 1 x Seat</p> 	<p>* <b>D</b> 2 x Back Legs</p> 
<p><b>B</b> 1 x Back</p> 	<p>* <b>E</b> 4 x Washers</p>  <p>φ47mm</p>
<p>* <b>C</b> 2 x Front Legs</p> 	<p>* Replaceable Parts</p>




## Assembly



### Step 1



### Step 2



### Step 3



Your style may differ from images. Care for your furniture by periodically tightening all legs.

**CAUTION:** Tighten all components securely before use. Failure to do so may result in personal injury.

About your furniture piece:

- Softening of foam is natural and will happen over time with use.
- Fabric will fade or discolor in direct sunlight. Minimize exposure to direct sunlight to extend the life of your furniture.
- Wood grain, knots, streaks, and color variation occur naturally in wood and are not considered defects.

Customer Support: 866-238-0531  
 Mon-Fri 8:00am - 4:30pm CST  
[customerservice@furniturequestions.com](mailto:customerservice@furniturequestions.com)