

Last update: November 11.2019

Please note:

This firmware version is applicable for OTT Parsivel² with order numbers 70.210.001.3.0 (without screen heating) and 70.210.002.3.0 (with screen heating). Devices without screen heating (70.210.001.3.0) can be updated as of the previous version V 1.11.0

How to install the update

- Download the file "Parsivel2 Firmware V2.11.6.bin" to your PC.
- Install the update as described in chapter 11.5 of the OTT Parsivel² operating manual.

[Get the newest release](#)

Release Notes

V 2.11.6 (11.11.2019)

- New operating mode has been implemented: "Sensor head heating with reduced heating power". This enables the use of a power supply with 50 watts rated power at 24 volts. This operating mode is deactivated in the factory default setting.
- Control of screenheating has been implemented. This function is only available for devices with screen heating (order number: 70.210.002.3.0).
- Various bugfixes

V 2.11.1 ... V 2.11.5

Internal versions; not published

V 2.11.0 (24.11.2016)

Various bugfixes

V 2.10.0 (25.05.2016)

- Two value numbers were added to the output telegram:
 - 60 (amount of all detected particles) and
 - 61 (list of all detected particles with particle size and -velocity)
- Now supports instruments with renewed hardware, produced after June 2016 (serial numbers > 390 640)
- Various bugfixes

V 2.02.6 (19.05.2015)

Various bugfixes

V 2.02.5 (26.02.2014)

- OTT Parsivel² now supports SDI-12 standard, version 1.3 (so far 1.1)
- Various bugfixes

