

Instructions for SL1000 Portable Parallel Analyzer™ Software Update

- 1.) Download the [software update](#) to PC.
- 2.) Plug instrument into AC power.
- 3.) Select Main Menu > Settings > Meter > USB Device Class > Mass Storage
- 4.) Connect USB cable to instrument and PC. The SL1000 Portable Parallel Analyzer™ should be automatically recognized by the PC.
- 5.) Drag/drop software zip file directly into instrument folder (Do not open zip file, just drop whole folder in).
- 6.) Safely remove USB connection.
- 7.) From the instrument Main Menu select Settings > Meter > Upgrade Software.

The unit will then automatically run the upgrade if found.

Verify the software update completed by selecting from the instrument Main Menu>Info>Meter and check the S/W Version matches the downloaded version.