## ÌnVue

Bottle Cap OneKEY Bottle Cap, Small, Medium & Large, RF & AM NBCS-AM/RF, NBCM-AM/RF, NBCL-AM/RF





 Press the button on the Bottle Cap.
NOTE: Be sure that the lip of the bottle sits above the cables within the Bottle Cap.

2



3 Twist the clear cap to tighten the cables and secure the bottle. Make sure that the bottle is secure.



CE 🔊

SD0648 Rev2 11/15/18

ÌnVue

www.invue.com

NA / LATAM // 704.752.6513 • 888.55.INVUE EMEA // +31.23.8900150 APAC // +852.3127.6811

 $\hfill \ensuremath{\textcircled{}}$  2018 InVue Security Products Inc. All rights reserved. InVue is a registered trademark of InVue Security Products.

To release the bottle cap, insert a OneKEY into the port on the front of the Bottle Cap and press the button on the key. The button on the Bottle Cap will pop up.



4b If the button fails to pop up, twist the cap back and forth slightly, while pressing the button on the OneKEY, to relieve any back pressure on the Bottle Cap.

