

S3100V Sensors & Stand



IMPORTANT:

Ensure that the LoRa Gateway and the InVue Alarm Nodes have been configured with the InVue LIVE app before beginning the installation. The stand should NOT be powered at this point.

Note:

All LIVE Display devices will need to be pre-enrolled before starting installation and enrollment into the LIVE Display ecosystem.

Record the Device ID numbers of any LIVE sensors and devices being installed and contact InVue Tech Support via phone or email.
1-888-55-INVUE
techsupport@invue.com




If you already have login information for the app proceed to the next step. Otherwise, see below.

First time setup

Before using the app, users and site information must be set up within the InVue LIVE web portal.

This should be completed by a manager or admin using the information sent by InVue Customer Service.

If you are a manager or admin and have not received this information via email from InVue Customer service, please submit a service request.




- 1 If not already installed on your smart phone or tablet, download the InVue LIVE Display app from the Google Play store. Log in using the information provided by your manager or admin.

- 2 **Enrolling Sensors:**
Locate the code on the sensor.



- 3 Within the InVue LIVE app, use the camera on your device to scan the code and enroll the sensor. Fill out the information for the sensor and the device that will be displayed.



- 4 If you have not already done so, when receiving this screen, record the Device ID number of the S3100V Sensor (and any other LIVE components) and contact InVue Tech Support to complete the Pre-Enrollment Process.




- 5 **Sensor Installation:**
Place the adapter appropriate for your fixture onto the sensor. The Product Availability hangbar adapter is shown below.



- 6 Plug the power connector on the sensor into the device.

IMPORTANT! Do NOT remove the red tab at this time!

S3100V Sensors & Stand



- 7 Ensure that the sensor sits squarely on the device.



- 8 While holding the sensor in place with one hand, pull the red tab to expose the adhesives.



- 9 Apply pressure for at least 10 seconds.



- 10 **Stand Installation:**
To install the stand, begin by using the provided alcohol wipe to clean the area where the stand will be placed. Allow it to dry completely.



- 11 Peel the clear film from the 2 adhesives on the bottom of the stand.



- 12 Place the stand where desired, with the logo facing away from the customer position, and apply pressure for at least 10 seconds.



- 13 Plug the power cable into a PS515 power supply. Plug the power supply into a power outlet.



- 14 Place the sensor and device into the stand. The gold LED on the sensor will illuminate to indicate that it is receiving power.

S3100V Sensors & Stand

LIVE Vertical Wireless

Model: VRTWRLSS

Hereby, InVue Security Products, Inc. declares that the radio equipment type VRTWRLSS is in compliance with Directive 2014/53/EU. The full text of the EU declaration of conformity is available at the following internet address:
<https://invue.com/product-compliance/>

EU Importer:
INVUE SECURITY PRODUCTS B.V.
Saturnusstraat 17 D
2132 HB Hoofddorp
The Netherlands
+31 23.8900150

Manufacturer:
InVue Security Products, Inc.
9201 Baybrook Lane
Charlotte, NC 28277, USA

Maximum output power is 5.2V. Operation is limited to the following channels/bands as supported in the country of use: 863-870MHz, 902-927MHz

Accessories and Software to operate as intended:

Zone Manager 30 (DBD702) and Zone Manager 52 (DBD701) establish wireless display security and has two alarm settings that are activated when a sensor enters an Alarm Zone, or when it exits a Secure Zone. Software version: FW0219_2021-01-05_810_0_x.

FCC Compliance

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) this device may not cause harmful interference, and (2) this device must accept any interference received, including interference that may cause undesired operation.

Changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate the equipment.

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation.

If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

ISED Regulatory Compliance

This device contains licence-exempt transmitter(s)/receiver(s) that comply with Innovation, Science and Economic Development Canada's licence-exempt RSS(s). Operation is subject to the following two conditions:

- (1) This device may not cause interference.
 - (2) This device must accept any interference, including interference that may cause undesired operation of the device.
- This equipment complies with IC RSS-102 radiation exposure limits set forth for an uncontrolled environment.

L'émetteur/récepteur exempt de licence contenu dans le présent appareil est conforme aux CNR d'Innovation, Sciences et Développement économique Canada applicables aux appareils radio exempts de licence. L'exploitation est autorisée aux deux conditions suivantes :

- (1) L'appareil ne doit pas produire de brouillage;
 - (2) L'appareil doit accepter tout brouillage radioélectrique subi, même si le brouillage est susceptible d'en compromettre le fonctionnement.
- Cet équipement est conforme aux limites d'exposition aux radiations IC CNR-102 établies pour un environnement non contrôlé.

