


**BOSCH**

500 Series VeroCafe

## Key Tips Before Starting

Random units receive additional quality checks, which may result in small amounts of coffee bean residue or water droplets being present upon purchase.




### Locate all parts inside the packaging

- Open the machine from the front to remove the **drip tray**. The **drip plate (grate)** can also be taken out for cleaning and should be realigned with the red floater during reassembly.
- The flexible milk hose is located inside the Welcome Box.



### Adjusting the temperature

- There are 3 coffee temperature settings: **Normal, High, and Max.**
- Press the **Settings**  button.
- Use the **arrow (▲ or ▼)** keys to navigate and **press OK** to select and save the setting.



### Using the water filter



- Refer to the Water Filter section of the user manual for **instructions on preparing the filter** before use.
- Insert the water filter into the water tank with **the “ring” (marked A-B-C) facing down**. Firmly press the filter down to secure.
- Shop for Original Bosch Mavea® Water Filters (SKU TCZ7003US) on **bosch-home.com/us** or **bosch-home.ca**. Designed specifically for your appliance.

SAMPLE ONLY



### Register to activate Bosch | Concierge

- Leave the sticker on your appliance. To register your appliance, simply scan the QR Code. Any time after registration, rescan the QR Code to access warranty information, owner manual, self-help resources, and more.
- Or register online at: **registerbosch.com**
- Failure to register your appliance will not affect your warranty right.

Need help or have questions?  
Please call Bosch Customer  
Support on 1-800-701-5231.

Scan the QR code  
for more tips

