

Diagnosing Ultra Low Range CL17sc Indicator Lights

Measurement Cycle Lights



- 1** Analyzer is flushing the cell in preparation for a new measurement.
- 2** Analyzer is adding and mixing reagents.
- 3** Analyzer is performing a measurement.



Diagnosing Ultra Low Range CL17sc Indicator Lights

Three-Color Status Lights



Green - Analyzer is operating normally.



Amber - Analyzer needs attention to prevent a future failure. Measurements will continue when status light is amber.



Red - Analyzer needs immediate attention. Measurements stop when status light is red.

In the event of an amber or red status light, navigate to the analyzer's diagnostics menu for more information.



Be Right™