




## Single-Pole Lightguide Installation Instructions

1. Remove the protective cover from the spot lamp's lightguide holder.
2. Remove the protective end caps from the lightguide. Visually inspect the two ends of the lightguide to verify no foreign material is present. The Dymax liquid-filled lightguide ends can be cleaned with isopropyl alcohol as required to remove foreign material and deposition from outgassing.
3. Insert the large end of the lightguide into the holder until it snaps into place.
4. If desired, the lightguide may be fastened into place by tightening the securing set screw installed in the lightguide holder. A hex wrench is provided with the unit for this purpose. The setscrew should be tightened gently to prevent damaging the lightguide.

Note: Multi-leg lightguides should be balanced by rotating the lightguide to obtain the desired UV intensity of each leg before tightening the setscrew.

5. The lightguide is now installed and is ready for use. The end of the lightguide should be periodically cleaned with isopropyl alcohol. Adhesive build-up may be removed from the end of the lightguide by using a razor blade or razor knife.

**Please Refer to Component User Guides for Detailed Operating Instructions.**



**Figure 1.** Lightguide Holder with protective cover and without



**Figure 2.** Tighten Set Screw with Hex Wrench

[www.dymax.com](http://www.dymax.com)

#### Americas

USA | +1.860.482.1010 | [info@dymax.com](mailto:info@dymax.com)

#### Europe

Germany | +49 611.962.7900 | [info\\_de@dymax.com](mailto:info_de@dymax.com)  
Ireland | +353 21.237.3016 | [info\\_ie@dymax.com](mailto:info_ie@dymax.com)

#### Asia

Singapore | +65.67522887 | [info\\_ap@dymax.com](mailto:info_ap@dymax.com)  
China | +86.755.83485759 | [dymaxasia@dymax.com](mailto:dymaxasia@dymax.com)  
Hong Kong | +852.2460.7038 | [dymaxasia@dymax.com](mailto:dymaxasia@dymax.com)  
Korea | +82.31.608.3434 | [info\\_kr@dymax.com](mailto:info_kr@dymax.com)

© 2021 Dymax Corporation. All rights reserved. All trademarks in this guide, except where noted, are the property of, or used under license by Dymax Corporation, U.S.A.

The data contained in this bulletin is of a general nature and is based on laboratory test conditions. Dymax does not warrant the data contained in this bulletin. Any warranty applicable to the product, its application and use is strictly limited to that contained in Dymax's standard Conditions of Sale. Dymax does not assume responsibility for test or performance results obtained by users. It is the user's responsibility to determine the suitability for the product application and purposes and the suitability for use in the user's intended manufacturing apparatus and methods. The user should adopt such precautions and use guidelines as may be reasonably advisable or necessary for the protection of property and persons. Nothing in this bulletin shall act as a representation that the product use or application will not infringe a patent owned by someone other than Dymax or act as a grant of license under any Dymax Corporation Patent. Dymax recommends that each user adequately test its proposed use and application before actual repetitive use, using the data contained in this bulletin as a general guide. QS016 08/25/2021