Direct Send and Resource Export

Create Resource Export File 2

Data Types Supported by each File Format 5

Operators 5

Crops 5

Send File to Connected AGCO machine via TaskDoc API 6

Send to Vehicle (PTx Trimble Display) 7

View Send History 8

Download 9

Export Resource Files to Connected Displays 10

Direct Send Remote Output Files to PTx Trimble Displays 11

© 2024, All rights reserved. PTx and associated logo are trademarks of AGCO Corporation. Trimble and the Globe & Triangle logo are trademarks of Trimble Inc, registered in the United States and in other countries. All other trademarks are the property of their respective owners. AGDOCS-501

Create Resource Export File

1. Navigate to Data Transfer > Resource Exports:
2. Click “+ Create” drop down
3. Select Export All of Customize Export
    a. Export All will create a file with all resources from your organization
    b. Customize Export allows you to select which specific resources to put in the file
4. Click the Checkbox “Customize Field Resource Selection” if you want to choose specific boundaries, guidance lines or landmarks for each field
5. Select which file format you would like to download in
    a. The options for what can be exported changes based on the file format you chose.



    b. Click through the different file formats and note the custom export page changes based on what each file type can support.

6. Click through each resource page and select what you would like to include in your export
    a. On the Fields tab, you can select certain actions for the fields to help you filter what you want to add. Click on the Select Actions dropdown and select what element you want to filter on. When you use the select actions drop down, it automatically selects all resources that match the selection.



    b. You can also filter to limit the fields shown by date, client, farm, field, guidance pattern, operation type, swath width, and landmark type



    c. On the materials page, click through the subpages to select resources from each category.



7. Add resources by checking them in the list (not applicable for export all)
8. Review in the Summary tab
9. Click Download Button



Note – Files are sent to a display, altering files on the list does not impact what is on each display.

Data Types Supported by each File Format

Data Type	Client, Farm, Field	Boundaries	Guidance Lines	Landmarks	Equipment	Materials	Operators	Crops
PTx Trimble *AgGPS*	✓	✓	✓	✓	✓	✓	-	-
PTx Trimble *AgData*	✓	✓	✓	✓	✓*	✓	-	-
ISOXML	✓	-	✓	✓	✓	✓	✓	✓
CNH *.cn1*	✓	-	✓	✓	✓	✓	✓	-
AgLeader *Integra*	✓	-	✓	-	✓	✓	✓	-
AgLeader *In Command*	✓	-	✓	-	✓	✓	✓	-
John Deere	✓	✓	✓	✓	✓	✓	✓	✓
Loup RDS	✓	✓	✓	✓	✓	✓	✓	✓

*Precision-IQ vehicle and implement profiles included

Send File to Connected AGCO machine via TaskDoc API

You can send exports directly to AGCO machines with TaskDoc

1. Select Resource Exports from the Data Transfer dropdown
2. Select the Send to TaskDoc option
3. Chose the vehicle you want to send the export to then select next



4. You can go through the tabs to select the information you want to export
5. On the summary page, you can view all your selections. Click send when you are finished



Send to Vehicle (PTx Trimble Display)

1. Navigate to Data Transfer > Resource Exports:
2. Click on a resource export in the list
3. Click Send to Vehicle in details tab OR
4. Select Send History tab and click Send to Vehicle OR
5. Select the three-dot icon on the resource export in the list and click Send to Vehicle
6. Make vehicle selection in Send to Vehicle dialog

Note – the AgData file format can only be sent to Precision-IQ displays.



View Send History

1. Click on a resource export in the list
2. In the Summary panel select Send History
3. View the status of the sent file
4. Click the 3-dot button next to the send history
    a. Cancel the send if in pending state
    b. Resend if in the sent state



Download

1. Navigate to Data Transfer > Resource Exports
2. Click on a resource file from the list
3. Click “Download”

OR

4. Click on the 3-dot menu on the file in the list
5. Click “Download”



Export Resource Files to Connected Displays

1. Log in to FarmENGAGE online
2. Click the Data Transfer tab (side menu)
3. Select Resource Exports from the left navigation menu
4. Select “+Create” in the top right corner



5. Chose to export all data or to customize an export
6. Name the file and choose to either download and choose the file format or directly send the export to the vehicle.
7. For custom export, click through fields, equipment, and materials and chose what to export
8. On the summary page, view what is being exported and click download or send to export.



Direct Send Remote Output Files to PTx Trimble Displays

1. Log in to FarmENGAGE online
2. Navigate to Data Transfer > Resource Exports
3. Click the upload and send button
4. Select ‘Remote Output (.shp, .shx, .dbf)’
5. Upload the remote output .shp, .shx, and .dbf files
    a. All three files are needed, to upload and send
6. Choose which display to send the Remote Output file to
7. Click ‘Send’
8. On the display
    a. The sent file will be available in the Remote Output folder in Data Transfer
    b. If a task is started with a remote output enabled implement, the remote output drawer is available to the user

Note: There is no way to view the send history of remote output files, and the uploaded file will not be shown in the resource export list