

# INSTALLATION GUIDE

**Note:** This product must be installed by a licensed plumber. This is a general installation guide - there are many factors involved that can alter the installation method. **AU/NZ:** For installations within Australia and New Zealand, this product must be installed in compliance with AS/NZS 3500. **UK:** For installations in the United Kingdom this product must be installed in compliance with the Water Supply (Water Fittings) Regulations and Water Supply (Water Fittings) (Scotland) Byelaws. **Other:** For installations outside these countries, this product must be installed in compliance with the standards in your respective country.



## SCOPE OF USE

Installation is subject to the requirements of the applicable regulatory authority, the National Construction Code Volume Three - Plumbing Code of Australia, associated reference standards as applicable at the time and AS/NZS 3500.

For water supply use only.

Suitable for indoor use.

Test before concealing.


|                          |   |
|--------------------------|---|
| TEMPERATURE RATING       | Maximum continuous working temperature 75°C<br>If the water temperature exceeds 75°C, an approved tempering valve must be fitted                |
| PRESSURE RATING          | Recommended minimum working pressure 150kPa<br>Recommended maximum working pressure 500kPa<br>Hot and cold water inlet pressure should be equal |
| SUITABLE HOT WATER UNITS | Storage tank: Yes<br>Continuous Flow: Yes<br>Gravity Feed: Not suitable   |
| LEAD FREE COMPLIANT      | No  |



Regularly clean with mild liquid detergent or soap and water



DO NOT use cream cleaners or bleach. These substances are abrasive



DO NOT use cleaning pads with abrasive surfaces as this may scratch the material