




SOLA OUTDOOR SHOWER SET



Note: Dimensions are nominal measurements only

SPECIFICATIONS	
RECOMMENDED USE	Domestic
MATERIAL	Stainless Steel 316
PRESSURE RATING	Recommended minimum working pressure 150kPa Recommended maximum working pressure 500kPa Hot and cold water inlet pressure should be equal
TEMPERATURE RATING	Maximum continuous working temperature 75°C If the water temperature exceeds 75°C, an approved tempering valve must be fitted
STANDARDS	WELS Star Rating 3 star - 9L/min S16553, WM-032145

Disclaimer: Products in this specification manual must by regulation be installed by licensed and registered trade people. The manufacturer/distributor reserves the right to vary specifications or delete models from their range without prior notification. Dimensions are nominal measurements only. Dimensions and set-outs listed are correct at time of publication however the manufacturer/distributor takes no responsibility for printing errors. All ABI Products are designed in Australia. Copyright ABI Interiors Pty Ltd 2021.

INSTALLATION GUIDE

Note: This product must be installed by a licensed plumber. This is a general installation guide - there are many factors that are involved that can alter the installation method. This product install must comply with AS/NZS 3500, for installs outside Australia and New Zealand, the standards in your respective country must be adhered to by your licensed tradesperson


Important!

There are many installation options for this product. We recommend consulting your designer or plumber prior to commencing any works to determine the most appropriate method for you. **Please note this product must not be installed encased in concrete to allow access to water connections.** See examples of correct installation methods below. ABI's warranty is void if this product is installed incorrectly or encased in concrete.


Note: Drainage not shown, please ensure drainage is compliant with your local standard

WARNING!


ABI'S WARRANTY IS VOID IF THIS PRODUCT IS INSTALLED INCORRECTLY OR ENCASED IN CONCRETE.



Installation on top of concrete slab with **timber decking**




Installation on top of concrete slab with **fine stone fill, decorative stone and removable paving**




Installation on top of concrete slab with **fine stone fill and decorative stones**


1. Use the base as a template to mark holes.
2. Place lid on top to check level. Double check your position is correct.




1. Tighten nuts to secure base down.
2. Attach hot and cold water pipes (use appropriate thread sealant).




5. Attach and bolt body to base.




2. 1. Remove base, drill the holes into the concrete footing to a depth of 60mm.
2. Insert dyna bolts.



4. 1. Trim plastic housing to be level with floor structure (if required).
2. Secure water pipes appropriately.




6. Connect shower head to Arm.




7. Connect Arm to Body.
 1. Connect internal flexi-hoses.
 2. Push together and use an alan key to fasten set screw.


* Test and check all water points for leaks.



9. 1. Attach hand held shower head.
2. Test and commission.



8. 1. Attach floor covering.
2. Push cover plate down.



In the box

1. Base
2. Lid
3. Cover Plate
4. Body
5. Arm
6. Shower Head
7. Hand-held Shower Head
8. Hose
9. Set Screw
10. 20mm Bolt x6
11. 90mm Dyna Bolt set x10
12. Alan key 6mm
13. Alan key 3mm

*ENLARGED PARTS

