



INVUE

WS2/W2000
USB-A Charging Cradle
ZW2101




Note: See the instructions included with your stand or sensor for full system installation information.


- 1** Use the provided alcohol wipe to clean the fixture where the stand will be placed. Allow it to dry completely.




- 2** Plug the band clamp cable into the bottom of the stand.




- 3** Peel the clear film from the adhesive on the bottom of the stand.




- 4 Optional:**
Route the power cable through a hole or slot in the fixture.




- 5** Place the stand in the desired location and apply pressure for at least 10 seconds.




- 6** Use a key fob tool to remove the plug from the side of the cradle.




- 7** Remove the plug and screw from the side of the cradle.




8 Remove the original cradle from the stand.




9 Place the custom charger cradle onto the stand.




10 Secure the custom charger cradle with the screw. Insert the plug into the hole in the side on the cradle.




11 Use the provided alcohol wipe to clean the underside of the wearable that will be displayed. Allow it to dry completely.




12 Use a TT8 bit to loosen the screw in the band clamp.




13 Open the band clamp.




14 With the watch in its normal orientation, identify the back band. This will be the band that will be installed into the band clamp.




15 Place the back band of the wearable into the open band clamp with the wearable face down.




- 16 Plug the universal flex sensor into the port on the inside of the band clamp over the wearable.




- 17 Adjust the wearable so that the area between the 2 white lines on the flex sensor (the shaded area in the below image) will sit over the "hinge" area (the area where the band connects to the watch body) of the wearable.




- 18 Peel the liner from the adhesive portion of the flex sensor.




- 19 Press the flex adhesive against the bottom of the wearable for at least 10 seconds. Ensure that all of the oval is adhered to the wearable and that no gap is visible.




- 20 Close the band clamp over the watch band and flex sensor.




- 21 Press down on the band clamp and use a TT8 bit to tighten the screw in the band clamp. Do NOT overtighten.




- 22 Place the wearable onto the cradle.




- 23a If using a WS2 stand, plug the stand's power cable into a POWERED Zips alarm unit or S2865 power/alarm box.




- 23b** If using a W2000 stand, plug the stand's power cable into a PS515 power supply and plug the power supply into a power outlet.




- 24** When the wearable needs to be charged, such as at the end of a day, plug the OEM charger into the USB-A port on the side of the cradle.



- 25** Depending on the wearable and charger type, either remove the wearable from the cradle and place on the charger, or if the charger placement allows, connect the charger to the wearable.



- 26** When charging is complete, remove the charger from the cradle and replace the wearable.



03/21/23

invue

www.invue.com

NA / LATAM // 704.752.6513 • 888.55.INVUE

EMEA // +31.23.8900150

APAC // +852.3127.6811

© 2023 InVue Security Products Inc. All rights reserved.
InVue is a registered trademark of InVue Security Products.