



## WS2/W2000 Apple Watch Ultra Flex Tray Sensor ZW1929 Installation



- 1 Open the polish packet included in polish kit ADH2300.



- 2 Squeeze a few drop of the polish compound onto the included microfiber cloth.




- 3 Carefully rub the polish onto the indicated areas along the sides of the wearable for 15-20 seconds.




- 4 Use a clean portion of the cloth to buff out the polish for 15-20 seconds.



- 5 Use a provided alcohol wipe to clean the bottom and sides of the wearable. Allow it to dry completely.



- 6 Ensure that the red pull tabs in the corners lay flat against the bottom of the tray sensor and that the pull tab along the bridge and the pull tab covering the switch are facing up as shown.



- 7 Insert the buckle band through the gap on the back of the tray sensor.



- 8 Snap the watch body down into the tray sensor.

## WS2/W2000 Apple Watch Ultra Flex Tray Sensor ZW1929 Installation



- 9 Flip the wearable over and pull the 3 red tabs out through the opening in the bottom of the tray sensor.



- 10 Pull the red tab for the adhesive along the bridge.



- 11 Pull the red tab covering the switch.



- 12 Press the adhesives on the tray sensor against the wearable for at least 10 seconds.




- 13 Lift the band clamp/sensor end from the stand.



- 14 **Optional:** If the cable stop clip is available, pull enough cable to allow for easy installation. Close the cable stop clip over the cable to prevent it from recoiling.




- 15a **Optional:** If present, remove the existing band clamp from the sensor end by loosening the screw with a TT8 bit.




- 15b Slide the sensor end from the existing band clamp.

## WS2/W2000 Apple Watch Ultra Flex Tray Sensor ZW1929 Installation



- 16a** **If installing on an Alpine/Loop Band:**  
To hold the band in place within the band clamp, begin by peeling the backing from the 2.25mm bumper (included in the ZW1023 kit).



- 16b** Place the bumper near the hinge in the provided band clamp and apply pressure for at least 10 seconds.



- 17** Slide the provided band clamp onto the sensor end so that the screw holes align.



- 18** With the wearable facing down, place the back band into the band clamp as shown.



- 19** Plug the sensor on the flex tray into the sensor end of the stand.



- 20** Close the band clamp over the band.



- 21** Use a TT8 bit to tighten the screw on the band clamp.




- 22** If using the charging cradle ZW1005, remove the top pad.

## WS2/W2000 Apple Watch Ultra Flex Tray Sensor ZW1929 Installation



- 23 Use an alcohol wipe to remove any adhesive residue from the depression. Allow it to dry completely.



- 24 Remove the backing from the included aligner pad.



- 25 Place the aligner pad into the depression on the charging cradle and apply pressure for at least 10 seconds.



- 26 If used, remove the cable stop clip from the cable.



- 27 Place the wearable and tray sensor onto the charging cradle.

**Note:** Consult the instructions included with the stand to finalize installation.

SD0902 Rev2 11/08/22