


**BOSCH**

800 Series VeroCafe

Key Tips Before Starting

Random units receive additional quality checks, which may result in small amounts of coffee bean residue or water droplets being present upon purchase.



Locate all parts inside the packaging

- Easily remove and empty the **drip tray** by pulling it from the front.
- The **drip plate (grate)** is located inside the Welcome Box. Align the drip plate with the red floater on the drip tray during assembly.



Adjusting the temperature

- Adjust the brewing temperature by pressing the **Settings** ⚙️ button.
- Keep in mind that **beverage temperature** may be affected by the room temperature, water temperature, milk temperature (if taken directly from the fridge), and other factors.



Using the water filter



- Refer to the Water Filter section of the user manual for **instructions on preparing the filter** before use.
- Insert the water filter into the water tank with the **“ring” (marked A-B-C) facing down**. Firmly press the filter down to secure.
- Shop for Original Bosch Mavea® Water Filters (SKU TCZ7003US) on **bosch-home.com/us** or **bosch-home.ca**. Designed specifically for your appliance.

SAMPLE ONLY



Register to activate Bosch | Concierge

- Leave the sticker on your appliance. To register your appliance, simply scan the QR Code. Any time after registration, rescan the QR Code to access warranty information, owner manual, self-help resources, and more.
- Or register online at: **registerbosch.com**
- Failure to register your appliance will not affect your warranty right.

Need help or have questions?
Please call Bosch Customer
Support on 1-800-701-5231.

Scan the QR code
for more tips

