



THE NEXT-GEN BLENDER



Take your cordless, portable blender anywhere to shake up your routine.

Make a smoothie, shake or cocktail in 20 seconds, anywhere.

Get all the juicy details you need to blend like a pro at BlendJet.com/Guide.

YOUR FIRST BLEND

1

Charge your BlendJet with the included USB cable for 1 hour or until you see a solid blue circle.

2

Ensure the arrows on the back of the jar & base are closely aligned. Power button will flash white.

3

Clean your BlendJet by blending water with a drop of soap, then rinse. (Deep clean as needed – visit BlendJet.com/Guide for video demo).

4

Add liquid first, then throw in your solids. Leave a little room at the top.

5

Tighten the lid & press the power button to blend for one 20-second cycle. Repeat as needed for thicker blends.

6

Enjoy your blended creation & clean immediately after each use.

FLAVOR ON FULL BLAST

Meet the JetPacks

Make a delicious, nutritious, juice-bar-quality smoothie anytime, anywhere.



No refrigeration needed, just add water—or get creative with your favorite milks, fruits, protein powders, yogurts or superfoods.

JetPacks' fruit is picked at peak ripeness & immediately freeze dried, locking in flavor, color & nutrients like potassium, calcium, iron & fiber.



Gluten Free



Good Source of Fiber



Vegan



No Artificial Flavors or Preservatives



Non-GMO



No Artificial Sugar

Get yours at BlendJet.com/JetPacks.



Let us know if you need anything!
support@blendjet.com

@blendjet



POWERING UP

BlendJet takes about 1.5 hours to fully charge & lasts for 15+ blends. Battery life is visible while charging.



Zero Charge
Circle flashes red & purple.



50% Charge
Circle is half purple, half blue.



Full Charge
Circle is solid blue.

Circle will turn purple (vs. blue) while blending to indicate low battery.

TROUBLESHOOTING



Flashing Red
Jar isn't aligned with base.

Loosen jar from base & screw it back in until arrows on back of jar & base are closely aligned, and the power button flashes white instead of red.



Solid Red
Blades are blocked.

Turn upside down & start blending, then turn right-side up again so your ingredients hit the blades at full speed.

A MODE FOR EVERY MOOD



Blend Mode
Perfect for smoothies, shakes & mixed drinks.

Press power button once to start a 20-second blend cycle, or press it again to stop mid-cycle.



Pulse Mode
Perfect for guacamole, salsa & hummus.

To enter Pulse Mode, double-press power button. Blue lights will flash left to right 3 times & the swirl will stay illuminated while Pulse Mode is active. Press & hold power button repeatedly to pulse. Pulse Mode will end after 5 seconds of inactivity.



Lock Mode
Perfect for sipping & travel.

To lock, you must be in Blend Mode. Secure lid, then hold down power button until purple circle flashes 3 times.
To unlock, hold down power button until blue circle flashes 3 times.